


REASSEMBLY

HINT:

- Thoroughly clean all parts to be assembled.
- Before installing the parts, apply new engine oil to all sliding and rotating surfaces.
- Replace all gaskets and oil seals with new ones.



1. INSTALL SPARK PLUG TUBES


HINT:

When using a new cylinder head, spark plug tubes must be installed.

- (a) Apply adhesive to the end of the spark plug tube.

Adhesive:


Part No. 08833-00070, THREE BOND 1324 or equivalent



- (b) Using a wooden block and hammer, tap in a new spark tube until there is 48.4 – 49.6 mm (1.906 – 1.953 in.) protruding from the camshaft bearing cap installation surface of the cylinder head.


NOTICE:

Avoid tapping a new spark plug tube in too far by measuring the amount of the protrusion while tapping.




2. INSTALL VALVES


- (a) Using SST, push in a new oil seal.
SST 09201-41020



- (b) Install these parts:
- (1) Valve
 - (2) Spring seat
 - (3) Valve spring
 - (4) Spring retainer



- (c) Using SST, compress the valve spring and place the 2 keepers around the valve stem.
SST 09202-70020 (09202-00010)



- (d) Using a plastic-faced hammer and the valve stem (not in use) tip wound with vinyl tape, lightly tap the valve stem tip to assure proper fit.

NOTICE:

Be careful not to damage the valve stem tip.

3. INSTALL SHIMS AND VALVE LIFTERS

- (a) Install the shim and valve lifter.
(b) Check that the valve lifter rotates smoothly by hand.