

# TERMS

## ABBREVIATIONS USED IN THIS MANUAL

IN00S-06

Abbreviations	Meaning
A/C	Air Conditioner
A/T	Automatic Transmission
BTDC	Before Top Dead Center
DLC3	Data Link Connector 3
DTC	Diagnostic Trouble Code
ECU	Electronic Control Unit
EFI	Electronic Fuel Injection
EVAP	Evaporative Emission Control
FIPG	Formed In Place Gasket
FL	Fusible Link
IG	Ignition
J/B	Junction Block
LH	Left-Hand
LHD	Left-Hand Drive
M/T	Manual Transmission
O/S	Oversize
PCV	Positive Crankcase Ventilation
RH	Right-Hand
RHD	Right-Hand Drive
SSM	Special Service Materials
SST	Special Service Tools
STD	Standard
SW	Switch
TDC	Top Dead Center
TWC	Three-Way Catalyst
U/S	Undersize
VSV	Vacuum Switching Valve
w/	With
w/o	Without