

Pattern Select Switch Circuit (2nd Start Switch) & 2nd Start Switch Indicator Light Circuit


CIRCUIT DESCRIPTION

When 2nd start mode is selected with the pattern select switch, the Engine and ECT ECU (2UZ-FE, 1FZ-FE) or ECT ECU (1HZ, 1HD-T, 1HD-FTE) controls the solenoid valves and the transmission starts from 2nd gear.

In D range, the transmission automatically shifts up through 3rd to O/D as usual.

In 2nd position, the transmission is held in 2nd gear.


WIRING DIAGRAM



D03956

Except 1FZ-FE


*1 Engine and ECT ECU
*2 ECT ECU



D03955

INSPECTION PROCEDURE

1 Check operation of 2nd start switch.

**PREPARATION:**

Turn the ignition switch ON.

CHECK:

- (a) Check "2nd STRT" indicator light when 2nd start switch is pushed in to ON.
- (b) Check "2nd STRT" indicator light when 2nd start switch is pushed again, or PWR mode switch is pushed into ON.

OK:

- (a) "2nd STRT" indicator light lights up.
- (b) "2nd STRT" indicator light goes off. When PWR mode switch is pushed in to ON, "2nd STRT" indicator light goes off, and "PWR" indicator light lights up.

OK

Proceed to next circuit inspection shown in problem symptoms table (See page DI-108).

NG


2 Check 2nd start indicator bulb.

NG

Replace the 2nd start indicator bulb.

OK

3 Check 2nd start switch.



D03270

PREPARATION:

Disconnect the pattern select switch connector.

CHECK:

Check continuity between terminals 2 and 3 of pattern select switch connector when pattern select switch is set to 2nd start switch ON and OFF.

OK:


2nd start switch	Specified condition
Press continuously "2nd" switch	Continuity
Release "2nd" switch	No continuity

NG

Replace the 2nd start indicator bulb.

OK

4 Check voltage between terminal SNWL (SNWO) and SNWL of Engine and ECT ECU or ECT ECU and body ground.



PREPARATION:

Turn the ignition switch ON.

CHECK:

Check voltage between terminal SNWL (SNWO) of Engine and ECT ECU or ECT ECU and body ground when the select switch is set to 2nd start switch ON and OFF.


OK:

2nd start switch	Voltage
ON	9 - 14 V
OFF	Below 1.5 V

OK

Check and replace the Engine and ECT ECU or ECT ECU (See page IN-35).

5 Check continuity between terminal SNWI of Engine and ECT ECU or ECT ECU and body ground.



PREPARATION:

Disconnect the connector of Engine and ECT ECU or ECT ECU.

CHECK:

Check continuity between terminal SNWI of Engine and ECT ECU or ECT ECU and body ground when the select switch is set to 2nd start switch ON and OFF.

OK:

2nd start switch	Specified condition
ON	Continuity
OFF	No continuity

OK

Check and replace the Engine and ECT ECU or ECT ECU (See page IN-35).

NG

Check and replace harness and connector between battery and pattern select switch, pattern select switch and Engine and ECT ECU or ECT ECU, battery and 2nd start indicator light, 2nd start indicator light and Engine and ECT ECU or ECT ECU ([See page IN-35](#)).