


#### 4. Model Position and Damper Operation



258RV71

##### ► Function of Main Damper ◀

Control Damper	Control Position	Damper Position	Operation
Air Inlet Control Damper	FRESH 187BE23	A	Brings in fresh air.
	RECIRC 187BE41	B	Recirculates internal air.
Air Mix Control Damper	MAX COLD – MAX HOT TEMP. SETTING {16°C (60.8°F) – 30°C (86°F)}	C, D, E	Varies the mixture ratio of the cool air and the warm air in order to regulate the temperature continuously from HOT to COLD.
Mode Control Damper	DEF 187BE28	F, K, L, O, S	Defrosts the windshield through the front defroster and side register.
	FOOT/DEF 187BE27	G, K, L, O, Q	Defrosts the windshield through the front defroster, side register and while air is also blown out from the front and rear foot well register ducts.
	FOOT 187BE26	H, K, L, O, P (I, K, L, O, P)	Air blows out of the footwell outlet and the side registers; also, a small amount of air blows out of the defroster.
	BI-LEVEL 187BE25	I, J, M, N, P	Air blows out of the front and rear center registers, side registers, and front and rear foot well register ducts.
	FACE 187BE24	I, J, M, N, R	Air blows out of the front and side registers, and side register.