

## REPLACEMENT

### REPLACEMENT REQUIREMENTS

In the following cases, replace the steering wheel pad, steering wheel or spiral cable.

| Case  | Replacing Part     |
|---|--------------------|
| If the airbag has been deployed.  | Steering wheel pad |
| If the steering wheel pad has been found to be faulty in troubleshooting.                     | Steering wheel pad |
| If the spiral cable has been found to be faulty in troubleshooting.                           | Spiral cable       |
| If the steering wheel pad has been found to be faulty during checking items (See page RS-12). | Steering wheel pad |
| If the steering wheel has been found to be faulty during checking items (See page RS-12).     | Steering wheel     |
| If the spiral cable has been found to be faulty during checking items (See page RS-12).       | Spiral cable       |
| If the steering wheel pad has been dropped.   | Steering wheel pad |

### CAUTION:

For removal and installation of the steering wheel pad, see page SR-13 and SR-24, and be sure to follow the correct procedure.