



INSPECTION

INSPECT REAR WIPER RELAY CONTINUITY

Switch position	Tester connection	Specified condition
OFF	–	–
INT	1 – 4 – 6	Continuity
LO	3 – 5 – 6	Continuity
Wash2	3 – 5 – 6	Continuity

If continuity is not as specified, replace the relay.