

9. Black screen appears when "MAP", "Menu" or "DESTINATION" switch pressed.

INSPECTION PROCEDURE

1	Check the navigation ECU.
---	---------------------------

CHECK:

Check terminals +B.

OK:

+B: 10 – 14 V

CHECK:

Check terminal ACC when turn ignition switch ACC or ON position.

OK:

ACC: 10 – 14 V

CHECK:

Check terminal R, G, B, VR or VG.

OK:

R, G, B, VR or VG: See "Navigation ECU" of "TERMINAL OF ECU"

NG

Replace the wire harness when all terminals are faulty. Replace the wire harness when SYNC terminal is faulty.

OK

Replace the multi-display.