

INSTALLATION

Installation is in the reverse order of removal (See page MT-4).

HINT:

After installation, do the road test.