

5. No navigation displayed, "Audio OFF" on audio screen and no audio sound.

INSPECTION PROCEDURE

1 Service check mode

NG

Troubleshoot for each diagnosis.

OK

2 Check the radio receiver assembly.

PREPARATION:

Disconnect the radio receiver assembly connector.

CHECK:

Check voltage at terminal +B.

OK:

+B: 10 – 14 V

CHECK:

Check voltage at terminal ACC when turning the ignition switch to the ACC or ON position.

OK:

ACC: 10 – 14 V

CHECK:

Check continuity at terminal GND.

OK:

GND: Continuity

NG

Replace or repair wire harness.

OK

3 Check "AVC-LAN communication circuit". (See page DI-275)

NG

Replace the AVC-LAN circuit or radio receiver assembly.

OK

Replace the multi display.