


DTC	RrACSW, FOOT	Rear Evaporator Temperature Sensor Circuit
-----	--------------	--

CIRCUIT DESCRIPTION

This sensor detects the rear evaporator temperature and sends the appropriate signals to the A/C amplifier.

Blinking light	Detection Item	Trouble Area
RrACSW, FOOT	Open or short in rear evaporator temperature sensor circuit.	<ul style="list-style-type: none">• Rear evaporator temperature sensor.• Harness or connector between rear evaporator temperature sensor and rear A/C amplifier.• Rear A/C amplifier


WIRING DIAGRAM



108289

INSPECTION PROCEDURE

1 Check voltage between terminals TEr and SG of rear A/C amplifier connector.



PREPARATION:

Remove rear A/C amplifier with connectors still connected.

CHECK:

- (a) Turn ignition switch to ON.
- (b) Measure voltage between terminals TEr and SG of rear A/C amplifier connector at each temperature.

OK:

Voltage

at 0°C (32°F) 2.0 - 2.4V

at 15°C (59°F) 1.4 - 1.8V

HINT:


As the temperature increases, the voltage decreases.

NG Go to step 2.

OK

Proceed to next circuit inspection shown on problem symptoms table (See page DI-130). However, if RrACSW and FACE indicators light up (or DTC 17 is displayed), check and replace A/C amplifier.

2 Check rear evaporator temperature sensor.



PREPARATION:

Remove rear evaporator temperature sensor (See Pub. No. RM616E on page AC-43).

CHECK:

Measure resistance between terminals 1 and 2 of evaporator temperature sensor connector at each temperature.

OK:

Resistance

at 0°C (32°F) 4.5 – 5.2 kΩ

at 15°C (59°F) 2.0 – 2.7 kΩ

HINT:

As the temperature increases, the resistance decreases.

NG

Replace rear evaporator temperature sensor.

OK

3 Check harness and connector between A/C amplifier and rear evaporator temperature sensor (See page IN-34).

NG

Repair or replace harness or connector.

OK

Check and replace A/C amplifier.