


DTC	42	Air Inlet Damper Control Servomotor Circuit
-----	----	---

CIRCUIT DESCRIPTION

The air inlet damper control servomotor is controlled by the A/C amplifier and moves the air inlet damper to the desired position.

DTC No.	Detection item	Trouble Area
42	Air inlet damper position sensor value does not change even if A/C amplifier operated air inlet damper control servomotor	<ul style="list-style-type: none"><li>• Air inlet damper control servomotor</li><li>• Harness or connector between air inlet damper control servomotor and A/C amplifier</li><li>• A/C amplifier</li></ul>

WIRING DIAGRAM



## INSPECTION PROCEDURE

## 1 Actuator check.

**PREPARATION:**

- (a) Warm up the engine.
- (b) Set to actuator check mode (See page DI-1226).
- (c) Press the DEF switch and change it to step operation.

**CHECK:**

Press the DEF switch and check the operation of the air inlet damper and the condition of the blower.

**OK:**

Display Code	Air Inlet Damper
0 – 1	FRESH
2	R/F (50%)
3	RECIRC
4 – 7	FRESH


OK

Proceed to next circuit inspection shown on problem symptoms table (See page DI-1238).

NG

## 2 Check air inlet damper control servomotor.

### LHD Models:



P

I24470

### PREPARATION:

Remove the air inlet servomotor.

### CHECK:

Connect positive (+) lead to terminal 5 and negative (-) lead to terminal 4.

### OK:

The lever moves smoothly to REC position.


### CHECK:

Connect positive (+) lead to terminal 4 and negative (-) lead to terminal 5.

### OK:

The lever moves smoothly to FRS position.

### RHD Models:



P

I24471

NG

Replace air inlet servomotor.

OK

## 3 Check harness and connector between air inlet damper control servomotor and A/C amplifier (See page IN-38).

NG

Repair or replace harness or connector.

OK

Check and replace A/C amplifier.