



w/o Sliding Roof



W/ Sliding Roof



I08069


INSPECTION

1. INSPECT FRONT PERSONAL LIGHT SWITCH CONTINUITY

Switch position	Tester connection	Specified condition
OFF	–	No continuity
ON	1 – 2	Continuity

If continuity is not as specified, replace the light assembly or bulb.

w/o Sliding Roof



I06429


2. INSPECT REAR PERSONAL LIGHT SWITCH CONTINUITY

w/o SLIDING ROOF :

Switch position	Tester connection	Specified condition
OFF	–	No continuity
ON	1 – 3	Continuity

If continuity is not as specified, replace the light assembly or bulb.

w/ Sliding Roof



I06421


3. INSPECT REAR PERSONAL LIGHT SWITCH CONTINUITY

w/ SLIDING ROOF :

Switch position	Tester connection	Specified condition
OFF	–	No continuity
ON	1 – 3	Continuity

If continuity is not as specified, replace the light assembly or bulb.

w/o Sliding Roof




I06430

4. INSPECT ROOM LIGHT SWITCH CONTINUITY

w/o SLIDING ROOF :

Switch position	Tester connection	Specified condition
Room Light Switch OFF	–	No continuity
Room Light Switch DOOR	2 – 3	Continuity
Room Light Switch ON	1 – 3	Continuity


If continuity is not as specified, replace the light assembly or bulb.



5. INSPECT ROOM LIGHT SWITCH CONTINUITY w/ SLIDING ROOF :

Switch position	Tester connection	Specified condition
Room Light Switch OFF	–	No continuity
Room Light Switch DOOR	2 – 3	Continuity
Room Light Switch ON	1 – 3	Continuity

If continuity is not as specified, replace the light assembly or bulb.




6. INSPECT REAR ROOM LIGHT SWITCH CONTINUITY

- Disconnect the connector from room light assembly.
- Turn the room light switch ON, check that continuity exists between terminal 2 and body ground.

7. INSPECT FRONT AND REAR ROOM LIGHT SWITCH CONTINUITY Normal Roof :


See step 6 in previous page.



8. INSPECT VANITY LIGHT CONTINUITY

Switch position	Tester connection	Specified condition
OFF (closed)	–	No continuity
ON (opened)	1 – 2	Continuity


If continuity is not as specified, replace the vanity light assembly or bulb.



9. INSPECT DOOR COURTESY SWITCH CONTINUITY

- Check that continuity exists between terminal and switch body with the switch ON (switch pin released).
- Check that no continuity exists between terminals and switch body with the switch OFF (switch pin pushed).


If continuity is not as specified, replace the switch.



10. INSPECT DOOR COURTESY LIGHT CONTINUITY

Using an ohmmeter, check that continuity exists between terminals.

If continuity is not as specified, replace the light assembly or bulb.

Liftgate Type

Back Door Lock Assembly
● Back Door Courtesy Switch

I06432

11. INSPECT BACK DOOR COURTESY SWITCH CONTINUITY**Liftgate Type :**

Switch position	Tester connection	Specified condition
OFF (closed)	–	No continuity
ON (opened)	1 – 2	Continuity

If continuity is not as specified, replace the back door lock assembly.

Swing Out Type


Back Door Lock Assembly
● Back Door Courtesy Switch

I08000

12. INSPECT BACK DOOR COURTESY SWITCH CONTINUITY**Swing Out Type :**

Switch position	Tester connection	Specified condition
OFF (closed)	–	No continuity
ON (opened)	1 – 2	Continuity

If continuity is not as specified, replace the back door lock assembly.

13. INSPECT GLOVE COMPARTMENT DOOR COURTESY SWITCH CONTINUITY

ON

I06433


Switch position	Tester connection	Specified condition
OFF (closed)	–	No continuity
ON (opened)	1 – 2	Continuity

If continuity is not as specified, replace the switch.

14. INSPECT LICENCE PLATE LIGHT CONTINUITY**Liftgate Type :**

Using an ohmmeter, check that continuity exists between terminals.

If continuity is not as specified, replace the light assembly or bulb.




e-2-2-J

I06434

15. INSPECT LICENCE PLATE LIGHT CONTINUITY**Swing Out Type :**

Using an ohmmeter, check that continuity exists between terminals.

If continuity is not as specified, replace the light assembly or bulb.



e-2-2-J

I04053