

















PREPARATION

SST (SPECIAL SERVICE TOOLS)

AT07N-01





	09032-00100 Oil Pan Seal Cutter	
	09350-36010 TOYOTA Automatic Transmission Tool Set	
	(09350-06010) No.2 Piston Spring Compressor	
	(09350-06020) No.3 Piston Spring Compressor	
	(09350-06030) No.1 Piston Spring Compressor	
	(09350-06035) Attachment	
	(09350-06040) Oil Seal Replacer	
	(09350-06050) Handle	
	(09350-06060) Transmission Rear Bearing Replacer	
	(09350-06090) Plate	
	(09350-06100) Check Ball Spring Compressor	
	(09350-06110) No.1 Measure Terminal	
	(09350-06120) No.2 Measure Terminal	

	(09350-06130) Extension Bar	
	(09350-06140) Oil Pump Puller	
	(09350-06150) Oil Seal Replacer	

AT

RECOMMENDED TOOL

AT07P-01

	09031-00030 Pin Punch	
	09905-00012 Snap Ring No. 1 Expander	
	09905-00013 Snap Ring Pliers	
	(09904-00090) Claw Set	

EQUIPMENT

AT07Q-01

Feeler gauge	Check major clearance.
Vernier calipers	Check length of second coast brake piston rod.
Dial indicator	Check piston stroke and play of the output shaft.
Dial indicator	Check inside diameter of major bushing.
Straight edge	Check side clearance of oil pump.
Torque wrench	
Cylinder gauge	Check inside diameter of the transmission case rear bushing.

LUBRICANT

Item	Capacity	Classification
Dry fill	15.4 liters (16.3 US qts, 13.6 Imp.qts)	ATF DEXRON® II
Drain and refill	6.0 liters (6.3 US qts,	

SSM (SPECIAL SERVICE MATERIALS)

08826-00090	Seal Packing 1281, Three bond 1281 or equivalent	
08833-00080	Adhesive 1344, THREE BOND 1344, LOCTITE 242 or equivalent	

AT