

INSPECTION

1. Vehicle not involved in collision:

INSPECT SUPPLEMENTAL RESTRAINT SYSTEM

Do a diagnostic system check (See page DI-432).

2. Vehicle involved in collision and airbag is not deployed:

INSPECT SUPPLEMENTAL RESTRAINT SYSTEM

Do a diagnostic system check (See page DI-432).

3. Vehicle involved in collision and airbag is deployed:

INSPECT SUPPLEMENTAL RESTRAINT SYSTEM

Replace the airbag sensor assembly (See page RS-80).