

# Acess Raspberry pi remote

🕒 Created	@September 4, 2023 3:53 PM
🏷️ Tags	Programming

## Procedure with putty

1. Install Putty
2. Discover raspberry pi ip
  - 2.1. On raspberry pi open terminal
  - 2.2. Write "ifconfig"
  - 2.3. Is the number that begins with "192.xxx.xx.xx"
3. Enable SSH and VNC in Raspberry pi
  - 3.1. Preferences - Raspberry pi configuration - Interfaces - Enable SSH
  - 3.2. Preferences - Raspberry pi configuration - Interfaces - Enable VNC
4. Put the Ip address on Putty
5. Login with your credentials
  - 5.1. Open terminal in raspberry pi and check the username
  - 5.2. Put a password in preference- Raspberry pi configuration - Change password
6. And you are in!

## Procedure without putty

1. Open terminal and put "ssh dingo@192.168.1.180" -casa
2. Open terminal and put "ssh dingo@192.168.10.25" -bladeinsight
3. Put password "1234"
4. You are in!

## VNC

1. Open RealVNC
2. Put the ip "192.168.1.180"
3. "dingo" and "1234"
4. You are in!

## Code

1. Insert a usb drive with the name ESD-USB
2. Check if the usb drive is detected "lsusb"
3. Go to Desktop
4. Run "python3 record\_video\_ds18b20\_bme680.py"
5. Remove usb drive and view "output\_video1" and "sensor\_data1"