

底盘控制指令下发

Issuance of Chassis Control Commands

(基于 ROS 消息)

(Based on ROS messages)

A、准备事项 Preparations

(注意：需要把底盘架起来，以防出现意外)

(Note: The chassis needs to be erected to prevent accidents)

1. 打开终端：candump can0，输入指令查看工控机与底盘通讯是否正常

Open the terminal: candump can0, enter the command to check whether the communication between the IPC and the chassis is normal

```
t@t-Default-string:~$ candump can0
can0 502 [8] 02 00 00 01 F4 01 F4 F0
can0 500 [8] 02 00 00 00 00 00 00 00
can0 501 [8] 02 00 00 00 00 00 00 00
can0 505 [8] 00 01 00 00 20 00 14 00
can0 506 [8] 00 00 00 00 00 00 00 00
can0 101 [8] 01 00 00 00 00 00 00 00
can0 103 [8] 01 04 00 00 00 00 00 00
can0 104 [0]
can0 102 [8] 01 00 00 01 F4 00 00 00
can0 100 [8] 01 00 00 00 00 1F 00 00
can0 105 [8] 00 01 00 00 00 00 00 00
can0 507 [8] 00 00 00 00 00 00 00 00
can0 509 [8] 00 00 00 00 00 00 00 00
can0 511 [8] 00 00 00 00 00 00 00 00
can0 512 [8] 1C B6 70 33 20 00 8C 00
can0 502 [8] 02 00 00 01 F4 01 F4 F0
can0 500 [8] 02 00 00 00 00 00 00 00
```

如果没有出现 CAN0，CAN1，则表示 CAN 驱动启动失败

If Can0 and can1 do not appear, it means that the CAN driver failed to start

(1)集合诚工控机 JHCTECH Industrial Personal Computer

- 在该目录/home/EMUC_B202_SocketCAN_driver_v3.2_utility_v3.1_20210302 下执行；
Operating
directory:/home/EMUC_B202_SocketCAN_driver_v3.2_utility_v3.1_20210302
- sudo ./start.sh ;
- 输入密码：11111111 ; input Password: 11111111

```
t@t-Default-string:~$ candump can0
SIOCGIFINDEX: No such device
t@t-Default-string:~$ cd /home/EMUC_B202_SocketCAN_driver_v3.2_utility_v3.1_20210302/
t@t-Default-string:/home/EMUC_B202_SocketCAN_driver_v3.2_utility_v3.1_20210302$
sudo ./start.sh
[sudo] password for t:
/sbin/ifconfig
t@t-Default-string:/home/EMUC_B202_SocketCAN_driver_v3.2_utility_v3.1_20210302$
candump can0
can0 502 [8] 00 00 01 01 F4 01 F4 00
can0 501 [8] 00 00 01 00 00 00 00 00
can0 500 [8] 00 00 01 00 00 00 00 00
can0 505 [8] 00 00 00 00 38 00 12 00
```

(2)宸耀工控机 Neousys Industrial Personal Computer

- 在该目录~/Downloads/B202 下执行； Operating directory:Downloads/B202
- sudo ./start_2p.sh;
- 输入密码：12345678； Input Password: 12345678;

```
neousys@neousys-Nuvo-6108GC:~$ cd Downloads/
neousys@neousys-Nuvo-6108GC:~/Downloads$ ls
autoware autoware-20210515.bag autoware-220515.pcd boundary_test.osm cccnote-setting_pc.zip cert.pem key.pem novatel_ws NVIDIA-Linux-x86_64-470.63.01.run other ouster_tline_sync SDK
neousys@neousys-Nuvo-6108GC:~/Downloads$ cd B202/
neousys@neousys-Nuvo-6108GC:~/Downloads/B202$ ls
emuc2socketcan ko EMUC-B202_SocketCAN_Installation_Guide_20210304.pdf emucd_64 HOWTO.md Release_Note.txt start_2p.sh start_2p_相同波特率.sh start_2p.sh
start_2_4p_相同波特率.sh start_2p.sh start_2p.sh start_2p_相同波特率.sh start_2p.sh start_2p_不同波特率.sh
neousys@neousys-Nuvo-6108GC:~/Downloads/B202$ sudo ./start_2p.sh
```

2. 启动 pix_driver: roslaunch pix_driver pix_driver.launch

```
t@t-Default-string:~$ roslaunch pix_driver pix_driver.launch
... logging to /home/t/.ros/log/15065238-018d-11ed-b5db-0002af003e44/roslaunch-t-Default-string-8121.log
Checking log directory for disk usage. This may take a while.
Press Ctrl-C to Interrupt
Done checking log file disk usage. Usage is <1GB.

started roslaunch server http://t-Default-string:42129/

SUMMARY
*****

PARAMETERS
 * /aeb_en_ctrl: 1
 * /rostdistro: melodic
 * /rosversion: 1.14.12

NODES
 /
  command_node (pix_driver/pix_driver_command_node)
  control_converter (pix_driver/control_converter_speed_1.py)
  read_converter (pix_driver/report_converter.py)
  report_node (pix_driver/pix_driver_report_node)
  vehicle_report (pix_driver/vehicle_report_2.py)

auto-starting new master
process[master]: started with pid [8146]
ROS_MASTER_URI=http://localhost:11311

setting /run_id to 15065238-018d-11ed-b5db-0002af003e44
process[rosout-1]: started with pid [8172]
started core service [/rosout]
process[report_node-2]: started with pid [8175]
process[command_node-3]: started with pid [8176]
process[read_converter-4]: started with pid [8181]
process[control_converter-5]: started with pid [8186]
process[vehicle_report-6]: started with pid [8192]
-0.360068930108
```

3. 启动 socketcan_bridge: roslaunch socketcan_bridge socketcan_bridge.launch

```
tqt-Default-string:/$ roslaunch socketcan_bridge socketcan_bridge.launch
... logging to /home/t/.ros/log/951dc378-0185-11ed-b5db-0802af083e44/roslaunch-t-Default-string-7321.log
Checking log directory for disk usage. This may take a while.
Press Ctrl-C to interrupt
Done checking log file disk usage. Usage is <1GB.

started roslaunch server http://t-Default-string:33965/

SUMMARY
=====

PARAMETERS
 * /rostdistro: melodic
 * /rosversion: 1.14.12
 * /socketcan_bridge/can_device: can0

NODES
 /
   socketcan_bridge (socketcan_bridge/socketcan_bridge_node)


ROS_MASTER_URI=http://localhost:11311

process[socketcan_bridge-1]: started with pid [7351]
[ INFO] [1657593204.404556611]: Successfully connected to can0.
```

3.1 速度、转向、刹车 Speed, steering, brakes

启动 ros 工具: `roslaunch rqt_publisher rqt_publisher`


Start the ros tool: `roslaunch rqt_publisher rqt_publisher`



Topic 添加以下话题: `brake_command` `gear_command` `park_command` `throttle_command` `vehicle_command` 然后 rate 改为 100

Add the following message to Topic: brake_command gear_command park_command throttle_command vehicle_command.


And please change the rate to 100



然后给车使能 Then enable the chassis

给箭头的地方改为 1，让车使能

Change the position of the arrows to 1 to enable the chassis




给速度或者转向、刹车值

Give speed or steering, braking value

刹车: Brake

转向: Steering

速度: Speed, 单位米每秒 Unit: meter/second



遥控器放权: 档位-N, self-driving、speed

Remote control decentralization: gear-N, self-driving, speed

档位调至 D 或 R: Shift to gear D or R

模式改为 Speed: Change the mode to Speed

遥控器放权: Remote control decentralization




3.2 驻车、档位 Parking, gear

输入档位或者驻车的值，放权

Enter the value of the gear or parking, realize the decentralization

档位：0-2 Gear: 0-2

驻车：1 是驻车 Parking: 1 means parking



档位调至 D 或 R: Shift to gear D or R

模式改为 Speed: Change the mode to Speed

遥控器放权: Remote control decentralization

