



Table of Contents


Safety Measures.....	Page 3
R2-D2 Terminologies.....	Page 4-6
Operation Procedures.....	Page 7-8
Keypad Controls.....	Page 9
PS4 Controls.....	Page 10
Battery and External Power.....	Page 11-12
Troubleshooting.....	Page 13-15

Safety Measures

- Press EMS switch to shut down all motors during an emergency situation
- Have a fire extinguisher in close proximity for fire hazards
- Do NOT connect the charging plug and external plug at the same time!
- Ensure battery is at a minimum of 20% to prevent discharge malfunctions
- Make sure to unscrew one of the battery terminal if battery is not used
- Dispose old batteries properly
- Current R2-D2 wheels (as of May 2018) are only compatible to drive inside Fairchild hallways
- Avoid nearby stairways at all times
- Avoid driving R2-D2 at full speed to prevent collision with nearby people
- Seek professional assistance if the troubleshooting methods in this manual does not fix any software, electrical, or mechanical problems

R2-D2 Terminologies

(Front View)



LED Arrays

Flashlight

Camera

Power
Button


Keypad

Right Sensor


Left Sensor

4
Front Sensor

(Back View)



(Left View)



Operation Procedures

- 1) - Press the power button to turn ON power (if using battery)
 - Plug in external power plug (if using external power)
- 2) - Wait for "Window XP" startup sound to play (signals startup success)
 - If power fails, turn power button OFF/ON or unplug/plug external power
- 3) - Afterwards, connect PS4 controller by pressing and holding the "share" and "PlayStation" button together until the blue light starts blinking.
 - Connection is successful when the blue light stops blinking and turns dark blue.
 - Connection is unsuccessful when the blue light stops blinking and/or turns light blue.
 - If connection is unsuccessful, try re-connecting the PS4 controller or restart the entire system by pressing the "Reboot" button on the keypad.



Connected



NOT Connected!



NOT Connected!

- 4) - Press number 1 on keypad to activate "Standby" mode or safe mode

"Red" Color Indicator




5) - Press number 2 on keypad to activate "Static display" mode

"Green" Color Indicator



6) - Press number 3 on keypad to activate "Remote" mode
- You can only use PS4 controller during "Remote" mode

"Orange" Color Indicator



7) - Press number 4, 5, or 6 on keypad to activate "Happy", "Chill", or "Angry" emotions

8) - Press the star key (*) to reboot/restart the system

9) - Press the pound key (#) to shut down the system
- The "Window XP" shutdown sound will play immediately
- After 15 seconds, press the power button to turn OFF the power

IMPORTANT → Press EMS to shut down all motors during an emergency situation

Go to this link for a quick Demo → <https://youtu.be/QTvlnzKIVoA>

Keypad Controls

1) Mode selection buttons:


- Press number 1 for "standby" or safe mode
- Press number 2 for "static display" mode
- Press number 3 for "remote" mode

2) Emotion selection buttons:


- Press number 4 for "Happy"
- Press number 5 for "Chill"
- Press number 6 for "Angry"

3) Software power buttons:

- Press (*) for "restart/reboot"
- Press (#) for "shutdown"



PS4 Controls



Triangle – Turn ON flashlights

Circle – Turn OFF flashlights

Square – R2-D2 talking

X – Random LED array patterns

Up button – “Happy” emotion

Left button – “Chill” emotion

Right button – “Angry” emotion

Left joystick (push left) – Turn left

Left joystick (push right) – Turn right

Right joystick (push up) – Move backward

Right joystick (push down) – Move forward

R1 button – Turn dome clockwise

L1 button – Turn dome counter clockwise

R2 button – Close dome panels

L2 button – Open dome panels

Share + PlayStation buttons – Connect PS4 controller to R2-D2

Battery and External Power

Battery Replacement:


- 1) Ensure power button is OFF
- 2) Open and close back door using back door opener (strap) on the left side
- 3) Unscrew battery terminals and disconnect battery strap
- 4) Remove old battery and insert new battery
 - a. Recommend Lithium Iron Phosphate 12V 35Ah (or higher) battery
- 5) Connect strap and screw in battery terminals
 - a. Unscrew one terminal if battery is not currently in used

External Power Plug:


- Do NOT connect the charging plug and external plug at the same time!
- Ensure one of the battery terminals is disconnected when using external power

Charging Plug:

- Do NOT connect the charging plug and external plug at the same time!
- Utilize "Battery Meter" to keep track of battery power percentage
- Ensure battery is at 20% or higher to prevent discharge malfunctions



100% Battery



50% Battery

25% Battery



0% Battery



- Battery can be charged inside of R2-D2 by connecting the charge plug
- Battery can also be taken out and charged using the external charge plug
- A fully charged battery (10% to 100%) takes at least 3 hours

Troubleshooting

Software:

- If "Window XP" startup sound does not play 30 secs after startup, turn power button OFF/ON or unplug/plug external power plug
- If keypad does not work after a successful startup, turn power button OFF/ON or unplug/plug external power plug
- If all other electronics, except the keypad, does not work after a successful startup, press the star key (*) to reboot – Do NOT turn OFF power button
- If PS4 controller does not connect after 3 disconnecting/reconnecting tries, press the star key (*) to reboot – Do NOT turn OFF power button
- If any electronic glitches (especially the sensors, speaker, and keypad)...
 - a. Press number 1 on keypad twice for "Standby" mode
 - b. Press the star key (*) to reboot
 - c. Otherwise, turn power button OFF/ON for hard reset
- If a motor glitch occurs, press EMS switch for emergency situation before turning power OFF/ON or unplug/plug external power plug
- Seek professional assistance regarding code modification on Raspberry Pi and Arduino (user can connect HDMI and USB cables by accessing the control panel through the back door) – Warning: code modification can break the original R2-D2 program code

Electrical:

- Consider troubleshooting “software” first before troubleshooting any electrical issues
- Ensure power button is turned OFF, battery terminals disconnected, external power plug disconnected, and charging plug disconnected before troubleshooting
- Consider wearing safety glasses to prevent any eye injury
- If any electrical components does not work after a successful startup, open the back door to check any wire disconnection on the control panel and dome area
- If the dome motor does not work...
 - a. Check that EMS switch is OFF
 - b. Otherwise, check for mechanical problems
- If one of the leg motors does not work...
 - a. Check to make sure EMS switch is OFF
 - b. Check if the fuse is burnt or not – If so, change fuse (20 A min)
 - c. Otherwise, check for mechanical problems
- Seek professional assistance for more serious electrical issues

Mechanical:

- Ensure power button is turned OFF, battery terminals disconnected, external power plug disconnected, and charging plug disconnected before troubleshooting
- Consider troubleshooting “electrical” issues first before troubleshooting for mechanical problems

- If dome head does not spin, check to make sure that dome motor axel is not loose – if so, consider 3D printing another axel or getting another metal axel
- If a leg wheel does not spin, check to make sure the motor axel is not loose – if so, tighten the axel or consider getting a new axel gear if broken
- If squeaky sounds becomes noticeable, put some oil or WD-40 on the wheel chain
- If any skin panel falls off, recommend reattaching skin with epoxy
- Seek professional assistance for any other mechanical problems

