

DDJ-1000 TRAKTOR MAPPING – v7.1

v7 NEW FEATURES:


- 16x Filter SuperKnobs (p30)
- Access all 9x MixerFX (p30)
- Resonant Filter (p31)
- Turntable FX (p16)
- Remix decks recorder (p46)
- STEMS (p50)
- Tempo enlarger (p20)
- Loop Backwards adjust (p21)
- 4x Echo out (p35)

v7 BUG FIXES:

- Can now restart bome
- Can now swap usb cable
- Loads in 3 seconds
- Perfect timestamps (p13)
- LED warning blinks (p9)
- BeatFX (p27)
- Classic / Parallel (p23)
- Everything for all decks

v6 FEATURES:


- Jogscreens (p13)
- 7x jogFX chains (p33)
- 21x padFX (p39)
- Preview player (p25)
- TonePlay (p43)
- Slicer (p45)
- 3x shift layers (p4)



HOW TO LEARN THIS MAPPING?

Installation:

Step-by-step video (20 min)




Installation guide (50 pages)

**BOME+Traktor installation guide
for Pioneer DDJ controllers**

Installation video: https://youtu.be/MbGP_ECnWiQ
Installation pdf: <https://bit.ly/351FtCe>

FAQ (6 pages)




DDJ-1000 v7.0

Usage:

Step-by-step video (90 min)



Quick overview (60 slides)



Full Manual (20 pages)

DDJ-1000	Traktor Version	Traktor	Mapping Tool
1.1	4.10.0	4.10.0	4.10.0
1.2	4.10.0	4.10.0	4.10.0
1.3	4.10.0	4.10.0	4.10.0
1.4	4.10.0	4.10.0	4.10.0
1.5	4.10.0	4.10.0	4.10.0
1.6	4.10.0	4.10.0	4.10.0
1.7	4.10.0	4.10.0	4.10.0
1.8	4.10.0	4.10.0	4.10.0
1.9	4.10.0	4.10.0	4.10.0
2.0	4.10.0	4.10.0	4.10.0
2.1	4.10.0	4.10.0	4.10.0
2.2	4.10.0	4.10.0	4.10.0
2.3	4.10.0	4.10.0	4.10.0
2.4	4.10.0	4.10.0	4.10.0
2.5	4.10.0	4.10.0	4.10.0
2.6	4.10.0	4.10.0	4.10.0
2.7	4.10.0	4.10.0	4.10.0
2.8	4.10.0	4.10.0	4.10.0
2.9	4.10.0	4.10.0	4.10.0
3.0	4.10.0	4.10.0	4.10.0
3.1	4.10.0	4.10.0	4.10.0
3.2	4.10.0	4.10.0	4.10.0
3.3	4.10.0	4.10.0	4.10.0
3.4	4.10.0	4.10.0	4.10.0
3.5	4.10.0	4.10.0	4.10.0
3.6	4.10.0	4.10.0	4.10.0
3.7	4.10.0	4.10.0	4.10.0
3.8	4.10.0	4.10.0	4.10.0
3.9	4.10.0	4.10.0	4.10.0
4.0	4.10.0	4.10.0	4.10.0
4.1	4.10.0	4.10.0	4.10.0
4.2	4.10.0	4.10.0	4.10.0
4.3	4.10.0	4.10.0	4.10.0
4.4	4.10.0	4.10.0	4.10.0
4.5	4.10.0	4.10.0	4.10.0
4.6	4.10.0	4.10.0	4.10.0
4.7	4.10.0	4.10.0	4.10.0
4.8	4.10.0	4.10.0	4.10.0
4.9	4.10.0	4.10.0	4.10.0
5.0	4.10.0	4.10.0	4.10.0
5.1	4.10.0	4.10.0	4.10.0
5.2	4.10.0	4.10.0	4.10.0
5.3	4.10.0	4.10.0	4.10.0
5.4	4.10.0	4.10.0	4.10.0
5.5	4.10.0	4.10.0	4.10.0
5.6	4.10.0	4.10.0	4.10.0
5.7	4.10.0	4.10.0	4.10.0
5.8	4.10.0	4.10.0	4.10.0
5.9	4.10.0	4.10.0	4.10.0
6.0	4.10.0	4.10.0	4.10.0
6.1	4.10.0	4.10.0	4.10.0
6.2	4.10.0	4.10.0	4.10.0
6.3	4.10.0	4.10.0	4.10.0
6.4	4.10.0	4.10.0	4.10.0
6.5	4.10.0	4.10.0	4.10.0
6.6	4.10.0	4.10.0	4.10.0
6.7	4.10.0	4.10.0	4.10.0
6.8	4.10.0	4.10.0	4.10.0
6.9	4.10.0	4.10.0	4.10.0
7.0	4.10.0	4.10.0	4.10.0

Link to videos: <https://www.youtube.com/user/djestrela2>

OVERVIEW

DDJ-1000/SRT: Shifts

Main shift

Second shift



Config shift



(DDJ-SX2/SZ)



Other combinations:

Config shift



Beatgrid shift




Loop adjust shift




Preview player shift



Remix decks shift



(DDJ-SX2/SZ)



Besides the main shifts, these are the other button combinations

DDJ-1000: General overview - Deck



DDJ-1000: General overview - Mixer




DDJ-1000: General overview – 16x SuperKnobs



Deck 3&4 knobs are used by deck 1&2 as shortcuts

DDJ-1000: Jog Screens and LEDs



(Comparison with 1000SRT)



(Comparison with 1000 HID)



Jog Ring: Blink meaning

On:

- Volume on

Off:

- When Volume zero
- While scratching (helper)

Blink:

- JogFX active
- End of Track Warning
- Reverse



Which effects runs in which FX Units?

FX1



TTFX Deck1



MacroFX Deck1



JogFX (all decks)

EchoOut (all decks)


FX2



TTFX Deck2



MacroFX Deck2



Per-channel effects (all decks, except master!)

FX3




FX4




When doing an automated effect, look at the screen on the correct FX unit.
This picture explains what runs where.
Do not forget to install the mapping twice to have the correct FX list.

SCREENS

DDJ-1000: Jog Screens



Phase error (zoomed around zero)



Phase error (GUI)

DDJ-1000: Jog Screens



Preview Tempo range


+10.0%

tempo range

(Double Tap)



Toggle time elapsed / remain



Preview loop / move sizes (sign blinks)


loop warning

-04:04

loop size move size



+



Preview track length and base BPM

Base BPM

127.9




+



Screens Reset



+





+



Raise/Lower BOME clock period

TRANSPORT

DDJ-1000/SRT: Transport / TurnTable FX



ALL DDJs: Jog operations



Scratch



JogFX (if blinking)



+




Quick Search



+



Loop Adjust



+



Beatgrid adjust

DDJ: Sync Section




Sync (toggle)



+



Set master deck




+



Tempo override:
(=sync off, tempo = 0)



+



+



Tempo override:
(= sync off, force that tempo)

DDJ: Elastic Beatgrid Helpers




Toggle Sync aids




when active: also ENABLES Sync



when active: also DISABLES Sync





Phase error (zoomed around zero)



Phase error (GUI)

For more info on elastic beatgrids in Traktor, see this [blog post](#)

DDJ-1000: Automatic tempo enlarger



- When tempo range changes, both tempo % and sync led will blink
- When soft takeover is in progress, tempo % shows wanted value, and sync led blinks
- Use "shift+memory+master_tempo" to configure this feature

DDJ-1000/SRT: Loop Section

OUTSIDE A LOOP:

(tap)




In / Out / 4-beat

(long press)



Re-Loop / Loop activate



+



Half / Double / Loop Set

INSIDE A LOOP:

(tap)



Half / Double / Deactivate Loop

(longpress)



+



Loop Adjust Whole / Adjust Out

BACKWARD LOOPS:




+




Increase / Decrease / Backwards Loop

More info: <https://www.traktorbible.com/articles/shorten-loops.aspx>

DDJ-1000/SRT: BeatJump Section




(DDJ-SX2/SZ)



- Search buttons operate on beatjump or Loops depending if loop is active
- Use dedicated pad mode 6 for finer control

DDJ-1000/SRT: Deck layout




Manually override layout



Toggle 2-deck / 4-deck view



(Double Tap)
+



Toggle Parallel / Classic view



+



+




Enable/Disable auto Layout

- Automatic Layouts:
 - Single tap “deck select” to toggle 2/4 decks. This is optimized for small screens
 - Double tap “deck select” to toggle parallel/classic views
- To disable this feature:
 - Manually select any layout with the mouse
 - Press “shift+memory+deck_select”
 - Change it permanently on the BOME config (see page 64)

ALL DDJs: Browser

(BROWSER)



Turn: Browse List
Press: Load Track

Load+Start Preview player

Only browser

BACK VIEW

(BROWSER TREE)



+



Turn: Scroll Tree
Press: Expand Folder

Scroll Favorites

Goto Collection

BACK VIEW

(DECK ZOOM)



+




Turn: Zoom deck
Press: Zoom reset

BACK VIEW

ALL DDJs: Preview Player

(hold)



LOAD PREVIEW PLAYER



+



SEEK PREVIEW PLAYER


(release)



UNLOAD PREVIEW PLAYER



SELECT ANOTHER TRACK



- Hold “back” to load the preview player
- Without moving your hand: turn browser to seek
- Release “back” to unload the preview player
- Without moving your hand: turn browser to select another track

EFFECTS

SAFETY FIRST! EMERGENCY SITUATIONS:

This mapping has dozen of effects, which could be confusing at times.

If you are in an emergency where nothing is heard, simply select “Sample” to disable ALL effects at once.

(SP position)



DDJ-1000: BeatFX selection



FX info ONLY for MST case!




FX parameter



+



Single/Group mode



Select Traktor OR Pioneer Effect



Select source. Important:
MST = Pioneer; 1..4 = Traktor!



- ONLY the master channel has Pioneer effects!
- Per channel, effects are ALWAYS Traktor effects (“internal mode”)
- Parameters are saved when switching FX

DDJ-1000: BeatFX ON/OFF



FX Dry/Wet





+



FX parameter



Toggle effect ON/OFF
(note: see firmware bug
on next page)



DDJ-1000: BeatFX firmware bug

- The pioneer firmware has a bug on beatFX
 - The blue button can be solid, but the FX is on
 - The blue button can be blinking, but the FX is off



- If this happens, press “memory” + “ON/OFF” once




DDJ-1000 bug workaround

Single-Knob Effects: Overview

DDJ-1000:




Traktor GUI



- Every knob has two effects, one on each side (like RMX-1000)
- Deck3 knob is a shortcut to Deck1
- Result: 4x different immediately accessible
- The 4x mixer buttons affects all decks. Total of 16x effects
- Pad shortcuts affect that deck only

Single-Knob Effects: Set selection

MIXER:



PAD MODE #3:

Mode3			
Echo: Wormhole Flanger: PolarWind Echo: Dot delay Flanger: Barber Pole	Echo: FlightTest Filter: EventHorizon Echo: Dual Delay Flanger: BarberPole	Masher: LaserSlicer Masher: Zzuurp Echo: Reverb White: Noise	<u>Resonant</u> <u>Filter</u> Bit Crush Time Gater
Noise: DarkMatter Masher: BassOMatic	Masher: Granuphse Stretch fast	Stretch slow Stretch fast	



- The 4x mixer buttons affects all decks. Total of 16x effects
- Pad shortcuts affect that deck only

Single-Knob Effects: Control



TURN LEFT: Left MixerFX (Echos)
TURN RIGHT: Right MixerFX (Flangers)

(note: Windows-only feature)



TURN LEFT: Left MacroFX (Echos)
TURN RIGHT: Right MacroFX (Flangers/Filters)

(any)



+



Access full range of current effect
(this is applicable to all knobs)

(deck 3&4)




+



Access mixerFX for deck C and D

- Every knob has two effects, one on each side (like RMX-1000)
- Deck3 knob is a shortcut to Deck1
- Result: 4x different immediately accessible


JogFX chains #1



- Press “Sampler” to enter jogFX (jog blinks)
- Touch to apply FX;
- Turn to change FX;
- Release to stop FX;
- Press “hotcues” to cancel jogFX (=scratch mode)

List of FX chains: <https://github.com/pestrela/music/blob/master/traktor/README.md#list-of-fx-chains>

JogFX chains #2



DDJ-1000/SRT: Slip reverse

(long press)



Censor

(tap)



Echo Out

(tap)




Echo Out resume



+



Reverse



(DDJ-SX2/SZ)




+

- Use censor button, or pad #8 for echo out
- Echo out type can be customized

DDJ-1000/SRT: Echo out


FAVORITES:



Favorite #3: Hold beat



Favorite #2: Slow Long Tail



Favorite #1: Fast Long Tail

CUSTOM:



Favorite #4: User custom



Echo Out Parameter #3





Echo Out Parameter #1+#2



Dry Wet FX Unit 1+2+3

- Use censor button, or pad #8 for echo out
- Echo Out type can be customized to favorites or custom

PAD MODES




(+shift)




Pad mode #1: HotCues

HOTCUES:



- Hotcues always move the temporary cue as well



HOTCUE DELETE:



- Use shift to delete hot cues
- In settings / analyse options, disable : *“store beatmarker as hotcue”*
- Use *“left mode”* to cycle advanced panel tab (move -> cue -> grid)

Pad mode #2: PadFX and Rolls (1)


MAIN PAGES:




- Use "left mode" button to cycle the top two pages

Pad mode #2: PadFX and Rolls (2)

EXTRA PAGES:




PAGE SELECTOR:




- Use “mode” button to cycle the top two pages
- Use “<” to cycle all pages
- Use “>” or “shift” to select a specific page

Pad mode #3: Single-Knob Effects

MIXER:



PAD MODE #3:




- Mixer shortcuts affects all decks
- Pad shortcut affect that deck only

Pad mode #4: JogFX

JOG FX:

(cancel)

Mode 4



Beatmasher Digital filter Gater	Beatmasher Filter Reverb	EventHorizon (none) Gater	Gater Beatmasher Reverb
Flanger (None) Gater	Beatmasher Peak filter Gater	FormatFilter Peak filter Flightest	Echo out




- Enter jogFX mode on mode 4 (jog will blink)
- Touch jog to apply FX;
- Turn jog to change FX;
- Release jog to stop FX;
- Sampler volume to Dry/Wet
- Press “hotcues” to cancel jogFX (=scratch mode)


List of FX chains: <https://github.com/pestrela/music/blob/master/traktor/README.md#list-of-fx-chains>

Pad mode #5: Tone Play



PAGE 1:



PAGE 2:




Use shift to choose between 3x modes:




Pad mode #6: BeatJumps and Loops

BEATJUMP page:



- Use “<” arrow to select “beatjump” mode
- Beatjumps are performed even if a loop is active


Detailed page:




- Use “>” arrow to select “detailed” mode with full control of adjustment abilities

Pad mode #7: Slicer

SLICER:



SLICER MODES:



Use shift to choose between 3x modes:

Pad mode #8: Pattern Recorder

Overview:



IN: record steps →


IN: adjust samples →

← OUT: triggered steps

← OUT: current step




Blink: Recording steps



Solid: Only Playing



+



Off: Sequencer off

- Use “sampler cue” to start recording

Pad mode #8: Pattern Recorder

Overview:



IN: record steps



IN: adjust samples




OUT: triggered steps



OUT: current step



Page "1":



- Use "Trigger pads" to record a 16-step pattern
- See the current timeline on "adjust pads"

Pad mode #8: Pattern Recorder

Overview:




IN: record steps →

IN: adjust samples →

← OUT: triggered steps

← OUT: current step

Shift:



- Use “shift” to Mute the slot, and to delete the recording + stopping samples

Pad mode #8: Pattern Recorder

Overview:







IN: record steps →

IN: adjust samples →

← OUT: triggered steps

← OUT: current step


Adjust:

Adjust #1	+		Slot Volume
Adjust #1	+		Slot Filter
Adjust #1	+		Slot FX Send
Adjust #1	+		Change Sample


- Hold the Pad to adjust the Volume, Filter, FX and Selected sample per slot
- Decks A controls Deck C (**except** if it holds a Stem track)

Pad mode #8: Pattern Recorder

Page "2":










Page "2":



- Use "page 2" to change pattern length, Swing, Key lock, and One-Shot / Loop

Pad mode #8: STEMS

Adjust:

Adjust #1	+		Slot Volume	
Adjust #1	+		Slot Filter	
Adjust #1	+		Slot FX Send	
Adjust #1	+		Change Sample	

- Hold the Pad to adjust the Volume, Filter, FX and Selected sample per slot
- Decks A controls Deck C (**except** if it holds a Stem track)

Ean Golden Stems Mix Walkthrough:

<https://www.youtube.com/watch?v=AtwRVk9a99w>

Creating Custom STEMS:

<https://github.com/pestrela/music/blob/master/traktor/README.md#how-to-create-your-own-karaoke-files-automatically-using-stems-and-ai>

DDJ-1000: External Microphones



Mic1 Volume


Mic2 Volume

Mic Hi Adjust / STEM FX (while pressing pad mode 8)

Mic Low adjust / STEM FILTER (while pressing pad mode 8)

- The Mic Equalization is done in hardware and cannot be disabled
- If you use Mics, do NOT use STEM FX or Filter.
 - This is very easy – the new functions only activate when you press a very specific pad as a new shift
 - Instead, just set them with your mouse


DDJ-1000: Cross-Fader




Crossfader



+



Crossfader Curve Adjust



DDJ-1000/SRT: Beatgrid

BPM button:



BPM adjust (fine)

Lock track

Set Beatmarker

SLIDE button:



Grid Slide (fine)

Auto BPM

Delete Beatmarker

(DDJ-SX2/SZ)

(involved buttons)



Panel shortcuts



3x Panels (Traktor screen)



Cycle between 3x panels



Goto CUE panel



Goto MOVE panel



Goto MOVE panel



Goto GRID panel

REFERENCE / CONFIG

DDJ-1000/SRT: What blinks, and for what reason



Blink: press to set floating cue



Blink: press to un-pause track



**Blink: Echo out is active
Censor Reverse is active (also blinks jog)**



Blink: Flux is active

(sign blinks)



-05:58



Blink: Inside active loop



Blink: Pattern recording



Blink: Set loop in point








Blink: Tempo soft-takeover, Changed tempo range










**Blink: JogFX active, End of Track Warning, Reverse
Off: Volume zero, while scratching
On: Volume on**

DDJ-1000/SRT: All gestures


Single Tap	Button	<u>Long Press</u>
Echo Out		Slip reverse (AKA Censor)
4-Beat loop		Loop activate
Set IN/OUT points Half / Double loop		Re-Loop (like in CDJs)
		Loop Adjust Whole / Loop Adjust Out

Single Tap	Button	<u>Double Tap</u>
Toggle 2-deck / 4-deck view		Toggle Parallel / Classic view
Shift		Toggle elapsed / remain
Select PadFX mode		Toggle padFX subpages


DDJ-1000/SRT: All shifts

Shift	Button
Main shift	
Second shift	
Configure shift	 + 
Beatgrid shifts	 
Loop adjust shift	
Preview player shift	
Remix decks shift	<div>Pads mode 8</div>

DDJ-1000: Main Shift (part #1/#3)



DDJ-1000: Main Shift (part #2/#3)



Increase / Decrease / Backwards Loop

Beatjump "1" / Loop move "1"

Browser Tree


Single/Group mode

FX parameter

**Access full range of current effect
(this is applicable to all knobs)**

**Cycle Tempo range
(6%→10%→16%→100%)**

DDJ-1000: Main Shift (part #3/#3)



DDJ-1000: Second shift



+



Half / Double / Loop Set

Move size half / double

Deck Zoom

Tempo override:
(= sync off, force that tempo)

Tempo override:
(=sync off, tempo = 0)

DDJ-1000 bug workaround

3&4: Access mixerFX for deck C and D

Dry Wet FX Unit 1+2+3

DDJ-1000: Configurable Settings




Manual Reset

			Button	What	Default
				BOME clock	60ms
				Auto Layout	✓
				TurnTable FX	✓
				Sync Aid	✗
				External CUE	✗
				Filter Superknobs	✓
				Tempo Enlarger	✓
				Prev/Next track	(not a config)

DDJ-1000: Configurable Settings – Setting defaults

To make the settings permanent, edit the BOME file as shown below, and then restart BOME using the red button:



NOTES / FAQs

RELEASE NOTES v7.0.0:

KNOWN MAPPING ISSUES:

- Using MixerFX superknob opens the preferences window
 - Workaround: move it off screen
- MixerFX superknobs are not supported in macOS
 - If you know AppleScript please contact me
- Timestamp doesn't work on deck 3&4
 - This is a limitation of DN-HC4500. A workaround will be released later

NON-MAPPING BUGS:

- Pioneer effects are only on the master channel
 - This is by design of the DDJ-1000 hardware
- Small loops (1/2, 1/4, etc) are displayed as "zero"
 - Only integer digits can be displayed on screen
- Feature "X" or "Y" is supported in Rekordbox / VirtualDJ, but not here
 - The MIDI firmware has several bugs and missing features
 - Please help reporting this to Pioneer, as explained in [in this link](#)

DDJ-1000/SRT: Empty sub-pages

Warning: All main pad modes DO NOT have anything on the “right” sub-pages. Going there shows an empty set of pads.

In this case just press “left” to return to the normal sub-pages.



DO NOT CLICK HERE UNLESS INSTRUCTED!

Exceptions: Keyboard mode, beatjump/loop, remix decks modes

Differences of Mac vs Windows versions

MacroFX SuperKnobs are supported in both Mac and Windows.
However, MixerFX SuperKnobs are only support for Windows.

This could be done in mac as well [using AppleScript](#).

If you have experience in AppleScript please contact me.

TABLE OF CONTENTS:

- Overview: 2x Shifts
- Overview: Decks
- Overview: Mixer
- Overview: Screens/Leds
- Overview: JogRing
- Overview: FX units
- Overview: Jog Screens
- Transport
- Turntable FX
- Sync
- Sync aids
- Auto tempo enlarger
- Loops
- BeatJumps / Loop Shifts
- Layout
- Browser
- Preview Player
- Beat FX
- Filter SuperKnobs
- JogFX chains
- Censor
- Echo Out
- Pad 1: Hotcues
- Pad 2: PadFX/Rolls
- Pad 3: Superknobs
- Pad 4: JogFX
- Pad 5: Tone Play
- Pad 6: Beatjump/loop
- Pad 7: Slicer
- Pad 8: Pattern Recorder
- Pad 8: Stems
- CrossFader
- Beatgrid
- Reset and Startup
- Summary: Gestures
- Summary: Warning blinks
- Summary: Config Settings
- Release notes v7.0.0
- Windows vs MAC versions

V7.1 update



Enable/disable turntable FX



Raise/Lower BOME clock period




DDJ-1000 bug workaround
(see page 29)

(SP position)



emergency deactivate all FXs,
MixerFX, key shift and Balance



Manually override layout



Enable/Disable auto Layout




Enable/Disable Enlarger

Performance: To make the mapping run faster, do this:

a) Reset the screens using shift+quantize



b) Ensure bome logging is DISABLED



c) Raise the BOME clock to “100” (or higher)



d) Delete/Disable the CH3 and CH4 presets in BOME

e) Delete the HC-4500 page in the Traktor controller manager.
(this will remove timestamp support)

DDJ-1000: Reset and Startup



Manual Reset

To reset the mapping use “shift+quantize”.

It takes some seconds, and sometimes needs to be done twice.

This procedure enables you to restart BOME or swap the USB cable.

Also use this method first if you have weird behavior like no Leds, the needle doest turn, or Leds do not match the traktor GUI.

If possible, prefer starting the components in a specific sequence:

#0 USB cable ON

#1 laptop ON

#2 DDJ ON

#3 BOME ON

#4 Traktor ON

ENJOY!