

XDJ-XZ

for rekordbox VIDEO



Group	No.	Name	Action	Function
BROWSE	1	MENU	Press	Open/close rekordbox VIDEO CONTROL window when selecting MEDIA SELECT MIDI.
	2	BACK	Press	Close rekordbox VIDEO CONTROL window.
	3	TEXT	Touch	Display text in VIDEO display area.
	4	IMAGE	Touch	Display image in VIDEO display area.
	5	CAMERA	Touch	Display live feed from CAMERA in VIDEO display area.
	6	SLIDESHOW	Touch	Display live feed from CAMERA in VIDEO master out window.
	7	AV SYNC	Touch	Display and start SLIDE SHOW in VIDEO display area.
	8	TRANSITION FX	Touch	Pause SLIDE SHOW.
	9	TRANSITION FX CALL	Touch	Sync the video cross fader and the audio cross fader or cancel it.
	10	TRANSITION FX RANDOM	Touch	Go to TRANSITION FX selection window.
	11	TRANSITION FX FAVORITE(1~5)	Touch	Call TRANSITION FX (order as listed)



Group	No.	Name	Action	Function
BROWSE	1	Rotary Selector	Turn	Move to next/previous page.
	2	BACK	Press	Back to rekordbox CONTROL window.
	3	BACK	Touch	Back to rekordbox VIDEO CONTROL window.
	4	TRANSITION FX select	Touch	Select TRANSITION FX.