

Pioneer DJ

DDJ-SZ

Hardware Diagram for rekordbox dj



GROUP	No.	UI NAME	FUNCTION	+SHIFT
1, DECK				
	1	JOG	<i>Top of jog</i> Scratch (Vinyl on)	Search
			Pitch Bend (Vinyl off)	Search
			<i>Side of jog</i> Pitch bend	
2	TEMPO		Tempo control	
3	KEYLOCK		Master tempo On/Off	Tempo range
4	DECK 1-4		Select Deck 1-4	No function assigned here
5	SYNC		Sync On/Off	Master
6	LOOP IN		Loop in / Adjust loop in	RE-TRIGGER
7	LOOP OUT		Loop out / Adjust loop out	Reloop / Exit
8	CENSOR (REVERSE)		SLIP REVERSE	REVERSE
9	SLIP		Slip mode on/off	Vinyl mode On/Off
10	SHIFT		Shift	No function assigned here
11	PANEL SELECT		Show FX panel	Show SAMPLER panel
12	Takeover Indicator			
13	PLAY/PAUSE		Play/Pause	
14	CUE		Cue set/play , Cue back	Jump to track start
15	AUTO LOOP		Auto loop, Manual loop On/Off	Loop Active/Non active
16	LOOP 1/2X		Loop Size Select (Half)	Loop move (left)
17	LOOP 2X		Loop Size Select (Double)	Loop move (right)
18	NEEDLE SEARCH		Needle Search	
19	GRID ADJUST		Adjust beat Grid	Beat grid 1/2x
20	GRID SLIDE		Move Beat Grid	Beat grid 2x

GROUP	No.	UI NAME		FUNCTION	+SHIFT
2. EFFECT					
COMMON					
	9	FX1		FX1 assign On/Off	
	10	FX2		FX2 assign On/Off	
FX Group Mode					
	1	1		Adjust FX1/2-1 level	
	2	2		Adjust FX1/2-2 level	
	3	3		Adjust FX1/2-3 level	
4	BEATS	rotate	Select FX1/2 beat	Select release FX	
		push	Release FX On	No function assigned here	
5	ON	FX1/2-1 On/Off		Select FX1/2-1	
6	ON	FX1/2-2 On/Off		Select FX1/2-2	
7	ON	FX1/2-3 On/Off		Select FX1/2-3	
8	TAP	FX TAP (Adjust tempo manually)		Switch FX MODE	
		long press	FX auto beat	No function assigned here	
FX Single Mode					
	1	1		Adjust FX level	
	2	2		Adjust FX parameter1	
	3	3		Adjust FX parameter2	
4	BEATS	rotate	Select FX1/2 beat	Select release FX	
		push	Release FX On	No function assigned here	
5	ON	FX1/2 On/Off		Select FX1/2	
6	ON	FX Parameter1 On/Off		No function assigned here	
7	ON	FX Parameter2 On/Off		No function assigned here	
8	TAP	FX TAP (Tempo adjust manually)		Switch FX MODE	
		long press	FX auto beat	No function assigned here	
3, BROWSER					
1	BROWSE	rotate	Scroll through files/folders/items	Waveform Zoom In/Out	
		push	Load Track (DECK1), Inst. Doubles Show other panels	Add/delete Tag List	
2	BACK	Show tree view/panels backward		Show Tag List/Playlist Bank	
3	LOAD PREPARE	Show panels forward		Show Related Tracks	

GROUP	No.	UI NAME	FUNCTION	+SHIFT
4. PERFORMANCE PADS				
	9	HOT CUE		Hot Cue Mode
			<i>long press</i> QUANTIZE On/Off	Beat Jump Mode
10	ROLL		PAD FX1 Mode	PAD FX2 Mode
11	SLICER		Slicer Mode	Slicer Loop Mode
12	SAMPLER		Sampler Mode	Velocity Sampler Mode
1-8	PERFORMANCE PAD 1-8	<i>mode</i>		
		<i>Hot Cue</i>	Set/Call Hot Cue	Delete Hot Cue
		<i>Beat Jump</i>	BEAT JUMP	
		<i>PAD FX1</i>	PAD FX1 ON (Momentary)	
		<i>PAD FX2</i>	PAD FX2 ON (Momentary)	
		<i>Slicer</i>	Play Slicer	Slice Shift (Only PAD 5,6)
		<i>Slicer Loop</i>	Play Slicer Loop	Slice Shift (Only PAD 5,6)
		<i>Sampler</i>	Play Sampler	Stop Sampler
		<i>Velocity</i>	Play Sampler	Stop Sampler
		<i>mode</i>		
13	PARAMETER (◀)	<i>Hot Cue</i>	Call Memory Cue (◀)	No function assigned here
		<i>Beat Jump</i>	Change JUMP range (1/2x)	Change JUMP range (1/16x)
		<i>PAD FX1</i>	Adjust beat (down)	No function assigned here
		<i>PAD FX2</i>	Adjust beat (down)	No function assigned here
		<i>Slicer</i>	Change roll (down)	Change length (down)
		<i>Slicer Loop</i>	Change roll (down)	Change length (down)
		<i>Sampler</i>	Change bank (down)	No function assigned here
		<i>Velocity</i>	Change bank (down)	No function assigned here
		<i>mode</i>		
		<i>Hot Cue</i>	Call Memory Cue (▶)	No function assigned here
14	PARAMETER (▶)	<i>Beat Jump</i>	Change JUMP range (2x)	Change JUMP range (16x)
		<i>PAD FX1</i>	Adjust beat (up)	No function assigned here
		<i>PAD FX2</i>	Adjust beat (up)	No function assigned here
		<i>Slicer</i>	Change roll (up)	Change length (up)
		<i>Slicer Loop</i>	Change roll (up)	Change length (up)
		<i>Sampler</i>	Change bank (up)	No function assigned here
		<i>Velocity</i>	Change bank (up)	No function assigned here
		<i>mode</i>		