

Compiling -Uart:

1. cd the cross compilation dir.

Enable the toolchain

• /opt/poky-linux/2.5.2/environment-setup-cortexa9hf-neon-poky
-linux-musl-miscabi

2. Compile the Application cross compilation.

\$cc 03-UART.c -o Uart

3. Execute

• /Uart

4. Set to and Run Mikrotik Simulator (MS) with Jumper.
cave.