

Instructions for running the Door Lock

1. Start the node server with "node api.js"
2. Start the raspberry pi. If hodoor.service is not being used, run ssh -R 8081:localhost:8081 <user>@<ec2 ip>
3. Start the Flask server
Open a terminal window, navigate to the project directory, and enter:
`python pyserver.py`
4. Start the doorbell script
In a new terminal window, enter:
`python main.py`
5. Wait for a message from your door lock.