

GCS	PLUGIN
GLOBAL_POSITION_INT	I_State
time_boot_ms (unsigned int) lat (int) lon (int) alt (int) relative_alt (int) vx (int) vy (int) vz (int) hdg (unsigned int)	time_boot_ms (unsigned int) lat (int) lon (int) alt (int) relative_alt (int) vx (int) vy (int) vz (int) hdg (unsigned int)
ATTITUDE	I_Rotation
time_boot_ms (unsigned int) roll (float) pitch (float) yaw (float) rollspeed (float) pitchspeed (float) yawspeed (float)	data status (byte) data quality (byte) timestamp (timestampType) roll (double) pitch (double) yaw (double) attitudeType (EAttitudeType) deviceId (string)
MISSION_ITEM	I_Waypoint
target_system (unsigned int) target_component (unsigned int) seq (unsigned int) frame (unsigned int) command (unsigned int) current (unsigned int) autocontinue (unsigned int) param1 (float) param2(float) param3 (float) param4 (float) x (float) y (float) z (float)	target_system (unsigned int) target_component (unsigned int) seq (unsigned int) frame (unsigned int) command (unsigned int) current (unsigned int) autocontinue (unsigned int) param1 (float) param2(float) param3 (float) param4 (float) x (float) y (float) z (float)
COMMAND_LONG	I_Command
target_system (unsigned int) target_component (unsigned int) command (unsigned int) confirmation (unsigned int) param1(float) param2(float) param3(float) param4(float) param5(float) param6(float) param7(float)	target_system (unsigned int) target_component (unsigned int) command (unsigned int) confirmation (unsigned int) param1(float) param2(float) param3(float) param4(float) param5(float) param6(float) param7(float)
STATUSTEXT	I_Error
Severity (unsigned int) Text (char[50])	errorMessage (string) id (string) level (ECriticalityLevel) timestamp (timeStampType)