



## APPENDIX D - MPD/MRB/TASK CARD CROSS REFERENCE INDEXES

### A. SCOPE

This appendix to the MPD includes cross-reference indexes to the MRB, MPD, and Task Card Numbers. These indexes are sorted by MRB item no., MPD item no., and Task Card no. This appendix contains all airplane configurations, and is not specific to an individual operator fleet. Since operator task card decks reflect delivery configuration, not all listed task cards may apply to an individual operator.

### B. NOTES

This Appendix is arranged into three sections. The first section is sorted by MPD item no., the second section by MRB item no. and the last section by Task Card no.

### C. PAGE FORMAT

#### 1. MPD ITEM NUMBER

MPD item number for each task.

#### 2. MRB ITEM NUMBER

MRB item number for each task.

#### 3. TASK CARD NO.

Task card number for each task.

Task card numbers reflect all fleet configurations.

#### 4. RELATED DESCRIPTION TASK CODE

- A- Perform AFTER the related task.
- B- Perform BEFORE the related task.
- W- Perform WITH the related task.
- P- Task PRECLUDED by performing the related task.
- R- Task PRECLUDES performing the related task.
- G- Task is GROUPED with other systems tasks which are accomplished at the same time.

#### 5. TASK TITLE

The type of task performed.

#### 6. TASK DESCRIPTION

A short description of the task intent





## 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

### TASKS SORTED BY MPD ITEM NUMBER

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
20-010-01	20-010-01	20-010-01-01		INSPECTION - GEN VISUAL	GVI of HIRF/L Sensitive Wire Runs Outside Pressure Vessel - Left
20-010-02	20-010-02	20-010-02-01		INSPECTION - GEN VISUAL	GVI of HIRF/L Sensitive Wire Runs Outside Pressure Vessel - Right
20-020-00	20-020-00	20-020-00-01		INSPECTION - GEN VISUAL	GVI of HIRF/L Sensitive Wire Runs Inside the Pressure Vessel
20-030-01	20-030-01	20-030-01-01		INSPECTION - DETAILED	DET of L/HIRF protection components Outside the Pressure Vessel - Left
20-030-02	20-030-02	20-030-02-01		INSPECTION - DETAILED	DET of L/HIRF protection components Outside the Pressure Vessel- Right
20-040-01	20-040-01	20-040-01-01		FUNCTIONAL	H/L Sensitive Connectors Outside the Pressure Vessel - Left
20-040-02	20-040-02	20-040-02-01		FUNCTIONAL	HIRF/L Sensitive Connectors Outside the Pressure Vessel - Right
20-040-04	20-040-04	20-040-04-01		FUNCTIONAL	L/HIRF Protection Components Outside the Pressure Vessel - Vertical Stabilizer
20-040-05	20-040-05	20-040-05-01 20-040-05-02		FUNCTIONAL	Lightning/HIRF Protection Components - Wing to Body Fairing
20-040-06	20-040-06	20-040-06-01 20-040-06-02		FUNCTIONAL	Lightning/HIRF Protection Components - Wing to Body Fairing
20-050-00	20-050-00	20-050-00-01		INSPECTION - DETAILED	DVI of HIRF/L Sensitive Connectors Inside Pressure Vessel
20-060-00	20-060-00	20-060-00-01		FUNCTIONAL	H/L Sensitive Connectors Inside Pressure Vessel
20-070-00	20-070-00	20-070-00-01		INSPECTION - DETAILED	DVI of HIRF/L Sensitive Pig Tails Inside the Pressure Vessel
20-100-00	20-100-00	20-100-00-01		INSPECTION - GEN VISUAL	GVI of HIRF/L Sensitive Bonding Straps (Flight Controls, Door)
20-110-01	20-110-01	20-110-01-01		INSPECTION - GEN VISUAL	Engine Harness (Cowl Open) - Left Engine
20-110-02	20-110-02	20-110-02-01		INSPECTION - GEN VISUAL	Engine Harness (Cowl Open) - Right Engine



# 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

## TASKS SORTED BY MPD ITEM NUMBER

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
20-120-01	20-120-01	20-120-01-01		INSPECTION - DETAILED	Connector Tightness - Left Engine
20-120-02	20-120-02	20-120-02-01		INSPECTION - DETAILED	Connector Tightness - Right Engine
20-130-01	20-130-01	20-130-01-01		INSPECTION - GEN VISUAL	Bonding Straps GVI - Left Engine
20-130-02	20-130-02	20-130-02-01		INSPECTION - GEN VISUAL	Bonding Straps GVI - Right Engine
20-140-00	20-140-00	20-140-00-01		FUNCTIONAL	HIRF/L Sensitive Connectors Inside the Empennage
20-141-00	20-141-00	20-141-00-01		FUNCTIONAL	Lightning/HIRF Protection Components - Tail Cone (L/HIRF)
20-142-01	20-142-01	20-142-01-01		FUNCTIONAL	Lightning/HIRF Protection Components Aft of E/E rack in the FWD Cargo Compartment
20-142-02	20-142-02	20-142-02-01		FUNCTIONAL	Lightning/HIRF Protection Components Aft of E/E rack in the FWD Cargo Compartment
20-142-03	20-142-03	20-142-03-01		FUNCTIONAL	Lightning/HIRF Protection Components Aft of E/E rack in the FWD Cargo Compartment
20-290-00	20-290-00	20-290-00-01		RESTORE	Area Forward of Nose Wheel Well
20-300-00	20-300-00	20-300-00-01		RESTORE	Area Above Nose Wheel Well And Outbd of Nose Wheel Well
20-305-00	20-305-00	20-305-00-01		INSPECTION - DETAILED	External power feeder wiring and connected EWIS
20-310-00	20-310-00	20-310-00-01		RESTORE	Electrical and Electronics Compartment
20-320-00	20-320-00	20-320-00-01		INSPECTION - DETAILED	Electrical and Electronics Compartment
20-325-00	20-325-00	20-325-00-01		INSPECTION - GEN VISUAL	Exposed EWIS in the Electrical and Electronics Compartment
20-330-00	20-330-00	20-330-00-01		RESTORE	Forward Cargo Compartment
20-335-00	20-335-00	20-335-00-01		INSPECTION - GEN VISUAL	Exposed EWIS in the Forward Cargo Compartment. (EZAP)



# 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

## TASKS SORTED BY MPD ITEM NUMBER

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
20-340-00	20-340-00	20-340-00-01	W-53-888-00-01 W-53-886-00-01 W-53-886-00-02	RESTORE	Area Below Forward Cargo Compartment
20-350-00	20-350-00	20-350-00-01		RESTORE	Area AFT of Forward Cargo Compartment
20-360-00	20-360-00	20-360-00-01		INSPECTION - GEN VISUAL	Main Landing Gear Wheel Well
20-370-00	20-370-00	20-370-00-01		RESTORE	Aft Cargo Compartment
20-375-00	20-375-00	20-375-00-01		INSPECTION - GEN VISUAL	Exposed EWIS in Aft Cargo Compartment
20-380-00	20-380-00	20-380-00-01		RESTORE	Area Below Aft Cargo Compartment
20-390-00	20-390-00	20-390-00-01		RESTORE	Aft Cargo Compartment Equipment Bay
20-400-00	20-400-00	20-400-00-01		RESTORE	Flight Compartment
20-410-00	20-410-00	20-410-00-01		INSPECTION - DETAILED	Flight Compartment
20-415-00	20-415-00	20-415-00-01		INSPECTION - GEN VISUAL	Exposed EWIS in Flight Compartment
20-420-00	20-420-00	20-420-00-01		RESTORE	Passenger Compartment - Aft of Control Compartment to Fwd Entry Door
20-430-00	20-430-00	20-430-00-01		RESTORE	Fwd Passenger Compartment - Fwd Entry Door to STA 663.75
20-435-00	20-435-00	20-435-00-01		RESTORE	Restore Passenger Compartment, Sta. 360 to 663.75
20-440-00	20-440-00	20-440-00-01		RESTORE	Aft Passenger Compartment - STA 663.75 to Aft Pressure Bulkhead
20-445-00	20-445-00	20-445-00-01		RESTORE	Restore Passenger Compartment STA 663.75 to Aft Pressure Bulkhead
20-450-00	20-450-00	20-450-00-01		INSPECTION - DETAILED	Area Aft of Pressure Bulkhead
20-460-00	20-460-00	20-460-00-01		INSPECTION - DETAILED	APU Compartment
20-465-00	20-465-00	20-465-00-01		INSPECTION - GEN VISUAL	Exposed EWIS in the tail cone



**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
20-470-00	20-470-00	20-470-00-01		INSPECTION - DETAILED	Engine No. 1
20-480-00	20-480-00	20-480-00-01		INSPECTION - DETAILED	Engine No. 2
20-490-00	20-490-00	20-490-00-01		INSPECTION - DETAILED	Fwd Strut Fairing - Engine No. 1
20-500-00	20-500-00	20-500-00-01		INSPECTION - DETAILED	Fan Cowl Support Beam - Engine No. 1
20-510-00	20-510-00	20-510-00-01		INSPECTION - DETAILED	Strut Torque Box - Engine No. 1
20-520-00	20-520-00	20-520-00-01		INSPECTION - DETAILED	Fwd Strut Fairing - Engine No. 2
20-530-00	20-530-00	20-530-00-01		INSPECTION - DETAILED	Fan Cowl Support Beam - Engine No. 2
20-540-00	20-540-00	20-540-00-01		INSPECTION - DETAILED	Strut Torque Box - Engine No. 2
20-550-00	20-550-00	20-550-00-01		INSPECTION - DETAILED	Leading Edge to Front Spar - Inboard of Nacelle Strut - Left Wing
20-560-00	20-560-00	20-560-00-01		INSPECTION - DETAILED	Leading Edge to Front Spar - Outboard of Nacelle Strut - Left Wing
20-570-00	20-570-00	20-570-00-01		INSPECTION - DETAILED	Rear Spar to Landing Gear Support Beam - Left Wing
20-580-00	20-580-00	20-580-00-01		INSPECTION - DETAILED	Rear Spar to T.E. - Outbd of Inbd Flap - Inbd of Fixed T.E. - Left Wing
20-590-00	20-590-00	20-590-00-01		INSPECTION - DETAILED	Leading Edge to Front Spar - Inboard of Nacelle Strut - Right Wing
20-600-00	20-600-00	20-600-00-01		INSPECTION - DETAILED	Leading Edge to Front Spar - Outboard of Nacelle Strut - Right Wing
20-610-00	20-610-00	20-610-00-01		INSPECTION - DETAILED	Rear Spar to Landing Gear Support Beam - Right Wing



# 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

## TASKS SORTED BY MPD ITEM NUMBER

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
20-620-00	20-620-00	20-620-00-01		INSPECTION - DETAILED	Rear Spar to T.E. - Outbd of Inbd Flap - Inbd of Fixed T.E. - Right Wing
20-630-00		20-630-00-01		RESTORE	Main Deck Cargo Compartment - STA 360 to STA 1016
20-640-00		20-640-00-01		RESTORE	Restore Main Deck Cargo Compartment, Sta. 360 to 1016
21-010-00	21-010-00	21-010-00-01		REPLACE	Recirculation Fan Hepa Filter(s)
21-015-00	21-015-00	21-015-00-01		INSPECTION - DETAILED	Recirculation Fan Check Valve(s)
21-020-00	21-020-00	21-020-00-01		OPERATIONAL	Alternate E/E Cooling Supply Fan
21-030-00	21-030-00	21-030-00-01		OPERATIONAL	Alternate E/E Cooling Exhaust Fan
21-040-00	21-040-00	21-040-00-01		REPLACE	E/E Cooling Supply Fan Filter
21-050-00	21-050-00	21-050-00-01		OPERATIONAL	Overboard Exhaust Valve Check
21-060-00	21-060-00	21-060-00-01		OPERATIONAL	Outflow Valve Motor, Selector Panel, Indicator, Feed Back Module
21-070-00	21-070-00	21-070-00-01		FUNCTIONAL	Positive Pressure Relief Valves
21-080-00	21-080-00	21-080-00-01		REPLACE	Positive Pressure Relief Valves Filters
21-090-00	21-090-00	21-090-00-01		FUNCTIONAL	Negative Pressure Relief Door
21-100-00	21-100-00	21-100-00-01 21-100-00-03 21-100-00-04		RESTORE	Primary and Secondary Heat Exchangers
21-110-01	21-110-01	21-110-01-01		FUNCTIONAL	Compressor Discharge and Turbine Inlet Overheat Switches
21-110-02	21-110-02	21-110-02-01		FUNCTIONAL	Compressor Discharge and Turbine Inlet Overheat Switches
21-120-00	21-120-00	21-120-00-01 21-120-00-02		OPERATIONAL	Pack Overheat Switch
21-130-00	21-130-00	21-130-00-01		OPERATIONAL	Trim Air Pressure Regulator and Shutoff Valve
21-140-01	21-140-01	21-140-01-01		OPERATIONAL	Water Separator Indication Disk
21-140-02	21-140-02	21-140-02-01		OPERATIONAL	Water Separator Indication Disk
21-150-00	21-150-00	21-150-00-01		RESTORE	Cabin Temperature Sensor Filters



# 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

## TASKS SORTED BY MPD ITEM NUMBER

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
21-160-00	21-160-00	21-160-00-01		RESTORE	Ozone Converters
21-170-00	21-170-00	21-170-00-01		INSPECTION - DETAILED	Pack Supply Air Cleaner System
21-180-00	21-180-00	21-180-00-01		OPERATIONAL	Pack Supply Air Cleaner System
21-190-00	21-190-00	21-190-00-01		DISCARD	APU Boot Pressure Seal
23-030-00	23-030-00	23-030-00-01		FUNCTIONAL	Resistance of Static Discharges
23-040-00	23-040-00	23-040-00-01		OPERATIONAL	Voice Recorder
23-050-00	23-050-00	23-050-00-01		FUNCTIONAL	Voice Recorder for Audio Fidelity
23-052-00	23-052-00	23-052-00-01		DISCARD	RIPS System Battery
23-054-00	23-054-00	23-054-00-01		FUNCTIONAL	RIPS Capacity
23-056-00	23-056-00	23-056-00-01		FUNCTIONAL	RIPS Maintenance Port
23-060-00	23-060-00	23-060-00-01		OPERATIONAL	ULB (Underwater Locator Beacon) for Voice Recorder
23-070-00	23-070-00	23-070-00-01		REPLACE	ULB (Underwater Locator Beacon) for Voice Recorder
23-080-00	23-080-00	23-080-00-01		OPERATIONAL	Oxygen Mask Microphone
23-100-00	23-100-00	23-100-00-01 23-100-00-02 23-100-00-03		OPERATIONAL	Emergency Locator Transmitter (Automatic / Fixed Type)
23-110-00	23-110-00	23-110-00-01 23-110-00-02 23-110-00-03		DISCARD	Emergency Locator Transmitter (Automatic / Fixed Type)
23-120-00	23-120-00	23-120-00-01		FUNCTIONAL	Functionally check the underwater locator device
23-130-00	23-130-00	23-130-00-01		DISCARD	Discard the underwater locator device battery
24-010-01	24-010-01	24-010-01-01		SERVICE	IDG Oil - Left IDG
24-010-02	24-010-02	24-010-02-01		SERVICE	IDG Oil - Right IDG
24-020-01	24-020-01	24-020-01-01		INSPECTION - DETAILED	Left IDG Delta P Indicator (DPI)





# 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

## TASKS SORTED BY MPD ITEM NUMBER

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
24-020-02	24-020-02	24-020-02-01		INSPECTION - DETAILED	Right IDG Delta P Indicator (DPI)
24-030-01	24-030-01	24-030-01-01		INSPECTION - DETAILED	Left IDG Oil Level
24-030-02	24-030-02	24-030-02-01		INSPECTION - DETAILED	Right IDG Oil Level
24-040-01	24-040-01	24-040-01-01	W-24-010-01-01	REPLACE	Left IDG Charge and Scavenge Filters
24-040-02	24-040-02	24-040-02-01	W-24-010-02-01	REPLACE	Right IDG Charge and Scavenge Filters
24-050-01	24-050-01	24-050-01-01		FUNCTIONAL	Left QAD
24-050-02	24-050-02	24-050-02-01		FUNCTIONAL	Right QAD
24-060-01	24-060-01	24-060-01-01		INSPECTION - GEN VISUAL	Left Engine IDG Surface Air Cooled Oil Cooler
24-060-02	24-060-02	24-060-02-01		INSPECTION - GEN VISUAL	Right Engine IDG Surface Air Cooled Oil Cooler
24-080-00	24-080-00	24-080-00-01		OPERATIONAL	Standby Power Control Unit (SPCU)
24-090-00	24-090-00	24-090-00-02		RESTORE	Restore the Main Battery
24-100-00	24-100-00	24-100-00-01		OPERATIONAL	Standby Power Control Unit (SPCU)
24-110-00	24-110-00	24-110-00-01		OPERATIONAL	Remote Control Circuit Breaker
24-120-00	24-120-00	24-120-00-01		RESTORE	Restore the Main and Auxiliary Batteries
24-130-00	24-130-00	24-130-00-01		FUNCTIONAL	External Power Receptacle (Wear Check)
24-140-00	24-140-00	24-140-00-01		INSPECTION - DETAILED	External Power Receptacle (Inspection)
25-010-01	25-010-01	25-010-01-01		INSPECTION - DETAILED	Captains Seat Tracks and Locking Mechanism
25-010-02	25-010-02	25-010-02-01		INSPECTION - DETAILED	First Officer seat tracks and locking mechanism



# 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

## TASKS SORTED BY MPD ITEM NUMBER

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
25-020-00	25-020-00	25-020-00-01		INSPECTION - DETAILED	Flight Compartment Crew Seat Harnesses, Straps, and Belts
25-030-00	25-030-00	25-030-00-01		OPERATIONAL	Check Captain, First Officer, & First Observer Seat Harness Inertia Reels
25-040-00	25-040-00	25-040-00-01		INSPECTION - DETAILED	Inspect Passenger Seat Belts
25-041-00	25-041-00	25-041-00-01		OPERATIONAL	Inflatable Seat Restraint System Operational Check
25-042-00	25-042-00	25-042-00-01		INSPECTION - DETAILED	Inflatable Seat Restraint System Detailed Inspection
25-043-00	25-043-00	25-043-00-01		DISCARD	Inflatable Seat Restraint System Inflator
25-044-00	25-044-00	25-044-00-01		RESTORE	Inflatable Seat Restraint System Electronics Module Assembly
25-045-00	25-045-00	25-045-00-01		INSPECTION - DETAILED	Passenger Compartment Seats
25-050-00	25-050-00	25-050-00-01		OPERATIONAL	Check Passenger Seat Break-Over Feature
25-070-00	25-070-00	25-070-00-01		FUNCTIONAL	Inspect Passenger Seat Back Recline Mechanisms
25-090-00	25-090-00	25-090-00-01		INSPECTION - DETAILED	Inspect Attendant Seat Harness
25-100-00	25-100-00	25-100-00-01		OPERATIONAL	Check Attendant Seat Harness
25-130-00	25-130-00	25-130-00-01		INSPECTION - DETAILED	Lavatory Waste Compartment Flapper Door and Spring and Access Door
25-160-00	25-160-00	25-160-00-01 25-160-00-02		INSPECTION - GEN VISUAL	Inspect Cargo Compartment Panels/Liners
25-165-00	25-165-00	25-165-00-01		INSPECTION - GEN VISUAL	Inspect Main Deck Cargo Compartment Panels/Liners
25-170-00	25-170-00	25-170-00-01 25-170-00-02		INSPECTION - GEN VISUAL	Inspect Cargo Door Restraint System
25-190-01	25-190-01	25-190-01-01		INSPECTION - DETAILED	Left Emergency Exit Hatch Escape Straps



## 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

### TASKS SORTED BY MPD ITEM NUMBER

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
25-190-02	25-190-02	25-190-02-01		INSPECTION - DETAILED	Right Emergency Exit Hatch Escape Straps
25-210-00	25-210-00	25-210-00-01		INSPECTION - DETAILED	Inspect Flight Compartment Escape Lanyards
25-220-00	25-220-00	25-220-00-01		OPERATIONAL	Emergency Escape System Operational Check
25-225-00	25-225-00	25-225-00-01		OPERATIONAL	Mid-Exit Door Emergency Escape System Operational Check
25-240-00	25-240-00	25-240-00-01 25-240-00-02 25-240-00-03 25-240-00-04		RESTORE	Emergency Escape Slides
25-245-00	25-245-00	25-245-00-01 25-245-00-02		RESTORE	Mid-Exit Doors Emergency Escape Slides
25-290-00	25-290-00	25-290-00-01		RESTORE	Restore Life Jackets
25-300-00	25-300-00	25-300-00-01		RESTORE	Restore Life Rafts
25-305-00	25-305-00	25-305-00-01		RESTORE	Restore Flight Deck Life Raft
25-330-00	25-330-00	25-330-00-01		OPERATIONAL	Power Megaphones
25-340-00	25-340-00	25-340-00-01		REPLACE	Power Megaphones Batteries
25-350-00	25-350-00	25-350-00-01		OPERATIONAL	Emergency Locator Transmitter (Survival / Portable Type)
25-360-00	25-360-00	25-360-00-01		DISCARD	Emergency Locator Transmitter (Survival / Portable Type) - Batteries
25-370-00	25-370-00	25-370-00-01		VISUAL CHECK	Detachable Emergency Equipment
25-380-00	25-380-00	25-380-00-01 25-380-00-02		OPERATIONAL	Emergency Flashlights
25-390-00	25-390-00	25-390-00-01		REPLACE	Emergency Flashlights Batteries
25-395-00	25-395-00	25-395-00-01		RESTORE	Restore Emergency Flashlight Batteries
25-400-00	25-400-00	25-400-00-01		INSPECTION - DETAILED	Smoke Hoods
25-410-00	25-410-00	25-410-00-01		DISCARD	Smoke Hoods



# 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

## TASKS SORTED BY MPD ITEM NUMBER

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
25-420-00	25-420-00	25-420-00-01		RESTORE	First Aid Kits
25-430-00	25-430-00	25-430-00-01		RESTORE	Medical Kits
25-440-00	25-440-00	25-440-00-01		OPERATIONAL	Emergency Alert Panels
25-450-00	25-450-00	25-450-00-01 25-450-00-02		INSPECTION - GEN VISUAL	Pallet Locks, Forward End Stops, and Aft End Stops
25-460-00	25-460-00	25-460-00-01		INSPECTION - GEN VISUAL	Main Deck Cargo Barrier Net Receptacle Fittings
25-470-00	25-470-00	25-470-00-01		INSPECTION - DETAILED	Main Deck Cargo Barrier Net and Fittings
25-480-00	25-480-00	25-480-00-01		FUNCTIONAL	Main Deck Cargo Barrier Net Test Strap
26-010-00	26-010-00	26-010-00-01		OPERATIONAL	Lavatory Smoke Detector
26-018-00	26-018-00	26-018-00-01		OPERATIONAL	Wing and Lower Aft Body Overheat Detection
26-020-00	26-020-00	26-020-00-01		RESTORE	Lavatory Smoke Detector Grill Cleaning
26-030-00	26-030-00	26-030-00-01		OPERATIONAL	APU Remote Fire Detection System
26-050-00	26-050-00	26-050-00-01		VISUAL CHECK	Engine Fire Bottle Pressure Gauges
26-070-00	26-070-00	26-070-00-01		REPLACE	Engine Fire Bottle Squib
26-080-00	26-080-00	26-080-00-01		FUNCTIONAL	Engine Fire Extinguishing System Squib Circuit
26-090-00	26-090-00	26-090-00-01	W-26-100-00-01 W-26-120-00-01 W-26-130-00-01	OPERATIONAL	Engine Fire Extinguishing System Check Valve
26-100-00	26-100-00	26-100-00-01	W-26-090-00-01 W-26-120-00-01 W-26-130-00-01	FUNCTIONAL	Engine Fire Bottle Pressure Switch
26-110-00	26-110-00	26-110-00-01	W-29-100-00-01	OPERATIONAL	Engine Fire Handle for Engine Shutdown and Isolation
26-120-00	26-120-00	26-120-00-01	W-26-090-00-01 W-26-100-00-01 W-26-130-00-01	FUNCTIONAL	Engine Fire Bottle Pressure Gauge



# 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

## TASKS SORTED BY MPD ITEM NUMBER

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
26-130-00	26-130-00	26-130-00-01	W-26-090-00-01 W-26-100-00-01 W-26-120-00-01	DISCARD	Engine Fire Bottle Pressure Relief Disc.
26-140-00	26-140-00	26-140-00-01		FUNCTIONAL	Engine Fire Bottle Weight Check
26-150-00	26-150-00	26-150-00-01		FUNCTIONAL	Engine Fire Extinguisher Distribution System
26-170-00	26-170-00	26-170-00-01		INSPECTION - GEN VISUAL	Engine Fire Extinguisher Distribution System
26-210-00	26-210-00	26-210-00-01		REPLACE	APU Fire Bottle Squib
26-220-00	26-220-00	26-220-00-01		FUNCTIONAL	APU Fire Extinguishing System Squib Circuit
26-230-00	26-230-00	26-230-00-01		OPERATIONAL	APU Fire Handle for APU Shutdown and Isolation
26-250-00	26-250-00	26-250-00-01		INSPECTION - GEN VISUAL	APU Remote Control Panel
26-260-00	26-260-00	26-260-00-01		FUNCTIONAL	APU Fire Bottle Pressure Switch
26-265-00	26-265-00	26-265-00-01		FUNCTIONAL	APU Fire Bottle Pressure Gauge
26-270-00	26-270-00	26-270-00-01		DISCARD	APU Fire Bottle Over Pressure Relief Disc
26-275-00	26-275-00	26-275-00-01		FUNCTIONAL	APU Fire Bottle Weight Check
26-280-00	26-280-00	26-280-00-01		INSPECTION - DETAILED	APU Fire Extinguisher Distribution System
26-290-00	26-290-00	26-290-00-01		FUNCTIONAL	Lavatory Fire Bottle Weight Check
26-300-00	26-300-00	26-300-00-01		INSPECTION - DETAILED	Lavatory Fire Bottle Fusible Tips and Discharge
26-310-00	26-310-00	26-310-00-01		VISUAL CHECK	Lavatory Heat Sensitive Tape
26-330-00	26-330-00	26-330-00-01 26-330-00-02		REPLACE	Cargo Fire Bottle Squib
26-340-00	26-340-00	26-340-00-01 26-340-00-02 26-340-00-03 26-340-00-04		FUNCTIONAL	Cargo Fire Extinguishing Tubing



**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
26-360-00	26-360-00	26-360-00-01 26-360-00-02	W-26-400-00-01 W-26-400-00-03 W-26-400-00-04	FUNCTIONAL	Cargo Fire Bottle Pressure Switch
26-365-00	26-365-00	26-365-00-01 26-365-00-02		FUNCTIONAL	Cargo Fire Bottle(s) Weight Check
26-370-00	26-370-00	26-370-00-01 26-370-00-02 26-370-00-03 26-370-00-04		OPERATIONAL	Cargo Fire Extinguishing Arm/Discharge Switches
26-390-00	26-390-00	26-390-00-01		REPLACE	Cargo Fire Extinguishing System
26-400-00	26-400-00	26-400-00-01 26-400-00-03 26-400-00-04	W-26-370-00-02 W-26-370-00-03 W-26-370-00-04	FUNCTIONAL	Cargo Fire Extinguishing 60-Minute Timer
26-410-00	26-410-00	26-410-00-01	W-26-370-00-02 W-26-370-00-03 W-26-370-00-04	OPERATIONAL	Cargo Fire Protection Operation Check
26-411-00	26-411-00	26-411-00-01		OPERATIONAL	Cargo Fire Protection Air supply Shutoff Valves Operational Check
26-412-00	26-412-00	26-412-00-01		OPERATIONAL	Cargo Fire Protection Mix Manifold Exhaust Shutoff Valves Operational Check
26-414-00	26-414-00	26-414-00-01		OPERATIONAL	Pressurization Control Panel Outflow Valve Operational Check
26-420-00	26-420-00	26-420-00-01		RESTORE	Main Deck Cargo Compartment Ceiling Grill Cleaning
26-430-00	26-430-00	26-430-00-01		OPERATIONAL	Operationally Check the Forward Galley Smoke Detector
26-440-00	26-440-00	26-440-00-01		RESTORE	Forward Galley Smoke Detector Grill Cleaning
26-450-00	26-450-00	26-450-00-01		INSPECTION - DETAILED	Portable Halon Fire Extinguishers Inspection
26-470-00	26-470-00	26-470-00-01		INSPECTION - DETAILED	Portable Water Fire Extinguisher Inspection
26-490-00	26-490-00			INSPECTION - DETAILED	Inspect Portable Carbon Dioxide Fire Extinguishers
26-510-00	26-510-00	26-510-00-01		INSPECTION - DETAILED	Inspect Portable Chemical Fire Extinguishers



**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
26-550-02		26-550-02-01		INSPECTION - DETAILED	Center Wing Rear Spar Vapor Web
27-011-00	27-011-00	27-011-00-01		INSPECTION - GEN VISUAL	Aileron Mechanical Components
27-012-00	27-012-00	27-012-00-01		INSPECTION - GEN VISUAL	Aileron Transfer Mechanism
27-013-01	27-013-01	27-013-01-01		INSPECTION - GEN VISUAL	Left Wing Aileron Mechanical Components
27-013-02	27-013-02	27-013-02-01		INSPECTION - GEN VISUAL	Right Wing Aileron Mechanical Components
27-016-00	27-016-00	27-016-00-01		OPERATIONAL	Aileron Spring Cartridge and Transfer Mechanism
27-018-00	27-018-00	27-018-00-01		FUNCTIONAL	Aileron Spring Cartridge and Transfer Mechanism
27-022-00	27-022-00	27-022-00-01		FUNCTIONAL	Aileron Power Control Units
27-024-00	27-024-00	27-024-00-01	W-27-078-00-01 W-27-210-00-01 W-27-212-00-01	FUNCTIONAL	Aileron PCU Internal Leakage Test
27-026-01	27-026-01	27-026-01-01		LUBRICATE	Left Wing Aileron Lubrication
27-026-02	27-026-02	27-026-02-01		LUBRICATE	Right Wing Aileron Lubrication
27-028-00	27-028-00	27-028-00-01		INSPECTION - DETAILED	Aileron Feel and Centering Springs
27-030-00	27-030-00	27-030-00-01		OPERATIONAL	Full Range Aileron Travel
27-032-00	27-032-00	27-032-00-01		FUNCTIONAL	Aileron Wheel Forces
27-033-00	27-033-00	27-033-00-01 27-033-00-02	W-27-035-00-01 W-27-035-00-02	FUNCTIONAL	Wing Aileron Tab Freeplay Inspection
27-034-01	27-034-01	27-034-01-01		INSPECTION - DETAILED	Left Wing Aileron Balance Bay Seals
27-034-02	27-034-02	27-034-02-01		INSPECTION - DETAILED	Right Wing Aileron Balance Bay Seals



**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
27-035-00	27-035-00	27-035-00-01 27-035-00-02	W-27-033-00-01 W-27-033-00-02	FUNCTIONAL	Wing Aileron Surface Freeplay Inspection
27-036-00	27-036-00	27-036-00-01		INSPECTION - DETAILED	Rudder Aft Components
27-038-00	27-038-00	27-038-00-01		INSPECTION - DETAILED	Forward Rudder Mechanical Control Path
27-040-00	27-040-00	27-040-00-01		LUBRICATE	Feel and Centering Spring Lubrication
27-041-00	27-041-00	27-041-00-01		OPERATIONAL	Operational Check of the Main Rudder PCU Force Fight Monitor
27-043-00	27-043-00	27-043-00-01		OPERATIONAL	Operational Check of Rudder PCU Overrides
27-044-00	27-044-00	27-044-00-01		FUNCTIONAL	Rudder PCU Internal Leakage Check
27-046-00	27-046-00	27-046-00-01		LUBRICATE	Rudder PCU and Hinge Lubrication
27-047-00	27-047-00	27-047-00-01		FUNCTIONAL	Rudder PCU Internal Leakage Check
27-048-00	27-048-00	27-048-00-01		FUNCTIONAL	RUDDER AUTHORITY LIMITER
27-050-00	27-050-00	27-050-00-01		OPERATIONAL	Rudder PCU Pressure Reducing Valve
27-054-00	27-054-00	27-054-00-01		FUNCTIONAL	Standby Rudder PCU Internal Leakage Test
27-056-00	27-056-00	27-056-00-01		INSPECTION - GEN VISUAL	Standby Rudder Power Control Unit
27-058-00	27-058-00	27-058-00-01	W-27-048-00-01 W-27-047-00-01	INSPECTION - DETAILED	Standby Rudder PCU Attachment Points
27-060-00	27-060-00	27-060-00-01 27-060-00-02		OPERATIONAL	Wheel to Rudder Interconnect
27-062-00	27-062-00	27-062-00-01 27-062-00-02		OPERATIONAL	Rudder Trim Travel
27-064-00	27-064-00	27-064-00-01 27-064-00-02		FUNCTIONAL	Rudder Surface Freeplay
27-068-00	27-068-00	27-068-00-01		OPERATIONAL	Elevator Feel Shift Function





**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
27-070-00	27-070-00	27-070-00-01 27-070-00-02	W-27-024-00-01 W-27-210-00-01 W-27-212-00-01	LUBRICATE	Elevator Lubrication
27-073-00	27-073-00	27-073-00-01		INSPECTION - GEN VISUAL	Elevator Mechanical Control Path
27-074-00	27-074-00	27-074-00-01		OPERATIONAL	Elevator Range of Travel
27-075-01	27-075-01	27-075-01-01		INSPECTION - GEN VISUAL	Left Elevator Balance Weight and Tab Control Mechanism
27-075-02	27-075-02	27-075-02-01		INSPECTION - GEN VISUAL	Right Elevator Balance Weight and Tab Control Mechanism
27-076-00	27-076-00	27-076-00-01		INSPECTION - GEN VISUAL	Elevator Power Control Unit Inspection
27-078-00	27-078-00	27-078-00-01		FUNCTIONAL	Elevator PCU Internal Leakage Test
27-080-00	27-080-00	27-080-00-01		FUNCTIONAL	Elevator Pitot Static Tube
27-084-00	27-084-00	27-084-00-01		FUNCTIONAL	Elevator Control Column Override
27-086-00	27-086-00	27-086-00-01		OPERATIONAL	Elevator Tab Control
27-088-00	27-088-00	27-088-00-01		FUNCTIONAL	Stall Warning System
27-092-00	27-092-00	27-092-00-01		FUNCTIONAL	Elevator Input Rod Pogo's
27-093-00	27-093-00	27-093-00-01 27-093-00-02		INSPECTION - DETAILED	Elevator Tab and Tab Mechanism Inspection Left and Right
27-094-00	27-094-00	27-094-00-01		OPERATIONAL	Elevator Autopilot Servo Pressure Regulator
27-095-00	27-095-00	27-095-00-01 27-095-00-02		INSPECTION - DETAILED	Elevator Tab and Tab Mechanism Inspection
27-097-00	27-097-00	27-097-00-01 27-097-00-02		FUNCTIONAL	Elevator Balance Tab Freeplay Check
27-098-01	27-098-01	27-098-01-01		FUNCTIONAL	Elevator Surface Freeplay Check



**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
27-099-00	27-099-00	27-099-00-01 27-099-00-02	W-27-107-00-01 W-27-106-00-01	FUNCTIONAL	Elevator Balance Tab Freeplay Check
27-100-00	27-100-00	27-100-00-01		INSPECTION - DETAILED	Elevator Pushrods
27-101-00	27-101-00	27-101-00-01		INSPECTION - DETAILED	Feel and Centering Single Element Dual Load Path Components
27-102-00	27-102-00	27-102-00-01		LUBRICATE	Stabilizer Trim Actuator Lubrication
27-104-00	27-104-00	27-104-00-01		LUBRICATE	Forward Stabilizer Trim Drive Train
27-106-00	27-106-00	27-106-00-01		FUNCTIONAL	Secondary Stabilizer Trim Brake
27-107-00	27-107-00	27-107-00-01		SERVICE	Stabilizer Trim Brake Servicing
27-108-00	27-108-00	27-108-00-01		RESTORE	Stabilizer Trim Restoration
27-110-00	27-110-00	27-110-00-01		INSPECTION - DETAILED	Stabilizer Trim Jackscrew Inspection
27-112-00	27-112-00	27-112-00-01		OPERATIONAL	Stabilizer Trim Limit Switches
27-114-00	27-114-00	27-114-00-01		OPERATIONAL	Control Column Switching Module
27-116-00	27-116-00	27-116-00-01		OPERATIONAL	Control Column Cutout Switches
27-118-00	27-118-00	27-118-00-01		OPERATIONAL	Stabilizer Trim Override Switch
27-120-00	27-120-00	27-120-00-01		INSPECTION - DETAILED	Stabilizer Trim Forward Mechanism
27-121-00	27-121-00	27-121-00-01		INSPECTION - GEN VISUAL	Forward Stabilizer Trim Mechanism and the Speedbrake Lever Assembly
27-122-00	27-122-00	27-122-00-01		OPERATIONAL	Stabilizer Trim Switches
27-132-00	27-132-00	27-132-00-01		SERVICE	Flap Power Drive Unit
27-134-00	27-134-00	27-134-00-01		SERVICE	Flap Power Drive Unit
27-136-01	27-136-01	27-136-01-01		LUBRICATE	Left Wing Flap Skew Sensor Mechanism Lubrication
27-136-02	27-136-02	27-136-02-01		LUBRICATE	Right Wing Flap Skew Sensor Mechanism Lubrication



# 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

## TASKS SORTED BY MPD ITEM NUMBER

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
27-138-00	27-138-00	27-138-00-01 27-138-00-02		LUBRICATE	Wing Flap Drive Torque Tubes
27-140-01	27-140-01	27-140-01-01		SERVICE	Left Wing Flap Transmission Oil Level
27-140-02	27-140-02	27-140-02-01		SERVICE	Right Wing Flap Transmission Oil Level
27-142-01	27-142-01	27-142-01-01		SERVICE	Left Wing Flap Transmission Oil
27-142-02	27-142-02	27-142-02-01		SERVICE	Right Wing Flap Transmission Universal Oil
27-144-00	27-144-00	27-144-00-01 27-144-00-02		LUBRICATE	Wing Flap Ballscrew Assemblies and Transmission Universal Joints Lubrication
27-148-03	27-148-03	27-148-03-01		INSPECTION - DETAILED	Left Wing Ballscrew Assembly
27-148-04	27-148-04	27-148-04-01		INSPECTION - DETAILED	Right Wing Ballscrew Assembly
27-152-01	27-152-01	27-152-01-01		LUBRICATE	#4 Flap Transmission Angle/Tee GearBox Universal Joints
27-152-02	27-152-02	27-152-02-01		LUBRICATE	#5 Flap Transmission Angle/Tee GearBox Universal Joints
27-154-00	27-154-00	27-154-00-01		OPERATIONAL	Flap Load Relief System
27-156-00	27-156-00	27-156-00-01		FUNCTIONAL	Flap Load Relief System
27-158-00	27-158-00	27-158-00-01		FUNCTIONAL	Alternate Flap Drive System
27-162-00	27-162-00	27-162-00-01		OPERATIONAL	Flap Skew and Asymmetry System
27-164-00	27-164-00	27-164-00-01		OPERATIONAL	Flap Uncommanded Motion Protection
27-166-00	27-166-00	27-166-00-01		INSPECTION - DETAILED	Flap Lever Sensor
27-168-01	27-168-01	27-168-01-01		OPERATIONAL	Left Wing Flap Transmission No-Back Brake
27-168-02	27-168-02	27-168-02-01		OPERATIONAL	Right Wing Flap Transmission No-Back Brake
27-170-01	27-170-01	27-170-01-01		LUBRICATE	Left Wing Flap Actuation Mechanism Lubrication
27-170-02	27-170-02	27-170-02-01		LUBRICATE	Right Wing Flap Actuation Mechanism Lubrication



# 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

## TASKS SORTED BY MPD ITEM NUMBER

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
27-171-01	27-171-01	27-171-01-01		INSPECTION - GEN VISUAL	Left Wing Flap Drive System
27-171-02	27-171-02	27-171-02-01		INSPECTION - GEN VISUAL	Right Wing Flap Drive System
27-172-01	27-172-01	27-172-01-01		INSPECTION - DETAILED	Left Wing Flap Actuation System
27-172-02	27-172-02	27-172-02-01		INSPECTION - DETAILED	Right Wing Flap Actuation System
27-174-01	27-174-01	27-174-01-01		LUBRICATE	Left Wing Forward Flap Track Attachment Pin
27-174-02	27-174-02	27-174-02-01		LUBRICATE	Right Wing Forward Flap Track Attachment Pin
27-176-01	27-176-01	27-176-01-01		LUBRICATE	Left Wing Inboard Flap Track Attachment Fitting
27-176-02	27-176-02	27-176-02-01		LUBRICATE	Right Wing Inboard Flap Track Attachment Fitting
27-178-00	27-178-00	27-178-00-01		SERVICE	Alternate Flap Drive Gearbox Servicing
27-182-00	27-182-00	27-182-00-01		LUBRICATE	Lubricate the Spoiler Mechanical Control Path (Spoiler Mixer)
27-182-01	27-182-01	27-182-01-01		LUBRICATE	Left Wing Spoiler Mechanical Control Path Lubrication
27-182-02	27-182-02	27-182-02-01		LUBRICATE	Right Wing Spoiler Mechanical Control Path Lubrication
27-184-00	27-184-00	27-184-00-01		FUNCTIONAL	Spoiler Ratio Changer No-Back Assembly
27-186-00	27-186-00	27-186-00-01		LUBRICATE	Speedbrake Lever No-Back Brake
27-187-00	27-187-00	27-187-00-01		OPERATIONAL	Operationally Check the Speedbrake Handle Stop
27-188-00	27-188-00	27-188-00-01 27-188-00-02		OPERATIONAL	Speedbrake RTO System
27-190-00	27-190-00	27-190-00-01		OPERATIONAL	Speedbrake Extended Light
27-191-00	27-191-00	27-191-00-01		FUNCTIONAL	Speedbrake Autostow System Functional Check
27-192-01	27-192-01	27-192-01-01		OPERATIONAL	Left Wing Spoiler Actuator Override Quadrants
27-192-02	27-192-02	27-192-02-01		OPERATIONAL	Right Wing Spoiler Actuator Override Quadrants
27-194-00	27-194-00	27-194-00-01		OPERATIONAL	Spoiler Mixer Centering Mechanism



**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
27-196-00	27-196-00	27-196-00-01		FUNCTIONAL	Functionally Check the Spoiler Electrical Control System Relays for Continuity
27-210-00	27-210-00	27-210-00-01	W-27-024-00-01 W-27-078-00-01 W-27-212-00-01	FUNCTIONAL	Leading Edge Slat Actuators Internal Leakage Test
27-212-00	27-212-00	27-212-00-01	W-27-024-00-01 W-27-078-00-01 W-27-210-00-01	FUNCTIONAL	Leading Edge Flap Actuators Internal Leakage Test
27-214-00	27-214-00	27-214-00-01	W-29-240-00-01	OPERATIONAL	Leading Edge Standby Actuation
27-215-01	27-215-01	27-215-01-01		INSPECTION - GEN VISUAL	Left Wing Spoiler Actuators
27-215-02	27-215-02	27-215-02-01		INSPECTION - GEN VISUAL	Right Wing Spoiler Actuators
27-215-03	27-215-03	27-215-03-01		INSPECTION - GEN VISUAL	Spoiler Mechanical Control Path
27-216-00	27-216-00	27-216-00-01		FUNCTIONAL	Autoslat System
27-218-00	27-218-00	27-218-00-01		OPERATIONAL	Leading Edge Uncommanded Motion Protection
27-220-01	27-220-01	27-220-01-01		LUBRICATE	Left Wing Leading Edge Slat Roller Lubrication
27-220-02	27-220-02	27-220-02-01		LUBRICATE	Right Wing Leading Edge Slat Roller Lubrication
27-222-01	27-222-01	27-222-01-01		LUBRICATE	Left Wing Leading Edge Slat Tracks
27-222-02	27-222-02	27-222-02-01		LUBRICATE	Right Wing Leading Edge Slat Tracks
27-224-00	27-224-00	27-224-00-01		OPERATIONAL	Standby Hydraulic System Leading Edge Uncommanded Motion
27-225-01	27-225-01	27-225-01-01		INSPECTION - GEN VISUAL	Left Wing Leading Edge Flap and Slat Actuators and Actuation Mechanism
27-225-02	27-225-02	27-225-02-01		INSPECTION - GEN VISUAL	Right Wing Leading Edge Flap and Slat Actuators and Actuation Mechanism
27-226-00	27-226-00	27-226-00-01 27-226-00-02 27-226-00-03 27-226-00-04	W-32-440-00-02 W-32-440-00-03	INSPECTION - DETAILED	Flight Control Cables



# 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

## TASKS SORTED BY MPD ITEM NUMBER

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
27-228-00	27-228-00	27-228-00-01 27-228-00-02 27-228-00-03 27-228-00-04 27-228-00-05 27-228-00-06 27-228-00-07 27-228-00-08		INSPECTION - DETAILED	Flight Control Cables
27-229-00	27-229-00	27-229-00-01 27-229-00-02	W-57-856-01-01 W-57-926-02-01	INSPECTION - DETAILED	Inboard Trailing Edge Aft Flap Drive Cable Inspection
27-230-00	27-230-00	27-230-00-01 27-230-00-02	W-32-460-00-01 W-32-460-00-02	INSPECTION - DETAILED	Flight Control Cables
27-235-00	27-235-00	27-235-00-01 27-235-00-02		FUNCTIONAL	Flight Control Cable Tension
28-010-00	28-010-00	28-010-00-01		INSPECTION - GEN VISUAL	Inspect Fuel Tanks Lower Surface - External
28-020-01	28-020-01	28-020-01-01		OPERATIONAL	Operationally Check Left Surge Tank Pressure Relief Valves
28-020-02	28-020-02	28-020-02-01		OPERATIONAL	Operationally Check Right Surge Tank Pressure Relief Valves
28-030-01	28-030-01	28-030-01-01		INSPECTION - DETAILED	Inspect (Detailed) the Left Surge Tank Vent Flame Arrestor
28-030-02	28-030-02	28-030-02-01		INSPECTION - DETAILED	Inspect (Detailed) the Right Surge Tank Vent Flame Arrestor
28-040-00	28-040-00	28-040-00-01		OPERATIONAL	Operationally Check Center Tank Fuel Scavenge System
28-050-00	28-050-00	28-050-00-01		OPERATIONAL	ENGINE FUEL SUCTION FEED
28-054-00	28-054-00	28-054-00-01		OPERATIONAL	GFI Relay Check
28-056-00	28-056-00	28-056-00-01		FUNCTIONAL	Center Tank Fuel Pump Power Failed On Protection System
28-060-01	28-060-01	28-060-01-01		RESTORE	Restore (Clean) Left Main Fuel Tank Scavenger Jet Pump
28-060-02	28-060-02	28-060-02-01		RESTORE	Restore (Clean) Right Main Fuel Tank Scavenger Jet Pump
28-060-03	28-060-03	28-060-03-01		RESTORE	Restore (Clean) the Center Fuel Tank Left and Right Water Scavenger Jet Pump



# 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

## TASKS SORTED BY MPD ITEM NUMBER

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
28-070-00	28-070-00	28-070-00-01		FUNCTIONAL	Functionally (Pressure Decay) Check the APU Fuel Line Shroud
28-080-00	28-080-00	28-080-00-01		OPERATIONAL	Operationally (Bite) Check the Fuel Quantity Indicating System
28-090-00		28-090-00-01		INSPECTION - DETAILED	Detailed inspection of the out of tank wire bundles
28-100-00		28-100-00-01	W-28-110-00-01	INSPECTION - DETAILED	Visual Inspection of Fuel Pumps
28-110-00		28-110-00-01	W-28-100-00-01	FUNCTIONAL	Insulation Resistance Test of Fuel Pumps
28-115-00	28-115-00	28-115-00-01		FUNCTIONAL	Center Tank Boost Pump Auto Shutoff Test
28-125-00	28-125-00	28-125-00-01		OPERATIONAL	Engine Fuel Spar and APU Shutoff Valve Battery
28-130-00	28-130-00	28-130-00-01		DISCARD	Engine Spar and APU Fuel Shut-Off Valve Battery Restoration
28-140-00	28-140-00	28-140-00-01 28-140-00-02 28-140-00-03		INSPECTION - DETAILED	Inspect (Detailed) the Tubing, Static Ground Straps and Clamps, No. 1, 2 and Center Tank (SFAR 88)
28-150-00	28-150-00	28-150-00-01 28-150-00-02		FUNCTIONAL	FUNCTIONAL CHECK OF THE FUEL PUMP BONDING TO STRUCTURE - LEFT AND RIGHT WING (SFAR 88)
28-160-00	28-160-00	28-160-00-01		FUNCTIONAL	FUNCTIONAL CHECK OF BONDING RESISTANCE OF APU DC FUEL PUMP (SFAR 88)
28-170-00	28-170-00	28-170-00-01 28-170-00-02 28-170-00-03	W-28-171-00-01 W-28-171-00-02 W-28-171-00-03	INSPECTION - DETAILED	DETAILED INSPECTION IN-TANK FQIS (SFAR 88) (EZAP)
28-171-00	28-171-00	28-171-00-01 28-171-00-02 28-171-00-03	W-28-170-00-01 W-28-170-00-02 W-28-170-00-03	INSPECTION - DETAILED	Detailed Inspection of FQIS components (SFAR 88)
28-173-00	28-173-00	28-173-00-01		FUNCTIONAL	Functional Check of FQIS wire bundle lightning shield to ground termination (SFAR 88)
28-180-00	28-180-00	28-180-00-01		FUNCTIONAL	Functional Check of the Equipment Fault Current Ground Strap for HSP (SFAR 88)
28-181-00	28-181-00	28-181-00-01		INSPECTION - DETAILED	Inspect (detailed) the equipment current ground straps for the Densitometer Hot Short Protector (SFAR 88)



# 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

## TASKS SORTED BY MPD ITEM NUMBER

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
28-199-00		28-199-00-01		FUNCTIONAL	Motor Operated Valve (MOV) Actuator
28-200-00		28-200-00-01		INSPECTION - DETAILED	Wire Bundles Routed on Main Deck over Center Fuel Tank
28-201-00	28-201-00	28-201-00-01		FUNCTIONAL	Functional check of bonding resistance between the hydraulic line fitting and structure (SFAR 88)
28-204-00	28-204-00	28-204-00-01		FUNCTIONAL	Functional Check of the Bonding of Air Vent to the Door Structure (SFAR 88)
28-205-00	28-205-00	28-205-00-01		FUNCTIONAL	Functional Check the Bonding of Pressure Relief Valve to the Structure (SFAR 88)
28-207-00	28-207-00	28-207-00-01		FUNCTIONAL	Functional Check of Shutoff Valves Actuator to structure (SFAR 88)
28-208-00	28-208-00	28-208-00-01		FUNCTIONAL	Functional Check of the Bonding of the Fueling Receptacle to Structure (SFAR 88)
28-211-00	28-211-00	28-211-00-01 28-211-00-02		FUNCTIONAL	Functional Check of the Bonding of MOV actuator to the Structure (SFAR 88)
28-213-00	28-213-00	28-213-00-01		FUNCTIONAL	Functional check of the Bonding of APU Shutoff valve to Structure (SFAR 88)
29-005-00	29-005-00	29-005-00-01		OPERATIONAL	A & B Engine Driven Pump Depressurization Solenoid Valve
29-010-00	29-010-00	29-010-00-01		FUNCTIONAL	Internal Hydraulic System Leakage
29-020-00	29-020-00	29-020-00-01 29-020-00-02		REPLACE	Hydraulic System "A" and "B" Pressure Filter Elements (EMDP Pumps)
29-030-01	29-030-01	29-030-01-01		REPLACE	EMDP Case Drain Filter
29-030-02	29-030-02	29-030-02-01		REPLACE	EMDP Case Drain Filter
29-050-01	29-050-01	29-050-01-01		REPLACE	EDP Case Drain Filter
29-050-02	29-050-02	29-050-02-01		REPLACE	EDP Case Drain Filter
29-070-00	29-070-00	29-070-00-01 29-070-00-02		RESTORE	Reservoir Pressurization Module Filter
29-080-00	29-080-00	29-080-00-01		FUNCTIONAL	EMDP Ground Fault Protection System
29-090-00	29-090-00	29-090-00-01		VISUAL CHECK	A & B System Return Filter Module





## 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

### TASKS SORTED BY MPD ITEM NUMBER

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
29-100-00	29-100-00	29-100-00-01	W-26-110-00-01	OPERATIONAL	A & B System Engine Pump (EDP) Shutoff Valves
29-110-00	29-110-00	29-110-00-01		FUNCTIONAL	Nose Landing Gear (NLG) Down Line Fuse
29-120-00	29-120-00	29-120-00-01		FUNCTIONAL	Nose Landing Gear (NLG) up Line Fuse
29-130-00	29-130-00	29-130-00-01	W-29-300-00-01	FUNCTIONAL	Thrust Reverser A System EMDP Fuse
29-140-00	29-140-00	29-140-00-01	W-29-290-00-01	FUNCTIONAL	Leading Edge B System Fuses
29-150-00	29-150-00	29-150-00-01	W-29-160-00-01	FUNCTIONAL	B System Brake Fuses
29-160-00	29-160-00	29-160-00-01	W-29-150-00-01	FUNCTIONAL	A System Brake Fuses
29-170-00	29-170-00	29-170-00-01		FUNCTIONAL	B System Rudder Fuse
29-180-00	29-180-00	29-180-00-01		REPLACE	Reservoir Fill Filter
29-200-00	29-200-00	29-200-00-01	W-27-214-00-01	OPERATIONAL	Standby Hydraulic Electric Motor Driven Pump
29-210-00	29-210-00	29-210-00-01		REPLACE	Standby Hydraulic Pressure Filter
29-220-00	29-220-00	29-220-00-01		REPLACE	Standby Hydraulic System Case Drain Filter
29-230-00	29-230-00	29-230-00-01		OPERATIONAL	Standby Rudder System
29-240-00	29-240-00	29-240-00-01		OPERATIONAL	Leading Edge Standby Actuation
29-250-00	29-250-00	29-250-00-01		OPERATIONAL	Power Transfer Unit Control System
29-260-00	29-260-00	29-260-00-01	W-29-140-00-01	FUNCTIONAL	Power Transfer Unit
29-270-00	29-270-00	29-270-00-01		REPLACE	Power Transfer Unit Pressure Filter
29-290-00	29-290-00	29-290-00-01		FUNCTIONAL	Leading Edge Standby Fuse
29-300-00	29-300-00	29-300-00-01	W-29-130-00-01	FUNCTIONAL	Thrust Reverser Standby Fuse
29-310-00	29-310-00	29-310-00-01		FUNCTIONAL	Case Drain Warning Switches
30-010-00	30-010-00	30-010-00-01		OPERATIONAL	Automatic Air Data Sensor Heat
31-010-00	31-010-00	31-010-00-01		FUNCTIONAL	Aural Warning System
31-020-00	31-020-00	31-020-00-01		FUNCTIONAL	Cabin Pressure Switch
31-030-00	31-030-00	31-030-00-01		OPERATIONAL	Mach/Airspeed System 1 and 2 Discrete Outputs



# 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

## TASKS SORTED BY MPD ITEM NUMBER

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
31-040-00	31-040-00	31-040-00-01		OPERATIONAL	Landing Gear Logic Module to the AWM Systems 1 and 2
31-050-00	31-050-00	31-050-00-01		FUNCTIONAL	Takeoff Warning for the Aural Warning System
31-120-00	31-120-00	31-120-00-01 31-120-00-02 31-120-00-03 31-120-00-04 31-120-00-05		FUNCTIONAL	Download FDR Data Req'd Parameters to Check Interfacing Systems
31-140-00	31-140-00	31-140-00-01	W-31-150-00-01	OPERATIONAL	DFDR ULB OPS Check
31-150-00	31-150-00	31-150-00-01	W-31-140-00-01	REPLACE	DFDR ULB Battery Replacement
31-160-01	31-160-01	31-160-01-01		RESTORE	Captain's Display Units Ventilation Hole Cleaning
31-160-02	31-160-02	31-160-02-01		RESTORE	First Officer's Display Units Ventilation Hole Cleaning
32-010-01	32-010-01	32-010-01-01		CLEAN/INSP	Left Main Gear Shock Strut Cleaning
32-010-02	32-010-02	32-010-02-01		CLEAN/INSP	Right Main Gear Shock Strut Cleaning
32-020-01	32-020-01	32-020-01-01		SERVICE	Left Main Landing Gear Servicing
32-020-02	32-020-02	32-020-02-01		SERVICE	Right Main Landing Gear Servicing
32-030-01	32-030-01	32-030-01-01		LUBRICATE	Left Main Landing Gear Lubrication
32-030-02	32-030-02	32-030-02-01		LUBRICATE	Right Main Landing Gear Lubrication
32-040-01	32-040-01	32-040-01-01	W-32-720-01-01	RESTORE	Left Main Landing Gear Restoration
32-040-02	32-040-02	32-040-02-01	W-32-720-02-01	RESTORE	Right Main Landing Gear Restoration
32-050-01	32-050-01	32-050-01-01		REPLACE	Left Main Landing Gear Discard
32-050-02	32-050-02	32-050-02-01		REPLACE	Right Main Landing Gear Discard
32-060-00	32-060-00	32-060-00-01		CLEAN/INSP	Clean Nose Gear Shock Strut
32-070-00	32-070-00	32-070-00-01		SERVICE	Nose Gear Shock Strut Service
32-080-00	32-080-00	32-080-00-01		LUBRICATE	Nose Gear Lubrication
32-085-00	32-085-00	32-085-00-01		INSPECTION - DETAILED	Nose Landing Gear Axle inspection



# 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

## TASKS SORTED BY MPD ITEM NUMBER

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
32-090-00	32-090-00	32-090-00-01	W-32-750-00-01	RESTORE	Restore Nose Landing Gear
32-100-00	32-100-00	32-100-00-01		REPLACE	Discard Nose Gear
32-110-00	32-110-00	32-110-00-01		INSPECTION - DETAILED	Landing Gear Selector Valve
32-120-00	32-120-00	32-120-00-01		INSPECTION - DETAILED	Nose Landing Gear Inspection
32-150-00	32-150-00	32-150-00-01 32-150-00-02		INSPECTION - DETAILED	Main Landing Gear Inspection
32-200-00	32-200-00	32-200-00-01		FUNCTIONAL	Nose Gear Manual Extension
32-220-00	32-220-00	32-220-00-01 32-220-00-02		FUNCTIONAL	Manual Extension System
32-230-00	32-230-00	32-230-00-01 32-230-00-02		FUNCTIONAL	Main Gear Wheel Well Protection Retract Pressure Fuse
32-240-00	32-240-00	32-240-00-01		OPERATIONAL	Landing Gear Transfer Valve
32-250-00	32-250-00	32-250-00-01		INSPECTION - DETAILED	Brake Control Linkage and Quadrants
32-260-00	32-260-00	32-260-00-01		INSPECTION - DETAILED	Brake Metering Valve Inspection
32-270-01	32-270-01	32-270-01-01		INSPECTION - GEN VISUAL	Left Main Gear Brake Wear Pins
32-270-02	32-270-02	32-270-02-01		INSPECTION - GEN VISUAL	Right Main Gear Brake Wear Pins
32-290-00	32-290-00	32-290-00-01		OPERATIONAL	Alternate Brake System
32-300-00	32-300-00	32-300-00-01		SERVICE	Brake Accumulator Precharge Pressure
32-310-00	32-310-00	32-310-00-01		OPERATIONAL	Brake Accumulator Isolation Valve
32-330-00	32-330-00	32-330-00-01		INSPECTION - DETAILED	Parking Brake Mechanical Control Path
32-340-00	32-340-00	32-340-00-01		FUNCTIONAL	Parking Brake System



# 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

## TASKS SORTED BY MPD ITEM NUMBER

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE	
32-350-00	32-350-00	32-350-00-01	W-32-360-00-01	SERVICE	Tire Inflation Check	
32-360-00	32-360-00	32-360-00-01	W-32-350-00-01	INSPECTION - GEN VISUAL	Nose and Main Gear Tires and Wheels	
32-380-00	32-380-00	32-380-00-01		RESTORE	Nose Wheel Assemblies	
32-380-01	32-380-01	32-380-01-01		RESTORE	Left Main Gear Wheel Assemblies	
32-380-02	32-380-02	32-380-02-01		RESTORE	Right Main Gear Wheel Assemblies	
32-390-00	32-390-00	32-390-00-01		INSPECTION - DETAILED	Nose Wheel Steering Control Path	
32-400-00	32-400-00	32-400-00-01		INSPECTION - DETAILED	Steering Actuator Rod Ends	
32-420-00	32-420-00	32-420-00-01		OPERATIONAL	PSEU Operational Check	
32-430-00	32-430-00	32-430-00-01	W-27-226-00-01 W-27-226-00-02	VISUAL CHECK	Tail Skid Inspection	
32-440-00	32-440-00	32-440-00-01 32-440-00-02 32-440-00-03		INSPECTION - DETAILED	Landing Gear Control Cables	
32-450-00	32-450-00	32-450-00-01 32-450-00-02 32-450-00-03 32-450-00-04 32-450-00-05		INSPECTION - DETAILED	Landing Gear Control System Cables	
32-460-00	32-460-00	32-460-00-01 32-460-00-02		W-27-230-00-01 W-27-230-00-02	INSPECTION - DETAILED	Landing Gear Control System Cables
32-480-00	32-480-00	32-480-00-01		OPERATIONAL	Operationally BITE-check the SPSEU	
32-490-00	32-490-00	32-490-00-01	W-32-040-01-01	OPERATIONAL	Tailskid Actuator and Mechanism	
32-720-01	32-720-01	32-720-01-01		GENERAL VISUAL	Left Main Landing Gear Assembly	
32-720-02	32-720-02	32-720-02-01		W-32-040-02-01	GENERAL VISUAL	Right Main Landing Gear Assembly



# 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

## TASKS SORTED BY MPD ITEM NUMBER

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
32-750-00	32-750-00	32-750-00-01	W-32-090-00-01	GENERAL VISUAL	Nose Landing Gear Assembly
32-800-00	32-800-00	32-800-00-01		ZONAL (GV)	Nose Landing Gear and Landing Gear Doors (from Ground)
32-804-01	32-804-01	32-804-01-01		ZONAL (GV)	Left Main Landing Gear and Landing Gear Doors (from Ground)
32-806-01	32-806-01	32-806-01-01		ZONAL (GV)	Left Main Landing Gear and Landing Gear Doors
32-808-02	32-808-02	32-808-02-01		ZONAL (GV)	Right Main Landing Gear and Landing Gear Doors (From Ground)
32-810-02	32-810-02	32-810-02-01		ZONAL (GV)	Right Main Landing Gear and Landing Gear Doors
33-010-00	33-010-00	33-010-00-01 33-010-00-02 33-010-00-03		OPERATIONAL	Emergency Lights
33-020-00	33-020-00	33-020-00-01 33-020-00-02 33-020-00-03		OPERATIONAL	Emergency Lighting Switch Operational Test
33-055-00	33-055-00	33-055-00-01 33-055-00-02		FUNCTIONAL	Emergency Battery Pack Capacity Functional Check
33-060-00	33-060-00	33-060-00-01 33-060-00-02		RESTORE	Emergency Lighting - Battery Pack Restoration
33-065-00	33-065-00	33-065-00-01		FUNCTIONAL	Self Illuminating Exit Signs
33-070-00	33-070-00	33-070-00-01		FUNCTIONAL	Photoluminescent Floor Proximity Lighting
33-080-00	33-080-00	33-080-00-01		REPLACE	Replace Photoluminescent Floor Proximity Lighting
33-090-00	33-090-00	33-090-00-01		INSPECTION - GEN VISUAL	Winglet Leading Edge Lens
33-090-01		33-090-01-01		INSPECTION - GEN VISUAL	Winglet Leading Edge Lens
34-030-00	34-030-00	34-030-00-01 34-030-00-10		FUNCTIONAL	Pitot Static System Leak Check
34-060-00	34-060-00	34-060-00-01 34-060-00-10		FUNCTIONAL	Pitot Static System Leak Check



# 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

## TASKS SORTED BY MPD ITEM NUMBER

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
34-060-10	34-060-10	34-060-10-01 34-060-10-02		FUNCTIONAL	Air Data System - Altimetry System
34-070-00	34-070-00	34-070-00-01 34-070-00-10		INSPECTION - DETAILED	Pitot Probes
34-070-01	34-070-01	34-070-01-01		INSPECTION - DETAILED	Pitot Probes
34-080-00	34-080-00	34-080-00-01		INSPECTION - DETAILED	Static Ports
34-090-00	34-090-00	34-090-00-01 34-090-00-02		INSPECTION - DETAILED	Pitot Systems
34-100-00	34-100-00	34-100-00-01 34-100-00-02		INSPECTION - DETAILED	Static Systems
34-105-00	34-105-00	34-105-00-01		OPERATIONAL	Source Select Panel Inertial Reference System Transfer Switch
34-110-01		34-110-01-01 34-110-01-02 34-110-01-03 34-110-01-04		FUNCTIONAL	ATC System Functional Check
34-130-00	34-130-00	34-130-00-01		REPLACE	Integrated Standby Flight Display
34-140-00	34-140-00	34-140-00-01		OPERATIONAL	Integrated Standby Flight Display
35-010-00	35-010-00	35-010-00-01		OPERATIONAL	Flight Crew Oxygen Mask/Regulator
35-011-00	35-011-00	35-011-00-01		OPERATIONAL	Gaseous Oxygen Mask/Regulator Operational Check
35-012-00	35-012-00	35-012-00-01		OPERATIONAL	Operational Check Each Cylinder Oxygen Mask/Regulator
35-020-00	35-020-00	35-020-00-01		FUNCTIONAL	Flight Crew Oxygen Mask/Regulator
35-021-00	35-021-00	35-021-00-01		FUNCTIONAL	Gaseous Oxygen Mask/Regulator Functional Check
35-040-00	35-040-00	35-040-00-01 35-040-00-02		REPLACE	Flight Crew Oxygen Cylinder
35-041-00	35-041-00	35-041-00-01		REPLACE	Flight Crew Oxygen Cylinder



# 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

## TASKS SORTED BY MPD ITEM NUMBER

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
35-050-00	35-050-00	35-050-00-01	W-35-085-00-01 W-35-085-00-02 W-35-085-00-03  W-35-080-00-01 W-35-080-00-02 W-35-080-00-03	VISUAL CHECK	Flight Crew Oxygen Cylinder
35-052-00	35-052-00	35-052-00-01		VISUAL CHECK	Flight Crew Oxygen Cylinder
35-060-00	35-060-00	35-060-00-01 35-060-00-02		VISUAL CHECK	Chemical Oxygen Generator Temperature Sensitive Tape
35-065-00	35-065-00	35-065-00-01 35-065-00-02		VISUAL CHECK	Lavatory Oxygen Constant Dispensing System (CDS).
35-070-00	35-070-00	35-070-00-01 35-070-00-02 35-070-00-03 35-070-00-04 35-070-00-05		REPLACE	Chemical Oxygen Generators
35-075-00	35-075-00	35-075-00-01		DISCARD	Lavatory Oxygen CDS system cylinder
35-080-00	35-080-00	35-080-00-01 35-080-00-02 35-080-00-03		FUNCTIONAL	Passenger Oxygen System
35-085-00	35-085-00	35-085-00-01 35-085-00-02 35-085-00-03		OPERATIONAL	Passenger Oxygen System Manual Actuation
35-090-00	35-090-00	35-090-00-01 35-090-00-02 35-090-00-03 35-090-00-04		INSPECTION - DETAILED	Passenger Oxygen Masks
35-100-00	35-100-00	35-100-00-01		INSPECTION - GEN VISUAL	Portable Oxygen Cylinders
35-120-00	35-120-00	35-120-00-01 35-120-00-02		REPLACE	Portable Oxygen Cylinders
35-150-00	35-150-00	35-150-00-01		OPERATIONAL	Manual Shutoff Valve Sensor
35-163-00	35-163-00	35-163-00-01 35-163-00-02		DISCARD	GASEOUS PASSENGER OXYGEN SYSTEM
35-164-00	35-164-00	35-164-00-01		FUNCTIONAL	Gaseous passenger oxygen flow control units.



# 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

## TASKS SORTED BY MPD ITEM NUMBER

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
35-165-00	35-165-00	35-165-00-01		FUNCTIONAL	Passenger gaseous oxygen low pressure distribution system
35-166-00	35-166-00	35-166-00-01		FUNCTIONAL	Passenger gaseous oxygen system pressure regulators.
35-167-00	35-167-00	35-167-00-01		OPERATIONAL	Check Valve Operational Check
36-020-01	36-020-01	36-020-01-01		FUNCTIONAL	Precooler Control Valve and Wing TAI Solenoid - Left
36-020-02	36-020-02	36-020-02-01		FUNCTIONAL	Precooler Control Valve and Wing TAI Solenoid - Right
36-030-01	36-030-01	36-030-01-01		FUNCTIONAL	Precooler Control Valve Sensor - Left
36-030-02	36-030-02	36-030-02-01		FUNCTIONAL	Precooler Control Valve Sensor - Right
38-015-00	38-015-00	38-015-00-01		OPERATIONAL	Forward Gray Water Drain Valve
38-030-00	38-030-00	38-030-00-01		RESTORE	Restore Vacuum Blower Filter
38-040-00	38-040-00	38-040-00-01		RESTORE	Restore Waste Drain Ball-Valve
38-060-00	38-060-00	38-060-00-01		REPLACE	Replace Bleed Air In-Line Filter
38-070-00	38-070-00	38-070-00-01		DISINFECT	Disinfect Potable Water System
38-090-00	38-090-00	38-090-00-01		RESTORE	Waste Tank Water Separator
38-100-00	38-100-00	38-100-00-01		RESTORE	Waste Tank Water Separator
47-200-00	47-200-00	47-200-00-02		VISUAL CHECK	NGS Drain - Fluid Accumulation
47-210-00	47-210-00	47-210-00-01		OPERATIONAL	Center Tank Cross Vent Check Valve
47-220-00	47-220-00	47-220-00-01		INSPECTION - DETAILED	NEA distribution lines inspection
47-300-00	47-300-00	47-300-00-01		RESTORE	Ozone Converter
47-310-00	47-310-00	47-310-00-01		CLEAN	Nitrogen generation system heat exchanger
47-320-00		47-320-00-01		RESTORE	Nitrogen generation system oxygen sensor
47-330-00		47-330-00-01		DISCARD	Nitrogen Generation System Filter Element
47-400-00	47-400-00	47-400-00-01		FUNCTIONAL	Thermal switch





# 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

## TASKS SORTED BY MPD ITEM NUMBER

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
49-010-00	49-010-00	49-010-00-01		INSPECTION - GEN VISUAL	APU Mounts
49-020-00	49-020-00	49-020-00-01		INSPECTION - DETAILED	APU Mounts
49-030-00	49-030-00	49-030-00-01		INSPECTION - DETAILED	Sigma Seal
49-040-00	49-040-00	49-040-00-01		INSPECTION - DETAILED	APU Insulation Panels
49-052-00	49-052-00	49-052-00-01	W-49-062-00-01 W-49-072-00-01 W-49-082-00-01	REPLACE	Engine Compressor Impeller
49-062-00	49-062-00	49-062-00-01	W-49-052-00-01 W-49-072-00-01 W-49-082-00-01	REPLACE	First Stage Turbine Disk
49-072-00	49-072-00	49-072-00-01	W-49-052-00-01 W-49-062-00-01 W-49-082-00-01	REPLACE	Second Stage Turbine Rotor
49-082-00	49-082-00	49-082-00-01	W-49-052-00-01 W-49-062-00-01 W-49-072-00-01	REPLACE	Turbine Shaft
49-102-00	49-102-00	49-102-00-01		REPLACE	Fuel Inlet Filter Element
49-140-00	49-140-00	49-140-00-01		OPERATIONAL	CDU'S APU Maintenance Pages
49-172-00	49-172-00	49-172-00-01		INSPECTION - DETAILED	APU Exhaust Seal
49-212-00	49-212-00	49-212-00-01		INSPECTION - GEN VISUAL	APU Eductor
49-220-00	49-220-00	49-220-00-01		INSPECTION - DETAILED	APU Eductor Inlet Duct
49-240-00	49-240-00	49-240-00-01		LUBRICATE	APU Vortex Generator Hinge Pin



# 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

## TASKS SORTED BY MPD ITEM NUMBER

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
52-010-00	52-010-00	52-010-00-01 52-010-00-02 52-010-00-03 52-010-00-04		LUBRICATE	Service and Entry Door Lubrication
52-020-00	52-020-00	52-020-00-01 52-020-00-02 52-020-00-03 52-020-00-04		LUBRICATE	Service and Entry Door Lubrication
52-030-00	52-030-00	52-030-00-01		INSPECTION - DETAILED	Forward Entry Door Inspection
52-040-00	52-040-00	52-040-00-01 52-040-00-02 52-040-00-03		INSPECTION - DETAILED	Service and Entry Door Centering Guide Bearing
52-050-00	52-050-00	52-050-00-01 52-050-00-02 52-050-00-03 52-050-00-04		INSPECTION - GEN VISUAL	Service and Entry Door Seals
52-090-00	52-090-00	52-090-00-01 52-090-00-02		LUBRICATE	Forward and Aft Cargo Compartment Door Lubrication
52-100-00	52-100-00	52-100-00-01 52-100-00-02		INSPECTION - GEN VISUAL	Forward and Aft Cargo Door Seal
52-120-00	52-120-00	52-120-00-01		LUBRICATE	E/E Access Door Lubrication
52-130-00	52-130-00	52-130-00-01		INSPECTION - GEN VISUAL	E/E Access Door Seal
52-140-00	52-140-00	52-140-00-01		INSPECTION - GEN VISUAL	Forward Access Door Seal
52-150-00	52-150-00	52-150-00-01		LUBRICATE	Airstair Door System Lubrication
52-160-00	52-160-00	52-160-00-01		LUBRICATE	Airstair System Lubrication
52-170-00	52-170-00	52-170-00-01		INSPECTION - DETAILED	Airstair System Inspection



**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
52-180-00	52-180-00	52-180-00-01		INSPECTION - GEN VISUAL	Airstair Door Pressure Seal Inspection
52-200-00	52-200-00	52-200-00-01 52-200-00-02		OPERATIONAL	Door Sensor Check
52-202-00	52-202-00	52-202-00-01		OPERATIONAL	MID EXIT DOOR LATCH AND LOCK SWITCHES
52-220-00	52-220-00	52-220-00-01		OPERATIONAL	Automatic Emergency Door Operational Check
52-222-00	52-222-00	52-222-00-01		OPERATIONAL	MID EXIT DOOR OPERATIONAL CHECK
52-230-00	52-230-00	52-230-00-01		INSPECTION - DETAILED	Inspection of Automatic Emergency Exit Door Components
52-232-00	52-232-00	52-232-00-01		INSPECTION - DETAILED	MID EXIT DOOR INSPECTION
52-240-00	52-240-00	52-240-00-01		OPERATIONAL	Automatic Emergency Exit Door Flight Lock Operational Check
52-242-00	52-242-00	52-242-00-01		OPERATIONAL	MID EXIT DOOR FLIGHT LOCK OPERATIONAL CHECK
52-250-00	52-250-00	52-250-00-01		INSPECTION - DETAILED	Automatic Emergency Door Flight Lock Inspection
52-262-00	52-262-00	52-262-00-01		INSPECTION - DETAILED	MID EXIT DOOR PRESSURE SEAL INSPECTION
52-263-00	52-263-00	52-263-00-01		INSPECTION - DETAILED	MID EXIT DOOR VENT DOOR SEAL INSPECTION
52-264-00	52-264-00	52-264-00-01 52-264-00-02		INSPECTION - DETAILED	MID EXIT DOOR PRESSURE SEAL INSPECTION
52-265-00	52-265-00	52-265-00-01		INSPECTION - DETAILED	MID EXIT DOOR VENT DOOR SEAL INSPECTION
52-280-00	52-280-00	52-280-00-01		INSPECTION - DETAILED	Crew Door Seals
52-290-00	52-290-00	52-290-00-01		INSPECTION - GEN VISUAL	Main Deck Cargo Door
52-300-00	52-300-00	52-300-00-01		LUBRICATE	Main Deck Cargo Door Lubrication



# 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

## TASKS SORTED BY MPD ITEM NUMBER

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
52-305-00	52-305-00	52-305-00-01		LUBRICATE	Lift Linkages, Latch Cams and Lock Torque Tube Lubrications
52-310-00	52-310-00	52-310-00-01		INSPECTION - DETAILED	Main Deck Cargo Door Lift Actuator Linkage
52-320-00	52-320-00	52-320-00-01 52-320-00-02		OPERATIONAL	Main Deck Cargo Door Manual Pump
52-325-00	52-325-00	52-325-00-01		OPERATIONAL	Operationally check the manual operation of PULL-IN/LATCH ACTUATOR and LOCK ACTUATOR
52-330-00	52-330-00	52-330-00-01		INSPECTION - DETAILED	Main Deck Cargo Door Lift Actuator Attachment Points
52-340-00	52-340-00	52-340-00-01		OPERATIONAL	Main Deck Cargo Door Unlock Switch
52-350-00	52-350-00	52-350-00-01		OPERATIONAL	Main Deck Cargo Door Control Panel Operational Check
52-360-00	52-360-00	52-360-00-01		FUNCTIONAL	Flight Deck Door Decompression Panel Latches/Pressure Switches
52-370-00	52-370-00	52-370-00-01		OPERATIONAL	Flight Deck Door Decompression Panel Hinges
52-380-00	52-380-00	52-380-00-01		INSPECTION - GEN VISUAL	Flight Deck Door Decompression Panel Hinges
52-390-00	52-390-00	52-390-00-01		INSPECTION - GEN VISUAL	Flight Deck Door Seals for Condition and Security
52-400-00	52-400-00	52-400-00-01		INSPECTION - GEN VISUAL	Flight Deck Door Decompression Panel Seals
52-410-00	52-410-00	52-410-00-01		FUNCTIONAL	Deny Time Delay and Deny Function
52-450-00		52-450-00-01		DETAILED	Flight Deck Security Door Panel Assembly
52-460-00		52-460-00-01		GENERAL VISUAL	Flight Deck Security Door Surround Assembly
52-470-00		52-470-00-01		DETAILED	Flight Deck Security Door Surround Assembly
52-490-00		52-490-00-01		DETAILED	Flight Deck Door Latch and Hinge Support Assemblies
52-510-00	52-510-00	52-510-00-01		DETAILED	Forward Access Door Stop Fittings and Pins



**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
52-530-00	52-530-00	52-530-00-01		GENERAL VISUAL	Forward Access Door
52-540-00	52-540-00	52-540-00-01		DETAILED	E/E Equipment Compartment Access Door Stop Fittings and Pins
52-550-00	52-550-00	52-550-00-01		DETAILED	E/E Equipment Compartment Access Door
52-570-00	52-570-00	52-570-00-01		GENERAL VISUAL	E/E Equipment Compartment Access Door
52-580-00	52-580-00	52-580-00-01		DETAILED	Forward Airstairs Door Stop Fittings and Pins
52-590-00	52-590-00	52-590-00-01		GENERAL VISUAL	Forward Airstairs Door
52-600-00	52-600-00	52-600-00-01		GENERAL VISUAL	Forward Airstairs Door
52-610-00	52-610-00	52-610-00-01 52-610-00-02 52-610-00-03 52-610-00-04		DETAILED	Entry and Galley Service Doors
52-620-00	52-620-00	52-620-00-01 52-620-00-02 52-620-00-03 52-620-00-04		DETAILED	Entry and Galley Service Doors
52-650-00	52-650-00	52-650-00-01 52-650-00-02 52-650-00-03 52-650-00-04		GENERAL VISUAL	Entry and Galley Service Doors
52-670-00	52-670-00	52-670-00-01 52-670-00-02		DETAILED	Cargo Doors
52-680-00	52-680-00	52-680-00-01 52-680-00-02		DETAILED	Cargo Doors
52-710-00	52-710-00	52-710-00-01 52-710-00-02		GENERAL VISUAL	Cargo Doors



# 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

## TASKS SORTED BY MPD ITEM NUMBER

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
52-730-00	52-730-00	52-730-00-01 52-730-00-02		DETAILED	Automatic Overwing Exit Doors
52-740-00	52-740-00	52-740-00-01 52-740-00-02		DETAILED	Automatic Overwing Exit Doors
52-760-00	52-760-00	52-760-00-01 52-760-00-02		GENERAL VISUAL	Automatic Overwing Exit Doors
52-762-00	52-762-00	52-762-00-01 52-762-00-02		GENERAL VISUAL	Mid Emergency Exit Door
52-764-00	52-764-00	52-764-00-01 52-764-00-02		DETAILED	Mid Emergency Exit Door
52-766-00	52-766-00	52-766-00-01 52-766-00-02		GENERAL VISUAL	Mid Emergency Exit Door
52-768-00	52-768-00	52-768-00-01 52-768-00-02		DETAILED	Mid Emergency Exit Door
52-770-00	52-770-00	52-770-00-01		DETAILED	Main Deck Cargo Door
52-780-00	52-780-00	52-780-00-01		DETAILED	Main Deck Cargo Door
52-790-00	52-790-00	52-790-00-01		GENERAL VISUAL	Main Deck Cargo Door
52-795-00		52-795-00-01		SPECIAL DETAILED	Main Deck Cargo Door
52-795-10		52-795-10-01		SPECIAL DETAILED	Main Deck Cargo Door
52-796-00		52-796-00-01		DETAILED	Electronic Equipment Access Door Aluminum Casting only
52-800-00	52-800-00	52-800-00-01		ZONAL (GV)	Entry Doors, Service Doors, Automatic Overwing Exits, Mid-Exit Doors, and Cargo Doors
52-802-02	52-802-02	52-802-02-01		ZONAL (GV)	Forward Cargo Door
52-804-02	52-804-02	52-804-02-01		ZONAL (GV)	Forward Cargo Door
52-806-02	52-806-02	52-806-02-01		ZONAL (GV)	Aft Cargo Door



**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
52-808-02	52-808-02	52-808-02-01		ZONAL (GV)	Aft Cargo Door
52-810-01	52-810-01	52-810-01-01		ZONAL (GV)	Forward Passenger Door
52-812-01	52-812-01	52-812-01-01		ZONAL (GV)	Forward Passenger Door
52-814-01	52-814-01	52-814-01-01		ZONAL (GV)	Automatic Overwing Exit
52-816-01	52-816-01	52-816-01-01		ZONAL (GV)	Automatic Overwing Exit
52-818-01	52-818-01	52-818-01-01		ZONAL (GV)	Automatic Overwing Exit
52-820-01	52-820-01	52-820-01-01		ZONAL (GV)	Automatic Overwing Exit
52-822-01	52-822-01	52-822-01-01 52-822-01-02		ZONAL (GV)	Aft Passenger Door
52-824-01	52-824-01	52-824-01-01		ZONAL (GV)	Aft Passenger Door
52-826-02	52-826-02	52-826-02-01		ZONAL (GV)	Forward Galley Service Door
52-828-02	52-828-02	52-828-02-01		ZONAL (GV)	Forward Galley Service Door
52-830-02	52-830-02	52-830-02-01		ZONAL (GV)	Automatic Overwing Exit
52-832-02	52-832-02	52-832-02-01		ZONAL (GV)	Automatic Overwing Exit
52-834-02	52-834-02	52-834-02-01		ZONAL (GV)	Automatic Overwing Exit
52-836-02	52-836-02	52-836-02-01		ZONAL (GV)	Automatic Overwing Exit
52-838-02	52-838-02	52-838-02-01 52-838-02-02		ZONAL (GV)	Aft Galley Service Door
52-840-02	52-840-02	52-840-02-01		ZONAL (GV)	Aft Galley Service Door
52-842-01	52-842-01	52-842-01-01		ZONAL (GV)	Main Deck Cargo Door
52-844-01	52-844-01	52-844-01-01		ZONAL (GV)	Main Deck Cargo Door
52-846-01	52-846-01	52-846-01-01		ZONAL (GV)	Mid-Exit Door
52-846-02	52-846-02	52-846-02-01		ZONAL (GV)	Mid-Exit Door
52-846-03	52-846-03	52-846-03-01		ZONAL (GV)	Mid-Exit Door



**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
52-846-04	52-846-04	52-846-04-01		ZONAL (GV)	Mid-Exit Door
52-846-05	52-846-05	52-846-05-01		ZONAL (GV)	Mid-Exit Door
52-846-06	52-846-06	52-846-06-01		ZONAL (GV)	Mid-Exit Door
53-010-00	53-010-00	53-010-00-01 53-010-00-02 53-010-00-03		GENERAL VISUAL	Fuselage Lower Lobe
53-020-00	53-020-00	53-020-00-01		GENERAL VISUAL	Nose Wheel Well
53-030-00	53-030-00	53-030-00-01 53-030-00-02		DETAILED	Cargo Door Surround Structure, Fittings and Stops
53-050-00	53-050-00	53-050-00-01		GENERAL VISUAL	Main Landing Gear Wheel Well
53-060-00	53-060-00	53-060-00-01		GENERAL VISUAL	Forward Pressure Bulkhead
53-070-00	53-070-00	53-070-00-01		GENERAL VISUAL	Area Forward of Nose Wheel Well
53-080-00	53-080-00	53-080-00-01		GENERAL VISUAL	Flight Compartment Floor Structure
53-090-00	53-090-00	53-090-00-01		GENERAL VISUAL	Area Above and Outboard of Nose Wheel Well
53-100-00	53-100-00	53-100-00-01		GENERAL VISUAL	Passenger Compartment Floor Structure - Dry Area
53-110-00	53-110-00	53-110-00-01		GENERAL VISUAL	Passenger Compartment Floor Structure - Wet Area
53-120-00	53-120-00	53-120-00-01		GENERAL VISUAL	Electrical and Electronics Compartment
53-130-00	53-130-00	53-130-00-01		GENERAL VISUAL	Forward Cargo Compartment





# 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

## TASKS SORTED BY MPD ITEM NUMBER

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
53-140-00	53-140-00	53-140-00-01 53-140-00-02		GENERAL VISUAL	Forward and Aft Cargo Compartment - Floor Structure
53-150-00	53-150-00	53-150-00-01		DETAILED	Forward Cargo Door Cutout
53-160-00	53-160-00	53-160-00-01		GENERAL VISUAL	Forward Bilge
53-170-00	53-170-00	53-170-00-01		GENERAL VISUAL	Area Aft of Forward Cargo Compartment
53-180-00	53-180-00	53-180-00-01		GENERAL VISUAL	Area Under Lower Wing-To-Body Fairing (forward of wing box)
53-190-00	53-190-00	53-190-00-01		GENERAL VISUAL	Area Above Wing Box Center Section
53-200-00	53-200-00	53-200-00-01		GENERAL VISUAL	Area Above Main Landing Gear Wheel Well
53-210-00	53-210-00	53-210-00-01		GENERAL VISUAL	Keel Beam Under Wing-To-Body Fairing (under wing box)
53-220-00	53-220-00	53-220-00-01		GENERAL VISUAL	Keel Beam In Wheel Well
53-230-00	53-230-00	53-230-00-01		GENERAL VISUAL	Aft Cargo Compartment
53-235-00	53-235-00	53-235-00-01 53-235-00-02		GENERAL VISUAL	Mid Emergency Exit Door Cutout
53-240-00	53-240-00	53-240-00-01		DETAILED	Aft Cargo Door Cutout
53-250-00	53-250-00	53-250-00-01		GENERAL VISUAL	Aft Bilge
53-260-00	53-260-00	53-260-00-01		GENERAL VISUAL	Area Aft of Cargo Compartment
53-262-00	53-262-00	53-262-00-01		GENERAL VISUAL	Area Aft of Cargo Compartment
53-270-00	53-270-00	53-270-00-01		GENERAL VISUAL	Area Under Lower Wing-To-Body Fairing (aft of Wheel Well)



# 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

## TASKS SORTED BY MPD ITEM NUMBER

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
53-280-00	53-280-00	53-280-00-01		GENERAL VISUAL	Area Under Wing-To-Body Fairing (above wing)
53-290-00	53-290-00	53-290-00-01		GENERAL VISUAL	Overwing Emergency Exit Cutout
53-310-00	53-310-00	53-310-00-01 53-310-00-02 53-310-00-03 53-310-00-04		DETAILED	Fuselage Upper Lobe Door Frames, Stops, Latches and Hinges
53-330-00	53-330-00	53-330-00-01		GENERAL VISUAL	Flight Compartment from Sta 178 to 270
53-335-00	53-335-00	53-335-00-01		GENERAL VISUAL	Flight Compartment from Sta 178 to 270
53-340-00	53-340-00	53-340-00-01		GENERAL VISUAL	Flight Compartment Floor Structure
53-350-00	53-350-00	53-350-00-01		GENERAL VISUAL	Passenger Compartment from Sta 270 to 360
53-360-00	53-360-00	53-360-00-01 53-360-00-02 53-360-00-03 53-360-00-04		DETAILED	Passenger Compartment Door Cutouts
53-370-00	53-370-00	53-370-00-01 53-370-00-02		GENERAL VISUAL	Passenger Compartment Floor Structure - Dry Area
53-380-00	53-380-00	53-380-00-01 53-380-00-02		GENERAL VISUAL	Passenger Compartment Floor Structure - Wet Area
53-390-00	53-390-00	53-390-00-01		GENERAL VISUAL	Passenger Compartment Floor Structure - Wet Area
53-400-00	53-400-00	53-400-00-01		GENERAL VISUAL	Forward Passenger Compartment, Sta 360 to 663.75
53-410-00	53-410-00	53-410-00-01		GENERAL VISUAL	Aft Passenger Compartment, STA 663.75 to 1016



**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
53-412-00	53-412-00	53-412-00-01		GENERAL VISUAL	Aft Passenger Compartment, STA 663.75 to 1042
53-414-00	53-414-00	53-414-00-01 53-414-00-02		GENERAL VISUAL	Mid Emergency Exit Door Surround Structure
53-415-00	53-415-00	53-415-00-01 53-415-00-02		DETAILED	Mid Exit Structural Plug Surround
53-416-00	53-416-00	53-416-00-01 53-416-00-02		GENERAL VISUAL	Mid Emergency Exit Door
53-417-00	53-417-00	53-417-00-01 53-417-00-02		DETAILED	Mid Exit Structural Plug
53-418-00	53-418-00	53-418-00-01 53-418-00-02		GENERAL VISUAL	Mid Exit Structural Plug
53-419-00	53-419-00	53-419-00-01 53-419-00-02		GENERAL VISUAL	Mid Exit Structural Plug
53-420-00	53-420-00	53-420-00-01		GENERAL VISUAL	Area Aft of STA 1016 Bulkhead
53-422-00	53-422-00	53-422-00-01		GENERAL VISUAL	Area Aft of STA 1042 Bulkhead
53-430-00	53-430-00	53-430-00-01		GENERAL VISUAL	Stabilizer Torsion Box Compartment and APU Compartment
53-440-00	53-440-00	53-440-00-01		GENERAL VISUAL	STA 1156 Bulkhead
53-450-00	53-450-00	53-450-00-01		GENERAL VISUAL	Fuselage Skin Under Dorsal Fin
53-460-00	53-460-00	53-460-00-01		GENERAL VISUAL	Vertical Fin Front Spar Fitting
53-470-00	53-470-00	53-470-00-01		GENERAL VISUAL	Vertical Fin Front Spar Fitting
53-480-00	53-480-00	53-480-00-01		GENERAL VISUAL	Vertical Fin Rear Spar Fitting



**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
53-490-00	53-490-00	53-490-00-01		DETAILED	Main Deck Cargo Door Cutout Frames, Fittings, Pins, and Hinges
53-495-00	53-495-00	53-495-00-01		DETAILED	Main Deck Cargo Door Cutout Frames, Fittings, Pins, and Hinges
53-500-00	53-500-00	53-500-00-01		DETAILED	Main Deck Cargo Door Cutout and Surround Structure
53-505-00	53-505-00	53-505-00-01		DETAILED	Main Deck Cargo Door Cutout and Surround Structure
53-510-00	53-510-00	53-510-00-01		GENERAL VISUAL	Crown Skin Panel
53-510-10		53-510-10-01		DETAILED	KU Band Antenna Installation
53-520-00	53-520-00	53-520-00-01		DETAILED	Seat Track to Frame Attachment, Sta 540 to 727
53-530-00	53-530-00	53-530-00-01		GENERAL VISUAL	Crown Skin Panel, Sta 360 to 500H
53-600-00		53-600-00-01 53-600-00-02		SPECIAL DETAILED	Longitudinal Lap Splice
53-600-01		53-600-01-01 53-600-01-02		SPECIAL DETAILED	Longitudinal Lap Splice
53-600-20		53-600-20-01 53-600-20-02		SPECIAL DETAILED	Longitudinal Lap Splice
53-600-21		53-600-21-01 53-600-21-02		SPECIAL DETAILED	Longitudinal Lap Splice
53-600-30		53-600-30-01 53-600-30-02		SPECIAL DETAILED	Longitudinal Lap Splice
53-600-40		53-600-40-01 53-600-40-02		SPECIAL DETAILED	Longitudinal Lap Splice
53-600-41		53-600-41-01 53-600-41-02		GENERAL VISUAL	Longitudinal Lap Splice
53-600-50		53-600-50-01 53-600-50-02		SPECIAL DETAILED	Longitudinal Lap Splice
53-601-00		53-601-00-01		SPECIAL DETAILED	Cutout - Crew Cab Windows



**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
53-601-01		53-601-01-01		SPECIAL DETAILED	Cutout - Crew Cab Windows
53-601-20		53-601-20-01 53-601-20-02		DETAILED	Cutout - Crew Cab Windows
53-601-21		53-601-21-01 53-601-21-02		DETAILED	Cutout - Crew Cab Windows
53-601-30		53-601-30-01 53-601-30-02		DETAILED	Cutout - Crew Cab Windows
53-601-40		53-601-40-01 53-601-40-02		SPECIAL DETAILED	Cutout - Crew Cabin Windows
53-601-41		53-601-41-01 53-601-41-02		SPECIAL DETAILED	Cutout - Crew Cabin Windows
53-601-50		53-601-50-01 53-601-50-02		SPECIAL DETAILED	Cutout - Crew Cabin Windows
53-601-60		53-601-60-01 53-601-60-02		SPECIAL DETAILED	Cutout - Crew Cabin Windows
53-602-10		53-602-10-01 53-602-10-02		SPECIAL DETAILED	Crown Skin Panel - FWD of STA 259.5
53-602-20		53-602-20-01		DETAILED	Crown Skin Panel - STA 259.5 to 360
53-603-10		53-603-10-01		SPECIAL DETAILED	Cutout - Forward Access Door, Forward Edge of Cutout
53-605-10		53-605-10-01		DETAILED	Cutout - Electronic Equipment Door
53-606-40		53-606-40-01		SPECIAL DETAILED	Cutout - Forward Entry Door Frame
53-606-50		53-606-50-01		SPECIAL DETAILED	Cutout - Forward Entry Door Frame
53-606-70		53-606-70-01		DETAILED	FWD Entry Door, FWD Edge Frame Stops
53-618-00		53-618-00-01		SPECIAL DETAILED	FWD Entry Door FWD Edge Frame Stops



# 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

## TASKS SORTED BY MPD ITEM NUMBER

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
53-619-00		53-619-00-01		SPECIAL DETAILED	FWD Entry Door, FWD Edge Frame Stops
53-620-00		53-620-00-01		DETAILED	FWD Entry Door, AFT Edge Frame Stops
53-621-00		53-621-00-01		DETAILED	FWD Entry Door, AFT Edge Frame Stops
53-622-00		53-622-00-01		SPECIAL DETAILED	FWD Entry Door Cutout
53-623-00		53-623-00-01		SPECIAL DETAILED	FWD Galley Door Cutout
53-624-00		53-624-00-01		SPECIAL DETAILED	Forward Galley Door Surround Structure, Door Stop Backup Structure
53-625-00		53-625-00-01		SPECIAL DETAILED	Cutout - FWD Galley Door
53-626-00		53-626-00-01 53-626-00-02		SPECIAL DETAILED	Bulkhead, STA 294.5
53-627-00		53-627-00-01 53-627-00-02		DETAILED	Nose Wheel Well Side and Top Panels
53-628-00		53-628-00-01 53-628-00-02		DETAILED	Nose Landing Gear Support Fittings
53-629-00		53-629-00-01 53-629-00-02		DETAILED	Nose Landing Gear Trunnion Support Fittings
53-630-00		53-630-00-01		DETAILED	Air Stair Door Cutout
53-630-01		53-630-01-01		GENERAL VISUAL	Air Stair Door Cutout
53-631-00		53-631-00-01		SPECIAL DETAILED	Air Stair Door Cutout
53-631-01		53-631-01-01		GENERAL VISUAL	Air Stair Door Cutout
53-632-00		53-632-00-01		SPECIAL DETAILED	Forward Nose Wheel Well Cutout Outer Chord



**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
53-633-00		53-633-00-01		DETAILED	Crown Skin Panel, STA 360 to 540
53-634-00		53-634-00-01		DETAILED	Crown Skin Panel, STA 360 to 540
53-634-10		53-634-10-01		SPECIAL DETAILED	Crown Skin Panel, STA 360 to 540
53-635-00		53-635-00-01 53-635-00-02		DETAILED	SATCOM AERO - H Antenna Installation
53-636-00		53-636-00-01 53-636-00-02		GENERAL VISUAL	Fuselage Side Skin Panels
53-636-10		53-636-10-01 53-636-10-02		DETAILED	Fuselage Side Skin Panels Under the Wing-to-Body Fairing
53-636-20		53-636-20-01 53-636-20-02		SPECIAL DETAILED	Fuselage Skin Under the Upper Wing-to-Body Drag Angle
53-637-00		53-637-00-01 53-637-00-02		SPECIAL DETAILED	Longitudinal Lap Splice
53-637-10		53-637-10-01 53-637-10-02		SPECIAL DETAILED	Longitudinal Lap Splice
53-638-00		53-638-00-01 53-638-00-02		SPECIAL DETAILED	Longitudinal Lap Splice
53-638-10		53-638-10-01 53-638-10-02		SPECIAL DETAILED	Longitudinal Lap Splice
53-639-00		53-639-00-01 53-639-00-02		SPECIAL DETAILED	Longitudinal Skin Splice
53-639-10		53-639-10-02		SPECIAL DETAILED	Longitudinal Skin Splice
53-640-00		53-640-00-01 53-640-00-02		DETAILED	Longitudinal Lap Splice
53-640-10		53-640-10-01		DETAILED	Longitudinal Lap Splice
53-641-00		53-641-00-01 53-641-00-02		DETAILED	Longitudinal Lap Splice



**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
53-641-10		53-641-10-01 53-641-10-02		DETAILED	Longitudinal Lap Splice
53-642-00		53-642-00-01 53-642-00-02		SPECIAL DETAILED	Longitudinal Lap Splice
53-642-10		53-642-10-01 53-642-10-02		SPECIAL DETAILED	Longitudinal Lap Splice
53-643-00		53-643-00-01 53-643-00-02		SPECIAL DETAILED	Longitudinal Lap Splice
53-644-00		53-644-00-01 53-644-00-02		DETAILED	Longitudinal Lap Splice
53-645-00		53-645-00-01 53-645-00-02		DETAILED	Window Belt STA 360 to 540
53-645-01		53-645-01-01 53-645-01-02		DETAILED	Window Belt STA 360 to STA 540
53-646-00		53-646-00-01		SPECIAL DETAILED	Forward Cargo Door Surround Structure
53-646-10		53-646-10-01		SPECIAL DETAILED	Forward Cargo Door Surround, Forward and Aft Edge Frames at STA 440 and 492.4
53-646-20		53-646-20-01		SPECIAL DETAILED	Forward Cargo Door Surround, Forward and Aft Edge Frames at STA 440 and 492.4
53-646-30		53-646-30-01		SPECIAL DETAILED	Forward Cargo Door Surround
53-646-40		53-646-40-01		SPECIAL DETAILED	Forward Cargo Door Surround Structure
53-646-50		53-646-50-01		SPECIAL DETAILED	Forward Cargo Door Surround Structure
53-646-60		53-646-60-01		SPECIAL DETAILED	Forward Cargo Door Surround Structure
53-646-61		53-646-61-01		SPECIAL DETAILED	Forward Cargo Door Surround Structure





**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
53-646-62		53-646-62-01		DETAILED	Forward Cargo Door Surround Structure
53-646-63		53-646-63-01		GENERAL VISUAL	Forward Cargo Door Surround Structure
53-646-70		53-646-70-01		SPECIAL DETAILED	Forward Cargo Door Surround Structure
53-646-71		53-646-71-01		SPECIAL DETAILED	Forward Cargo Door Surround Structure
53-646-75		53-646-75-01		DETAILED	Forward Cargo Door Surround Structure
53-646-80		53-646-80-01		SPECIAL DETAILED	Forward Cargo Door Surround Structure
53-647-00		53-647-00-01		SPECIAL DETAILED	Forward Cargo Door Fittings and Stops at the Forward and Aft Edge Frames
53-648-00		53-648-00-01 53-648-00-02		SPECIAL DETAILED	Wing to Body Lower Drag Angle
53-649-00		53-649-00-01 53-649-00-02		SPECIAL DETAILED	Wing to Body Upper Drag Angle
53-649-01		53-649-01-01 53-649-01-02		SPECIAL DETAILED	Wing to Body Upper Drag Angle
53-650-00		53-650-00-01 53-650-00-02		SPECIAL DETAILED	Wing to Body Upper Drag Angle
53-651-00		53-651-00-01 53-651-00-02		SPECIAL DETAILED	Floor Beam to Frame Joint
53-652-00		53-652-00-01		DETAILED	Crown Skin Panel - STA 540 to 727
53-653-00		53-653-00-01 53-653-00-02		SPECIAL DETAILED	Longitudinal Lap Splice
53-653-10		53-653-10-01 53-653-10-02		SPECIAL DETAILED	Longitudinal Lap Splice
53-654-00		53-654-00-01 53-654-00-02		SPECIAL DETAILED	Longitudinal Lap Splice



**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
53-654-10		53-654-10-01 53-654-10-02		SPECIAL DETAILED	Longitudinal Lap Splice
53-655-00		53-655-00-01 53-655-00-02		SPECIAL DETAILED	Longitudinal Skin Splice
53-655-10		53-655-10-01 53-655-10-02		SPECIAL DETAILED	Longitudinal Skin Splice
53-656-00		53-656-00-01 53-656-00-02		DETAILED	Window Belt, STA 540 to 727
53-657-00		53-657-00-01 53-657-00-02		DETAILED	Window Belt, STA 540 to 727
53-658-00		53-658-00-01 53-658-00-02		DETAILED	Stringer Splice, STA 663
53-659-00		53-659-00-01 53-659-00-02		DETAILED	Keel Beam Chords, Stiffeners and Splice
53-660-00		53-660-00-01 53-660-00-02		SPECIAL DETAILED	Stiffener Attachment to Floor Beam, STA 727
53-661-00		53-661-00-01 53-661-00-02		SPECIAL DETAILED	Stringer 18 Strap Side of Body
53-662-00		53-662-00-01 53-662-00-02		SPECIAL DETAILED	Stringer 18A Chord and Links
53-663-00		53-663-00-01 53-663-00-02		SPECIAL DETAILED	Frame Splice at STA 540
53-664-00		53-664-00-01		DETAILED	BS 540 Bulkhead
53-665-00		53-665-00-01 53-665-00-02		DETAILED	BS 663 Bulkhead
53-666-00		53-666-00-01 53-666-00-02		SPECIAL DETAILED	BS 663 Bulkhead
53-667-00		53-667-00-01 53-667-00-02		SPECIAL DETAILED	Aft Wheel Well Bulkhead STA 727



**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
53-667-10		53-667-10-01 53-667-10-02		SPECIAL DETAILED	Aft Wheel Well Bulkhead STA 727
53-668-00		53-668-00-01 53-668-00-02		SPECIAL DETAILED	Wheel Well Aft Bulkhead
53-668-10		53-668-10-01 53-668-10-02		SPECIAL DETAILED	Wheel Well Aft Bulkhead
53-669-00		53-669-00-01 53-669-00-02		SPECIAL DETAILED	Wheel Well Aft Bulkhead and Pressure Web STA 727
53-670-00		53-670-00-01		DETAILED	Aft Wheel Well Bulkhead and Pressure Web, STA 727
53-671-00		53-671-00-01 53-671-00-02		SPECIAL DETAILED	Aft Wheel Well Bulkhead Frame STA 727
53-672-00		53-672-00-01 53-672-00-02		SPECIAL DETAILED	Side Strut Support Frame STA 706
53-673-00		53-673-00-01 53-673-00-02		GENERAL VISUAL	Main Landing Gear Support Frame, STA 695
53-674-00		53-674-00-01 53-674-00-02		SPECIAL DETAILED	Main Landing Gear Support Frame STA 716
53-675-00		53-675-00-01 53-675-00-02		SPECIAL DETAILED	Main Landing Gear Support Frame STA 716
53-676-00		53-676-00-01 53-676-00-02		SPECIAL DETAILED	Main Landing Gear Support Frame STA 716
53-676-10		53-676-10-01 53-676-10-02		SPECIAL DETAILED	Main Landing Gear Support Frame STA 716
53-677-00		53-677-00-01 53-677-00-02		DETAILED	Wheel Well Frame, STA 685
53-678-00		53-678-00-01 53-678-00-02		SPECIAL DETAILED	Wheel Well Frame STA 685
53-679-00		53-679-00-01 53-679-00-02		SPECIAL DETAILED	Wheel Well Frame At STA 685



**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
53-680-00		53-680-00-01 53-680-00-02		SPECIAL DETAILED	Overwing Emergency Exit Cutout
53-681-00		53-681-00-01 53-681-00-02		SPECIAL DETAILED	Overwing Emergency Exit Cutout
53-681-01		53-681-01-01 53-681-01-02		SPECIAL DETAILED	Overwing Emergency Exit Cutout
53-681-02		53-681-02-01 53-681-02-02		SPECIAL DETAILED	Overwing Emergency Exit Cutout
53-682-00		53-682-00-01 53-682-00-02		SPECIAL DETAILED	Overwing Emergency Exit Cutout Skin Assembly & Frame Outer Chord
53-682-01		53-682-01-01 53-682-01-02		SPECIAL DETAILED	Overwing Emergency Exit Cutout Skin Assembly & Frame Outer Chord
53-682-03		53-682-03-01 53-682-03-02		SPECIAL DETAILED	Overwing Emergency Exit Cutout Skin Assembly & Frame Outer Chord
53-683-00		53-683-00-01 53-683-00-02		SPECIAL DETAILED	Overwing Emergency Exit Cutout
53-684-00		53-684-00-01 53-684-00-02		SPECIAL DETAILED	Overwing Emergency Exit Cutout
53-684-01		53-684-01-01 53-684-01-02		SPECIAL DETAILED	Overwing Emergency Exit Cutout
53-684-02		53-684-02-01 53-684-02-02		SPECIAL DETAILED	Overwing Emergency Exit Cutout
53-685-00		53-685-00-01 53-685-00-02		SPECIAL DETAILED	Overwing Emergency Exit Cutout - Door Cutout Corners
53-685-01		53-685-01-01 53-685-01-02		SPECIAL DETAILED	Overwing Emergency Exit Cutout - Door Cutout Corners
53-686-00		53-686-00-01 53-686-00-02		SPECIAL DETAILED	Overwing Emergency Exit Cutout



**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
53-687-00		53-687-00-01 53-687-00-02		SPECIAL DETAILED	Overwing Emergency Exit Cutout
53-687-10		53-687-10-01 53-687-10-02		SPECIAL DETAILED	Overwing Emergency Exit Cutout
53-688-00		53-688-00-01 53-688-00-02		SPECIAL DETAILED	Overwing Emergency Exit Cutout
53-689-00		53-689-00-01 53-689-00-02		SPECIAL DETAILED	Overwing Emergency Exit Cutout Skin and Frame Assembly Section at STA 616 and Stringer S-13
53-690-00		53-690-00-01 53-690-00-02		SPECIAL DETAILED	Overwing Emergency Exit Cutout Skin Assembly and Frame Outer Chord
53-691-00		53-691-00-01 53-691-00-02		DETAILED	Overwing Emergency Exit Cutout
53-692-00		53-692-00-01 53-692-00-02		GENERAL VISUAL	Overwing Emergency Exit Cutout
53-693-00		53-693-00-01 53-693-00-02		SPECIAL DETAILED	Overwing Emergency Exit Cutout Structure
53-693-01		53-693-01-01 53-693-01-02		SPECIAL DETAILED	Overwing Emergency Exit Cutout Structure
53-694-00		53-694-00-01 53-694-00-02		SPECIAL DETAILED	Overwing Emergency Exit Cutout Structure
53-695-00		53-695-00-01 53-695-00-02		DETAILED	Overwing Emergency Exit Door Stops and Fittings
53-696-00		53-696-00-01 53-696-00-02		DETAILED	Overwing Emergency Exit Door Stops and Fittings
53-697-00		53-697-00-01 53-697-00-02		SPECIAL DETAILED	Overwing Exit Door Stops and Fittings
53-697-10		53-697-10-01		GENERAL VISUAL	Pressure Deck Attachments to Rear Spar Extension
53-698-00		53-698-00-01		DETAILED	Crown Skin Panel - STA 727 to 887



# 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

## TASKS SORTED BY MPD ITEM NUMBER

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
53-699-00		53-699-00-01		DETAILED	Crown Skin Panel STA 727 to 887
53-700-00		53-700-00-01		SPECIAL DETAILED	SATCOM Antenna Installation (Canadian Marconi and Honeywell)
53-701-00		53-701-00-01		DETAILED	SATCOM Antenna Installation (Canadian Marconi and Honeywell)
53-702-00		53-702-00-01		SPECIAL DETAILED	SATCOM Antenna Installation (All except those covered by PSE 53-60-01-5)
53-702-01		53-702-01-01		DETAILED	SATCOM Antenna Installation (All except those covered by PSE 53-60-01-5)
53-703-00		53-703-00-01 53-703-00-02		GENERAL VISUAL	Fuselage Side Skin Panels
53-703-10		53-703-10-01 53-703-10-02		DETAILED	Fuselage Side Skin Panels Under the Wing-to-Body Fairing
53-704-00		53-704-00-01 53-704-00-02		SPECIAL DETAILED	Longitudinal Lap Splice
53-704-10		53-704-10-01 53-704-10-02		SPECIAL DETAILED	Longitudinal Lap Splice
53-705-00		53-705-00-01 53-705-00-02		SPECIAL DETAILED	Longitudinal Lap Splice
53-705-10		53-705-10-01 53-705-10-02		SPECIAL DETAILED	Longitudinal Lap Splice
53-706-00		53-706-00-01 53-706-00-02		SPECIAL DETAILED	Longitudinal Skin Splice
53-706-10		53-706-10-01 53-706-10-02		SPECIAL DETAILED	Longitudinal Skin Splice
53-707-00		53-707-00-01 53-707-00-02		DETAILED	Longitudinal Lap Splice
53-707-10		53-707-10-01 53-707-10-02		DETAILED	Longitudinal Lap Splice
53-708-00		53-708-00-01 53-708-00-02		DETAILED	Longitudinal Lap Splice



**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
53-708-10		53-708-10-01 53-708-10-02		DETAILED	Longitudinal Lap Splice
53-709-00		53-709-00-01 53-709-00-02		SPECIAL DETAILED	Longitudinal Lap Splice
53-709-10		53-709-10-01 53-709-10-02		SPECIAL DETAILED	Longitudinal Lap Splice
53-710-00		53-710-00-01 53-710-00-02		SPECIAL DETAILED	Longitudinal Lap Splice
53-711-00		53-711-00-01 53-711-00-02		DETAILED	Window Belt STA 727 to 888
53-711-01		53-711-01-01 53-711-01-02		DETAILED	Window Belt STA 727 to 888
53-712-00		53-712-00-01		SPECIAL DETAILED	Aft Cargo Door Surround Structure
53-713-00		53-713-00-01		SPECIAL DETAILED	Aft Cargo Door Surround Structure
53-713-01		53-713-01-01		SPECIAL DETAILED	Aft Cargo Door Surround Structure
53-714-00		53-714-00-01		SPECIAL DETAILED	Aft Cargo Door Surround Structure
53-714-01		53-714-01-01		SPECIAL DETAILED	Aft Cargo Door Surround Structure
53-715-00		53-715-00-01		SPECIAL DETAILED	Aft Cargo Door Surround Structure
53-716-00		53-716-00-01		SPECIAL DETAILED	Aft Cargo Door Surround Structure
53-717-00		53-717-00-01		SPECIAL DETAILED	Aft Cargo Door Surround Structure
53-718-00		53-718-00-01		SPECIAL DETAILED	Aft Cargo Door Surround Forward and Aft Edge Frames at BS 794.37 and 847



# 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

## TASKS SORTED BY MPD ITEM NUMBER

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
53-719-00		53-719-00-01		SPECIAL DETAILED	Aft Cargo Door Surround Forward and Aft Edge Frames at BS 794.37 and 847
53-720-00		53-720-00-01		SPECIAL DETAILED	Aft Cargo Door Surround Structure
53-721-00		53-721-00-01		DETAILED	Aft Cargo Door Surround Structure
53-721-10		53-721-10-01		GENERAL VISUAL	Aft Cargo Door Surround Structure
53-721-20		53-721-20-01		DETAILED	Aft Cargo Door Surround Structure
53-722-00		53-722-00-01		SPECIAL DETAILED	Aft Cargo Door Fittings and Stops at the Forward and Aft Edge Frames
53-722-10		53-722-10-01 53-722-10-02		DETAILED	Mid Exit Door Surround Structure
53-722-15		53-722-15-01 53-722-15-02		DETAILED	Mid Exit Door Surround Structure
53-723-00		53-723-00-01 53-723-00-02		SPECIAL DETAILED	Longitudinal Lap Splice
53-723-10		53-723-10-01 53-723-10-02		SPECIAL DETAILED	Longitudinal Lap Splice
53-724-00		53-724-00-01 53-724-00-02		SPECIAL DETAILED	Longitudinal Lap Splice
53-725-00		53-725-00-01 53-725-00-02		DETAILED	Longitudinal Lap Splice
53-726-00		53-726-00-01 53-726-00-02		SPECIAL DETAILED	Longitudinal Lap Splice
53-727-00		53-727-00-01		DETAILED	Crown Skin Panel - STA 887 to 1016
53-728-00		53-728-00-01		SPECIAL DETAILED	Aft Entry Door, Forward Edge Frame Door Stop Backup Structure
53-729-00		53-729-00-01		SPECIAL DETAILED	Aft Entry Door, Aft Edge Frame Door Stop Backup Intercostals





# 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

## TASKS SORTED BY MPD ITEM NUMBER

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
53-729-01		53-729-01-01		GENERAL VISUAL	Aft Entry Door, Aft Edge Frame Door Stop Backup Intercostals
53-730-00		53-730-00-01		DETAILED	Cutout, Aft Entry Door Surround Structure
53-731-00		53-731-00-01		DETAILED	Aft Entry Door Surround Structure
53-731-01		53-731-01-01		SPECIAL DETAILED	Aft Entry Door Surround Structure
53-732-00		53-732-00-01		DETAILED	Aft Entry Door Surround Structure
53-732-01		53-732-01-01		DETAILED	Aft Entry Door Surround Structure
53-732-10		53-732-10-01		SPECIAL DETAILED	Aft Entry Door Surround Structure
53-733-00		53-733-00-01		DETAILED	Aft Galley Door Surround Structure
53-733-01		53-733-01-01		DETAILED	Aft Galley Door Surround Structure
53-734-00		53-734-00-01		SPECIAL DETAILED	Aft Galley Door Forward Edge Frame Door Stop Backup Structure
53-734-01		53-734-01-01		SPECIAL DETAILED	Aft Galley Door Forward Edge Frame Door Stop Backup Structure
53-735-00		53-735-00-01		SPECIAL DETAILED	Aft Galley Door Aft Edge Frame Door Stop Backup Intercostals
53-735-01		53-735-01-01		GENERAL VISUAL	Aft Galley Door Aft Edge Frame Door Stop Backup Intercostals
53-736-00		53-736-00-01		DETAILED	Cutout, Aft Galley Door Surround Structure
53-737-00		53-737-00-01		DETAILED	Aft Galley Door Surround Structure
53-737-01		53-737-01-01		SPECIAL DETAILED	Aft Galley Door Surround Structure
53-737-10		53-737-10-01		SPECIAL DETAILED	Aft Galley Door Surround Structure
53-738-00		53-738-00-01 53-738-00-02		DETAILED	Window Belt STA 888 to 927



**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
53-738-01		53-738-01-01 53-738-01-02		DETAILED	Window Belt STA 888 to 927
53-739-00		53-739-00-01		DETAILED	Bulkhead STA 1016
53-740-00		53-740-00-01		DETAILED	Bulkhead STA 1016
53-741-00		53-741-00-01		SPECIAL DETAILED	Bulkhead STA 1016
53-742-00		53-742-00-01		SPECIAL DETAILED	Bulkhead STA 1016
53-743-00		53-743-00-01		SPECIAL DETAILED	Bulkhead STA 1016
53-743-01		53-743-01-01		SPECIAL DETAILED	Bulkhead STA 1016
53-744-00		53-744-00-01		SPECIAL DETAILED	Bulkhead STA 1016
53-745-00		53-745-00-01		SPECIAL DETAILED	Bulkhead STA 1016
53-746-00		53-746-00-01		SPECIAL DETAILED	Bulkhead STA 1016
53-747-00		53-747-00-01		SPECIAL DETAILED	Bulkhead STA 1016
53-747-10		53-747-10-01		SPECIAL DETAILED	Bulkhead STA 1016
53-748-00		53-748-00-01		SPECIAL DETAILED	Bulkhead STA 1016
53-749-00		53-749-00-01		SPECIAL DETAILED	Bulkhead STA 1016
53-749-10		53-749-10-01		DETAILED	Bulkhead STA 1016
53-750-00		53-750-00-01		DETAILED	Vertical Fin Front Spar Fitting Bulkhead Attachment - STA 1016



# 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

## TASKS SORTED BY MPD ITEM NUMBER

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
53-750-10		53-750-10-01		SPECIAL DETAILED	Vertical Fin Front Spar Fitting Bulkhead Attachment - STA 1016
53-751-00		53-751-00-01		SPECIAL DETAILED	Vertical Fin Front Spar Fitting - STA 1016
53-752-00		53-752-00-01		SPECIAL DETAILED	Stringer Splice Fittings
53-753-00		53-753-00-01		SPECIAL DETAILED	Jackscrew Fitting Lugs
53-754-00		53-754-00-01		SPECIAL DETAILED	Vertical Fin Rear Spar Attachment Fittings
53-755-00		53-755-00-01		DETAILED	Vertical Fin Rear Spar Attachment Fittings
53-756-00		53-756-00-01		SPECIAL DETAILED	Bulkhead Station 1156
53-757-00		53-757-00-01		SPECIAL DETAILED	Integrated Bulkhead STA 1156
53-758-00		53-758-00-01 53-758-00-02		SPECIAL DETAILED	Horizontal Stabilizer Pivot Fitting
53-759-00		53-759-00-01 53-759-00-02		SPECIAL DETAILED	Horizontal Stabilizer Pivot Pins
53-760-00		53-760-00-01 53-760-00-02		DETAILED	Section 48 Skin Panels, STA 1088 to 1156
53-761-00		53-761-00-01		DETAILED	STA 1042 Bulkhead Straps
53-762-00		53-762-00-01		DETAILED	STA 1042 Bulkhead Intercostals
53-763-00		53-763-00-01		DETAILED	STA 1042 Bulkhead Lugs, Links and Fittings Bulkhead Lugs
53-764-00		53-764-00-01		SPECIAL DETAILED	STA 1042 Bulkhead Lugs, Links and Fittings End Beam Lugs
53-765-00		53-765-00-01		SPECIAL DETAILED	STA 1042 Bulkhead Lugs, Links and Fittings End Beam Lug Attachment at Diagonal Beam
53-766-00		53-766-00-01		DETAILED	STA 1042 Bulkhead Link Fittings



**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
53-767-00		53-767-00-01		DETAILED	STA 1042 Bulkhead Lugs, Links and Fittings Link Attach Fittings
53-768-00		53-768-00-01		DETAILED	STA 1042 Bulkhead Chord Splice
53-769-00		53-769-00-01		SPECIAL DETAILED	APU Inlet Cutout Enclosure Forward Panel
53-770-00		53-770-00-01		DETAILED	APU Inlet Enclosure Installation - Pressure Panels
53-771-00		53-771-00-01		SPECIAL DETAILED	APU Inlet Enclosure Installation Pressure Panels
53-772-00		53-772-00-01		SPECIAL DETAILED	APU Enclosure Installation Pressure Panels
53-773-00		53-773-00-01		SPECIAL DETAILED	APU Enclosure Installation Pressure Panels
53-774-00		53-774-00-01		SPECIAL DETAILED	APU Inlet Enclosure Installation - Pressure Panels
53-775-00		53-775-00-01		SPECIAL DETAILED	APU Enclosure Installation
53-776-00		53-776-00-01 53-776-00-02		SPECIAL DETAILED	Section 48 Longitudinal Lap Splices S-4 Lap Splice, STA 1016 to 1042
53-777-00		53-777-00-01 53-777-00-02		SPECIAL DETAILED	Section 48 Longitudinal Lap Splices S-4 Lap Splice, STA 1016 to 1042
53-778-00		53-778-00-01 53-778-00-02		SPECIAL DETAILED	Section 48 Longitudinal Lap Splices S-24 Lap Splice, STA 1016 to 1042
53-779-00		53-779-00-01 53-779-00-02		SPECIAL DETAILED	Section 48 Butt Splice at S-9R and S-9L BS 1016 - BS 1042
53-780-00		53-780-00-01 53-780-00-02		SPECIAL DETAILED	Section 48 Butt Splice at S-9R and 9L BS 1016 - BS 1042
53-781-00		53-781-00-01 53-781-00-02		SPECIAL DETAILED	Section 48 Butt Splice at S-9R and S-9L BS 1016 - BS 1042
53-782-00		53-782-00-01		DETAILED	Side Skin Panel, STA 1016 to 1042 S-9R to S-16R - APU Inlet Cutout



## 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

### TASKS SORTED BY MPD ITEM NUMBER

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
53-790-00		53-790-00-01 53-790-00-02		GENERAL VISUAL	Section 48 Longitudinal Lap Splices S-24 Lap Splice, STA 1016 to 1042
53-791-00		53-791-00-01		DETAILED	Crown Skin Panel - STA 540 to 727
53-800-00	53-800-00	53-800-00-01		ZONAL (GV)	Lower Fuselage
53-802-00	53-802-00	53-802-00-01		ZONAL (GV)	Radome
53-804-00	53-804-00	53-804-00-01		ZONAL (GV)	Area Forward of Nose Wheel Well
53-806-00	53-806-00	53-806-00-01		ZONAL (GV)	Area Above and Outboard of Nose Wheel Well
53-808-00	53-808-00	53-808-00-01		ZONAL (GV)	Electrical and Electronics Compartment
53-810-00	53-810-00	53-810-00-01		ZONAL (GV)	Electrical and Electronics Compartment Access Door
53-812-00	53-812-00	53-812-00-01		ZONAL (GV)	Forward Cargo Compartment
53-814-00	53-814-00	53-814-00-01		ZONAL (GV)	Forward Cargo Compartment
53-816-00	53-816-00	53-816-00-01		ZONAL (GV)	Forward Cargo Compartment
53-818-00	53-818-00	53-818-00-01		ZONAL (GV)	Forward Cargo Door Surround Structure Fittings and Stops
53-820-00	53-820-00	53-820-00-01		ZONAL (GV)	Area Below Forward Cargo Compartment
53-822-00	53-822-00	53-822-00-01		ZONAL (GV)	Air Conditioning Distribution Bay
53-824-01	53-824-01	53-824-01-01		ZONAL (GV)	Area Above Center Section Wing Box
53-826-00	53-826-00	53-826-00-01		ZONAL (GV)	Pressure Deck Above Main Landing Gear Wheel Well
53-828-00	53-828-00	53-828-00-01		ZONAL (GV)	Keel Beam (Part) Sta 540 to 727
53-830-00	53-830-00	53-830-00-01		ZONAL (GV)	Aft Cargo Compartment
53-832-00	53-832-00	53-832-00-01		ZONAL (GV)	Aft Cargo Compartment
53-834-00	53-834-00	53-834-00-01		ZONAL (GV)	Aft Cargo Compartment
53-836-00	53-836-00	53-836-00-01		ZONAL (GV)	Aft Cargo Door Surround Structure Fittings and Stops
53-838-00	53-838-00	53-838-00-01		ZONAL (GV)	Aft Cargo Compartment Vacuum Waste Compartment
53-840-00	53-840-00	53-840-00-01		ZONAL (GV)	Area Below Aft Cargo Compartment



**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
53-842-00	53-842-00	53-842-00-01		ZONAL (GV)	Aft Cargo Compartment Equipment Bay
53-844-00	53-844-00	53-844-00-01		ZONAL (GV)	Wing to Body Fairing
53-846-00	53-846-00	53-846-00-01		ZONAL (GV)	Lower Wing to Body Fairing - Forward of Wing Box
53-848-00	53-848-00	53-848-00-01		ZONAL (GV)	Lower Wing to Body Fairing - Under Wing Box
53-850-00	53-850-00	53-850-00-01		ZONAL (GV)	Lower Wing to Body Fairing - Aft of Wheel Well
53-852-00	53-852-00	53-852-00-01		ZONAL (GV)	Lower Wing to Body Fairing - Aft of Wheel Well
53-854-02	53-854-02	53-854-02-01		ZONAL (GV)	Above Wing, Wing to Body Fairing - Right
53-856-01	53-856-01	53-856-01-01		ZONAL (GV)	Above Wing, Wing to Body Fairing - Left
53-858-00	53-858-00	53-858-00-01		ZONAL (GV)	Flight Control Compartment
53-860-00	53-860-00	53-860-00-01		ZONAL (GV)	Flight Control Compartment
53-862-00	53-862-00	53-862-00-01		ZONAL (GV)	Flight Control Compartment
53-864-00	53-864-00	53-864-00-01		ZONAL (GV)	Passenger Compartment - Aft of Control Compartment to Fwd Entry Door
53-866-00	53-866-00	53-866-00-01		ZONAL (GV)	Passenger Compartment - Section 41, STA 270 to STA 360
53-868-00	53-868-00	53-868-00-01		ZONAL (GV)	Passenger Compartment - Aft of Control Compartment to Fwd Entry Door
53-870-00	53-870-00	53-870-00-01		ZONAL (GV)	Forward Passenger Entry Door Stops, Latches and Hinges
53-872-00	53-872-00	53-872-00-01		ZONAL (GV)	Forward Galley Service Door Stops, Latches, and Hinges
53-874-00	53-874-00	53-874-00-01		ZONAL (GV)	Forward Passenger Compartment - Sta 360 to Sta 663.75
53-876-00	53-876-00	53-876-00-01		ZONAL (GV)	Forward Passenger Compartment - Sta 360 to Sta 663.75
53-878-00	53-878-00	53-878-00-01		ZONAL (GV)	Forward Passenger Compartment - Sta 360 to Sta 663.75 Wet Areas
53-880-00	53-880-00	53-880-00-01		ZONAL (GV)	Forward Passenger Compartment - Sta 360 to Sta 663.75 Dry Areas
53-882-00	53-882-00	53-882-00-01 53-882-00-02		ZONAL (GV)	Aft Passenger Compartment - Sta 663.75 to Aft Pressure Bulkhead
53-884-00	53-884-00	53-884-00-01 53-884-00-02		ZONAL (GV)	Aft Passenger Compartment - STA 663.75 to Aft Pressure Bulkhead



# 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

## TASKS SORTED BY MPD ITEM NUMBER

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
53-886-00	53-886-00	53-886-00-01 53-886-00-02	W-20-445-00-01	ZONAL (GV)	Aft Passenger Compartment - Sta 663.75 to Aft Pressure Bulkhead Wet Area
53-888-00	53-888-00	53-888-00-01 53-888-00-02	W-20-440-00-01	ZONAL (GV)	Aft Passenger Compartment - Sta 663.75 to Aft Pressure Bulkhead Dry Area
53-890-00	53-890-00	53-890-00-01		ZONAL (GV)	Aft Passenger Entry Door Stops, Latches, and Hinges
53-892-00	53-892-00	53-892-00-01		ZONAL (GV)	Aft Galley Service Door Stops, Latches, and Hinges
53-894-00	53-894-00	53-894-00-01 53-894-00-02		ZONAL (GV)	Area Aft of the Pressure Bulkhead
53-896-00	53-896-00	53-896-00-01 53-896-00-02		ZONAL (GV)	Area Aft of Pressure Bulkhead
53-898-00	53-898-00	53-898-00-01		ZONAL (GV)	Stabilizer Torsion Box Compartment
53-900-00	53-900-00	53-900-00-01		ZONAL (GV)	APU Compartment
53-902-00	53-902-00	53-902-00-01		ZONAL (GV)	Tail Cone
53-904-01	53-904-01	53-904-01-01		ZONAL (GV)	Flap Support No. 4 - Left Wing
53-906-02	53-906-02	53-906-02-01		ZONAL (GV)	Flap Support No. 5 - Right Wing
53-908-01	53-908-01	53-908-01-01		ZONAL (GV)	Main Deck Cargo Door Stops, Latches, Hinges and Fittings
53-910-00	53-910-00	53-910-00-01		ZONAL (GV)	Main Deck Cargo Compartment - Sta 360 to Sta 1016
53-914-00	53-914-00	53-914-00-01		ZONAL (GV)	Main Deck Cargo Compartment - Sta 360 to Sta 1016 Wet Areas
54-010-01	54-010-01	54-010-01-01		GENERAL VISUAL	Left Forward Engine Mount Assembly
54-010-02	54-010-02	54-010-02-01		GENERAL VISUAL	Right Forward Engine Mount Assembly
54-015-01	54-015-01	54-015-01-01		GENERAL VISUAL	Left Strut Attach Bolts at Forward Engine Mount
54-015-02	54-015-02	54-015-02-01		GENERAL VISUAL	Right Strut Attach Bolts at Forward Engine Mounts



# 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

## TASKS SORTED BY MPD ITEM NUMBER

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
54-020-01	54-020-01	54-020-01-01		GENERAL VISUAL	Left Strut Forward and Aft Engine Mount to Strut Shear Pins
54-020-02	54-020-02	54-020-02-01		GENERAL VISUAL	Right Strut Forward and Aft Engine Mount to Strut Shear Pins
54-030-01	54-030-01	54-030-01-01		GENERAL VISUAL	Left Strut Aft Engine Mount Assembly
54-030-02	54-030-02	54-030-02-01		GENERAL VISUAL	Right Strut Aft Engine Mount Assembly
54-040-01	54-040-01	54-040-01-01		GENERAL VISUAL	Left Strut to Wing Attachments
54-040-02	54-040-02	54-040-02-01		GENERAL VISUAL	Right Strut to Wing Attachments
54-050-01	54-050-01	54-050-01-01		DETAILED	Left Strut to Wing Attachments - Pins and Fuse Pins
54-050-02	54-050-02	54-050-02-01		DETAILED	Right Strut to Wing Attachments - Pins and Fuse Pins
54-060-01	54-060-01	54-060-01-01		DETAILED	Left Strut to Wing Attachments
54-060-02	54-060-02	54-060-02-01		DETAILED	Right Strut to Wing Attachments
54-070-01	54-070-01	54-070-01-01		GENERAL VISUAL	Left Strut Box
54-070-02	54-070-02	54-070-02-01		GENERAL VISUAL	Right Strut Box
54-080-01	54-080-01	54-080-01-01		GENERAL VISUAL	Left Strut Box
54-080-02	54-080-02	54-080-02-01		GENERAL VISUAL	Right Strut Box
54-090-01	54-090-01	54-090-01-01		FUNCTIONAL	Functional Check Left Engine Forward Strut and Aft Strut Fairing Drains
54-090-02	54-090-02	54-090-02-01		FUNCTIONAL	Functional Check Right Engine Forward Strut and Aft Strut Fairing Drains
54-600-00		54-600-00-01 54-600-00-02		GENERAL VISUAL	Strut to Wing Attachments





**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
54-610-00		54-610-00-01 54-610-00-02		SPECIAL DETAILED	Lower Spar Chord - Typical Exposed Detail
54-611-00		54-611-00-01 54-611-00-02		SPECIAL DETAILED	Lower Spar Chord at Fire Seal Depressor Bracket
54-611-01		54-611-01-01 54-611-01-02		SPECIAL DETAILED	Lower Spar Chord at Fire Seal Depressor Bracket
54-612-00		54-612-00-01 54-612-00-02		SPECIAL DETAILED	Lower Spar Chord - Bracket
54-613-00		54-613-00-01 54-613-00-02		SPECIAL DETAILED	Lower Spar Chord at Frames with Brackets
54-614-00		54-614-00-01 54-614-00-02		SPECIAL DETAILED	Lower Spar Chord (Direction 1)
54-614-01		54-614-01-01 54-614-01-02		SPECIAL DETAILED	Lower Spar Chord (Direction 2)
54-615-00		54-615-00-01 54-615-00-02		SPECIAL DETAILED	Lower Spar Chord, Web Only
54-616-00		54-616-00-01 54-616-00-02		SPECIAL DETAILED	Lower Spar Chord, Chord Only
54-617-00		54-617-00-01 54-617-00-02		SPECIAL DETAILED	Lower Spar Chord - Compression Pad Bracket, Horizontal Leg
54-617-01		54-617-01-01 54-617-01-02		SPECIAL DETAILED	Lower Spar Chord - Compression Pad Bracket, Horizontal Leg
54-618-00		54-618-00-01 54-618-00-02		SPECIAL DETAILED	Lower Spar Chord - Compression Pad Bracket, Vertical Leg
54-619-00		54-619-00-01 54-619-00-02		SPECIAL DETAILED	Lower Spar Chord - Typical Frame Detail, Vertical Leg (Direction 1)
54-619-01		54-619-01-01 54-619-01-02		SPECIAL DETAILED	Lower Spar Chord - Typical Frame Detail, Vertical Leg (Direction 2)



**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
54-620-00		54-620-00-01 54-620-00-02		SPECIAL DETAILED	Lower Spar Chord - Typical Frame Detail, Horizontal Leg
54-621-00		54-621-00-01 54-621-00-02		DETAILED	Lower Spar Chord
54-622-00		54-622-00-01 54-622-00-02		SPECIAL DETAILED	Forward Engine Mount Bulkhead
54-623-00		54-623-00-01 54-623-00-02		SPECIAL DETAILED	Mid Strut Bulkhead
54-624-00		54-624-00-01 54-624-00-02		SPECIAL DETAILED	Side Skin Cutouts
54-625-00		54-625-00-01 54-625-00-02		SPECIAL DETAILED	Strut Side Skin
54-626-00		54-626-00-01 54-626-00-02		SPECIAL DETAILED	Upper Spar Chord
54-627-00		54-627-00-01 54-627-00-02		SPECIAL DETAILED	Upper Spar Chord near Cutouts (Direction 1)
54-627-01		54-627-01-01 54-627-01-02		SPECIAL DETAILED	Upper Spar Chord near Cutouts (Direction 2)
54-628-00		54-628-00-01 54-628-00-02		SPECIAL DETAILED	Upper Spar, R1 - Fitting and Upper Spar Web Joints, Chord Only (Direction 1)
54-628-01		54-628-01-01 54-628-01-02		SPECIAL DETAILED	Upper Spar, R1 - Fitting and Upper Spar Web Joints, Chord Only (Direction 2)
54-629-00		54-629-00-01 54-629-00-02		SPECIAL DETAILED	Upper Spar, R1 - Fitting and Upper Spar Joints, Web Only
54-630-00		54-630-00-01 54-630-00-02		SPECIAL DETAILED	Upper and Lower Spar Chords
54-630-01		54-630-01-01 54-630-01-02		SPECIAL DETAILED	Upper and Lower Spar Chords



# 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

## TASKS SORTED BY MPD ITEM NUMBER

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
54-631-00		54-631-00-01 54-631-00-02		SPECIAL DETAILED	Upper Spar Chord
54-632-00		54-632-00-01 54-632-00-02		SPECIAL DETAILED	Upper Spar Chord
54-632-01		54-632-01-01 54-632-01-02		SPECIAL DETAILED	Upper Spar Chord
54-633-00		54-633-00-01 54-633-00-02		SPECIAL DETAILED	R3/R4 First Fastener Row - Vertical Leg
54-634-00		54-634-00-01 54-634-00-02		SPECIAL DETAILED	Forward Engine Mount Hanger
54-635-00		54-635-00-01 54-635-00-02		GENERAL VISUAL	Thrust Link Assembly
54-636-00		54-636-00-01 54-636-00-02		GENERAL VISUAL	Thrust Link Pin
54-637-00		54-637-00-01 54-637-00-02		SPECIAL DETAILED	Aft Engine Mount Assembly
54-638-00		54-638-00-01 54-638-00-02		GENERAL VISUAL	Evener Bar Assembly - Outboard Lugs
54-639-00		54-639-00-01 54-639-00-02		SPECIAL DETAILED	Aft Engine Mount Evener Bar - Mid Span
54-640-00		54-640-00-01 54-640-00-02		SPECIAL DETAILED	Strut Attach Bolts (Forward and Aft Mounts)
54-640-01		54-640-01-01 54-640-01-02		SPECIAL DETAILED	Strut Attach Bolts (Forward and Aft Mounts)
54-800-01	54-800-01	54-800-01-01		ZONAL (GV)	Forward Strut Fairing - Engine No. 1
54-802-01	54-802-01	54-802-01-01		ZONAL (GV)	Fan Cowl Support Beam - Engine No. 1
54-804-01	54-804-01	54-804-01-01		ZONAL (GV)	Strut Torque Box - Engine No. 1
54-806-01	54-806-01	54-806-01-01		ZONAL (GV)	Aft Strut Fairing - Engine No. 1



**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
54-808-02	54-808-02	54-808-02-01		ZONAL (GV)	Forward Strut Fairing - Engine No. 2
54-810-02	54-810-02	54-810-02-01		ZONAL (GV)	Fan Cowl Support Beam - Engine No. 2
54-812-02	54-812-02	54-812-02-01		ZONAL (GV)	Strut Torque Box - Engine No. 2
54-814-02	54-814-02	54-814-02-01		ZONAL (GV)	Aft Strut Fairing - Engine No. 2
55-010-00	55-010-00	55-010-00-01		GENERAL VISUAL	Horizontal Stabilizer Center Section
55-020-00	55-020-00	55-020-00-01		GENERAL VISUAL	Stabilizer Torsion Box Compartment
55-030-00	55-030-00	55-030-00-01		GENERAL VISUAL	Vertical Fin Leading Edge
55-050-00	55-050-00	55-050-00-01		GENERAL VISUAL	Vertical Fin
55-060-00	55-060-00	55-060-00-01		GENERAL VISUAL	Vertical Fin Trailing Edge
55-070-01	55-070-01	55-070-01-01		GENERAL VISUAL	Left Horizontal Stabilizer Leading Edge
55-070-02	55-070-02	55-070-02-01		GENERAL VISUAL	Right Horizontal Stabilizer Leading Edge
55-080-01	55-080-01	55-080-01-01		GENERAL VISUAL	Left Horizontal Stabilizer Leading Edge
55-080-02	55-080-02	55-080-02-01		GENERAL VISUAL	Right Horizontal Stabilizer Leading Edge
55-100-01	55-100-01	55-100-01-01		GENERAL VISUAL	Left Horizontal Stabilizer
55-100-02	55-100-02	55-100-02-01		GENERAL VISUAL	Right Horizontal Stabilizer
55-110-01	55-110-01	55-110-01-01		GENERAL VISUAL	Left Horizontal Stabilizer Trailing Edge and Elevator Tab Leading Edge



## 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

### TASKS SORTED BY MPD ITEM NUMBER

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
55-110-02	55-110-02	55-110-02-01		GENERAL VISUAL	Right Horizontal Stabilizer Trailing Edge and Elevator Tab Leading Edge
55-115-01	55-115-01	55-115-01-01		DETAILED	Left Elevator Tab Supt Ftgs on Front Spar and Tab Spar at Leading Edge
55-115-02	55-115-02	55-115-02-01		DETAILED	Right Elevator Tab Supt Ftgs on Front Spar and Tab Spar at Leading Edge
55-120-01	55-120-01	55-120-01-01		GENERAL VISUAL	Left Horizontal Stabilizer Trailing Edge
55-120-02	55-120-02	55-120-02-01		GENERAL VISUAL	Right Horizontal Stabilizer Trailing Edge
55-130-00	55-130-00	55-130-00-01		GENERAL VISUAL	Rudder, Elevator and Elevator Tab Attach Fittings
55-135-01	55-135-01	55-135-01-01		DETAILED	Left Elevator Hinge, Actuator, and Tab Mast Arm Ftgs and Balance Wt Suppt Struct.
55-135-02	55-135-02	55-135-02-01		DETAILED	Right Elevator Hinge, Actuator, and Tab Mast Arm Ftgs and Balance Wt Suppt Struct.
55-600-00		55-600-00-01 55-600-00-02		SPECIAL DETAILED	Horizontal Stabilizer Center Section Rear Spar Upper Chord
55-601-00		55-601-00-01 55-601-00-02		SPECIAL DETAILED	Horizontal Stabilizer Center Section Rear Spar Upper Chord
55-602-00		55-602-00-01 55-602-00-02		SPECIAL DETAILED	Horizontal Stabilizer Center Section Rear Spar Upper Chord
55-603-00		55-603-00-01 55-603-00-02		SPECIAL DETAILED	Horizontal Stabilizer Center Section Rear Spar Upper Chord
55-604-00		55-604-00-01 55-604-00-02		SPECIAL DETAILED	Horizontal Stabilizer Center Section Pivot Fitting
55-605-00		55-605-00-01 55-605-00-02		SPECIAL DETAILED	Horizontal Stabilizer Center Section Pivot Fitting
55-606-00		55-606-00-01 55-606-00-02		SPECIAL DETAILED	Horizontal Stabilizer Center Section Thrust Link Fittings



**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
55-607-00		55-607-00-01 55-607-00-02		SPECIAL DETAILED	Horizontal Stabilizer Center Section Jackscrew Fitting
55-608-00		55-608-00-01 55-608-00-02		SPECIAL DETAILED	Horizontal Stabilizer Rear Spar Lower Chord
55-609-00		55-609-00-01 55-609-00-02		SPECIAL DETAILED	Horizontal Stabilizer Rear Spar Lower Chord
55-610-00		55-610-00-01 55-610-00-02		SPECIAL DETAILED	Horizontal Stabilizer Rear Spar Lower Chord
55-611-00		55-611-00-01 55-611-00-02		SPECIAL DETAILED	Horizontal Stabilizer Rear Spar Lower Chord
55-611-10		55-611-10-01 55-611-10-02		SPECIAL DETAILED	Horizontal Stabilizer Rear Spar Lower Chord
55-611-12		55-611-12-01 55-611-12-02		SPECIAL DETAILED	Horizontal Stabilizer Rear Spar Lower Chord
55-611-14		55-611-14-01 55-611-14-02		SPECIAL DETAILED	Horizontal Stabilizer Rear Spar Lower Chord
55-611-16		55-611-16-01 55-611-16-02		SPECIAL DETAILED	Horizontal Stabilizer Rear Spar Lower Chord
55-611-18		55-611-18-01 55-611-18-02		SPECIAL DETAILED	Horizontal Stabilizer Rear Spar Lower Chord
55-611-20		55-611-20-01 55-611-20-02		SPECIAL DETAILED	Horizontal Stabilizer Rear Spar Upper Chord at Side-of-Body
55-611-22		55-611-22-01 55-611-22-02		SPECIAL DETAILED	Horizontal Stabilizer Rear Spar Upper Chord at Side-of-Body
55-611-23		55-611-23-01 55-611-23-02		SPECIAL DETAILED	Horizontal Stabilizer Rear Spar Upper Chord at Side-of-Body
55-611-24		55-611-24-01 55-611-24-02		SPECIAL DETAILED	Horizontal Stabilizer Rear Spar Upper Chord at Side-of-Body



**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
55-611-25		55-611-25-01 55-611-25-02		SPECIAL DETAILED	Horizontal Stabilizer Rear Spar Upper Chord at Side-of-Body
55-611-26		55-611-26-01 55-611-26-02		SPECIAL DETAILED	Horizontal Stabilizer Rear Spar Upper Chord
55-611-27		55-611-27-01 55-611-27-02		SPECIAL DETAILED	Horizontal Stabilizer Rear Spar Upper Chord
55-611-28		55-611-28-01 55-611-28-02		SPECIAL DETAILED	Horizontal Stabilizer Rear Spar Upper Chord
55-611-30		55-611-30-01 55-611-30-02		SPECIAL DETAILED	Horizontal Stabilizer Rear Spar Upper Chord
55-611-32		55-611-32-01 55-611-32-02		SPECIAL DETAILED	Horizontal Stabilizer Rear Spar Upper Chord
55-611-34		55-611-34-01 55-611-34-02		SPECIAL DETAILED	Horizontal Stabilizer Rear Spar Upper Chord
55-611-36		55-611-36-01 55-611-36-02		SPECIAL DETAILED	Horizontal Stabilizer Rear Spar Upper Chord
55-611-38		55-611-38-01 55-611-38-02		SPECIAL DETAILED	Horizontal Stabilizer Rear Spar Upper Chord
55-611-40		55-611-40-01 55-611-40-02		SPECIAL DETAILED	Horizontal Stabilizer Rear Spar Upper Chord
55-611-42		55-611-42-01 55-611-42-02		SPECIAL DETAILED	Horizontal Stabilizer Rear Spar Upper Chord
55-611-44		55-611-44-01 55-611-44-02		SPECIAL DETAILED	Horizontal Stabilizer Rear Spar Web
55-611-46		55-611-46-01 55-611-46-02		SPECIAL DETAILED	Horizontal Stabilizer Rear Spar Web
55-611-48		55-611-48-01 55-611-48-02		SPECIAL DETAILED	Horizontal Stabilizer Rear Spar Web



**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
55-611-50		55-611-50-01 55-611-50-02		SPECIAL DETAILED	Horizontal Stabilizer Rear Spar Web
55-611-52		55-611-52-01 55-611-52-02		SPECIAL DETAILED	Horizontal Stabilizer Rear Spar Web
55-612-00		55-612-00-01 55-612-00-02		SPECIAL DETAILED	Horizontal Stabilizer Rear Spar Upper and Failsafe Chord Lugs
55-613-00		55-613-00-01 55-613-00-02		SPECIAL DETAILED	Horizontal Stabilizer Rear Spar Upper Chord Terminal Fitting
55-613-01		55-613-01-01 55-613-01-02		SPECIAL DETAILED	Horizontal Stabilizer Rear Spar Upper Chord Terminal Fitting
55-613-10		55-613-10-01 55-613-10-02		DETAILED	Horizontal Stabilizer Rear Spar Upper Chord Terminal Fitting
55-614-00		55-614-00-01 55-614-00-02		SPECIAL DETAILED	Horizontal Stabilizer Rear Spar Terminal Fitting
55-614-10		55-614-10-01 55-614-10-02		SPECIAL DETAILED	Horizontal Stabilizer Rear Spar Upper Chord Terminal Fitting
55-614-12		55-614-12-01 55-614-12-02		SPECIAL DETAILED	Horizontal Stabilizer Rear Spar Lower Chord
55-615-00		55-615-00-01 55-615-00-02		SPECIAL DETAILED	Horizontal Stabilizer Front Spar Upper Chord
55-616-00		55-616-00-01 55-616-00-02		SPECIAL DETAILED	Horizontal Stabilizer Front Spar Upper Chord, Aft Flange
55-616-05		55-616-05-01 55-616-05-02		SPECIAL DETAILED	Horizontal Stabilizer Front Spar Upper Chord - Web Flange
55-616-06		55-616-06-01 55-616-06-02		SPECIAL DETAILED	Horizontal Stabilizer Front Spar Upper Chord - Web Flange
55-616-07		55-616-07-01 55-616-07-02		SPECIAL DETAILED	Horizontal Stabilizer Front Spar Upper Chord - Web Flange





**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
55-616-08		55-616-08-01 55-616-08-02		SPECIAL DETAILED	Horizontal Stabilizer Front Spar Upper Chord - Web Flange
55-616-09		55-616-09-01 55-616-09-02		SPECIAL DETAILED	Horizontal Stabilizer Front Spar Upper Chord - Web Flange
55-616-10		55-616-10-01 55-616-10-02		SPECIAL DETAILED	Horizontal Stabilizer Front Spar Upper Chord, Forward Flange
55-616-11		55-616-11-01 55-616-11-02		SPECIAL DETAILED	Horizontal Stabilizer Front Spar Upper Chord, Forward Flange
55-616-12		55-616-12-01 55-616-12-02		SPECIAL DETAILED	Horizontal Stabilizer Front Spar Upper Chord - Web Flange
55-616-14		55-616-14-01 55-616-14-02		SPECIAL DETAILED	Horizontal Stabilizer Front Spar Upper Chord, Web Flange
55-616-16		55-616-16-01 55-616-16-02		DETAILED	Horizontal Stabilizer Front Spar Lower Chord - Forward Flange
55-616-18		55-616-18-01 55-616-18-02		SPECIAL DETAILED	Horizontal Stabilizer Front Spar Lower Chord, Aft Flange
55-616-20		55-616-20-01 55-616-20-02		SPECIAL DETAILED	Horizontal Stabilizer Front Spar Lower Chord, Forward Flange
55-616-22		55-616-22-01 55-616-22-02		SPECIAL DETAILED	Horizontal Stabilizer Front Spar Lower Chord, Aft Flange
55-616-24		55-616-24-01 55-616-24-02		SPECIAL DETAILED	Horizontal Stabilizer Front Spar Lower Chord, Forward Flange
55-616-26		55-616-26-01 55-616-26-02		SPECIAL DETAILED	Horizontal Stabilizer Front Spar Lower Chord, Aft Flange
55-616-28		55-616-28-01 55-616-28-02		SPECIAL DETAILED	Horizontal Stabilizer Front Spar Web
55-616-30		55-616-30-01 55-616-30-02		SPECIAL DETAILED	Horizontal Stabilizer Front Spar Web



**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
55-616-32		55-616-32-01 55-616-32-02		SPECIAL DETAILED	Horizontal Stabilizer Front Spar Web
55-616-34		55-616-34-01 55-616-34-02		SPECIAL DETAILED	Horizontal Stabilizer Front Spar Web
55-616-36		55-616-36-01 55-616-36-02		SPECIAL DETAILED	Horizontal Stabilizer Front Spar Web
55-617-00		55-617-00-01 55-617-00-02		DETAILED	Horizontal Stabilizer Front Spar Upper Chord
55-618-00		55-618-00-01 55-618-00-02		SPECIAL DETAILED	Horizontal Stabilizer Front Spar Terminal Fitting
55-618-10		55-618-10-01 55-618-10-02		SPECIAL DETAILED	Horizontal Stabilizer Front Spar Lower Chord
55-619-00		55-619-00-01 55-619-00-02		SPECIAL DETAILED	Horizontal Stabilizer Elevator Hinge Ribs
55-620-00		55-620-00-01 55-620-00-02		SPECIAL DETAILED	Horizontal Stabilizer Elevator Hinge Ribs
55-621-00		55-621-00-01 55-621-00-02		SPECIAL DETAILED	Horizontal Stabilizer Trailing Edge Hinge Plate Lower Forward Lug
55-622-00		55-622-00-01 55-622-00-02		SPECIAL DETAILED	Horizontal Stabilizer Elevator Hinge Ribs
55-623-00		55-623-00-01 55-623-00-02		SPECIAL DETAILED	Horizontal Stabilizer Elevator Hinge Ribs Trailing Edge Clevis
55-623-01		55-623-01-01 55-623-01-02		SPECIAL DETAILED	Horizontal Stabilizer Elevator Hinge Ribs Trailing Edge Clevis
55-624-00		55-624-00-01 55-624-00-02		SPECIAL DETAILED	Horizontal Stabilizer Elevator Hinge Ribs
55-625-00		55-625-00-01 55-625-00-02		SPECIAL DETAILED	Horizontal Stabilizer Elevator Hinge Ribs



**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
55-626-00		55-626-00-01 55-626-00-02		SPECIAL DETAILED	Horizontal Stabilizer Elevator Hinge Ribs
55-627-00		55-627-00-01 55-627-00-02		SPECIAL DETAILED	Horizontal Stabilizer Trailing Edge Elevator Hinge Rib
55-628-00		55-628-00-01 55-628-00-02		SPECIAL DETAILED	Horizontal Stabilizer, Trailing Edge Hinge Rib to Rear Spar Attachment
55-629-00		55-629-00-01 55-629-00-02		SPECIAL DETAILED	Horizontal Stabilizer Elevator Hinge Ribs
55-630-00		55-630-00-01 55-630-00-02		SPECIAL DETAILED	Horizontal Stabilizer Elevator Hinge Ribs
55-631-00		55-631-00-01 55-631-00-02		SPECIAL DETAILED	Horizontal Stabilizer Elevator Hinge Ribs
55-631-10		55-631-10-01 55-631-10-02		SPECIAL DETAILED	Horizontal Stabilizer Upper Inspar Skin
55-633-00		55-633-00-01 55-633-00-02		DETAILED	Horizontal Stabilizer Lower Inspar Skin
55-634-00		55-634-00-01 55-634-00-02		DETAILED	Horizontal Stabilizer Center Section Front Spar Upper Chord
55-635-00		55-635-00-01 55-635-00-02		SPECIAL DETAILED	Horizontal Stabilizer Center Section Rear Spar Lugs
55-636-00		55-636-00-01 55-636-00-02		SPECIAL DETAILED	Horizontal Stabilizer Center Section Rear Spar Upper Chord
55-637-00		55-637-00-01 55-637-00-02		DETAILED	Horizontal Stabilizer Center Section Front Spar Upper Chord
55-638-00		55-638-00-01 55-638-00-02		SPECIAL DETAILED	Horizontal Stabilizer Center Section Primary and Thrust Beams
55-639-00		55-639-00-01 55-639-00-02		SPECIAL DETAILED	Horizontal Stabilizer Center Section Primary and Thrust Beams



# 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

## TASKS SORTED BY MPD ITEM NUMBER

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
55-640-00		55-640-00-01 55-640-00-02		SPECIAL DETAILED	Horizontal Stabilizer Center Section Primary and Thrust Beams
55-641-00		55-641-00-01 55-641-00-02		SPECIAL DETAILED	Horizontal Stabilizer Center Section Thrust Beams
55-642-00		55-642-00-01 55-642-00-02		SPECIAL DETAILED	Horizontal Stabilizer Center Section Thrust Beams
55-643-00		55-643-00-01 55-643-00-02		SPECIAL DETAILED	Horizontal Stabilizer Center Section Thrust Beams
55-644-00		55-644-00-01 55-644-00-02		SPECIAL DETAILED	Horizontal Stabilizer Center Section Thrust Beam Intersection
55-645-00		55-645-00-01 55-645-00-02		SPECIAL DETAILED	Horizontal Stabilizer Center Section Thrust Beams
55-646-00		55-646-00-01 55-646-00-02		SPECIAL DETAILED	Horizontal Stabilizer Center Section Primary Beam Chord to Web Attachment
55-647-00		55-647-00-01 55-647-00-02		SPECIAL DETAILED	Elevator Hinge Fittings
55-648-00		55-648-00-01 55-648-00-02		SPECIAL DETAILED	Elevator Mast Arm Assembly (Elevator Actuator Fitting)
55-649-00		55-649-00-01 55-649-00-02		GENERAL VISUAL	Elevator Horn Balance Weight Support Structure
55-650-00		55-650-00-01 55-650-00-02		SPECIAL DETAILED	Elevator Tab Mast Fitting
55-651-00		55-651-00-01 55-651-00-02		SPECIAL DETAILED	183A8700 Hinge/Mast Arm Fitting Upper Flange
55-652-00		55-652-00-01 55-652-00-02		SPECIAL DETAILED	183A8700 Hinge/Mast Arm Fitting Upper Flange
55-653-00		55-653-00-01 55-653-00-02		SPECIAL DETAILED	Elevator Tab Hinge Fittings 183A4211 Lug Assembly



# 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

## TASKS SORTED BY MPD ITEM NUMBER

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
55-654-00		55-654-00-01 55-654-00-02		SPECIAL DETAILED	183A8300 Bridge Fitting Upper/Lower Flange
55-655-00		55-655-00-01 55-655-00-02		SPECIAL DETAILED	183A8300 Bridge Fitting Upper/Lower Flange
55-656-00		55-656-00-01 55-656-00-02		SPECIAL DETAILED	183A1400 - Bracket Assy - Tab Control Mechanism, Elevator
55-657-00		55-657-00-01 55-657-00-02		SPECIAL DETAILED	183A1400 - Bracket Assy - Tab Control Mechanism, Elevator
55-658-00		55-658-00-01 55-658-00-02		SPECIAL DETAILED	Vertical Fin - Rear Spar
55-659-00		55-659-00-01 55-659-00-02		SPECIAL DETAILED	Vertical Fin - Rear Spar
55-660-00		55-660-00-01 55-660-00-02		DETAILED	Vertical Fin - Closure Rib
55-661-00		55-661-00-01		SPECIAL DETAILED	Vertical Fin - Closure Rib
55-662-00		55-662-00-01		DETAILED	Rudder Hinge Ribs
55-663-00		55-663-00-01		DETAILED	Rudder Hinge Ribs
55-664-00		55-664-00-01		DETAILED	Rudder Hinge Fittings
55-665-00		55-665-00-01		SPECIAL DETAILED	Rudder Actuator Fittings
55-666-00		55-666-00-01		DETAILED	737NG Rudder Balance Arm
55-800-00	55-800-00	55-800-00-01		ZONAL (GV)	Vertical Fin and Horizontal Stabilizer
55-802-00	55-802-00	55-802-00-01		ZONAL (GV)	Vertical Fin - Dorsal Fin
55-804-00	55-804-00	55-804-00-01		ZONAL (GV)	Vertical Fin - Leading Edge (Only if HF System Installed)
55-806-00	55-806-00	55-806-00-01		ZONAL (GV)	Vertical Fin - Leading Edge
55-808-00	55-808-00	55-808-00-01		ZONAL (GV)	Vertical Fin - Leading Edge



**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
55-810-00	55-810-00	55-810-00-01		ZONAL (GV)	Vertical Fin - Front Spar to Rear Spar
55-812-00	55-812-00	55-812-00-01		ZONAL (GV)	Vertical Fin - Front Spar to Rear Spar
55-814-00	55-814-00	55-814-00-01		ZONAL (GV)	Vertical Fin - Rear Spar to Trailing Edge
55-816-00	55-816-00	55-816-00-01		ZONAL (GV)	Vertical Fin - Rear Spar to Trailing Edge
55-818-00	55-818-00	55-818-00-01		ZONAL (GV)	Rudder
55-820-00	55-820-00	55-820-00-01		ZONAL (GV)	Vertical Fin Tip
55-822-01	55-822-01	55-822-01-01		ZONAL (GV)	Horizontal Stabilizer - Leading Edge - Left
55-824-01	55-824-01	55-824-01-01		ZONAL (GV)	Horizontal Stabilizer - Front Spar to Rear Spar - Left
55-826-01	55-826-01	55-826-01-01		ZONAL (GV)	Horizontal Stabilizer - Front Spar to Rear Spar - Left
55-828-01	55-828-01	55-828-01-01		ZONAL (GV)	Horizontal Stabilizer - Rear Spar to Trailing Edge - Left
55-830-01	55-830-01	55-830-01-01		ZONAL (GV)	Horizontal Stabilizer - Rear Spar to Trailing Edge - Left
55-832-01	55-832-01	55-832-01-01		ZONAL (GV)	Horizontal Stabilizer - Elevator - Left
55-834-01	55-834-01	55-834-01-01		ZONAL (GV)	Horizontal Stabilizer - Stabilizer Tip - Left
55-836-02	55-836-02	55-836-02-01		ZONAL (GV)	Horizontal Stabilizer - Leading Edge - Right
55-838-02	55-838-02	55-838-02-01		ZONAL (GV)	Horizontal Stabilizer - Front Spar to Rear Spar - Right
55-840-02	55-840-02	55-840-02-01		ZONAL (GV)	Horizontal Stabilizer - Front Spar to Rear Spar - Right
55-842-02	55-842-02	55-842-02-01		ZONAL (GV)	Horizontal Stabilizer - Rear Spar to Trailing Edge - Right
55-844-02	55-844-02	55-844-02-01		ZONAL (GV)	Horizontal Stabilizer - Rear Spar to Trailing Edge - Right
55-846-02	55-846-02	55-846-02-01		ZONAL (GV)	Horizontal Stabilizer - Elevator - Right
55-848-02	55-848-02	55-848-02-01		ZONAL (GV)	Horizontal Stabilizer - Stabilizer Tip - Right
56-010-00	56-010-00	56-010-00-01		LUBRICATE	Control Cabin Sliding Windows
56-020-00	56-020-00	56-020-00-01		LUBRICATE	Control Cabin Sliding Windows
56-030-00	56-030-00	56-030-00-01		OPERATIONAL	Control Cabin Sliding Windows
56-040-00	56-040-00	56-040-00-01		OPERATIONAL	Control Cabin Sliding Windows



**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
56-050-00	56-050-00	56-050-00-01		INSPECTION - GEN VISUAL	Control Cabin Sliding Windows
56-060-00	56-060-00	56-060-00-01		INSPECTION - GEN VISUAL	Control Cabin Sliding Windows
57-010-00	57-010-00	57-010-00-01		GENERAL VISUAL	Wing Center Section
57-020-00	57-020-00	57-020-00-01		GENERAL VISUAL	Wing Center Section
57-030-00	57-030-00	57-030-00-01		GENERAL VISUAL	Wing Center Section
57-040-00	57-040-00	57-040-00-01		GENERAL VISUAL	Wing Center Section
57-050-00	57-050-00	57-050-00-01		GENERAL VISUAL	Wing Center Section
57-060-01	57-060-01	57-060-01-01		GENERAL VISUAL	Left Outboard Wing
57-060-02	57-060-02	57-060-02-01		GENERAL VISUAL	Right Outboard Wing
57-070-01	57-070-01	57-070-01-01		GENERAL VISUAL	Left Outboard Wing
57-070-02	57-070-02	57-070-02-01		GENERAL VISUAL	Right Outboard Wing
57-090-00	57-090-00	57-090-00-01		GENERAL VISUAL	Wing Center Section
57-100-01	57-100-01	57-100-01-01		GENERAL VISUAL	Left Nacelle Support Fittings
57-100-02	57-100-02	57-100-02-01		GENERAL VISUAL	Right Nacelle Support Fittings
57-110-01	57-110-01	57-110-01-01		GENERAL VISUAL	Left Outboard Wing Lower Surface



# 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

## TASKS SORTED BY MPD ITEM NUMBER

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
57-110-02	57-110-02	57-110-02-01		GENERAL VISUAL	Right Outboard Wing Lower Surface
57-120-01	57-120-01	57-120-01-01		GENERAL VISUAL	Left Outboard Wing Front Spar
57-120-02	57-120-02	57-120-02-01		GENERAL VISUAL	Right Outboard Wing Front Spar
57-130-01	57-130-01	57-130-01-01		GENERAL VISUAL	Left Outboard Wing Leading Edge Structure
57-130-02	57-130-02	57-130-02-01		GENERAL VISUAL	Right Outboard Wing Leading Edge Structure
57-140-01	57-140-01	57-140-01-01		DETAILED	Left Wing Slat Tracks
57-140-02	57-140-02	57-140-02-01		DETAILED	Right Wing Slat Tracks
57-160-01	57-160-01	57-160-01-01		GENERAL VISUAL	Left Outboard Wing Access Holes
57-160-02	57-160-02	57-160-02-01		GENERAL VISUAL	Right Outboard Wing Access Holes
57-170-01	57-170-01	57-170-01-01	W-57-180-01-01 W-57-190-01-01	GENERAL VISUAL	Left Outboard Wing
57-170-02	57-170-02	57-170-02-01	W-57-180-02-01 W-57-190-02-01	GENERAL VISUAL	Right Outboard Wing
57-180-01	57-180-01	57-180-01-01	W-57-170-01-01 W-57-190-01-01	GENERAL VISUAL	Left Outboard Wing
57-180-02	57-180-02	57-180-02-01	W-57-170-02-01 W-57-190-02-01	GENERAL VISUAL	Right Outboard Wing
57-190-01	57-190-01	57-190-01-01	W-57-170-01-01 W-57-180-01-01	GENERAL VISUAL	Left Outboard Wing
57-190-02	57-190-02	57-190-02-01	W-57-170-02-01 W-57-180-02-01	GENERAL VISUAL	Right Outboard Wing
57-200-01	57-200-01	57-200-01-01		GENERAL VISUAL	Left Flap Support No. 4





**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
57-200-02	57-200-02	57-200-02-01		GENERAL VISUAL	Right Flap Support No. 5
57-210-01	57-210-01	57-210-01-01		GENERAL VISUAL	Left Flap Support No. 3
57-210-02	57-210-02	57-210-02-01		GENERAL VISUAL	Right Flap Support No. 6
57-220-01	57-220-01	57-220-01-01		GENERAL VISUAL	Left Outboard Wing Lower Surface
57-220-02	57-220-02	57-220-02-01		GENERAL VISUAL	Right Outboard Wing Lower Surface
57-230-01	57-230-01	57-230-01-01		GENERAL VISUAL	Flap Supports No. 1 & 2
57-230-02	57-230-02	57-230-02-01		GENERAL VISUAL	Flap Supports No.7 & 8
57-240-01	57-240-01	57-240-01-01		GENERAL VISUAL	Left Outboard Wing Lower Surface
57-240-02	57-240-02	57-240-02-01		GENERAL VISUAL	Right Outboard Wing Lower Surface
57-250-01	57-250-01	57-250-01-01		GENERAL VISUAL	Left Main Landing Gear Support Structure
57-250-02	57-250-02	57-250-02-01		GENERAL VISUAL	Right Main Landing Gear Support Structure
57-260-01	57-260-01	57-260-01-01		GENERAL VISUAL	Left Wing Outboard Rear Spar
57-260-02	57-260-02	57-260-02-01		GENERAL VISUAL	Right Wing Outboard Rear Spar
57-270-01	57-270-01	57-270-01-01		GENERAL VISUAL	Left Wing Outboard Trailing Edge Structure
57-270-02	57-270-02	57-270-02-01		GENERAL VISUAL	Right Wing Outboard Trailing Edge Structure



**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
57-280-01	57-280-01	57-280-01-01		GENERAL VISUAL	Left Inboard Ground Spoiler
57-280-02	57-280-02	57-280-02-01		GENERAL VISUAL	Right Inboard Ground Spoiler
57-300-01	57-300-01	57-300-01-01		GENERAL VISUAL	Left Inboard Flap
57-300-02	57-300-02	57-300-02-01		GENERAL VISUAL	Right Inboard Flap
57-310-01	57-310-01	57-310-01-01		GENERAL VISUAL	Left Outboard Wing Rear Spar
57-310-02	57-310-02	57-310-02-01		GENERAL VISUAL	Right Outboard Wing Rear Spar
57-330-01	57-330-01	57-330-01-01		GENERAL VISUAL	Left Outboard Flap
57-330-02	57-330-02	57-330-02-01		GENERAL VISUAL	Right Outboard Flap
57-340-01	57-340-01	57-340-01-01		SPECIAL DETAILED	Left Winglet
57-340-02	57-340-02	57-340-02-01		SPECIAL DETAILED	Right Winglet
57-351-01	57-351-01	57-351-01-01		DETAILED	Left Winglet
57-351-02	57-351-02	57-351-02-01		DETAILED	Right Winglet
57-600-00		57-600-00-01 57-600-00-02		SPECIAL DETAILED	Upper Side of Body Splice
57-601-00		57-601-00-01 57-601-00-02		SPECIAL DETAILED	Double Plus Chord at Stringer 18A Interface
57-601-10		57-601-10-01 57-601-10-02		SPECIAL DETAILED	Double Plus Chord Vertical Flange at Body Stringer 18A Interface



# 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

## TASKS SORTED BY MPD ITEM NUMBER

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
57-601-20		57-601-20-01 57-601-20-02		SPECIAL DETAILED	Double Plus Chord Upper Vertical Flange at Body Stringer 18A Interface
57-601-22		57-601-22-01 57-601-22-02		GENERAL VISUAL	Double Plus Chord Upper Horizontal Flange
57-601-25		57-601-25-01 57-601-25-02		SPECIAL DETAILED	Double Plus Chord Upper Horizontal Flange at Stub Beams
57-601-27		57-601-27-01 57-601-27-02		GENERAL VISUAL	Double Plus Chord Upper Vertical Flange
57-601-28		57-601-28-01 57-601-28-02		SPECIAL DETAILED	Double Plus Chord Upper Vertical Flange
57-601-30		57-601-30-01 57-601-30-02		SPECIAL DETAILED	Wing Center Section Upper Skin at Floor Beams and Shear Ties
57-602-00		57-602-00-01 57-602-00-02		DETAILED	Wing Center Section Lower Panel Typical Stringers
57-602-10		57-602-10-01 57-602-10-02		DETAILED	Wing Center Section Lower Panel Skin
57-603-00		57-603-00-01 57-603-00-02		DETAILED	Wing Center Section Lower Panel
57-603-10		57-603-10-01 57-603-10-02		SPECIAL DETAILED	Wing Center Section Lower Panel
57-604-00		57-604-00-01 57-604-00-02		GENERAL VISUAL	Wing Center Section Lower Panel
57-605-00		57-605-00-01 57-605-00-02		SPECIAL DETAILED	Side of Body Splice, Lower Surface
57-605-01		57-605-01-01 57-605-01-02		SPECIAL DETAILED	Side of Body Splice, Lower Surface
57-605-10		57-605-10-01 57-605-10-02		SPECIAL DETAILED	Side of Body Splice, Lower Surface Skin



**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
57-605-20		57-605-20-01 57-605-20-02		SPECIAL DETAILED	Side of Body Splice, Lower Surface Skin
57-606-00		57-606-00-01 57-606-00-02		SPECIAL DETAILED	Wing Center Section Lower Panel
57-606-01		57-606-01-01		SPECIAL DETAILED	Wing Center Section Lower Panel
57-607-00		57-607-00-01 57-607-00-02		SPECIAL DETAILED	Wing Center Section Lower Panel
57-607-10		57-607-10-01 57-607-10-02		DETAILED	Wing Center Section Rear Spar Typical Web (Crack initially hidden)
57-607-11		57-607-11-01 57-607-11-02		SPECIAL DETAILED	Wing Center Section Rear Spar Typical Web (Crack initially hidden)
57-607-20		57-607-20-01 57-607-20-02		DETAILED	Wing Center Section Rear Spar Typical Web (Non-Hidden Locations)
57-607-21		57-607-21-01 57-607-21-02		SPECIAL DETAILED	Wing Center Section Rear Spar Typical Web (Non-Hidden Locations)
57-607-30		57-607-30-01 57-607-30-02		SPECIAL DETAILED	Wing Center Section Rear Spar Keel Beam Stiffeners
57-608-00		57-608-00-01 57-608-00-02		SPECIAL DETAILED	Side of Body Splice Upper and Lower Rear Spar
57-609-00		57-609-00-01 57-609-00-02		SPECIAL DETAILED	Side of Body Splice Upper and Lower Front Spar
57-609-10		57-609-10-01 57-609-10-02		SPECIAL DETAILED	Wing Center Section Floor Beam Upper Chord
57-610-00		57-610-00-01 57-610-00-02		DETAILED	Wing Center Section Floor Beam Upper Chord
57-610-01		57-610-01-01 57-610-01-02		SPECIAL DETAILED	Wing Center Section Floor Beam Lower Chord Over Pressure Deck



**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
57-611-00		57-611-00-01 57-611-00-02		SPECIAL DETAILED	Wing Center Section Floor Beams Lower Chord - Overwing
57-611-10		57-611-10-01 57-611-10-02		DETAILED	Wing Center Section Floor Beams Lower Chord - Overwing
57-611-20		57-611-20-01 57-611-20-02		DETAILED	Side of Body Rib (Direction 1)
57-611-21		57-611-21-01 57-611-21-02		DETAILED	Side of Body Rib (Direction 2)
57-612-00		57-612-00-01 57-612-00-02		GENERAL VISUAL	Lower Wing Panel, Typical Stringers
57-612-01		57-612-01-01 57-612-01-02		GENERAL VISUAL	Lower Wing Panel, Typical Stringers
57-613-00		57-613-00-01 57-613-00-02		SPECIAL DETAILED	Lower Wing Panel, Typical Stringers
57-614-00		57-614-00-01 57-614-00-02		SPECIAL DETAILED	Lower Wing Panel Skin; Under the Flap Track Fairings and Nacelle Fairings
57-614-10		57-614-10-01 57-614-10-02		GENERAL VISUAL	Lower Wing Panel Skin
57-614-20		57-614-20-01 57-614-20-02		DETAILED	Lower Wing Panel Skin
57-614-30		57-614-30-01 57-614-30-02		GENERAL VISUAL	Lower Wing Panel Skin
57-614-40		57-614-40-01 57-614-40-02		DETAILED	Lower Wing Panel, Rail Stringers
57-615-00		57-615-00-01 57-615-00-02		SPECIAL DETAILED	Lower Wing Panel, Rail Stringers
57-615-01		57-615-01-01 57-615-01-02		SPECIAL DETAILED	Lower Wing Panel, Rail Stringers



# 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

## TASKS SORTED BY MPD ITEM NUMBER

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
57-616-00		57-616-00-01 57-616-00-02		GENERAL VISUAL	Lower Wing Panel, Rail Stringer
57-616-10		57-616-10-01 57-616-10-02		SPECIAL DETAILED	Lower Wing Panel, Rail Stringer
57-617-00		57-617-00-01 57-617-00-02		GENERAL VISUAL	Lower Wing Panel, Splice Stringers
57-617-01		57-617-01-01 57-617-01-02		SPECIAL DETAILED	Lower Wing Panel, Splice Stringers
57-618-00		57-618-00-01 57-618-00-02		SPECIAL DETAILED	Lower Wing Panel, Splice Stringers (Direction 3)
57-618-01		57-618-01-01 57-618-01-02		SPECIAL DETAILED	Lower Wing Panel, Splice Stringers (Direction 4)
57-619-00		57-619-00-01 57-619-00-02		SPECIAL DETAILED	Lower Wing Panel, Splice Stringers
57-619-01		57-619-01-01 57-619-01-02		SPECIAL DETAILED	Lower Wing Panel, Splice Stringers
57-620-00		57-620-00-01 57-620-00-02		DETAILED	Wing Lower Panel, Splice Stringers
57-620-01		57-620-01-01 57-620-01-02		SPECIAL DETAILED	Wing Lower Panel, Splice Stringer
57-621-00		57-621-00-01 57-621-00-02		DETAILED	Wing Lower Panel, Splice Stringers
57-621-01		57-621-01-01 57-621-01-02		SPECIAL DETAILED	Wing Lower Panel, Splice Stringer (Direction 3)
57-621-02		57-621-02-01 57-621-02-02		SPECIAL DETAILED	Wing Lower Panel, Splice Stringer (Direction 4)
57-621-10		57-621-10-01 57-621-10-02		SPECIAL DETAILED	Lower Wing Panel, Splice Stringers (Direction 3)



**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
57-621-11		57-621-11-01 57-621-11-02		SPECIAL DETAILED	Lower Wing Panel, Splice Stringers (Direction 4)
57-621-20		57-621-20-01 57-621-20-02		SPECIAL DETAILED	Splice Stringers at Chordwise Skin Splices (Upper and Lower Panel)
57-622-00		57-622-00-01 57-622-00-02		SPECIAL DETAILED	Front Spar Lower Chord (Skin Flange Inspections)
57-623-00		57-623-00-01 57-623-00-02		DETAILED	Front Spar Lower Chord (Skin Flange Inspections)
57-624-00		57-624-00-01 57-624-00-02		SPECIAL DETAILED	Front Spar Lower Chord (Web Flange Inspections)
57-625-00		57-625-00-01 57-625-00-02		SPECIAL DETAILED	Front Spar Lower Chord (Skin Flange Inspections)
57-626-00		57-626-00-01 57-626-00-02		DETAILED	Front Spar Lower Chord (Web Flange Inspections)
57-627-00		57-627-00-01 57-627-00-02		SPECIAL DETAILED	Front Spar Lower Chord (Web Flange Inspections)
57-627-01		57-627-01-01 57-627-01-02		SPECIAL DETAILED	Front Spar Lower Chord (Web Flange Inspections)
57-628-00		57-628-00-01 57-628-00-02		SPECIAL DETAILED	Front Spar Lower Chord (Web Flange Inspections)
57-628-01		57-628-01-01 57-628-01-02		SPECIAL DETAILED	Front Spar Lower Chord (Web Flange Inspections)
57-628-10		57-628-10-01 57-628-10-02		GENERAL VISUAL	Front Spar Lower Chord (Web Flange Inspections)
57-629-00		57-629-00-01 57-629-00-02		SPECIAL DETAILED	Front Spar Lower Chord (Direction 1)
57-630-00		57-630-00-01 57-630-00-02		SPECIAL DETAILED	Front Spar Lower Chord (Direction 2)



# 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

## TASKS SORTED BY MPD ITEM NUMBER

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
57-631-00		57-631-00-01 57-631-00-02		SPECIAL DETAILED	Front Spar Lower Chord (Direction 3)
57-632-00		57-632-00-01 57-632-00-02		SPECIAL DETAILED	Front Spar Lower Chord (Direction 4)
57-632-10		57-632-10-01 57-632-10-02		SPECIAL DETAILED	Front Spar Lower Chord (Skin and Web Flange Inspections)
57-633-00		57-633-00-01 57-633-00-02		SPECIAL DETAILED	Spar Chords at Chordwise Skin Splices (Upper and Lower Panel)
57-633-01		57-633-01-01 57-633-01-02		SPECIAL DETAILED	Spar Chords at Chordwise Skin Splices (Upper and Lower Panel)
57-634-00		57-634-00-01 57-634-00-02		GENERAL VISUAL	Rear Spar Lower Chord (Skin Flange Inspections)
57-635-00		57-635-00-01 57-635-00-02		GENERAL VISUAL	Rear Spar Lower Chord (Web Flange Inspections)
57-636-00		57-636-00-01 57-636-00-02		SPECIAL DETAILED	Rear Spar Lower Chord (Web Flange Inspections)
57-637-00		57-637-00-01 57-637-00-02		DETAILED	Rear Spar Lower Chord (Skin Flange Inspections)
57-638-00		57-638-00-01 57-638-00-02		SPECIAL DETAILED	Rear Spar Lower Chord (Skin Flange Inspections)
57-639-00		57-639-00-01 57-639-00-02		DETAILED	Rear Spar Lower Chord (Skin Flange Inspections)
57-640-00		57-640-00-01 57-640-00-02		DETAILED	Rear Spar Lower Chord (Web Flange Inspections)
57-641-00		57-641-00-01 57-641-00-02		SPECIAL DETAILED	Rear Spar Lower Chord (Skin and Web Flange Inspections)
57-641-10		57-641-10-01 57-641-10-02		SPECIAL DETAILED	Rear Spar Lower Chord (Skin Flange and Web Flange Inspections)





**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
57-642-00		57-642-00-01 57-642-00-02		SPECIAL DETAILED	Lower Skin Panel at Main Landing Gear Outboard Support Fittings
57-642-10		57-642-10-01 57-642-10-02		SPECIAL DETAILED	Lower Skin Panel at Main Landing Gear Outboard Support Fittings
57-643-00		57-643-00-01 57-643-00-02		SPECIAL DETAILED	Skin at Nacelle Support Fitting Attachments
57-643-01		57-643-01-01 57-643-01-02		SPECIAL DETAILED	Skin at Nacelle Support Fitting Attachments
57-643-10		57-643-10-01 57-643-10-02		SPECIAL DETAILED	Lower Wing Panel Skin at Shear Tied Rib Attachments
57-644-00		57-644-00-01 57-644-00-02		SPECIAL DETAILED	Lower Wing Panel Under Flap Track Fittings (Direction 1)
57-644-01		57-644-01-01 57-644-01-02		SPECIAL DETAILED	Lower Wing Panel Under Flap Track Fittings (Direction 1)
57-644-02		57-644-02-01 57-644-02-02		SPECIAL DETAILED	Lower Wing Panel Under Flap Track Fittings (Direction 2)
57-645-00		57-645-00-01 57-645-00-02		DETAILED	Upper Wing Panel Typical Stringers
57-645-05		57-645-05-01 57-645-05-02		SPECIAL DETAILED	Upper Wing Panel At Side-of-Body Double Plus Chord
57-645-10		57-645-10-01 57-645-10-02		SPECIAL DETAILED	Upper Wing Panel At Side-of-Body Double Plus Chord (Direction 2)
57-645-11		57-645-11-01 57-645-11-02		SPECIAL DETAILED	Upper Wing Panel At Side-of-Body Double Plus Chord (Direction 2)
57-645-12		57-645-12-01 57-645-12-02		SPECIAL DETAILED	Upper Wing Panel At Side-of-Body Double Plus Chord (Direction 3)
57-645-13		57-645-13-01 57-645-13-02		SPECIAL DETAILED	Upper Wing Panel At Side-of-Body Double Plus Chord (Direction 3)



**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
57-645-15		57-645-15-01 57-645-15-02		GENERAL VISUAL	Upper Wing Panel Splice Stringer
57-646-00		57-646-00-01 57-646-00-02		DETAILED	Rear Spar Upper Chord Skin Flange Inspections
57-647-00		57-647-00-01 57-647-00-02		SPECIAL DETAILED	Rear Spar Upper Chord (Skin Flange Inspections)
57-647-10		57-647-10-01 57-647-10-02		SPECIAL DETAILED	Rear Spar Upper Chord (Web Flange Inspections)
57-647-20		57-647-20-01 57-647-20-02		SPECIAL DETAILED	Rear Spar Upper Chord (Web Flange Inspections)
57-647-30		57-647-30-01 57-647-30-02		SPECIAL DETAILED	Rear Spar Upper Chord (Skin Flange and Web Flange Inspections)
57-648-00		57-648-00-01 57-648-00-02		SPECIAL DETAILED	Wing Upper Skin Tab at R1 Nacelle Fitting
57-649-00		57-649-00-01 57-649-00-02		DETAILED	Front Spar Web Crack - Typical Details
57-650-00		57-650-00-01 57-650-00-02		DETAILED	Outboard Wing Rear Spar Web Typical Details
57-650-10		57-650-10-01 57-650-10-02		SPECIAL DETAILED	Outboard Wing Rear Spar Web Typical Details
57-651-00		57-651-00-01 57-651-00-02		SPECIAL DETAILED	Rear Spar Web at Trunnion Attachment, MLG and T.E Fittings
57-651-10		57-651-10-01 57-651-10-02		SPECIAL DETAILED	Rib 25 Upper and Lower Horizontal Flange
57-652-00		57-652-00-01 57-652-00-02		SPECIAL DETAILED	RIB 27, Upper and Lower Rib Flange to Skin Attachment
57-653-00		57-653-00-01 57-653-00-02		SPECIAL DETAILED	Rib 27, Front and Rear Spar Tension Fittings



**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
57-654-00		57-654-00-01 57-654-00-02		DETAILED	Strut to Wing Attachments
57-655-00		57-655-00-01 57-655-00-02		SPECIAL DETAILED	In-Spar Rib, Station 0, Winglet
57-656-00		57-656-00-01 57-656-00-02		SPECIAL DETAILED	In-Spar Rib, Sta 0 Bolt Holes
57-658-00		57-658-00-01 57-658-00-02		DETAILED	Inboard Actuator Support Fittings
57-659-00		57-659-00-01 57-659-00-02		SPECIAL DETAILED	Gear Beam Inboard Support Fitting
57-660-00		57-660-00-01 57-660-00-02		DETAILED	Track #1 & #8 - Outboard Main Flap Outboard Track
57-660-10		57-660-10-01 57-660-10-02		SPECIAL DETAILED	Track #1 & #8 - Outboard Main Flap, Outboard Track
57-661-00		57-661-00-01 57-661-00-02		DETAILED	Support, Forward Fitting Assy Flap Tracks 1, 2, 3, (6, 7, & 8)
57-662-00		57-662-00-01 57-662-00-02		DETAILED	Track #2 & #7 - Outboard Main Flap, Inboard Track
57-663-00		57-663-00-01 57-663-00-02		SPECIAL DETAILED	Track #2 & #7 - Outboard Main Flap, Inboard Track
57-664-00		57-664-00-01 57-664-00-02		DETAILED	Track #3 & #6 - Inboard Main Flap, Outboard Track
57-665-00		57-665-00-01 57-665-00-02		SPECIAL DETAILED	Track #3 & #6 - Inboard Flap Support, Outboard Track
57-666-00		57-666-00-01 57-666-00-02		SPECIAL DETAILED	No. 4 and No. 5 Support, Aft Link Pins
57-667-00		57-667-00-01 57-667-00-02		DETAILED	Track #4 & #5 - Inboard Flap Support, Inboard Track



**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
57-667-10		57-667-10-01 57-667-10-02		SPECIAL DETAILED	Track #4 & #5 - Inboard Flap Support, Inboard Track
57-668-00		57-668-00-01 57-668-00-02		SPECIAL DETAILED	Inboard Main Flap Fitting Assembly Fwd, Inboard Track
57-669-00		57-669-00-01 57-669-00-02		DETAILED	Front Spar Upper Chord
57-669-10		57-669-10-01 57-669-10-02		SPECIAL DETAILED	Front Spar, Inboard Main Flap
57-669-20		57-669-20-01 57-669-20-02		GENERAL VISUAL	Front Spar Cutout/Front Spar Fitting
57-670-00		57-670-00-01 57-670-00-02		DETAILED	Rear Spar Chord at Inbd and Outbd Cutout
57-670-10		57-670-10-01 57-670-10-02		DETAILED	Rear Spar Chord at Inbd and Outbd Pushrod Cutout
57-670-11		57-670-11-01 57-670-11-02		DETAILED	Rear Spar Chord at Inbd and Outbd Pushrod Cutout
57-670-20		57-670-20-01 57-670-20-02		DETAILED	Rear Spar Upper Chord
57-670-30		57-670-30-01 57-670-30-02		SPECIAL DETAILED	Rear Spar Upper Chord
57-671-00		57-671-00-01 57-671-00-02		DETAILED	Inboard Main Flap - In-Spar Upper Skin Panels
57-672-00		57-672-00-01 57-672-00-02		SPECIAL DETAILED	Inbd Main Flap, Inbd Torque Tube Rib
57-673-00		57-673-00-01 57-673-00-02		GENERAL VISUAL	Inbd Main Flap - Torque Tube
57-674-00		57-674-00-01 57-674-00-02		SPECIAL DETAILED	Inbd Main Flap, Rear Spar



**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
57-675-00		57-675-00-01 57-675-00-02		SPECIAL DETAILED	Carriage Assembly No. 3 & No. 6 - Inboard Main Flap, Outboard Carriage.
57-676-00		57-676-00-01 57-676-00-02		SPECIAL DETAILED	Inbd Flap - No. 4 & No.5 Carriage Assy
57-676-10		57-676-10-01 57-676-10-02		DETAILED	Inbd Flap - No. 4 & No. 5 Carriage Assy
57-676-20		57-676-20-01 57-676-20-02		DETAILED	Inboard Main Flap
57-677-00		57-677-00-01 57-677-00-02		SPECIAL DETAILED	No. 1 & No. 8 Carriage Assembly
57-677-10		57-677-10-01 57-677-10-02		SPECIAL DETAILED	No. 1 & No. 8 Carriage Assembly
57-678-00		57-678-00-01 57-678-00-02		SPECIAL DETAILED	No. 2 & No. 7 Carriage Assembly
57-678-10		57-678-10-01 57-678-10-02		SPECIAL DETAILED	No. 2 & No. 7 Carriage Assembly
57-679-00		57-679-00-01 57-679-00-02		SPECIAL DETAILED	Front Spar Assembly - Outbd Main Flap
57-680-00		57-680-00-01 57-680-00-02		SPECIAL DETAILED	Front Spar Assembly - Outbd Main Flap
57-681-00		57-681-00-01 57-681-00-02		SPECIAL DETAILED	Rear Spar - Outbd Main Flap
57-682-00		57-682-00-01 57-682-00-02		SPECIAL DETAILED	Rear Spar - Outbd Main Flap
57-683-00		57-683-00-01 57-683-00-02		SPECIAL DETAILED	Rear Spar - Outbd Main Flap
57-684-00		57-684-00-01 57-684-00-02		SPECIAL DETAILED	Lower Skin - Outbd Main Flap, Front Spar and Rear Spar LWR Chord - LWR Skin Interface



# 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

## TASKS SORTED BY MPD ITEM NUMBER

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
57-685-00		57-685-00-01 57-685-00-02		SPECIAL DETAILED	Front Spar Spigot Fitting - Outbd Main Flap
57-686-00		57-686-00-01 57-686-00-02		DETAILED	Rear Spar Spigot Fitting - Outbd Main Flap
57-688-00		57-688-00-01 57-688-00-02		DETAILED	Hinge / Actuator Fittings, Inboard Spoiler #6 and #7
57-800-00	57-800-00	57-800-00-01		ZONAL (GV)	Center Section Wing Box
57-802-01	57-802-01	57-802-01-01		ZONAL (GV)	Left Wing
57-804-01	57-804-01	57-804-01-01		ZONAL (GV)	Leading Edge to Front Spar - Inboard of Nacelle Strut - Left Wing
57-806-01	57-806-01	57-806-01-01		ZONAL (GV)	Leading Edge to Front Spar - Inboard of Nacelle Strut - Left Wing
57-808-01	57-808-01	57-808-01-01		ZONAL (GV)	Krueger Flaps No. 1 and 2 - Left Wing
57-810-01	57-810-01	57-810-01-01		ZONAL (GV)	Krueger Flaps No. 1 and 2 - Left Wing
57-812-01	57-812-01	57-812-01-01		ZONAL (GV)	Leading Edge to Front Spar - Outboard of Nacelle Strut - Left Wing
57-814-01	57-814-01	57-814-01-01		ZONAL (GV)	Leading Edge to Front Spar - Outboard of Nacelle Strut - Left Wing
57-816-01	57-816-01	57-816-01-01		ZONAL (GV)	Slats No. 1, 2, 3, 4 - Left Wing
57-818-01	57-818-01	57-818-01-01		ZONAL (GV)	Left Wing Tip
57-820-01	57-820-01	57-820-01-01		ZONAL (GV)	Left Wing Tip
57-822-01	57-822-01	57-822-01-01		ZONAL (GV)	Center Fuel Tank - Left Wing
57-824-01	57-824-01	57-824-01-01		ZONAL (GV)	Center Fuel Tank - Left Wing
57-826-01	57-826-01	57-826-01-01		ZONAL (GV)	Main Fuel Tank - Left Wing
57-828-01	57-828-01	57-828-01-01		ZONAL (GV)	Main Fuel Tank - Left Wing
57-830-01	57-830-01	57-830-01-01		ZONAL (GV)	Surge Tank - Left Wing
57-832-01	57-832-01	57-832-01-01		ZONAL (GV)	Surge Tank - Left Wing
57-834-01	57-834-01	57-834-01-01		ZONAL (GV)	Dry Bay - Left Wing
57-836-01	57-836-01	57-836-01-01		ZONAL (GV)	Fairing Flap Support No. 3 - Left Wing



**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
57-838-01	57-838-01	57-838-01-01	W-27-229-00-01	ZONAL (GV)	Fairing Flap Support No. 3 - Left Wing
57-840-01	57-840-01	57-840-01-01		ZONAL (GV)	Fairing Flap Support No. 2 - Left Wing
57-842-01	57-842-01	57-842-01-01		ZONAL (GV)	Fairing Flap Support No. 2 - Left Wing
57-844-01	57-844-01	57-844-01-01		ZONAL (GV)	Fairing Flap Support No. 1 - Left Wing
57-846-01	57-846-01	57-846-01-01		ZONAL (GV)	Fairing Flap Support No. 1 - Left Wing
57-848-01	57-848-01	57-848-01-01		ZONAL (GV)	Rear Spar to Landing Gear Support Beam - Left Wing
57-850-01	57-850-01	57-850-01-01		ZONAL (GV)	Rear Spar to Landing Gear Support Beam - Left Wing
57-852-01	57-852-01	57-852-01-01		ZONAL (GV)	Inboard Spoiler No. 6 - L. Wing
57-854-01	57-854-01	57-854-01-01		ZONAL (GV)	Inboard Flaps - Left Wing
57-856-01	57-856-01	57-856-01-01		ZONAL (GV)	Inboard Main Flaps - Left Wing
57-858-01	57-858-01	57-858-01-01		ZONAL (GV)	Rear Spar to T.E. - Outbd of Inbd Flap - Inbd of Fixed T.E. - L. Wing
57-860-01	57-860-01	57-860-01-01		ZONAL (GV)	Spoilers No. 1, 2, 3, 4, 5 - Left Wing
57-862-01	57-862-01	57-862-01-01		ZONAL (GV)	Outboard Flaps - Left Wing
57-864-01	57-864-01	57-864-01-01		ZONAL (GV)	Fixed Trailing Edge - Left Wing
57-866-01	57-866-01	57-866-01-01		ZONAL (GV)	Fixed Trailing Edge - Left Wing
57-868-01	57-868-01	57-868-01-01		ZONAL (GV)	Fixed Trailing Edge - Left Wing
57-870-01	57-870-01	57-870-01-01		ZONAL (GV)	Aileron - Left Wing
57-872-02	57-872-02	57-872-02-01		ZONAL (GV)	Right Wing
57-874-02	57-874-02	57-874-02-01		ZONAL (GV)	Leading Edge to Front Spar - Inbd of Nacelle Strut - Right Wing
57-876-02	57-876-02	57-876-02-01		ZONAL (GV)	Leading Edge to Front Spar - Inbd of Nacelle Strut - Right Wing
57-878-02	57-878-02	57-878-02-01		ZONAL (GV)	Krueger Flaps No. 3 and 4 - Right Wing
57-880-02	57-880-02	57-880-02-01		ZONAL (GV)	Krueger Flaps No. 3 and 4 - Right Wing
57-882-02	57-882-02	57-882-02-01		ZONAL (GV)	Leading Edge to Front Spar - Outbd of Nacelle Strut - Right Wing
57-884-02	57-884-02	57-884-02-01		ZONAL (GV)	Leading Edge to Front Spar - Outbd of Nacelle Strut - Right Wing



**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
57-886-02	57-886-02	57-886-02-01	W-27-229-00-02	ZONAL (GV)	Slats No. 5, 6, 7, 8, - Right Wing
57-888-02	57-888-02	57-888-02-01		ZONAL (GV)	Right Wing Tip
57-890-02	57-890-02	57-890-02-01		ZONAL (GV)	Right Wing Tip
57-892-02	57-892-02	57-892-02-01		ZONAL (GV)	Center Fuel Tank - Right Wing
57-894-02	57-894-02	57-894-02-01		ZONAL (GV)	Center Fuel Tank - Right Wing
57-896-02	57-896-02	57-896-02-01		ZONAL (GV)	Main Fuel Tank - Right Wing
57-898-02	57-898-02	57-898-02-01		ZONAL (GV)	Main Fuel Tank - Right Wing
57-900-02	57-900-02	57-900-02-01		ZONAL (GV)	Surge Tank - Right Wing
57-902-02	57-902-02	57-902-02-01		ZONAL (GV)	Surge Tank - Right Wing
57-904-02	57-904-02	57-904-02-01		ZONAL (GV)	Dry Bay - Right Wing
57-906-02	57-906-02	57-906-02-01		ZONAL (GV)	Fairing Flap Support No. 6 - Right Wing
57-908-02	57-908-02	57-908-02-01		ZONAL (GV)	Fairing Flap Support No. 6 - Right Wing
57-910-02	57-910-02	57-910-02-01		ZONAL (GV)	Fairing Flap Support No. 7 - Right Wing
57-912-02	57-912-02	57-912-02-01		ZONAL (GV)	Fairing Flap Support No. 7 - Right Wing
57-914-02	57-914-02	57-914-02-01		ZONAL (GV)	Fairing Flap Support No. 8 - Right Wing
57-916-02	57-916-02	57-916-02-01		ZONAL (GV)	Fairing Flap Support No. 8 - Right Wing
57-918-02	57-918-02	57-918-02-01		ZONAL (GV)	Rear Spar to Landing Gear Support Beam - Right Wing
57-920-02	57-920-02	57-920-02-01		ZONAL (GV)	Rear Spar to Landing Gear Support Beam - Right Wing
57-922-02	57-922-02	57-922-02-01		ZONAL (GV)	Inboard Spoiler No. 7 - Right Wing
57-924-02	57-924-02	57-924-02-01		ZONAL (GV)	Inboard Flaps - Right Wing
57-926-02	57-926-02	57-926-02-01		ZONAL (GV)	Inboard Main Flap - Right Wing
57-928-02	57-928-02	57-928-02-01		ZONAL (GV)	Rear Spar to T.E. - Outbd of Inbd Flap - Inbd of Fixed T.E. - Right Wing
57-930-02	57-930-02	57-930-02-01		ZONAL (GV)	Spoiler No 8, 9, 10, 11, 12 - Right Wing
57-932-02	57-932-02	57-932-02-01		ZONAL (GV)	Outboard Flaps - Right Wing





**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
57-934-02	57-934-02	57-934-02-01		ZONAL (GV)	Fixed Trailing Edge - Right Wing
57-936-02	57-936-02	57-936-02-01		ZONAL (GV)	Fixed Trailing Edge - Right Wing
57-938-02	57-938-02	57-938-02-01		ZONAL (GV)	Fixed Trailing Edge - Right Wing
57-940-02	57-940-02	57-940-02-01		ZONAL (GV)	Aileron - Right Wing
57-950-01	57-950-01	57-950-01-01		ZONAL (GV)	Winglet - Left Wing
57-952-01	57-952-01	57-952-01-01		ZONAL (GV)	Winglet - Left Wing
57-960-02	57-960-02	57-960-02-01		ZONAL (GV)	Winglet - Right Wing
57-962-02	57-962-02	57-962-02-01		ZONAL (GV)	Winglet - Right Wing
70-800-01	70-800-01	70-800-01-01		ZONAL (GV)	Powerplant No. 1
70-802-01	70-802-01	70-802-01-01		ZONAL (GV)	Engine No. 1
70-804-01	70-804-01	70-804-01-01		ZONAL (GV)	Fan Cowl - Engine No. 1
70-806-01	70-806-01	70-806-01-01		ZONAL (GV)	Thrust Reverser - Engine No. 1
70-808-01	70-808-01	70-808-01-01		ZONAL (GV)	Thrust Reverser - Engine No. 1
70-810-02	70-810-02	70-810-02-01		ZONAL (GV)	Powerplant No. 2
70-812-02	70-812-02	70-812-02-01		ZONAL (GV)	Engine No. 2
70-814-02	70-814-02	70-814-02-01		ZONAL (GV)	Fan Cowl - Engine No. 2
70-816-02	70-816-02	70-816-02-01		ZONAL (GV)	Thrust Reverser - Engine No. 2
70-818-02	70-818-02	70-818-02-01		ZONAL (GV)	Thrust Reverser - Engine No. 2
71-010-01	71-010-01	71-010-01-01		INSPECTION - DETAILED	Inlet Cowl - Inner Surface
71-010-02	71-010-02	71-010-02-01		INSPECTION - DETAILED	Inlet Cowl - Inner Surface
71-040-01	71-040-01	71-040-01-01		OPERATIONAL	Check Left Engine Drain Lines
71-040-02	71-040-02	71-040-02-01		OPERATIONAL	Check Right Engine Drain Lines



**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
72-020-01	72-020-01	72-020-01-01		INSPECTION - DETAILED	Left Engine Inlet and Fan Blades
72-020-02	72-020-02	72-020-02-01		INSPECTION - DETAILED	Right Engine Inlet and Fan Blades
72-025-01	72-025-01	72-025-01-01		LUBRICATE	Lubricate Left Engine Fan Blades Dovetail.
72-025-02	72-025-02	72-025-02-01		LUBRICATE	Lubricate Right Engine Fan Blades Dovetail.
72-030-01	72-030-01	72-030-01-01		REPLACE	Left Fan Disk
72-030-02	72-030-02	72-030-02-01		REPLACE	Right Fan Disk
72-040-01	72-040-01	72-040-01-01		REPLACE	Left Engine Booster Spool
72-040-02	72-040-02	72-040-02-01		REPLACE	Right Engine Booster Spool
72-050-01	72-050-01	72-050-01-01		REPLACE	Left Engine Fan Shaft
72-050-02	72-050-02	72-050-02-01		REPLACE	Right Engine Fan Shaft
72-070-01	72-070-01	72-070-01-01		VISUAL CHECK	Left Engine AGB/TGB Mount Flanges and Fan Case/Frame Mounts
72-070-02	72-070-02	72-070-02-01		VISUAL CHECK	Right Engine AGB/TGB Mount Flanges and Fan Case/Frame Mounts
72-100-01	72-100-01	72-100-01-01		VISUAL CHECK	Left Engine Attachment Bolts for the Thrust Mount Fittings
72-100-02	72-100-02	72-100-02-01		VISUAL CHECK	Right Engine Attachment Bolts for the Thrust Mount Fittings
72-110-01	72-110-01	72-110-01-01		VISUAL CHECK	Left Engine Thrust Mount Fittings
72-110-02	72-110-02	72-110-02-01		VISUAL CHECK	Right Engine Thrust Mount Fittings
72-130-01	72-130-01	72-130-01-01		REPLACE	Left Engine Stage 1 and 2 Spool
72-130-02	72-130-02	72-130-02-01		REPLACE	Right Engine Stage 1 and 2 Spool
72-140-01	72-140-01	72-140-01-01		REPLACE	Left Engine Stage 3 Disk
72-140-02	72-140-02	72-140-02-01		REPLACE	Right Engine Stage 3 Disk
72-150-01	72-150-01	72-150-01-01		REPLACE	Left Engine Stages 4 - 9 Spool
72-150-02	72-150-02	72-150-02-01		REPLACE	Right Engine Stages 4 - 9 Spool
72-160-01	72-160-01	72-160-01-01		REPLACE	Left Engine Front Shaft



**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MPD ITEM NUMBER**

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
72-160-02	72-160-02	72-160-02-01		REPLACE	Right Engine Front Shaft
72-170-01	72-170-01	72-170-01-01		REPLACE	Left Engine Rear Rotating (CDP) Seal
72-170-02	72-170-02	72-170-02-01		REPLACE	Right Engine Rear Rotating (CDP) Seal
72-180-01	72-180-01	72-180-01-01		INSPECTION - DETAILED	Left Engine Combustion Chamber
72-180-02	72-180-02	72-180-02-01		INSPECTION - DETAILED	Right Engine Combustion Chamber
72-190-01	72-190-01	72-190-01-01		INSPECTION - DETAILED	Left Engine Double Annular Combustion Chamber
72-190-02	72-190-02	72-190-02-01		INSPECTION - DETAILED	Right Engine Double Annular Combustion Chamber
72-200-01	72-200-01	72-200-01-01 72-200-01-02		INSPECTION - DETAILED	Left Engine HPT Nozzle
72-200-02	72-200-02	72-200-02-01 72-200-02-02		INSPECTION - DETAILED	Right Engine HPT Nozzle
72-210-01	72-210-01	72-210-01-01		INSPECTION - DETAILED	Left Engine HPT Blades
72-210-02	72-210-02	72-210-02-01		INSPECTION - DETAILED	Right Engine HPT Blades
72-220-01	72-220-01	72-220-01-01		REPLACE	Left Engine HPT Front Shaft
72-220-02	72-220-02	72-220-02-01		REPLACE	Right Engine HPT Front Shaft
72-230-01	72-230-01	72-230-01-01		REPLACE	Left HPT Front Rotating Air Seal
72-230-02	72-230-02	72-230-02-01		REPLACE	Right HPT Front Rotating Air Seal
72-240-01	72-240-01	72-240-01-01		REPLACE	Left Engine HPT Disk
72-240-02	72-240-02	72-240-02-01		REPLACE	Right Engine HPT Disk
72-250-01	72-250-01	72-250-01-01		REPLACE	Left Engine HPT Rear Shaft
72-250-02	72-250-02	72-250-02-01		REPLACE	Right Engine HPT Rear Shaft



# 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

## TASKS SORTED BY MPD ITEM NUMBER

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
72-270-01	72-270-01	72-270-01-01		REPLACE	Left Engine LPT Rotor Support
72-270-02	72-270-02	72-270-02-01		REPLACE	Right Engine LPT Rotor Support
72-280-01	72-280-01	72-280-01-01		REPLACE	Left Engine LPT Shaft
72-280-02	72-280-02	72-280-02-01		REPLACE	Right Engine LPT Shaft
72-290-01	72-290-01	72-290-01-01		REPLACE	Left Engine Stage 1, 2, 3, 4 LPT Disks
72-290-02	72-290-02	72-290-02-01		REPLACE	Right Engine Stage 1, 2, 3, 4 LPT Disks
72-300-01	72-300-01	72-300-01-01		VISUAL CHECK	Left Engine Stage Aft Mounts Clevis
72-300-02	72-300-02	72-300-02-01		VISUAL CHECK	Right Engine Stage Aft Mounts Clevis
72-320-01	72-320-01	72-320-01-01		INSPECTION - DETAILED	Left Engine Fwd Sump, Aft Sump, AGB/TGB MCD or DMS detectors and scavenge screens
72-320-02	72-320-02	72-320-02-01		INSPECTION - DETAILED	Right Engine Fwd Sump, Aft Sump, AGB/TGB MCD or DMS detectors and scavenge screens
73-010-01	73-010-01	73-010-01-01		REPLACE	Replace the Left Engine Fuel Filter
73-010-02	73-010-02	73-010-02-01		REPLACE	Replace the Right Engine Fuel Filter
73-020-01	73-020-01	73-020-01-01		OPERATIONAL	FMC CDU for Left Engine Faults
73-020-02	73-020-02	73-020-02-01		OPERATIONAL	FMC CDU for Right Engine Faults
73-030-01		73-030-01-01		RESTORE	Remove the Left Engine Hydro Mechanical Unit for Inspection
73-030-02		73-030-02-01		RESTORE	Remove the Right Engine Hydro Mechanical Unit for Inspection
74-020-01	74-020-01	74-020-01-01		INSPECTION - DETAILED	Ignition Leads
74-020-02	74-020-02	74-020-02-01		INSPECTION - DETAILED	Ignition Leads
78-011-01	78-011-01	78-011-01-01		INSPECTION - DETAILED	Left Engine Exhaust Plug
78-011-02	78-011-02	78-011-02-01		INSPECTION - DETAILED	Right Engine Exhaust Plug



# 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

## TASKS SORTED BY MPD ITEM NUMBER

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
78-050-01	78-050-01	78-050-01-01		VISUAL CHECK	Left Engine T/R Fan Duct Walls
78-050-02	78-050-02	78-050-02-01		VISUAL CHECK	Right Engine T/R Fan Duct Walls
78-060-01	78-060-01	78-060-01-01		INSPECTION - DETAILED	Left Engine Drag Link's Spherical Bearing
78-060-02	78-060-02	78-060-02-01		INSPECTION - DETAILED	Right Engine Drag Link's Spherical Bearing
78-070-01	78-070-01	78-070-01-01		VISUAL CHECK	Left Engine Blocker Doors
78-070-02	78-070-02	78-070-02-01		VISUAL CHECK	Right Engine Blocker Doors
78-080-01	78-080-01	78-080-01-01		VISUAL CHECK	Left Engine Bullnose Seal and Retainer
78-080-02	78-080-02	78-080-02-01		VISUAL CHECK	Right Engine Bullnose Seal and Retainer
78-100-01	78-100-01	78-100-01-01		INSPECTION - DETAILED	Left Engine T/R Fire Seal
78-100-02	78-100-02	78-100-02-01		INSPECTION - DETAILED	Right Engine T/R Fire Seal
78-110-01	78-110-01	78-110-01-01		OPERATIONAL	Left Engine T/R Sync Lock
78-110-02	78-110-02	78-110-02-01		OPERATIONAL	Right Engine T/R Sync Lock
78-120-01	78-120-01	78-120-01-01		OPERATIONAL	Left Engine Bite Check the EAU
78-120-02	78-120-02	78-120-02-01		OPERATIONAL	Right Engine Bite Check the EAU
78-130-01	78-130-01	78-130-01-01		OPERATIONAL	Left Engine "Reverser" Light Indication System
78-130-02	78-130-02	78-130-02-01		OPERATIONAL	Right Engine "Reverser" Light Indication System
79-010-01	79-010-01	79-010-01-01		REPLACE	Oil Supply Filter Element - Left Engine
79-010-02	79-010-02	79-010-02-01		REPLACE	Oil Supply Filter Element - Right Engine
79-040-01	79-040-01	79-040-01-01		REPLACE	Oil Scavenge Filter Element - Left Engine
79-040-02	79-040-02	79-040-02-01		REPLACE	Oil Scavenge Filter Element - Right Engine
80-010-01	80-010-01	80-010-01-01		INSPECTION - DETAILED	Magnetic Chip Detector - Left Engine Starter



## 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

*TASKS SORTED BY MPD ITEM NUMBER*

MPD ITEM NUMBER	MRB ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
80-010-02	80-010-02	80-010-02-01		INSPECTION - DETAILED	Magnetic Chip Detector - Right Engine Starter



**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
20-010-01	20-010-01	20-010-01-01		INSPECTION - GEN VISUAL	GVI of HIRF/L Sensitive Wire Runs Outside Pressure Vessel - Left
20-010-02	20-010-02	20-010-02-01		INSPECTION - GEN VISUAL	GVI of HIRF/L Sensitive Wire Runs Outside Pressure Vessel - Right
20-020-00	20-020-00	20-020-00-01		INSPECTION - GEN VISUAL	GVI of HIRF/L Sensitive Wire Runs Inside the Pressure Vessel
20-030-01	20-030-01	20-030-01-01		INSPECTION - DETAILED	DET of L/HIRF protection components Outside the Pressure Vessel - Left
20-030-02	20-030-02	20-030-02-01		INSPECTION - DETAILED	DET of L/HIRF protection components Outside the Pressure Vessel- Right
20-040-01	20-040-01	20-040-01-01		FUNCTIONAL	H/L Sensitive Connectors Outside the Pressure Vessel - Left
20-040-02	20-040-02	20-040-02-01		FUNCTIONAL	HIRF/L Sensitive Connectors Outside the Pressure Vessel - Right
20-040-04	20-040-04	20-040-04-01		FUNCTIONAL	L/HIRF Protection Components Outside the Pressure Vessel - Vertical Stabilizer
20-040-05	20-040-05	20-040-05-01 20-040-05-02		FUNCTIONAL	Lightning/HIRF Protection Components - Wing to Body Fairing
20-040-06	20-040-06	20-040-06-01 20-040-06-02		FUNCTIONAL	Lightning/HIRF Protection Components - Wing to Body Fairing
20-050-00	20-050-00	20-050-00-01		INSPECTION - DETAILED	DVI of HIRF/L Sensitive Connectors Inside Pressure Vessel
20-060-00	20-060-00	20-060-00-01		FUNCTIONAL	H/L Sensitive Connectors Inside Pressure Vessel
20-070-00	20-070-00	20-070-00-01		INSPECTION - DETAILED	DVI of HIRF/L Sensitive Pig Tails Inside the Pressure Vessel
20-100-00	20-100-00	20-100-00-01		INSPECTION - GEN VISUAL	GVI of HIRF/L Sensitive Bonding Straps (Flight Controls, Door)
20-110-01	20-110-01	20-110-01-01		INSPECTION - GEN VISUAL	Engine Harness (Cowl Open) - Left Engine
20-110-02	20-110-02	20-110-02-01		INSPECTION - GEN VISUAL	Engine Harness (Cowl Open) - Right Engine



# 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

## TASKS SORTED BY MRB ITEM NUMBER

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
20-120-01	20-120-01	20-120-01-01		INSPECTION - DETAILED	Connector Tightness - Left Engine
20-120-02	20-120-02	20-120-02-01		INSPECTION - DETAILED	Connector Tightness - Right Engine
20-130-01	20-130-01	20-130-01-01		INSPECTION - GEN VISUAL	Bonding Straps GVI - Left Engine
20-130-02	20-130-02	20-130-02-01		INSPECTION - GEN VISUAL	Bonding Straps GVI - Right Engine
20-140-00	20-140-00	20-140-00-01		FUNCTIONAL	HIRF/L Sensitive Connectors Inside the Empennage
20-141-00	20-141-00	20-141-00-01		FUNCTIONAL	Lightning/HIRF Protection Components - Tail Cone (L/HIRF)
20-142-01	20-142-01	20-142-01-01		FUNCTIONAL	Lightning/HIRF Protection Components Aft of E/E rack in the FWD Cargo Compartment
20-142-02	20-142-02	20-142-02-01		FUNCTIONAL	Lightning/HIRF Protection Components Aft of E/E rack in the FWD Cargo Compartment
20-142-03	20-142-03	20-142-03-01		FUNCTIONAL	Lightning/HIRF Protection Components Aft of E/E rack in the FWD Cargo Compartment
20-290-00	20-290-00	20-290-00-01		RESTORE	Area Forward of Nose Wheel Well
20-300-00	20-300-00	20-300-00-01		RESTORE	Area Above Nose Wheel Well And Outbd of Nose Wheel Well
20-305-00	20-305-00	20-305-00-01		INSPECTION - DETAILED	External power feeder wiring and connected EWIS
20-310-00	20-310-00	20-310-00-01		RESTORE	Electrical and Electronics Compartment
20-320-00	20-320-00	20-320-00-01		INSPECTION - DETAILED	Electrical and Electronics Compartment
20-325-00	20-325-00	20-325-00-01		INSPECTION - GEN VISUAL	Exposed EWIS in the Electrical and Electronics Compartment
20-330-00	20-330-00	20-330-00-01		RESTORE	Forward Cargo Compartment
20-335-00	20-335-00	20-335-00-01		INSPECTION - GEN VISUAL	Exposed EWIS in the Forward Cargo Compartment. (EZAP)





# 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

## TASKS SORTED BY MRB ITEM NUMBER

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
20-340-00	20-340-00	20-340-00-01	W-53-888-00-01 W-53-886-00-01 W-53-886-00-02	RESTORE	Area Below Forward Cargo Compartment
20-350-00	20-350-00	20-350-00-01		RESTORE	Area AFT of Forward Cargo Compartment
20-360-00	20-360-00	20-360-00-01		INSPECTION - GEN VISUAL	Main Landing Gear Wheel Well
20-370-00	20-370-00	20-370-00-01		RESTORE	Aft Cargo Compartment
20-375-00	20-375-00	20-375-00-01		INSPECTION - GEN VISUAL	Exposed EWIS in Aft Cargo Compartment
20-380-00	20-380-00	20-380-00-01		RESTORE	Area Below Aft Cargo Compartment
20-390-00	20-390-00	20-390-00-01		RESTORE	Aft Cargo Compartment Equipment Bay
20-400-00	20-400-00	20-400-00-01		RESTORE	Flight Compartment
20-410-00	20-410-00	20-410-00-01		INSPECTION - DETAILED	Flight Compartment
20-415-00	20-415-00	20-415-00-01		INSPECTION - GEN VISUAL	Exposed EWIS in Flight Compartment
20-420-00	20-420-00	20-420-00-01		RESTORE	Passenger Compartment - Aft of Control Compartment to Fwd Entry Door
20-430-00	20-430-00	20-430-00-01		RESTORE	Fwd Passenger Compartment - Fwd Entry Door to STA 663.75
20-435-00	20-435-00	20-435-00-01		RESTORE	Restore Passenger Compartment, Sta. 360 to 663.75
20-440-00	20-440-00	20-440-00-01		RESTORE	Aft Passenger Compartment - STA 663.75 to Aft Pressure Bulkhead
20-445-00	20-445-00	20-445-00-01		RESTORE	Restore Passenger Compartment STA 663.75 to Aft Pressure Bulkhead
20-450-00	20-450-00	20-450-00-01		INSPECTION - DETAILED	Area Aft of Pressure Bulkhead
20-460-00	20-460-00	20-460-00-01		INSPECTION - DETAILED	APU Compartment
20-465-00	20-465-00	20-465-00-01		INSPECTION - GEN VISUAL	Exposed EWIS in the tail cone



**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
20-470-00	20-470-00	20-470-00-01		INSPECTION - DETAILED	Engine No. 1
20-480-00	20-480-00	20-480-00-01		INSPECTION - DETAILED	Engine No. 2
20-490-00	20-490-00	20-490-00-01		INSPECTION - DETAILED	Fwd Strut Fairing - Engine No. 1
20-500-00	20-500-00	20-500-00-01		INSPECTION - DETAILED	Fan Cowl Support Beam - Engine No. 1
20-510-00	20-510-00	20-510-00-01		INSPECTION - DETAILED	Strut Torque Box - Engine No. 1
20-520-00	20-520-00	20-520-00-01		INSPECTION - DETAILED	Fwd Strut Fairing - Engine No. 2
20-530-00	20-530-00	20-530-00-01		INSPECTION - DETAILED	Fan Cowl Support Beam - Engine No. 2
20-540-00	20-540-00	20-540-00-01		INSPECTION - DETAILED	Strut Torque Box - Engine No. 2
20-550-00	20-550-00	20-550-00-01		INSPECTION - DETAILED	Leading Edge to Front Spar - Inboard of Nacelle Strut - Left Wing
20-560-00	20-560-00	20-560-00-01		INSPECTION - DETAILED	Leading Edge to Front Spar - Outboard of Nacelle Strut - Left Wing
20-570-00	20-570-00	20-570-00-01		INSPECTION - DETAILED	Rear Spar to Landing Gear Support Beam - Left Wing
20-580-00	20-580-00	20-580-00-01		INSPECTION - DETAILED	Rear Spar to T.E. - Outbd of Inbd Flap - Inbd of Fixed T.E. - Left Wing
20-590-00	20-590-00	20-590-00-01		INSPECTION - DETAILED	Leading Edge to Front Spar - Inboard of Nacelle Strut - Right Wing
20-600-00	20-600-00	20-600-00-01		INSPECTION - DETAILED	Leading Edge to Front Spar - Outboard of Nacelle Strut - Right Wing
20-610-00	20-610-00	20-610-00-01		INSPECTION - DETAILED	Rear Spar to Landing Gear Support Beam - Right Wing



# 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

## TASKS SORTED BY MRB ITEM NUMBER

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
20-620-00	20-620-00	20-620-00-01		INSPECTION - DETAILED	Rear Spar to T.E. - Outbd of Inbd Flap - Inbd of Fixed T.E. - Right Wing
21-010-00	21-010-00	21-010-00-01		REPLACE	Recirculation Fan Hepa Filter(s)
21-015-00	21-015-00	21-015-00-01		INSPECTION - DETAILED	Recirculation Fan Check Valve(s)
21-020-00	21-020-00	21-020-00-01		OPERATIONAL	Alternate E/E Cooling Supply Fan
21-030-00	21-030-00	21-030-00-01		OPERATIONAL	Alternate E/E Cooling Exhaust Fan
21-040-00	21-040-00	21-040-00-01		REPLACE	E/E Cooling Supply Fan Filter
21-050-00	21-050-00	21-050-00-01		OPERATIONAL	Overboard Exhaust Valve Check
21-060-00	21-060-00	21-060-00-01		OPERATIONAL	Outflow Valve Motor, Selector Panel, Indicator, Feed Back Module
21-070-00	21-070-00	21-070-00-01		FUNCTIONAL	Positive Pressure Relief Valves
21-080-00	21-080-00	21-080-00-01		REPLACE	Positive Pressure Relief Valves Filters
21-090-00	21-090-00	21-090-00-01		FUNCTIONAL	Negative Pressure Relief Door
21-100-00	21-100-00	21-100-00-01 21-100-00-03 21-100-00-04		RESTORE	Primary and Secondary Heat Exchangers
21-110-01	21-110-01	21-110-01-01		FUNCTIONAL	Compressor Discharge and Turbine Inlet Overheat Switches
21-110-02	21-110-02	21-110-02-01		FUNCTIONAL	Compressor Discharge and Turbine Inlet Overheat Switches
21-120-00	21-120-00	21-120-00-01 21-120-00-02		OPERATIONAL	Pack Overheat Switch
21-130-00	21-130-00	21-130-00-01		OPERATIONAL	Trim Air Pressure Regulator and Shutoff Valve
21-140-01	21-140-01	21-140-01-01		OPERATIONAL	Water Separator Indication Disk
21-140-02	21-140-02	21-140-02-01		OPERATIONAL	Water Separator Indication Disk
21-150-00	21-150-00	21-150-00-01		RESTORE	Cabin Temperature Sensor Filters
21-160-00	21-160-00	21-160-00-01		RESTORE	Ozone Converters



# 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

## TASKS SORTED BY MRB ITEM NUMBER

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
21-170-00	21-170-00	21-170-00-01		INSPECTION - DETAILED	Pack Supply Air Cleaner System
21-180-00	21-180-00	21-180-00-01		OPERATIONAL	Pack Supply Air Cleaner System
21-190-00	21-190-00	21-190-00-01		DISCARD	APU Boot Pressure Seal
23-030-00	23-030-00	23-030-00-01		FUNCTIONAL	Resistance of Static Discharges
23-040-00	23-040-00	23-040-00-01		OPERATIONAL	Voice Recorder
23-050-00	23-050-00	23-050-00-01		FUNCTIONAL	Voice Recorder for Audio Fidelity
23-052-00	23-052-00	23-052-00-01		DISCARD	RIPS System Battery
23-054-00	23-054-00	23-054-00-01		FUNCTIONAL	RIPS Capacity
23-056-00	23-056-00	23-056-00-01		FUNCTIONAL	RIPS Maintenance Port
23-060-00	23-060-00	23-060-00-01	W-23-070-00-01	OPERATIONAL	ULB (Underwater Locator Beacon) for Voice Recorder
23-070-00	23-070-00	23-070-00-01	W-23-060-00-01	REPLACE	ULB (Underwater Locator Beacon) for Voice Recorder
23-080-00	23-080-00	23-080-00-01		OPERATIONAL	Oxygen Mask Microphone
23-100-00	23-100-00	23-100-00-01 23-100-00-02 23-100-00-03		OPERATIONAL	Emergency Locator Transmitter (Automatic / Fixed Type)
23-110-00	23-110-00	23-110-00-01 23-110-00-02 23-110-00-03		DISCARD	Emergency Locator Transmitter (Automatic / Fixed Type)
23-120-00	23-120-00	23-120-00-01		FUNCTIONAL	Functionally check the underwater locator device
23-130-00	23-130-00	23-130-00-01		DISCARD	Discard the underwater locator device battery
24-010-01	24-010-01	24-010-01-01	W-24-040-01-01	SERVICE	IDG Oil - Left IDG
24-010-02	24-010-02	24-010-02-01	W-24-040-02-01	SERVICE	IDG Oil - Right IDG
24-020-01	24-020-01	24-020-01-01		INSPECTION - DETAILED	Left IDG Delta P Indicator (DPI)



# 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

## TASKS SORTED BY MRB ITEM NUMBER

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
24-020-02	24-020-02	24-020-02-01	W-24-010-01-01 W-24-010-02-01	INSPECTION - DETAILED	Right IDG Delta P Indicator (DPI)
24-030-01	24-030-01	24-030-01-01		INSPECTION - DETAILED	Left IDG Oil Level
24-030-02	24-030-02	24-030-02-01		INSPECTION - DETAILED	Right IDG Oil Level
24-040-01	24-040-01	24-040-01-01		REPLACE	Left IDG Charge and Scavenge Filters
24-040-02	24-040-02	24-040-02-01		REPLACE	Right IDG Charge and Scavenge Filters
24-050-01	24-050-01	24-050-01-01		FUNCTIONAL	Left QAD
24-050-02	24-050-02	24-050-02-01		FUNCTIONAL	Right QAD
24-060-01	24-060-01	24-060-01-01		INSPECTION - GEN VISUAL	Left Engine IDG Surface Air Cooled Oil Cooler
24-060-02	24-060-02	24-060-02-01		INSPECTION - GEN VISUAL	Right Engine IDG Surface Air Cooled Oil Cooler
24-080-00	24-080-00	24-080-00-01		OPERATIONAL	Standby Power Control Unit (SPCU)
24-090-00	24-090-00	24-090-00-02		RESTORE	Restore the Main Battery
24-100-00	24-100-00	24-100-00-01		OPERATIONAL	Standby Power Control Unit (SPCU)
24-110-00	24-110-00	24-110-00-01		OPERATIONAL	Remote Control Circuit Breaker
24-120-00	24-120-00	24-120-00-01		RESTORE	Restore the Main and Auxiliary Batteries
24-130-00	24-130-00	24-130-00-01		FUNCTIONAL	External Power Receptacle (Wear Check)
24-140-00	24-140-00	24-140-00-01		INSPECTION - DETAILED	External Power Receptacle (Inspection)
25-010-01	25-010-01	25-010-01-01		INSPECTION - DETAILED	Captains Seat Tracks and Locking Mechanism
25-010-02	25-010-02	25-010-02-01		INSPECTION - DETAILED	First Officer seat tracks and locking mechanism
25-020-00	25-020-00	25-020-00-01		INSPECTION - DETAILED	Flight Compartment Crew Seat Harnesses, Straps, and Belts



## 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

### TASKS SORTED BY MRB ITEM NUMBER

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
25-030-00	25-030-00	25-030-00-01		OPERATIONAL	Check Captain, First Officer, & First Observer Seat Harness Inertia Reels
25-040-00	25-040-00	25-040-00-01		INSPECTION - DETAILED	Inspect Passenger Seat Belts
25-041-00	25-041-00	25-041-00-01		OPERATIONAL	Inflatable Seat Restraint System Operational Check
25-042-00	25-042-00	25-042-00-01		INSPECTION - DETAILED	Inflatable Seat Restraint System Detailed Inspection
25-043-00	25-043-00	25-043-00-01		DISCARD	Inflatable Seat Restraint System Inflator
25-044-00	25-044-00	25-044-00-01		RESTORE	Inflatable Seat Restraint System Electronics Module Assembly
25-045-00	25-045-00	25-045-00-01		INSPECTION - DETAILED	Passenger Compartment Seats
25-050-00	25-050-00	25-050-00-01		OPERATIONAL	Check Passenger Seat Break-Over Feature
25-070-00	25-070-00	25-070-00-01		FUNCTIONAL	Inspect Passenger Seat Back Recline Mechanisms
25-090-00	25-090-00	25-090-00-01		INSPECTION - DETAILED	Inspect Attendant Seat Harness
25-100-00	25-100-00	25-100-00-01		OPERATIONAL	Check Attendant Seat Harness
25-130-00	25-130-00	25-130-00-01		INSPECTION - DETAILED	Lavatory Waste Compartment Flapper Door and Spring and Access Door
25-160-00	25-160-00	25-160-00-01 25-160-00-02		INSPECTION - GEN VISUAL	Inspect Cargo Compartment Panels/Liners
25-165-00	25-165-00	25-165-00-01		INSPECTION - GEN VISUAL	Inspect Main Deck Cargo Compartment Panels/Liners
25-170-00	25-170-00	25-170-00-01 25-170-00-02		INSPECTION - GEN VISUAL	Inspect Cargo Door Restraint System
25-190-01	25-190-01	25-190-01-01		INSPECTION - DETAILED	Left Emergency Exit Hatch Escape Straps
25-190-02	25-190-02	25-190-02-01		INSPECTION - DETAILED	Right Emergency Exit Hatch Escape Straps



## 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

### TASKS SORTED BY MRB ITEM NUMBER

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
25-210-00	25-210-00	25-210-00-01		INSPECTION - DETAILED	Inspect Flight Compartment Escape Lanyards
25-220-00	25-220-00	25-220-00-01		OPERATIONAL	Emergency Escape System Operational Check
25-225-00	25-225-00	25-225-00-01		OPERATIONAL	Mid-Exit Door Emergency Escape System Operational Check
25-240-00	25-240-00	25-240-00-01 25-240-00-02 25-240-00-03 25-240-00-04		RESTORE	Emergency Escape Slides
25-245-00	25-245-00	25-245-00-01 25-245-00-02		RESTORE	Mid-Exit Doors Emergency Escape Slides
25-290-00	25-290-00	25-290-00-01		RESTORE	Restore Life Jackets
25-300-00	25-300-00	25-300-00-01		RESTORE	Restore Life Rafts
25-305-00	25-305-00	25-305-00-01		RESTORE	Restore Flight Deck Life Raft
25-330-00	25-330-00	25-330-00-01		OPERATIONAL	Power Megaphones
25-340-00	25-340-00	25-340-00-01		REPLACE	Power Megaphones Batteries
25-350-00	25-350-00	25-350-00-01		OPERATIONAL	Emergency Locator Transmitter (Survival / Portable Type)
25-360-00	25-360-00	25-360-00-01		DISCARD	Emergency Locator Transmitter (Survival / Portable Type) - Batteries
25-370-00	25-370-00	25-370-00-01		VISUAL CHECK	Detachable Emergency Equipment
25-380-00	25-380-00	25-380-00-01 25-380-00-02	W-25-390-00-01 W-25-395-00-01	OPERATIONAL	Emergency Flashlights
25-390-00	25-390-00	25-390-00-01	W-25-380-00-01	REPLACE	Emergency Flashlights Batteries
25-395-00	25-395-00	25-395-00-01	W-25-380-00-01	RESTORE	Restore Emergency Flashlight Batteries
25-400-00	25-400-00	25-400-00-01		INSPECTION - DETAILED	Smoke Hoods
25-410-00	25-410-00	25-410-00-01		DISCARD	Smoke Hoods
25-420-00	25-420-00	25-420-00-01		RESTORE	First Aid Kits



# 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

## TASKS SORTED BY MRB ITEM NUMBER

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
25-430-00	25-430-00	25-430-00-01		RESTORE	Medical Kits
25-440-00	25-440-00	25-440-00-01		OPERATIONAL	Emergency Alert Panels
25-450-00	25-450-00	25-450-00-01 25-450-00-02		INSPECTION - GEN VISUAL	Pallet Locks, Forward End Stops, and Aft End Stops
25-460-00	25-460-00	25-460-00-01		INSPECTION - GEN VISUAL	Main Deck Cargo Barrier Net Receptacle Fittings
25-470-00	25-470-00	25-470-00-01		INSPECTION - DETAILED	Main Deck Cargo Barrier Net and Fittings
25-480-00	25-480-00	25-480-00-01		FUNCTIONAL	Main Deck Cargo Barrier Net Test Strap
26-010-00	26-010-00	26-010-00-01		OPERATIONAL	Lavatory Smoke Detector
26-018-00	26-018-00	26-018-00-01		OPERATIONAL	Wing and Lower Aft Body Overheat Detection
26-020-00	26-020-00	26-020-00-01		RESTORE	Lavatory Smoke Detector Grill Cleaning
26-030-00	26-030-00	26-030-00-01		OPERATIONAL	APU Remote Fire Detection System
26-050-00	26-050-00	26-050-00-01		VISUAL CHECK	Engine Fire Bottle Pressure Gauges
26-070-00	26-070-00	26-070-00-01		REPLACE	Engine Fire Bottle Squib
26-080-00	26-080-00	26-080-00-01		FUNCTIONAL	Engine Fire Extinguishing System Squib Circuit
26-090-00	26-090-00	26-090-00-01		OPERATIONAL	Engine Fire Extinguishing System Check Valve
26-100-00	26-100-00	26-100-00-01	W-26-100-00-01 W-26-120-00-01 W-26-130-00-01	FUNCTIONAL	Engine Fire Bottle Pressure Switch
26-110-00	26-110-00	26-110-00-01	W-29-100-00-01	OPERATIONAL	Engine Fire Handle for Engine Shutdown and Isolation
26-120-00	26-120-00	26-120-00-01	W-26-090-00-01 W-26-100-00-01 W-26-130-00-01	FUNCTIONAL	Engine Fire Bottle Pressure Gauge





## 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

### TASKS SORTED BY MRB ITEM NUMBER

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
26-130-00	26-130-00	26-130-00-01	W-26-090-00-01 W-26-100-00-01 W-26-120-00-01	DISCARD	Engine Fire Bottle Pressure Relief Disc.
26-140-00	26-140-00	26-140-00-01		FUNCTIONAL	Engine Fire Bottle Weight Check
26-150-00	26-150-00	26-150-00-01		FUNCTIONAL	Engine Fire Extinguisher Distribution System
26-170-00	26-170-00	26-170-00-01		INSPECTION - GEN VISUAL	Engine Fire Extinguisher Distribution System
26-210-00	26-210-00	26-210-00-01		REPLACE	APU Fire Bottle Squib
26-220-00	26-220-00	26-220-00-01		FUNCTIONAL	APU Fire Extinguishing System Squib Circuit
26-230-00	26-230-00	26-230-00-01		OPERATIONAL	APU Fire Handle for APU Shutdown and Isolation
26-250-00	26-250-00	26-250-00-01		INSPECTION - GEN VISUAL	APU Remote Control Panel
26-260-00	26-260-00	26-260-00-01		FUNCTIONAL	APU Fire Bottle Pressure Switch
26-265-00	26-265-00	26-265-00-01		FUNCTIONAL	APU Fire Bottle Pressure Gauge
26-270-00	26-270-00	26-270-00-01		DISCARD	APU Fire Bottle Over Pressure Relief Disc
26-275-00	26-275-00	26-275-00-01		FUNCTIONAL	APU Fire Bottle Weight Check
26-280-00	26-280-00	26-280-00-01		INSPECTION - DETAILED	APU Fire Extinguisher Distribution System
26-290-00	26-290-00	26-290-00-01		FUNCTIONAL	Lavatory Fire Bottle Weight Check
26-300-00	26-300-00	26-300-00-01		INSPECTION - DETAILED	Lavatory Fire Bottle Fusible Tips and Discharge
26-310-00	26-310-00	26-310-00-01		VISUAL CHECK	Lavatory Heat Sensitive Tape
26-330-00	26-330-00	26-330-00-01 26-330-00-02		REPLACE	Cargo Fire Bottle Squib
26-340-00	26-340-00	26-340-00-01 26-340-00-02 26-340-00-03 26-340-00-04		FUNCTIONAL	Cargo Fire Extinguishing Tubing



# 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

## TASKS SORTED BY MRB ITEM NUMBER

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
26-360-00	26-360-00	26-360-00-01 26-360-00-02	W-26-400-00-01 W-26-400-00-03 W-26-400-00-04	FUNCTIONAL	Cargo Fire Bottle Pressure Switch
26-365-00	26-365-00	26-365-00-01 26-365-00-02		FUNCTIONAL	Cargo Fire Bottle(s) Weight Check
26-370-00	26-370-00	26-370-00-01 26-370-00-02 26-370-00-03 26-370-00-04		OPERATIONAL	Cargo Fire Extinguishing Arm/Discharge Switches
26-390-00	26-390-00	26-390-00-01		REPLACE	Cargo Fire Extinguishing System
26-400-00	26-400-00	26-400-00-01 26-400-00-03 26-400-00-04	W-26-370-00-02 W-26-370-00-03 W-26-370-00-04	FUNCTIONAL	Cargo Fire Extinguishing 60-Minute Timer
26-410-00	26-410-00	26-410-00-01	W-26-370-00-02 W-26-370-00-03 W-26-370-00-04	OPERATIONAL	Cargo Fire Protection Operation Check
26-411-00	26-411-00	26-411-00-01		OPERATIONAL	Cargo Fire Protection Air supply Shutoff Valves Operational Check
26-412-00	26-412-00	26-412-00-01		OPERATIONAL	Cargo Fire Protection Mix Manifold Exhaust Shutoff Valves Operational Check
26-414-00	26-414-00	26-414-00-01		OPERATIONAL	Pressurization Control Panel Outflow Valve Operational Check
26-420-00	26-420-00	26-420-00-01		RESTORE	Main Deck Cargo Compartment Ceiling Grill Cleaning
26-430-00	26-430-00	26-430-00-01		OPERATIONAL	Operationally Check the Forward Galley Smoke Detector
26-440-00	26-440-00	26-440-00-01		RESTORE	Forward Galley Smoke Detector Grill Cleaning
26-450-00	26-450-00	26-450-00-01		INSPECTION - DETAILED	Portable Halon Fire Extinguishers Inspection
26-470-00	26-470-00	26-470-00-01		INSPECTION - DETAILED	Portable Water Fire Extinguisher Inspection
26-490-00	26-490-00			INSPECTION - DETAILED	Inspect Portable Carbon Dioxide Fire Extinguishers
26-510-00	26-510-00	26-510-00-01		INSPECTION - DETAILED	Inspect Portable Chemical Fire Extinguishers



## 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

### TASKS SORTED BY MRB ITEM NUMBER

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
27-011-00	27-011-00	27-011-00-01	W-27-078-00-01 W-27-210-00-01 W-27-212-00-01	INSPECTION - GEN VISUAL	Aileron Mechanical Components
27-012-00	27-012-00	27-012-00-01		INSPECTION - GEN VISUAL	Aileron Transfer Mechanism
27-013-01	27-013-01	27-013-01-01		INSPECTION - GEN VISUAL	Left Wing Aileron Mechanical Components
27-013-02	27-013-02	27-013-02-01		INSPECTION - GEN VISUAL	Right Wing Aileron Mechanical Components
27-016-00	27-016-00	27-016-00-01		OPERATIONAL	Aileron Spring Cartridge and Transfer Mechanism
27-018-00	27-018-00	27-018-00-01		FUNCTIONAL	Aileron Spring Cartridge and Transfer Mechanism
27-022-00	27-022-00	27-022-00-01		FUNCTIONAL	Aileron Power Control Units
27-024-00	27-024-00	27-024-00-01		FUNCTIONAL	Aileron PCU Internal Leakage Test
27-026-01	27-026-01	27-026-01-01		LUBRICATE	Left Wing Aileron Lubrication
27-026-02	27-026-02	27-026-02-01		LUBRICATE	Right Wing Aileron Lubrication
27-028-00	27-028-00	27-028-00-01	W-27-035-00-01 W-27-035-00-02	INSPECTION - DETAILED	Aileron Feel and Centering Springs
27-030-00	27-030-00	27-030-00-01		OPERATIONAL	Full Range Aileron Travel
27-032-00	27-032-00	27-032-00-01		FUNCTIONAL	Aileron Wheel Forces
27-033-00	27-033-00	27-033-00-01 27-033-00-02		FUNCTIONAL	Wing Aileron Tab Freeplay Inspection
27-034-01	27-034-01	27-034-01-01		INSPECTION - DETAILED	Left Wing Aileron Balance Bay Seals
27-034-02	27-034-02	27-034-02-01		INSPECTION - DETAILED	Right Wing Aileron Balance Bay Seals
27-035-00	27-035-00	27-035-00-01 27-035-00-02	W-27-033-00-01 W-27-033-00-02	FUNCTIONAL	Wing Aileron Surface Freeplay Inspection



**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
27-036-00	27-036-00	27-036-00-01	W-27-048-00-01 W-27-047-00-01	INSPECTION - DETAILED	Rudder Aft Components
27-038-00	27-038-00	27-038-00-01		INSPECTION - DETAILED	Forward Rudder Mechanical Control Path
27-040-00	27-040-00	27-040-00-01		LUBRICATE	Feel and Centering Spring Lubrication
27-041-00	27-041-00	27-041-00-01		OPERATIONAL	Operational Check of the Main Rudder PCU Force Fight Monitor
27-043-00	27-043-00	27-043-00-01		OPERATIONAL	Operational Check of Rudder PCU Overrides
27-044-00	27-044-00	27-044-00-01		FUNCTIONAL	Rudder PCU Internal Leakage Check
27-046-00	27-046-00	27-046-00-01		LUBRICATE	Rudder PCU and Hinge Lubrication
27-047-00	27-047-00	27-047-00-01		FUNCTIONAL	Rudder PCU Internal Leakage Check
27-048-00	27-048-00	27-048-00-01		FUNCTIONAL	RUDDER AUTHORITY LIMITER
27-050-00	27-050-00	27-050-00-01		OPERATIONAL	Rudder PCU Pressure Reducing Valve
27-054-00	27-054-00	27-054-00-01		FUNCTIONAL	Standby Rudder PCU Internal Leakage Test
27-056-00	27-056-00	27-056-00-01		INSPECTION - GEN VISUAL	Standby Rudder Power Control Unit
27-058-00	27-058-00	27-058-00-01		INSPECTION - DETAILED	Standby Rudder PCU Attachment Points
27-060-00	27-060-00	27-060-00-01 27-060-00-02		OPERATIONAL	Wheel to Rudder Interconnect
27-062-00	27-062-00	27-062-00-01 27-062-00-02		OPERATIONAL	Rudder Trim Travel
27-064-00	27-064-00	27-064-00-01 27-064-00-02		FUNCTIONAL	Rudder Surface Freeplay
27-068-00	27-068-00	27-068-00-01		OPERATIONAL	Elevator Feel Shift Function
27-070-00	27-070-00	27-070-00-01 27-070-00-02		LUBRICATE	Elevator Lubrication



**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
27-073-00	27-073-00	27-073-00-01	W-27-024-00-01 W-27-210-00-01 W-27-212-00-01	INSPECTION - GEN VISUAL	Elevator Mechanical Control Path
27-074-00	27-074-00	27-074-00-01		OPERATIONAL	Elevator Range of Travel
27-075-01	27-075-01	27-075-01-01		INSPECTION - GEN VISUAL	Left Elevator Balance Weight and Tab Control Mechanism
27-075-02	27-075-02	27-075-02-01		INSPECTION - GEN VISUAL	Right Elevator Balance Weight and Tab Control Mechanism
27-076-00	27-076-00	27-076-00-01		INSPECTION - GEN VISUAL	Elevator Power Control Unit Inspection
27-078-00	27-078-00	27-078-00-01		FUNCTIONAL	Elevator PCU Internal Leakage Test
27-080-00	27-080-00	27-080-00-01		FUNCTIONAL	Elevator Pitot Static Tube
27-084-00	27-084-00	27-084-00-01		FUNCTIONAL	Elevator Control Column Override
27-086-00	27-086-00	27-086-00-01		OPERATIONAL	Elevator Tab Control
27-088-00	27-088-00	27-088-00-01		FUNCTIONAL	Stall Warning System
27-092-00	27-092-00	27-092-00-01		FUNCTIONAL	Elevator Input Rod Pogo's
27-093-00	27-093-00	27-093-00-01 27-093-00-02		INSPECTION - DETAILED	Elevator Tab and Tab Mechanism Inspection Left and Right
27-094-00	27-094-00	27-094-00-01		OPERATIONAL	Elevator Autopilot Servo Pressure Regulator
27-095-00	27-095-00	27-095-00-01 27-095-00-02		INSPECTION - DETAILED	Elevator Tab and Tab Mechanism Inspection
27-097-00	27-097-00	27-097-00-01 27-097-00-02		FUNCTIONAL	Elevator Balance Tab Freeplay Check
27-098-01	27-098-01	27-098-01-01		FUNCTIONAL	Elevator Surface Freeplay Check
27-099-00	27-099-00	27-099-00-01 27-099-00-02		FUNCTIONAL	Elevator Balance Tab Freeplay Check



## 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

### TASKS SORTED BY MRB ITEM NUMBER

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
27-100-00	27-100-00	27-100-00-01	W-27-107-00-01 W-27-106-00-01	INSPECTION - DETAILED	Elevator Pushrods
27-101-00	27-101-00	27-101-00-01		INSPECTION - DETAILED	Feel and Centering Single Element Dual Load Path Components
27-102-00	27-102-00	27-102-00-01		LUBRICATE	Stabilizer Trim Actuator Lubrication
27-104-00	27-104-00	27-104-00-01		LUBRICATE	Forward Stabilizer Trim Drive Train
27-106-00	27-106-00	27-106-00-01		FUNCTIONAL	Secondary Stabilizer Trim Brake
27-107-00	27-107-00	27-107-00-01		SERVICE	Stabilizer Trim Brake Servicing
27-108-00	27-108-00	27-108-00-01		RESTORE	Stabilizer Trim Restoration
27-110-00	27-110-00	27-110-00-01		INSPECTION - DETAILED	Stabilizer Trim Jackscrew Inspection
27-112-00	27-112-00	27-112-00-01		OPERATIONAL	Stabilizer Trim Limit Switches
27-114-00	27-114-00	27-114-00-01		OPERATIONAL	Control Column Switching Module
27-116-00	27-116-00	27-116-00-01		OPERATIONAL	Control Column Cutout Switches
27-118-00	27-118-00	27-118-00-01		OPERATIONAL	Stabilizer Trim Override Switch
27-120-00	27-120-00	27-120-00-01		INSPECTION - DETAILED	Stabilizer Trim Forward Mechanism
27-121-00	27-121-00	27-121-00-01		INSPECTION - GEN VISUAL	Forward Stabilizer Trim Mechanism and the Speedbrake Lever Assembly
27-122-00	27-122-00	27-122-00-01		OPERATIONAL	Stabilizer Trim Switches
27-132-00	27-132-00	27-132-00-01		SERVICE	Flap Power Drive Unit
27-134-00	27-134-00	27-134-00-01		SERVICE	Flap Power Drive Unit
27-136-01	27-136-01	27-136-01-01		LUBRICATE	Left Wing Flap Skew Sensor Mechanism Lubrication
27-136-02	27-136-02	27-136-02-01		LUBRICATE	Right Wing Flap Skew Sensor Mechanism Lubrication
27-138-00	27-138-00	27-138-00-01 27-138-00-02		LUBRICATE	Wing Flap Drive Torque Tubes



**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
27-140-01	27-140-01	27-140-01-01		SERVICE	Left Wing Flap Transmission Oil Level
27-140-02	27-140-02	27-140-02-01		SERVICE	Right Wing Flap Transmission Oil Level
27-142-01	27-142-01	27-142-01-01		SERVICE	Left Wing Flap Transmission Oil
27-142-02	27-142-02	27-142-02-01		SERVICE	Right Wing Flap Transmission Universal Oil
27-144-00	27-144-00	27-144-00-01 27-144-00-02		LUBRICATE	Wing Flap Ballscrew Assemblies and Transmission Universal Joints Lubrication
27-148-03	27-148-03	27-148-03-01		INSPECTION - DETAILED	Left Wing Ballscrew Assembly
27-148-04	27-148-04	27-148-04-01		INSPECTION - DETAILED	Right Wing Ballscrew Assembly
27-152-01	27-152-01	27-152-01-01		LUBRICATE	#4 Flap Transmission Angle/Tee GearBox Universal Joints
27-152-02	27-152-02	27-152-02-01		LUBRICATE	#5 Flap Transmission Angle/Tee GearBox Universal Joints
27-154-00	27-154-00	27-154-00-01		OPERATIONAL	Flap Load Relief System
27-156-00	27-156-00	27-156-00-01		FUNCTIONAL	Flap Load Relief System
27-158-00	27-158-00	27-158-00-01		FUNCTIONAL	Alternate Flap Drive System
27-162-00	27-162-00	27-162-00-01		OPERATIONAL	Flap Skew and Asymmetry System
27-164-00	27-164-00	27-164-00-01		OPERATIONAL	Flap Uncommanded Motion Protection
27-166-00	27-166-00	27-166-00-01		INSPECTION - DETAILED	Flap Lever Sensor
27-168-01	27-168-01	27-168-01-01		OPERATIONAL	Left Wing Flap Transmission No-Back Brake
27-168-02	27-168-02	27-168-02-01		OPERATIONAL	Right Wing Flap Transmission No-Back Brake
27-170-01	27-170-01	27-170-01-01		LUBRICATE	Left Wing Flap Actuation Mechanism Lubrication
27-170-02	27-170-02	27-170-02-01		LUBRICATE	Right Wing Flap Actuation Mechanism Lubrication
27-171-01	27-171-01	27-171-01-01		INSPECTION - GEN VISUAL	Left Wing Flap Drive System



## 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

### TASKS SORTED BY MRB ITEM NUMBER

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
27-171-02	27-171-02	27-171-02-01		INSPECTION - GEN VISUAL	Right Wing Flap Drive System
27-172-01	27-172-01	27-172-01-01		INSPECTION - DETAILED	Left Wing Flap Actuation System
27-172-02	27-172-02	27-172-02-01		INSPECTION - DETAILED	Right Wing Flap Actuation System
27-174-01	27-174-01	27-174-01-01		LUBRICATE	Left Wing Forward Flap Track Attachment Pin
27-174-02	27-174-02	27-174-02-01		LUBRICATE	Right Wing Forward Flap Track Attachment Pin
27-176-01	27-176-01	27-176-01-01		LUBRICATE	Left Wing Inboard Flap Track Attachment Fitting
27-176-02	27-176-02	27-176-02-01		LUBRICATE	Right Wing Inboard Flap Track Attachment Fitting
27-178-00	27-178-00	27-178-00-01		SERVICE	Alternate Flap Drive Gearbox Servicing
27-182-00	27-182-00	27-182-00-01		LUBRICATE	Lubricate the Spoiler Mechanical Control Path (Spoiler Mixer)
27-182-01	27-182-01	27-182-01-01		LUBRICATE	Left Wing Spoiler Mechanical Control Path Lubrication
27-182-02	27-182-02	27-182-02-01		LUBRICATE	Right Wing Spoiler Mechanical Control Path Lubrication
27-184-00	27-184-00	27-184-00-01		FUNCTIONAL	Spoiler Ratio Changer No-Back Assembly
27-186-00	27-186-00	27-186-00-01		LUBRICATE	Speedbrake Lever No-Back Brake
27-187-00	27-187-00	27-187-00-01		OPERATIONAL	Operationally Check the Speedbrake Handle Stop
27-188-00	27-188-00	27-188-00-01 27-188-00-02		OPERATIONAL	Speedbrake RTO System
27-190-00	27-190-00	27-190-00-01		OPERATIONAL	Speedbrake Extended Light
27-191-00	27-191-00	27-191-00-01		FUNCTIONAL	Speedbrake Autostow System Functional Check
27-192-01	27-192-01	27-192-01-01		OPERATIONAL	Left Wing Spoiler Actuator Override Quadrants
27-192-02	27-192-02	27-192-02-01		OPERATIONAL	Right Wing Spoiler Actuator Override Quadrants
27-194-00	27-194-00	27-194-00-01		OPERATIONAL	Spoiler Mixer Centering Mechanism
27-196-00	27-196-00	27-196-00-01		FUNCTIONAL	Functionally Check the Spoiler Electrical Control System Relays for Continuity





# 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

## TASKS SORTED BY MRB ITEM NUMBER

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
27-210-00	27-210-00	27-210-00-01	W-27-024-00-01 W-27-078-00-01 W-27-212-00-01	FUNCTIONAL	Leading Edge Slat Actuators Internal Leakage Test
27-212-00	27-212-00	27-212-00-01	W-27-024-00-01 W-27-078-00-01 W-27-210-00-01	FUNCTIONAL	Leading Edge Flap Actuators Internal Leakage Test
27-214-00	27-214-00	27-214-00-01	W-29-240-00-01	OPERATIONAL	Leading Edge Standby Actuation
27-215-01	27-215-01	27-215-01-01		INSPECTION - GEN VISUAL	Left Wing Spoiler Actuators
27-215-02	27-215-02	27-215-02-01		INSPECTION - GEN VISUAL	Right Wing Spoiler Actuators
27-215-03	27-215-03	27-215-03-01		INSPECTION - GEN VISUAL	Spoiler Mechanical Control Path
27-216-00	27-216-00	27-216-00-01		FUNCTIONAL	Autoslat System
27-218-00	27-218-00	27-218-00-01		OPERATIONAL	Leading Edge Uncommanded Motion Protection
27-220-01	27-220-01	27-220-01-01		LUBRICATE	Left Wing Leading Edge Slat Roller Lubrication
27-220-02	27-220-02	27-220-02-01		LUBRICATE	Right Wing Leading Edge Slat Roller Lubrication
27-222-01	27-222-01	27-222-01-01		LUBRICATE	Left Wing Leading Edge Slat Tracks
27-222-02	27-222-02	27-222-02-01		LUBRICATE	Right Wing Leading Edge Slat Tracks
27-224-00	27-224-00	27-224-00-01		OPERATIONAL	Standby Hydraulic System Leading Edge Uncommanded Motion
27-225-01	27-225-01	27-225-01-01		INSPECTION - GEN VISUAL	Left Wing Leading Edge Flap and Slat Actuators and Actuation Mechanism
27-225-02	27-225-02	27-225-02-01		INSPECTION - GEN VISUAL	Right Wing Leading Edge Flap and Slat Actuators and Actuation Mechanism
27-226-00	27-226-00	27-226-00-01 27-226-00-02 27-226-00-03 27-226-00-04	W-32-440-00-02 W-32-440-00-03	INSPECTION - DETAILED	Flight Control Cables



# 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

## TASKS SORTED BY MRB ITEM NUMBER

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
27-228-00	27-228-00	27-228-00-01 27-228-00-02 27-228-00-03 27-228-00-04 27-228-00-05 27-228-00-06 27-228-00-07 27-228-00-08		INSPECTION - DETAILED	Flight Control Cables
27-229-00	27-229-00	27-229-00-01 27-229-00-02	W-57-856-01-01 W-57-926-02-01	INSPECTION - DETAILED	Inboard Trailing Edge Aft Flap Drive Cable Inspection
27-230-00	27-230-00	27-230-00-01 27-230-00-02	W-32-460-00-01 W-32-460-00-02	INSPECTION - DETAILED	Flight Control Cables
27-235-00	27-235-00	27-235-00-01 27-235-00-02		FUNCTIONAL	Flight Control Cable Tension
28-010-00	28-010-00	28-010-00-01		INSPECTION - GEN VISUAL	Inspect Fuel Tanks Lower Surface - External
28-020-01	28-020-01	28-020-01-01		OPERATIONAL	Operationally Check Left Surge Tank Pressure Relief Valves
28-020-02	28-020-02	28-020-02-01		OPERATIONAL	Operationally Check Right Surge Tank Pressure Relief Valves
28-030-01	28-030-01	28-030-01-01		INSPECTION - DETAILED	Inspect (Detailed) the Left Surge Tank Vent Flame Arrestor
28-030-02	28-030-02	28-030-02-01		INSPECTION - DETAILED	Inspect (Detailed) the Right Surge Tank Vent Flame Arrestor
28-040-00	28-040-00	28-040-00-01		OPERATIONAL	Operationally Check Center Tank Fuel Scavenge System
28-050-00	28-050-00	28-050-00-01		OPERATIONAL	ENGINE FUEL SUCTION FEED
28-054-00	28-054-00	28-054-00-01		OPERATIONAL	GFI Relay Check
28-056-00	28-056-00	28-056-00-01		FUNCTIONAL	Center Tank Fuel Pump Power Failed On Protection System
28-060-01	28-060-01	28-060-01-01		RESTORE	Restore (Clean) Left Main Fuel Tank Scavenger Jet Pump
28-060-02	28-060-02	28-060-02-01		RESTORE	Restore (Clean) Right Main Fuel Tank Scavenger Jet Pump
28-060-03	28-060-03	28-060-03-01		RESTORE	Restore (Clean) the Center Fuel Tank Left and Right Water Scavenger Jet Pump



# 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

## TASKS SORTED BY MRB ITEM NUMBER

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
28-070-00	28-070-00	28-070-00-01		FUNCTIONAL	Functionally (Pressure Decay) Check the APU Fuel Line Shroud
28-080-00	28-080-00	28-080-00-01		OPERATIONAL	Operationally (Bite) Check the Fuel Quantity Indicating System
28-115-00	28-115-00	28-115-00-01		FUNCTIONAL	Center Tank Boost Pump Auto Shutoff Test
28-125-00	28-125-00	28-125-00-01		OPERATIONAL	Engine Fuel Spar and APU Shutoff Valve Battery
28-130-00	28-130-00	28-130-00-01		DISCARD	Engine Spar and APU Fuel Shut-Off Valve Battery Restoration
28-140-00	28-140-00	28-140-00-01 28-140-00-02 28-140-00-03		INSPECTION - DETAILED	Inspect (Detailed) the Tubing, Static Ground Straps and Clamps, No. 1, 2 and Center Tank (SFAR 88)
28-150-00	28-150-00	28-150-00-01 28-150-00-02		FUNCTIONAL	FUNCTIONAL CHECK OF THE FUEL PUMP BONDING TO STRUCTURE - LEFT AND RIGHT WING (SFAR 88)
28-160-00	28-160-00	28-160-00-01		FUNCTIONAL	FUNCTIONAL CHECK OF BONDING RESISTANCE OF APU DC FUEL PUMP (SFAR 88)
28-170-00	28-170-00	28-170-00-01 28-170-00-02 28-170-00-03		INSPECTION - DETAILED	DETAILED INSPECTION IN-TANK FQIS (SFAR 88) (EZAP)
28-171-00	28-171-00	28-171-00-01 28-171-00-02 28-171-00-03		INSPECTION - DETAILED	Detailed Inspection of FQIS components (SFAR 88)
28-173-00	28-173-00	28-173-00-01		FUNCTIONAL	Functional Check of FQIS wire bundle lightning shield to ground termination (SFAR 88)
28-180-00	28-180-00	28-180-00-01		FUNCTIONAL	Functional Check of the Equipment Fault Current Ground Strap for HSP (SFAR 88)
28-181-00	28-181-00	28-181-00-01		INSPECTION - DETAILED	Inspect (detailed) the equipment current ground straps for the Densitometer Hot Short Protector (SFAR 88)
28-201-00	28-201-00	28-201-00-01		FUNCTIONAL	Functional check of bonding resistance between the hydraulic line fitting and structure (SFAR 88)
28-204-00	28-204-00	28-204-00-01		FUNCTIONAL	Functional Check of the Bonding of Air Vent to the Door Structure (SFAR 88)



# 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

## TASKS SORTED BY MRB ITEM NUMBER

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
28-205-00	28-205-00	28-205-00-01		FUNCTIONAL	Functional Check the Bonding of Pressure Relief Valve to the Structure (SFAR 88)
28-207-00	28-207-00	28-207-00-01		FUNCTIONAL	Functional Check of Shutoff Valves Actuator to structure (SFAR 88)
28-208-00	28-208-00	28-208-00-01		FUNCTIONAL	Functional Check of the Bonding of the Fueling Receptacle to Structure (SFAR 88)
28-211-00	28-211-00	28-211-00-01 28-211-00-02		FUNCTIONAL	Functional Check of the Bonding of MOV actuator to the Structure (SFAR 88)
28-213-00	28-213-00	28-213-00-01		FUNCTIONAL	Functional check of the Bonding of APU Shutoff valve to Structure (SFAR 88)
29-005-00	29-005-00	29-005-00-01		OPERATIONAL	A & B Engine Driven Pump Depressurization Solenoid Valve
29-010-00	29-010-00	29-010-00-01		FUNCTIONAL	Internal Hydraulic System Leakage
29-020-00	29-020-00	29-020-00-01 29-020-00-02		REPLACE	Hydraulic System "A" and "B" Pressure Filter Elements (EMDP Pumps)
29-030-01	29-030-01	29-030-01-01		REPLACE	EMDP Case Drain Filter
29-030-02	29-030-02	29-030-02-01		REPLACE	EMDP Case Drain Filter
29-050-01	29-050-01	29-050-01-01		REPLACE	EDP Case Drain Filter
29-050-02	29-050-02	29-050-02-01		REPLACE	EDP Case Drain Filter
29-070-00	29-070-00	29-070-00-01 29-070-00-02		RESTORE	Reservoir Pressurization Module Filter
29-080-00	29-080-00	29-080-00-01		FUNCTIONAL	EMDP Ground Fault Protection System
29-090-00	29-090-00	29-090-00-01		VISUAL CHECK	A & B System Return Filter Module
29-100-00	29-100-00	29-100-00-01	W-26-110-00-01	OPERATIONAL	A & B System Engine Pump (EDP) Shutoff Valves
29-110-00	29-110-00	29-110-00-01		FUNCTIONAL	Nose Landing Gear (NLG) Down Line Fuse
29-120-00	29-120-00	29-120-00-01		FUNCTIONAL	Nose Landing Gear (NLG) up Line Fuse
29-130-00	29-130-00	29-130-00-01	W-29-300-00-01	FUNCTIONAL	Thrust Reverser A System EMDP Fuse
29-140-00	29-140-00	29-140-00-01	W-29-290-00-01	FUNCTIONAL	Leading Edge B System Fuses
29-150-00	29-150-00	29-150-00-01	W-29-160-00-01	FUNCTIONAL	B System Brake Fuses



**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
29-160-00	29-160-00	29-160-00-01	W-29-150-00-01	FUNCTIONAL	A System Brake Fuses
29-170-00	29-170-00	29-170-00-01		FUNCTIONAL	B System Rudder Fuse
29-180-00	29-180-00	29-180-00-01		REPLACE	Reservoir Fill Filter
29-200-00	29-200-00	29-200-00-01		OPERATIONAL	Standby Hydraulic Electric Motor Driven Pump
29-210-00	29-210-00	29-210-00-01		REPLACE	Standby Hydraulic Pressure Filter
29-220-00	29-220-00	29-220-00-01		REPLACE	Standby Hydraulic System Case Drain Filter
29-230-00	29-230-00	29-230-00-01	W-27-214-00-01	OPERATIONAL	Standby Rudder System
29-240-00	29-240-00	29-240-00-01		OPERATIONAL	Leading Edge Standby Actuation
29-250-00	29-250-00	29-250-00-01		OPERATIONAL	Power Transfer Unit Control System
29-260-00	29-260-00	29-260-00-01		FUNCTIONAL	Power Transfer Unit
29-270-00	29-270-00	29-270-00-01		REPLACE	Power Transfer Unit Pressure Filter
29-290-00	29-290-00	29-290-00-01	W-29-140-00-01	FUNCTIONAL	Leading Edge Standby Fuse
29-300-00	29-300-00	29-300-00-01	W-29-130-00-01	FUNCTIONAL	Thrust Reverser Standby Fuse
29-310-00	29-310-00	29-310-00-01		FUNCTIONAL	Case Drain Warning Switches
30-010-00	30-010-00	30-010-00-01		OPERATIONAL	Automatic Air Data Sensor Heat
31-010-00	31-010-00	31-010-00-01		FUNCTIONAL	Aural Warning System
31-020-00	31-020-00	31-020-00-01		FUNCTIONAL	Cabin Pressure Switch
31-030-00	31-030-00	31-030-00-01		OPERATIONAL	Mach/Airspeed System 1 and 2 Discrete Outputs
31-040-00	31-040-00	31-040-00-01		OPERATIONAL	Landing Gear Logic Module to the AWM Systems 1 and 2
31-050-00	31-050-00	31-050-00-01		FUNCTIONAL	Takeoff Warning for the Aural Warning System
31-120-00	31-120-00	31-120-00-01		FUNCTIONAL	Download FDR Data Req'd Parameters to Check Interfacing Systems
		31-120-00-02			
		31-120-00-03			
		31-120-00-04			
		31-120-00-05			



# 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

## TASKS SORTED BY MRB ITEM NUMBER

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
31-140-00	31-140-00	31-140-00-01	W-31-150-00-01	OPERATIONAL	DFDR ULB OPS Check
31-150-00	31-150-00	31-150-00-01	W-31-140-00-01	REPLACE	DFDR ULB Battery Replacement
31-160-01	31-160-01	31-160-01-01		RESTORE	Captain's Display Units Ventilation Hole Cleaning
31-160-02	31-160-02	31-160-02-01		RESTORE	First Officer's Display Units Ventilation Hole Cleaning
32-010-01	32-010-01	32-010-01-01		CLEAN/INSP	Left Main Gear Shock Strut Cleaning
32-010-02	32-010-02	32-010-02-01		CLEAN/INSP	Right Main Gear Shock Strut Cleaning
32-020-01	32-020-01	32-020-01-01		SERVICE	Left Main Landing Gear Servicing
32-020-02	32-020-02	32-020-02-01		SERVICE	Right Main Landing Gear Servicing
32-030-01	32-030-01	32-030-01-01		LUBRICATE	Left Main Landing Gear Lubrication
32-030-02	32-030-02	32-030-02-01		LUBRICATE	Right Main Landing Gear Lubrication
32-040-01	32-040-01	32-040-01-01	W-32-720-01-01	RESTORE	Left Main Landing Gear Restoration
32-040-02	32-040-02	32-040-02-01	W-32-720-02-01	RESTORE	Right Main Landing Gear Restoration
32-050-01	32-050-01	32-050-01-01		REPLACE	Left Main Landing Gear Discard
32-050-02	32-050-02	32-050-02-01		REPLACE	Right Main Landing Gear Discard
32-060-00	32-060-00	32-060-00-01		CLEAN/INSP	Clean Nose Gear Shock Strut
32-070-00	32-070-00	32-070-00-01		SERVICE	Nose Gear Shock Strut Service
32-080-00	32-080-00	32-080-00-01		LUBRICATE	Nose Gear Lubrication
32-085-00	32-085-00	32-085-00-01		INSPECTION - DETAILED	Nose Landing Gear Axle inspection
32-090-00	32-090-00	32-090-00-01	W-32-750-00-01	RESTORE	Restore Nose Landing Gear
32-100-00	32-100-00	32-100-00-01		REPLACE	Discard Nose Gear
32-110-00	32-110-00	32-110-00-01		INSPECTION - DETAILED	Landing Gear Selector Valve
32-120-00	32-120-00	32-120-00-01		INSPECTION - DETAILED	Nose Landing Gear Inspection



## 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

### TASKS SORTED BY MRB ITEM NUMBER

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
32-150-00	32-150-00	32-150-00-01 32-150-00-02		INSPECTION - DETAILED	Main Landing Gear Inspection
32-200-00	32-200-00	32-200-00-01		FUNCTIONAL	Nose Gear Manual Extension
32-220-00	32-220-00	32-220-00-01 32-220-00-02		FUNCTIONAL	Manual Extension System
32-230-00	32-230-00	32-230-00-01 32-230-00-02		FUNCTIONAL	Main Gear Wheel Well Protection Retract Pressure Fuse
32-240-00	32-240-00	32-240-00-01		OPERATIONAL	Landing Gear Transfer Valve
32-250-00	32-250-00	32-250-00-01		INSPECTION - DETAILED	Brake Control Linkage and Quadrants
32-260-00	32-260-00	32-260-00-01		INSPECTION - DETAILED	Brake Metering Valve Inspection
32-270-01	32-270-01	32-270-01-01		INSPECTION - GEN VISUAL	Left Main Gear Brake Wear Pins
32-270-02	32-270-02	32-270-02-01		INSPECTION - GEN VISUAL	Right Main Gear Brake Wear Pins
32-290-00	32-290-00	32-290-00-01		OPERATIONAL	Alternate Brake System
32-300-00	32-300-00	32-300-00-01		SERVICE	Brake Accumulator Precharge Pressure
32-310-00	32-310-00	32-310-00-01		OPERATIONAL	Brake Accumulator Isolation Valve
32-330-00	32-330-00	32-330-00-01		INSPECTION - DETAILED	Parking Brake Mechanical Control Path
32-340-00	32-340-00	32-340-00-01		FUNCTIONAL	Parking Brake System
32-350-00	32-350-00	32-350-00-01	W-32-360-00-01	SERVICE	Tire Inflation Check
32-360-00	32-360-00	32-360-00-01	W-32-350-00-01	INSPECTION - GEN VISUAL	Nose and Main Gear Tires and Wheels
32-380-00	32-380-00	32-380-00-01		RESTORE	Nose Wheel Assemblies
32-380-01	32-380-01	32-380-01-01		RESTORE	Left Main Gear Wheel Assemblies



# 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

## TASKS SORTED BY MRB ITEM NUMBER

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
32-380-02	32-380-02	32-380-02-01		RESTORE	Right Main Gear Wheel Assemblies
32-390-00	32-390-00	32-390-00-01		INSPECTION - DETAILED	Nose Wheel Steering Control Path
32-400-00	32-400-00	32-400-00-01		INSPECTION - DETAILED	Steering Actuator Rod Ends
32-420-00	32-420-00	32-420-00-01		OPERATIONAL	PSEU Operational Check
32-430-00	32-430-00	32-430-00-01		VISUAL CHECK	Tail Skid Inspection
32-440-00	32-440-00	32-440-00-01 32-440-00-02 32-440-00-03	W-27-226-00-01 W-27-226-00-02	INSPECTION - DETAILED	Landing Gear Control Cables
32-450-00	32-450-00	32-450-00-01 32-450-00-02 32-450-00-03 32-450-00-04 32-450-00-05		INSPECTION - DETAILED	Landing Gear Control System Cables
32-460-00	32-460-00	32-460-00-01 32-460-00-02	W-27-230-00-01 W-27-230-00-02	INSPECTION - DETAILED	Landing Gear Control System Cables
32-480-00	32-480-00	32-480-00-01		OPERATIONAL	Operationally BITE-check the SPSEU
32-490-00	32-490-00	32-490-00-01		OPERATIONAL	Tailskid Actuator and Mechanism
32-720-01	32-720-01	32-720-01-01	W-32-040-01-01	GENERAL VISUAL	Left Main Landing Gear Assembly
32-720-02	32-720-02	32-720-02-01	W-32-040-02-01	GENERAL VISUAL	Right Main Landing Gear Assembly
32-750-00	32-750-00	32-750-00-01	W-32-090-00-01	GENERAL VISUAL	Nose Landing Gear Assembly
32-800-00	32-800-00	32-800-00-01		ZONAL (GV)	Nose Landing Gear and Landing Gear Doors (from Ground)
32-804-01	32-804-01	32-804-01-01		ZONAL (GV)	Left Main Landing Gear and Landing Gear Doors (from Ground)
32-806-01	32-806-01	32-806-01-01		ZONAL (GV)	Left Main Landing Gear and Landing Gear Doors





**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
32-808-02	32-808-02	32-808-02-01		ZONAL (GV)	Right Main Landing Gear and Landing Gear Doors (From Ground)
32-810-02	32-810-02	32-810-02-01		ZONAL (GV)	Right Main Landing Gear and Landing Gear Doors
33-010-00	33-010-00	33-010-00-01 33-010-00-02 33-010-00-03		OPERATIONAL	Emergency Lights
33-020-00	33-020-00	33-020-00-01 33-020-00-02 33-020-00-03		OPERATIONAL	Emergency Lighting Switch Operational Test
33-055-00	33-055-00	33-055-00-01 33-055-00-02		FUNCTIONAL	Emergency Battery Pack Capacity Functional Check
33-060-00	33-060-00	33-060-00-01 33-060-00-02		RESTORE	Emergency Lighting - Battery Pack Restoration
33-065-00	33-065-00	33-065-00-01		FUNCTIONAL	Self Illuminating Exit Signs
33-070-00	33-070-00	33-070-00-01		FUNCTIONAL	Photoluminescent Floor Proximity Lighting
33-080-00	33-080-00	33-080-00-01		REPLACE	Replace Photoluminescent Floor Proximity Lighting
33-090-00	33-090-00	33-090-00-01		INSPECTION - GEN VISUAL	Winglet Leading Edge Lens
34-030-00	34-030-00	34-030-00-01 34-030-00-10		FUNCTIONAL	Pitot Static System Leak Check
34-060-00	34-060-00	34-060-00-01 34-060-00-10		FUNCTIONAL	Pitot Static System Leak Check
34-060-10	34-060-10	34-060-10-01 34-060-10-02		FUNCTIONAL	Air Data System - Altimetry System
34-070-00	34-070-00	34-070-00-01 34-070-00-10		INSPECTION - DETAILED	Pitot Probes
34-070-01	34-070-01	34-070-01-01		INSPECTION - DETAILED	Pitot Probes
34-080-00	34-080-00	34-080-00-01		INSPECTION - DETAILED	Static Ports



**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
34-090-00	34-090-00	34-090-00-01 34-090-00-02	R-35-USF-02-01 R-35-USK-02-01	INSPECTION - DETAILED	Pitot Systems
34-100-00	34-100-00	34-100-00-01 34-100-00-02		INSPECTION - DETAILED	Static Systems
34-105-00	34-105-00	34-105-00-01		OPERATIONAL	Source Select Panel Inertial Reference System Transfer Switch
34-130-00	34-130-00	34-130-00-01		REPLACE	Integrated Standby Flight Display
34-140-00	34-140-00	34-140-00-01		OPERATIONAL	Integrated Standby Flight Display
35-010-00	35-010-00	35-010-00-01		OPERATIONAL	Flight Crew Oxygen Mask/Regulator
35-011-00	35-011-00	35-011-00-01		OPERATIONAL	Gaseous Oxygen Mask/Regulator Operational Check
35-012-00	35-012-00	35-012-00-01		OPERATIONAL	Operational Check Each Cylinder Oxygen Mask/Regulator
35-020-00	35-020-00	35-020-00-01		FUNCTIONAL	Flight Crew Oxygen Mask/Regulator
35-021-00	35-021-00	35-021-00-01		FUNCTIONAL	Gaseous Oxygen Mask/Regulator Functional Check
35-040-00	35-040-00	35-040-00-01 35-040-00-02		REPLACE	Flight Crew Oxygen Cylinder
35-041-00	35-041-00	35-041-00-01		REPLACE	Flight Crew Oxygen Cylinder
35-050-00	35-050-00	35-050-00-01		VISUAL CHECK	Flight Crew Oxygen Cylinder
35-052-00	35-052-00	35-052-00-01		VISUAL CHECK	Flight Crew Oxygen Cylinder
35-060-00	35-060-00	35-060-00-01 35-060-00-02		VISUAL CHECK	Chemical Oxygen Generator Temperature Sensitive Tape
35-065-00	35-065-00	35-065-00-01 35-065-00-02		VISUAL CHECK	Lavatory Oxygen Constant Dispensing System (CDS).
35-070-00	35-070-00	35-070-00-01 35-070-00-02 35-070-00-03 35-070-00-04 35-070-00-05		REPLACE	Chemical Oxygen Generators



**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
35-075-00	35-075-00	35-075-00-01		DISCARD	Lavatory Oxygen CDS system cylinder
35-080-00	35-080-00	35-080-00-01 35-080-00-02 35-080-00-03	W-35-085-00-01 W-35-085-00-02 W-35-085-00-03	FUNCTIONAL	Passenger Oxygen System
35-085-00	35-085-00	35-085-00-01 35-085-00-02 35-085-00-03	W-35-080-00-01 W-35-080-00-02 W-35-080-00-03	OPERATIONAL	Passenger Oxygen System Manual Actuation
35-090-00	35-090-00	35-090-00-01 35-090-00-02 35-090-00-03 35-090-00-04		INSPECTION - DETAILED	Passenger Oxygen Masks
35-100-00	35-100-00	35-100-00-01		INSPECTION - GEN VISUAL	Portable Oxygen Cylinders
35-120-00	35-120-00	35-120-00-01 35-120-00-02		REPLACE	Portable Oxygen Cylinders
35-150-00	35-150-00	35-150-00-01		OPERATIONAL	Manual Shutoff Valve Sensor
35-163-00	35-163-00	35-163-00-01 35-163-00-02		DISCARD	GASEOUS PASSENGER OXYGEN SYSTEM
35-164-00	35-164-00	35-164-00-01		FUNCTIONAL	Gaseous passenger oxygen flow control units.
35-165-00	35-165-00	35-165-00-01		FUNCTIONAL	Passenger gaseous oxygen low pressure distribution system
35-166-00	35-166-00	35-166-00-01		FUNCTIONAL	Passenger gaseous oxygen system pressure regulators.
35-167-00	35-167-00	35-167-00-01		OPERATIONAL	Check Valve Operational Check
36-020-01	36-020-01	36-020-01-01		FUNCTIONAL	Precooler Control Valve and Wing TAI Solenoid - Left
36-020-02	36-020-02	36-020-02-01		FUNCTIONAL	Precooler Control Valve and Wing TAI Solenoid - Right
36-030-01	36-030-01	36-030-01-01		FUNCTIONAL	Precooler Control Valve Sensor - Left
36-030-02	36-030-02	36-030-02-01		FUNCTIONAL	Precooler Control Valve Sensor - Right
38-015-00	38-015-00	38-015-00-01		OPERATIONAL	Forward Gray Water Drain Valve



**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
38-030-00	38-030-00	38-030-00-01		RESTORE	Restore Vacuum Blower Filter
38-040-00	38-040-00	38-040-00-01		RESTORE	Restore Waste Drain Ball-Valve
38-060-00	38-060-00	38-060-00-01		REPLACE	Replace Bleed Air In-Line Filter
38-070-00	38-070-00	38-070-00-01		DISINFECT	Disinfect Potable Water System
38-090-00	38-090-00	38-090-00-01		RESTORE	Waste Tank Water Separator
38-100-00	38-100-00	38-100-00-01		RESTORE	Waste Tank Water Separator
47-200-00	47-200-00	47-200-00-02		VISUAL CHECK	NGS Drain - Fluid Accumulation
47-210-00	47-210-00	47-210-00-01		OPERATIONAL	Center Tank Cross Vent Check Valve
47-220-00	47-220-00	47-220-00-01		INSPECTION - DETAILED	NEA distribution lines inspection
47-300-00	47-300-00	47-300-00-01		RESTORE	Ozone Converter
47-310-00	47-310-00	47-310-00-01		CLEAN	Nitrogen generation system heat exchanger
47-400-00	47-400-00	47-400-00-01		FUNCTIONAL	Thermal switch
49-010-00	49-010-00	49-010-00-01		INSPECTION - GEN VISUAL	APU Mounts
49-020-00	49-020-00	49-020-00-01		INSPECTION - DETAILED	APU Mounts
49-030-00	49-030-00	49-030-00-01		INSPECTION - DETAILED	Sigma Seal
49-040-00	49-040-00	49-040-00-01		INSPECTION - DETAILED	APU Insulation Panels
49-052-00	49-052-00	49-052-00-01	W-49-062-00-01 W-49-072-00-01 W-49-082-00-01	REPLACE	Engine Compressor Impeller
49-062-00	49-062-00	49-062-00-01	W-49-052-00-01 W-49-072-00-01 W-49-082-00-01	REPLACE	First Stage Turbine Disk



# 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

## TASKS SORTED BY MRB ITEM NUMBER

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
49-072-00	49-072-00	49-072-00-01	W-49-052-00-01 W-49-062-00-01 W-49-082-00-01	REPLACE	Second Stage Turbine Rotor
49-082-00	49-082-00	49-082-00-01	W-49-052-00-01 W-49-062-00-01 W-49-072-00-01	REPLACE	Turbine Shaft
49-102-00	49-102-00	49-102-00-01		REPLACE	Fuel Inlet Filter Element
49-140-00	49-140-00	49-140-00-01		OPERATIONAL	CDU'S APU Maintenance Pages
49-172-00	49-172-00	49-172-00-01		INSPECTION - DETAILED	APU Exhaust Seal
49-212-00	49-212-00	49-212-00-01		INSPECTION - GEN VISUAL	APU Eductor
49-220-00	49-220-00	49-220-00-01		INSPECTION - DETAILED	APU Eductor Inlet Duct
49-240-00	49-240-00	49-240-00-01		LUBRICATE	APU Vortex Generator Hinge Pin
52-010-00	52-010-00	52-010-00-01 52-010-00-02 52-010-00-03 52-010-00-04		LUBRICATE	Service and Entry Door Lubrication
52-020-00	52-020-00	52-020-00-01 52-020-00-02 52-020-00-03 52-020-00-04		LUBRICATE	Service and Entry Door Lubrication
52-030-00	52-030-00	52-030-00-01		INSPECTION - DETAILED	Forward Entry Door Inspection
52-040-00	52-040-00	52-040-00-01 52-040-00-02 52-040-00-03		INSPECTION - DETAILED	Service and Entry Door Centering Guide Bearing



# 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

## TASKS SORTED BY MRB ITEM NUMBER

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
52-050-00	52-050-00	52-050-00-01 52-050-00-02 52-050-00-03 52-050-00-04		INSPECTION - GEN VISUAL	Service and Entry Door Seals
52-090-00	52-090-00	52-090-00-01 52-090-00-02		LUBRICATE	Forward and Aft Cargo Compartment Door Lubrication
52-100-00	52-100-00	52-100-00-01 52-100-00-02		INSPECTION - GEN VISUAL	Forward and Aft Cargo Door Seal
52-120-00	52-120-00	52-120-00-01		LUBRICATE	E/E Access Door Lubrication
52-130-00	52-130-00	52-130-00-01		INSPECTION - GEN VISUAL	E/E Access Door Seal
52-140-00	52-140-00	52-140-00-01		INSPECTION - GEN VISUAL	Forward Access Door Seal
52-150-00	52-150-00	52-150-00-01		LUBRICATE	Airstair Door System Lubrication
52-160-00	52-160-00	52-160-00-01		LUBRICATE	Airstair System Lubrication
52-170-00	52-170-00	52-170-00-01		INSPECTION - DETAILED	Airstair System Inspection
52-180-00	52-180-00	52-180-00-01		INSPECTION - GEN VISUAL	Airstair Door Pressure Seal Inspection
52-200-00	52-200-00	52-200-00-01 52-200-00-02		OPERATIONAL	Door Sensor Check
52-202-00	52-202-00	52-202-00-01		OPERATIONAL	MID EXIT DOOR LATCH AND LOCK SWITCHES
52-220-00	52-220-00	52-220-00-01		OPERATIONAL	Automatic Emergency Door Operational Check
52-222-00	52-222-00	52-222-00-01		OPERATIONAL	MID EXIT DOOR OPERATIONAL CHECK
52-230-00	52-230-00	52-230-00-01		INSPECTION - DETAILED	Inspection of Automatic Emergency Exit Door Components
52-232-00	52-232-00	52-232-00-01		INSPECTION - DETAILED	MID EXIT DOOR INSPECTION
52-240-00	52-240-00	52-240-00-01		OPERATIONAL	Automatic Emergency Exit Door Flight Lock Operational Check



**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
52-242-00	52-242-00	52-242-00-01		OPERATIONAL	MID EXIT DOOR FLIGHT LOCK OPERATIONAL CHECK
52-250-00	52-250-00	52-250-00-01		INSPECTION - DETAILED	Automatic Emergency Door Flight Lock Inspection
52-262-00	52-262-00	52-262-00-01		INSPECTION - DETAILED	MID EXIT DOOR PRESSURE SEAL INSPECTION
52-263-00	52-263-00	52-263-00-01		INSPECTION - DETAILED	MID EXIT DOOR VENT DOOR SEAL INSPECTION
52-264-00	52-264-00	52-264-00-01 52-264-00-02		INSPECTION - DETAILED	MID EXIT DOOR PRESSURE SEAL INSPECTION
52-265-00	52-265-00	52-265-00-01		INSPECTION - DETAILED	MID EXIT DOOR VENT DOOR SEAL INSPECTION
52-280-00	52-280-00	52-280-00-01		INSPECTION - DETAILED	Crew Door Seals
52-290-00	52-290-00	52-290-00-01		INSPECTION - GEN VISUAL	Main Deck Cargo Door
52-300-00	52-300-00	52-300-00-01		LUBRICATE	Main Deck Cargo Door Lubrication
52-305-00	52-305-00	52-305-00-01		LUBRICATE	Lift Linkages, Latch Cams and Lock Torque Tube Lubrications
52-310-00	52-310-00	52-310-00-01		INSPECTION - DETAILED	Main Deck Cargo Door Lift Actuator Linkage
52-320-00	52-320-00	52-320-00-01 52-320-00-02		OPERATIONAL	Main Deck Cargo Door Manual Pump
52-325-00	52-325-00	52-325-00-01		OPERATIONAL	Operationally check the manual operation of PULL-IN/LATCH ACTUATOR and LOCK ACTUATOR
52-330-00	52-330-00	52-330-00-01		INSPECTION - DETAILED	Main Deck Cargo Door Lift Actuator Attachment Points
52-340-00	52-340-00	52-340-00-01		OPERATIONAL	Main Deck Cargo Door Unlock Switch
52-350-00	52-350-00	52-350-00-01		OPERATIONAL	Main Deck Cargo Door Control Panel Operational Check
52-360-00	52-360-00	52-360-00-01		FUNCTIONAL	Flight Deck Door Decompression Panel Latches/Pressure Switches



# 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

## TASKS SORTED BY MRB ITEM NUMBER

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
52-370-00	52-370-00	52-370-00-01		OPERATIONAL	Flight Deck Door Decompression Panel Hinges
52-380-00	52-380-00	52-380-00-01		INSPECTION - GEN VISUAL	Flight Deck Door Decompression Panel Hinges
52-390-00	52-390-00	52-390-00-01		INSPECTION - GEN VISUAL	Flight Deck Door Seals for Condition and Security
52-400-00	52-400-00	52-400-00-01		INSPECTION - GEN VISUAL	Flight Deck Door Decompression Panel Seals
52-410-00	52-410-00	52-410-00-01		FUNCTIONAL	Deny Time Delay and Deny Function
52-510-00	52-510-00	52-510-00-01		DETAILED	Forward Access Door Stop Fittings and Pins
52-530-00	52-530-00	52-530-00-01		GENERAL VISUAL	Forward Access Door
52-540-00	52-540-00	52-540-00-01		DETAILED	E/E Equipment Compartment Access Door Stop Fittings and Pins
52-550-00	52-550-00	52-550-00-01		DETAILED	E/E Equipment Compartment Access Door
52-570-00	52-570-00	52-570-00-01		GENERAL VISUAL	E/E Equipment Compartment Access Door
52-580-00	52-580-00	52-580-00-01		DETAILED	Forward Airstairs Door Stop Fittings and Pins
52-590-00	52-590-00	52-590-00-01		GENERAL VISUAL	Forward Airstairs Door
52-600-00	52-600-00	52-600-00-01		GENERAL VISUAL	Forward Airstairs Door
52-610-00	52-610-00	52-610-00-01 52-610-00-02 52-610-00-03 52-610-00-04		DETAILED	Entry and Galley Service Doors
52-620-00	52-620-00	52-620-00-01 52-620-00-02 52-620-00-03 52-620-00-04		DETAILED	Entry and Galley Service Doors





**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
52-650-00	52-650-00	52-650-00-01 52-650-00-02 52-650-00-03 52-650-00-04		GENERAL VISUAL	Entry and Galley Service Doors
52-670-00	52-670-00	52-670-00-01 52-670-00-02		DETAILED	Cargo Doors
52-680-00	52-680-00	52-680-00-01 52-680-00-02		DETAILED	Cargo Doors
52-710-00	52-710-00	52-710-00-01 52-710-00-02		GENERAL VISUAL	Cargo Doors
52-730-00	52-730-00	52-730-00-01 52-730-00-02		DETAILED	Automatic Overwing Exit Doors
52-740-00	52-740-00	52-740-00-01 52-740-00-02		DETAILED	Automatic Overwing Exit Doors
52-760-00	52-760-00	52-760-00-01 52-760-00-02		GENERAL VISUAL	Automatic Overwing Exit Doors
52-762-00	52-762-00	52-762-00-01 52-762-00-02		GENERAL VISUAL	Mid Emergency Exit Door
52-764-00	52-764-00	52-764-00-01 52-764-00-02		DETAILED	Mid Emergency Exit Door
52-766-00	52-766-00	52-766-00-01 52-766-00-02		GENERAL VISUAL	Mid Emergency Exit Door
52-768-00	52-768-00	52-768-00-01 52-768-00-02		DETAILED	Mid Emergency Exit Door
52-770-00	52-770-00	52-770-00-01		DETAILED	Main Deck Cargo Door
52-780-00	52-780-00	52-780-00-01		DETAILED	Main Deck Cargo Door
52-790-00	52-790-00	52-790-00-01		GENERAL VISUAL	Main Deck Cargo Door



**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
52-800-00	52-800-00	52-800-00-01		ZONAL (GV)	Entry Doors, Service Doors, Automatic Overwing Exits, Mid-Exit Doors, and Cargo Doors
52-802-02	52-802-02	52-802-02-01		ZONAL (GV)	Forward Cargo Door
52-804-02	52-804-02	52-804-02-01		ZONAL (GV)	Forward Cargo Door
52-806-02	52-806-02	52-806-02-01		ZONAL (GV)	Aft Cargo Door
52-808-02	52-808-02	52-808-02-01		ZONAL (GV)	Aft Cargo Door
52-810-01	52-810-01	52-810-01-01		ZONAL (GV)	Forward Passenger Door
52-812-01	52-812-01	52-812-01-01		ZONAL (GV)	Forward Passenger Door
52-814-01	52-814-01	52-814-01-01		ZONAL (GV)	Automatic Overwing Exit
52-816-01	52-816-01	52-816-01-01		ZONAL (GV)	Automatic Overwing Exit
52-818-01	52-818-01	52-818-01-01		ZONAL (GV)	Automatic Overwing Exit
52-820-01	52-820-01	52-820-01-01		ZONAL (GV)	Automatic Overwing Exit
52-822-01	52-822-01	52-822-01-01 52-822-01-02		ZONAL (GV)	Aft Passenger Door
52-824-01	52-824-01	52-824-01-01		ZONAL (GV)	Aft Passenger Door
52-826-02	52-826-02	52-826-02-01		ZONAL (GV)	Forward Galley Service Door
52-828-02	52-828-02	52-828-02-01		ZONAL (GV)	Forward Galley Service Door
52-830-02	52-830-02	52-830-02-01		ZONAL (GV)	Automatic Overwing Exit
52-832-02	52-832-02	52-832-02-01		ZONAL (GV)	Automatic Overwing Exit
52-834-02	52-834-02	52-834-02-01		ZONAL (GV)	Automatic Overwing Exit
52-836-02	52-836-02	52-836-02-01		ZONAL (GV)	Automatic Overwing Exit
52-838-02	52-838-02	52-838-02-01 52-838-02-02		ZONAL (GV)	Aft Galley Service Door
52-840-02	52-840-02	52-840-02-01		ZONAL (GV)	Aft Galley Service Door
52-842-01	52-842-01	52-842-01-01		ZONAL (GV)	Main Deck Cargo Door



**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
52-844-01	52-844-01	52-844-01-01		ZONAL (GV)	Main Deck Cargo Door
52-846-01	52-846-01	52-846-01-01		ZONAL (GV)	Mid-Exit Door
52-846-02	52-846-02	52-846-02-01		ZONAL (GV)	Mid-Exit Door
52-846-03	52-846-03	52-846-03-01		ZONAL (GV)	Mid-Exit Door
52-846-04	52-846-04	52-846-04-01		ZONAL (GV)	Mid-Exit Door
52-846-05	52-846-05	52-846-05-01		ZONAL (GV)	Mid-Exit Door
52-846-06	52-846-06	52-846-06-01		ZONAL (GV)	Mid-Exit Door
53-010-00	53-010-00	53-010-00-01 53-010-00-02 53-010-00-03		GENERAL VISUAL	Fuselage Lower Lobe
53-020-00	53-020-00	53-020-00-01		GENERAL VISUAL	Nose Wheel Well
53-030-00	53-030-00	53-030-00-01 53-030-00-02		DETAILED	Cargo Door Surround Structure, Fittings and Stops
53-050-00	53-050-00	53-050-00-01		GENERAL VISUAL	Main Landing Gear Wheel Well
53-060-00	53-060-00	53-060-00-01		GENERAL VISUAL	Forward Pressure Bulkhead
53-070-00	53-070-00	53-070-00-01		GENERAL VISUAL	Area Forward of Nose Wheel Well
53-080-00	53-080-00	53-080-00-01		GENERAL VISUAL	Flight Compartment Floor Structure
53-090-00	53-090-00	53-090-00-01		GENERAL VISUAL	Area Above and Outboard of Nose Wheel Well
53-100-00	53-100-00	53-100-00-01		GENERAL VISUAL	Passenger Compartment Floor Structure - Dry Area
53-110-00	53-110-00	53-110-00-01		GENERAL VISUAL	Passenger Compartment Floor Structure - Wet Area



**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
53-120-00	53-120-00	53-120-00-01		GENERAL VISUAL	Electrical and Electronics Compartment
53-130-00	53-130-00	53-130-00-01		GENERAL VISUAL	Forward Cargo Compartment
53-140-00	53-140-00	53-140-00-01 53-140-00-02		GENERAL VISUAL	Forward and Aft Cargo Compartment - Floor Structure
53-150-00	53-150-00	53-150-00-01		DETAILED	Forward Cargo Door Cutout
53-160-00	53-160-00	53-160-00-01		GENERAL VISUAL	Forward Bilge
53-170-00	53-170-00	53-170-00-01		GENERAL VISUAL	Area Aft of Forward Cargo Compartment
53-180-00	53-180-00	53-180-00-01		GENERAL VISUAL	Area Under Lower Wing-To-Body Fairing (forward of wing box)
53-190-00	53-190-00	53-190-00-01		GENERAL VISUAL	Area Above Wing Box Center Section
53-200-00	53-200-00	53-200-00-01		GENERAL VISUAL	Area Above Main Landing Gear Wheel Well
53-210-00	53-210-00	53-210-00-01		GENERAL VISUAL	Keel Beam Under Wing-To-Body Fairing (under wing box)
53-220-00	53-220-00	53-220-00-01		GENERAL VISUAL	Keel Beam In Wheel Well
53-230-00	53-230-00	53-230-00-01		GENERAL VISUAL	Aft Cargo Compartment
53-235-00	53-235-00	53-235-00-01 53-235-00-02		GENERAL VISUAL	Mid Emergency Exit Door Cutout
53-240-00	53-240-00	53-240-00-01		DETAILED	Aft Cargo Door Cutout
53-250-00	53-250-00	53-250-00-01		GENERAL VISUAL	Aft Bilge
53-260-00	53-260-00	53-260-00-01		GENERAL VISUAL	Area Aft of Cargo Compartment



**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
53-262-00	53-262-00	53-262-00-01		GENERAL VISUAL	Area Aft of Cargo Compartment
53-270-00	53-270-00	53-270-00-01		GENERAL VISUAL	Area Under Lower Wing-To-Body Fairing (aft of Wheel Well)
53-280-00	53-280-00	53-280-00-01		GENERAL VISUAL	Area Under Wing-To-Body Fairing (above wing)
53-290-00	53-290-00	53-290-00-01		GENERAL VISUAL	Overwing Emergency Exit Cutout
53-310-00	53-310-00	53-310-00-01 53-310-00-02 53-310-00-03 53-310-00-04		DETAILED	Fuselage Upper Lobe Door Frames, Stops, Latches and Hinges
53-330-00	53-330-00	53-330-00-01		GENERAL VISUAL	Flight Compartment from Sta 178 to 270
53-335-00	53-335-00	53-335-00-01		GENERAL VISUAL	Flight Compartment from Sta 178 to 270
53-340-00	53-340-00	53-340-00-01		GENERAL VISUAL	Flight Compartment Floor Structure
53-350-00	53-350-00	53-350-00-01		GENERAL VISUAL	Passenger Compartment from Sta 270 to 360
53-360-00	53-360-00	53-360-00-01 53-360-00-02 53-360-00-03 53-360-00-04		DETAILED	Passenger Compartment Door Cutouts
53-370-00	53-370-00	53-370-00-01 53-370-00-02		GENERAL VISUAL	Passenger Compartment Floor Structure - Dry Area
53-380-00	53-380-00	53-380-00-01 53-380-00-02		GENERAL VISUAL	Passenger Compartment Floor Structure - Wet Area
53-390-00	53-390-00	53-390-00-01		GENERAL VISUAL	Passenger Compartment Floor Structure - Wet Area



# 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

## TASKS SORTED BY MRB ITEM NUMBER

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
53-400-00	53-400-00	53-400-00-01		GENERAL VISUAL	Forward Passenger Compartment, Sta 360 to 663.75
53-410-00	53-410-00	53-410-00-01		GENERAL VISUAL	Aft Passenger Compartment, STA 663.75 to 1016
53-412-00	53-412-00	53-412-00-01		GENERAL VISUAL	Aft Passenger Compartment, STA 663.75 to 1042
53-414-00	53-414-00	53-414-00-01 53-414-00-02		GENERAL VISUAL	Mid Emergency Exit Door Surround Structure
53-415-00	53-415-00	53-415-00-01 53-415-00-02		DETAILED	Mid Exit Structural Plug Surround
53-416-00	53-416-00	53-416-00-01 53-416-00-02		GENERAL VISUAL	Mid Emergency Exit Door
53-417-00	53-417-00	53-417-00-01 53-417-00-02		DETAILED	Mid Exit Structural Plug
53-418-00	53-418-00	53-418-00-01 53-418-00-02		GENERAL VISUAL	Mid Exit Structural Plug
53-419-00	53-419-00	53-419-00-01 53-419-00-02		GENERAL VISUAL	Mid Exit Structural Plug
53-420-00	53-420-00	53-420-00-01		GENERAL VISUAL	Area Aft of STA 1016 Bulkhead
53-422-00	53-422-00	53-422-00-01		GENERAL VISUAL	Area Aft of STA 1042 Bulkhead
53-430-00	53-430-00	53-430-00-01		GENERAL VISUAL	Stabilizer Torsion Box Compartment and APU Compartment
53-440-00	53-440-00	53-440-00-01		GENERAL VISUAL	STA 1156 Bulkhead
53-450-00	53-450-00	53-450-00-01		GENERAL VISUAL	Fuselage Skin Under Dorsal Fin
53-460-00	53-460-00	53-460-00-01		GENERAL VISUAL	Vertical Fin Front Spar Fitting



**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
53-470-00	53-470-00	53-470-00-01		GENERAL VISUAL	Vertical Fin Front Spar Fitting
53-480-00	53-480-00	53-480-00-01		GENERAL VISUAL	Vertical Fin Rear Spar Fitting
53-490-00	53-490-00	53-490-00-01		DETAILED	Main Deck Cargo Door Cutout Frames, Fittings, Pins, and Hinges
53-495-00	53-495-00	53-495-00-01		DETAILED	Main Deck Cargo Door Cutout Frames, Fittings, Pins, and Hinges
53-500-00	53-500-00	53-500-00-01		DETAILED	Main Deck Cargo Door Cutout and Surround Structure
53-505-00	53-505-00	53-505-00-01		DETAILED	Main Deck Cargo Door Cutout and Surround Structure
53-510-00	53-510-00	53-510-00-01		GENERAL VISUAL	Crown Skin Panel
53-520-00	53-520-00	53-520-00-01		DETAILED	Seat Track to Frame Attachment, Sta 540 to 727
53-530-00	53-530-00	53-530-00-01		GENERAL VISUAL	Crown Skin Panel, Sta 360 to 500H
53-800-00	53-800-00	53-800-00-01		ZONAL (GV)	Lower Fuselage
53-802-00	53-802-00	53-802-00-01		ZONAL (GV)	Radome
53-804-00	53-804-00	53-804-00-01		ZONAL (GV)	Area Forward of Nose Wheel Well
53-806-00	53-806-00	53-806-00-01		ZONAL (GV)	Area Above and Outboard of Nose Wheel Well
53-808-00	53-808-00	53-808-00-01		ZONAL (GV)	Electrical and Electronics Compartment
53-810-00	53-810-00	53-810-00-01		ZONAL (GV)	Electrical and Electronics Compartment Access Door
53-812-00	53-812-00	53-812-00-01		ZONAL (GV)	Forward Cargo Compartment
53-814-00	53-814-00	53-814-00-01		ZONAL (GV)	Forward Cargo Compartment
53-816-00	53-816-00	53-816-00-01		ZONAL (GV)	Forward Cargo Compartment
53-818-00	53-818-00	53-818-00-01		ZONAL (GV)	Forward Cargo Door Surround Structure Fittings and Stops
53-820-00	53-820-00	53-820-00-01		ZONAL (GV)	Area Below Forward Cargo Compartment
53-822-00	53-822-00	53-822-00-01		ZONAL (GV)	Air Conditioning Distribution Bay



**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
53-824-01	53-824-01	53-824-01-01		ZONAL (GV)	Area Above Center Section Wing Box
53-826-00	53-826-00	53-826-00-01		ZONAL (GV)	Pressure Deck Above Main Landing Gear Wheel Well
53-828-00	53-828-00	53-828-00-01		ZONAL (GV)	Keel Beam (Part) Sta 540 to 727
53-830-00	53-830-00	53-830-00-01		ZONAL (GV)	Aft Cargo Compartment
53-832-00	53-832-00	53-832-00-01		ZONAL (GV)	Aft Cargo Compartment
53-834-00	53-834-00	53-834-00-01		ZONAL (GV)	Aft Cargo Compartment
53-836-00	53-836-00	53-836-00-01		ZONAL (GV)	Aft Cargo Door Surround Structure Fittings and Stops
53-838-00	53-838-00	53-838-00-01		ZONAL (GV)	Aft Cargo Compartment Vacuum Waste Compartment
53-840-00	53-840-00	53-840-00-01		ZONAL (GV)	Area Below Aft Cargo Compartment
53-842-00	53-842-00	53-842-00-01		ZONAL (GV)	Aft Cargo Compartment Equipment Bay
53-844-00	53-844-00	53-844-00-01		ZONAL (GV)	Wing to Body Fairing
53-846-00	53-846-00	53-846-00-01		ZONAL (GV)	Lower Wing to Body Fairing - Forward of Wing Box
53-848-00	53-848-00	53-848-00-01		ZONAL (GV)	Lower Wing to Body Fairing - Under Wing Box
53-850-00	53-850-00	53-850-00-01		ZONAL (GV)	Lower Wing to Body Fairing - Aft of Wheel Well
53-852-00	53-852-00	53-852-00-01		ZONAL (GV)	Lower Wing to Body Fairing - Aft of Wheel Well
53-854-02	53-854-02	53-854-02-01		ZONAL (GV)	Above Wing, Wing to Body Fairing - Right
53-856-01	53-856-01	53-856-01-01		ZONAL (GV)	Above Wing, Wing to Body Fairing - Left
53-858-00	53-858-00	53-858-00-01		ZONAL (GV)	Flight Control Compartment
53-860-00	53-860-00	53-860-00-01		ZONAL (GV)	Flight Control Compartment
53-862-00	53-862-00	53-862-00-01		ZONAL (GV)	Flight Control Compartment
53-864-00	53-864-00	53-864-00-01		ZONAL (GV)	Passenger Compartment - Aft of Control Compartment to Fwd Entry Door
53-866-00	53-866-00	53-866-00-01		ZONAL (GV)	Passenger Compartment - Section 41, STA 270 to STA 360
53-868-00	53-868-00	53-868-00-01		ZONAL (GV)	Passenger Compartment - Aft of Control Compartment to Fwd Entry Door
53-870-00	53-870-00	53-870-00-01		ZONAL (GV)	Forward Passenger Entry Door Stops, Latches and Hinges





## 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

### TASKS SORTED BY MRB ITEM NUMBER

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
53-872-00	53-872-00	53-872-00-01		ZONAL (GV)	Forward Galley Service Door Stops, Latches, and Hinges
53-874-00	53-874-00	53-874-00-01		ZONAL (GV)	Forward Passenger Compartment - Sta 360 to Sta 663.75
53-876-00	53-876-00	53-876-00-01		ZONAL (GV)	Forward Passenger Compartment - Sta 360 to Sta 663.75
53-878-00	53-878-00	53-878-00-01		ZONAL (GV)	Forward Passenger Compartment - Sta 360 to Sta 663.75 Wet Areas
53-880-00	53-880-00	53-880-00-01		ZONAL (GV)	Forward Passenger Compartment - Sta 360 to Sta 663.75 Dry Areas
53-882-00	53-882-00	53-882-00-01 53-882-00-02		ZONAL (GV)	Aft Passenger Compartment - Sta 663.75 to Aft Pressure Bulkhead
53-884-00	53-884-00	53-884-00-01 53-884-00-02	W-20-445-00-01	ZONAL (GV)	Aft Passenger Compartment - STA 663.75 to Aft Pressure Bulkhead
53-886-00	53-886-00	53-886-00-01 53-886-00-02		ZONAL (GV)	Aft Passenger Compartment - Sta 663.75 to Aft Pressure Bulkhead Wet Area
53-888-00	53-888-00	53-888-00-01 53-888-00-02	W-20-440-00-01	ZONAL (GV)	Aft Passenger Compartment - Sta 663.75 to Aft Pressure Bulkhead Dry Area
53-890-00	53-890-00	53-890-00-01		ZONAL (GV)	Aft Passenger Entry Door Stops, Latches, and Hinges
53-892-00	53-892-00	53-892-00-01		ZONAL (GV)	Aft Galley Service Door Stops, Latches, and Hinges
53-894-00	53-894-00	53-894-00-01 53-894-00-02		ZONAL (GV)	Area Aft of the Pressure Bulkhead
53-896-00	53-896-00	53-896-00-01 53-896-00-02		ZONAL (GV)	Area Aft of Pressure Bulkhead
53-898-00	53-898-00	53-898-00-01		ZONAL (GV)	Stabilizer Torsion Box Compartment
53-900-00	53-900-00	53-900-00-01		ZONAL (GV)	APU Compartment
53-902-00	53-902-00	53-902-00-01		ZONAL (GV)	Tail Cone
53-904-01	53-904-01	53-904-01-01		ZONAL (GV)	Flap Support No. 4 - Left Wing
53-906-02	53-906-02	53-906-02-01		ZONAL (GV)	Flap Support No. 5 - Right Wing
53-908-01	53-908-01	53-908-01-01		ZONAL (GV)	Main Deck Cargo Door Stops, Latches, Hinges and Fittings
53-910-00	53-910-00	53-910-00-01		ZONAL (GV)	Main Deck Cargo Compartment - Sta 360 to Sta 1016



# 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

## TASKS SORTED BY MRB ITEM NUMBER

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
53-914-00	53-914-00	53-914-00-01		ZONAL (GV)	Main Deck Cargo Compartment - Sta 360 to Sta 1016 Wet Areas
54-010-01	54-010-01	54-010-01-01		GENERAL VISUAL	Left Forward Engine Mount Assembly
54-010-02	54-010-02	54-010-02-01		GENERAL VISUAL	Right Forward Engine Mount Assembly
54-015-01	54-015-01	54-015-01-01		GENERAL VISUAL	Left Strut Attach Bolts at Forward Engine Mount
54-015-02	54-015-02	54-015-02-01		GENERAL VISUAL	Right Strut Attach Bolts at Forward Engine Mounts
54-020-01	54-020-01	54-020-01-01		GENERAL VISUAL	Left Strut Forward and Aft Engine Mount to Strut Shear Pins
54-020-02	54-020-02	54-020-02-01		GENERAL VISUAL	Right Strut Forward and Aft Engine Mount to Strut Shear Pins
54-030-01	54-030-01	54-030-01-01		GENERAL VISUAL	Left Strut Aft Engine Mount Assembly
54-030-02	54-030-02	54-030-02-01		GENERAL VISUAL	Right Strut Aft Engine Mount Assembly
54-040-01	54-040-01	54-040-01-01		GENERAL VISUAL	Left Strut to Wing Attachments
54-040-02	54-040-02	54-040-02-01		GENERAL VISUAL	Right Strut to Wing Attachments
54-050-01	54-050-01	54-050-01-01		DETAILED	Left Strut to Wing Attachments - Pins and Fuse Pins
54-050-02	54-050-02	54-050-02-01		DETAILED	Right Strut to Wing Attachments - Pins and Fuse Pins
54-060-01	54-060-01	54-060-01-01		DETAILED	Left Strut to Wing Attachments
54-060-02	54-060-02	54-060-02-01		DETAILED	Right Strut to Wing Attachments
54-070-01	54-070-01	54-070-01-01		GENERAL VISUAL	Left Strut Box
54-070-02	54-070-02	54-070-02-01		GENERAL VISUAL	Right Strut Box



**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
54-080-01	54-080-01	54-080-01-01		GENERAL VISUAL	Left Strut Box
54-080-02	54-080-02	54-080-02-01		GENERAL VISUAL	Right Strut Box
54-090-01	54-090-01	54-090-01-01		FUNCTIONAL	Functional Check Left Engine Forward Strut and Aft Strut Fairing Drains
54-090-02	54-090-02	54-090-02-01		FUNCTIONAL	Functional Check Right Engine Forward Strut and Aft Strut Fairing Drains
54-800-01	54-800-01	54-800-01-01		ZONAL (GV)	Forward Strut Fairing - Engine No. 1
54-802-01	54-802-01	54-802-01-01		ZONAL (GV)	Fan Cowl Support Beam - Engine No. 1
54-804-01	54-804-01	54-804-01-01		ZONAL (GV)	Strut Torque Box - Engine No. 1
54-806-01	54-806-01	54-806-01-01		ZONAL (GV)	Aft Strut Fairing - Engine No. 1
54-808-02	54-808-02	54-808-02-01		ZONAL (GV)	Forward Strut Fairing - Engine No. 2
54-810-02	54-810-02	54-810-02-01		ZONAL (GV)	Fan Cowl Support Beam - Engine No. 2
54-812-02	54-812-02	54-812-02-01		ZONAL (GV)	Strut Torque Box - Engine No. 2
54-814-02	54-814-02	54-814-02-01		ZONAL (GV)	Aft Strut Fairing - Engine No. 2
55-010-00	55-010-00	55-010-00-01		GENERAL VISUAL	Horizontal Stabilizer Center Section
55-020-00	55-020-00	55-020-00-01		GENERAL VISUAL	Stabilizer Torsion Box Compartment
55-030-00	55-030-00	55-030-00-01		GENERAL VISUAL	Vertical Fin Leading Edge
55-050-00	55-050-00	55-050-00-01		GENERAL VISUAL	Vertical Fin
55-060-00	55-060-00	55-060-00-01		GENERAL VISUAL	Vertical Fin Trailing Edge
55-070-01	55-070-01	55-070-01-01		GENERAL VISUAL	Left Horizontal Stabilizer Leading Edge



**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
55-070-02	55-070-02	55-070-02-01		GENERAL VISUAL	Right Horizontal Stabilizer Leading Edge
55-080-01	55-080-01	55-080-01-01		GENERAL VISUAL	Left Horizontal Stabilizer Leading Edge
55-080-02	55-080-02	55-080-02-01		GENERAL VISUAL	Right Horizontal Stabilizer Leading Edge
55-100-01	55-100-01	55-100-01-01		GENERAL VISUAL	Left Horizontal Stabilizer
55-100-02	55-100-02	55-100-02-01		GENERAL VISUAL	Right Horizontal Stabilizer
55-110-01	55-110-01	55-110-01-01		GENERAL VISUAL	Left Horizontal Stabilizer Trailing Edge and Elevator Tab Leading Edge
55-110-02	55-110-02	55-110-02-01		GENERAL VISUAL	Right Horizontal Stabilizer Trailing Edge and Elevator Tab Leading Edge
55-115-01	55-115-01	55-115-01-01		DETAILED	Left Elevator Tab Supt Ftgs on Front Spar and Tab Spar at Leading Edge
55-115-02	55-115-02	55-115-02-01		DETAILED	Right Elevator Tab Supt Ftgs on Front Spar and Tab Spar at Leading Edge
55-120-01	55-120-01	55-120-01-01		GENERAL VISUAL	Left Horizontal Stabilizer Trailing Edge
55-120-02	55-120-02	55-120-02-01		GENERAL VISUAL	Right Horizontal Stabilizer Trailing Edge
55-130-00	55-130-00	55-130-00-01		GENERAL VISUAL	Rudder, Elevator and Elevator Tab Attach Fittings
55-135-01	55-135-01	55-135-01-01		DETAILED	Left Elevator Hinge, Actuator, and Tab Mast Arm Ftgs and Balance Wt Suppt Struct.
55-135-02	55-135-02	55-135-02-01		DETAILED	Right Elevator Hinge, Actuator, and Tab Mast Arm Ftgs and Balance Wt Suppt Struct.
55-800-00	55-800-00	55-800-00-01		ZONAL (GV)	Vertical Fin and Horizontal Stabilizer
55-802-00	55-802-00	55-802-00-01		ZONAL (GV)	Vertical Fin - Dorsal Fin
55-804-00	55-804-00	55-804-00-01		ZONAL (GV)	Vertical Fin - Leading Edge (Only if HF System Installed)



**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
55-806-00	55-806-00	55-806-00-01		ZONAL (GV)	Vertical Fin - Leading Edge
55-808-00	55-808-00	55-808-00-01		ZONAL (GV)	Vertical Fin - Leading Edge
55-810-00	55-810-00	55-810-00-01		ZONAL (GV)	Vertical Fin - Front Spar to Rear Spar
55-812-00	55-812-00	55-812-00-01		ZONAL (GV)	Vertical Fin - Front Spar to Rear Spar
55-814-00	55-814-00	55-814-00-01		ZONAL (GV)	Vertical Fin - Rear Spar to Trailing Edge
55-816-00	55-816-00	55-816-00-01		ZONAL (GV)	Vertical Fin - Rear Spar to Trailing Edge
55-818-00	55-818-00	55-818-00-01		ZONAL (GV)	Rudder
55-820-00	55-820-00	55-820-00-01		ZONAL (GV)	Vertical Fin Tip
55-822-01	55-822-01	55-822-01-01		ZONAL (GV)	Horizontal Stabilizer - Leading Edge - Left
55-824-01	55-824-01	55-824-01-01		ZONAL (GV)	Horizontal Stabilizer - Front Spar to Rear Spar - Left
55-826-01	55-826-01	55-826-01-01		ZONAL (GV)	Horizontal Stabilizer - Front Spar to Rear Spar - Left
55-828-01	55-828-01	55-828-01-01		ZONAL (GV)	Horizontal Stabilizer - Rear Spar to Trailing Edge - Left
55-830-01	55-830-01	55-830-01-01		ZONAL (GV)	Horizontal Stabilizer - Rear Spar to Trailing Edge - Left
55-832-01	55-832-01	55-832-01-01		ZONAL (GV)	Horizontal Stabilizer - Elevator - Left
55-834-01	55-834-01	55-834-01-01		ZONAL (GV)	Horizontal Stabilizer - Stabilizer Tip - Left
55-836-02	55-836-02	55-836-02-01		ZONAL (GV)	Horizontal Stabilizer - Leading Edge - Right
55-838-02	55-838-02	55-838-02-01		ZONAL (GV)	Horizontal Stabilizer - Front Spar to Rear Spar - Right
55-840-02	55-840-02	55-840-02-01		ZONAL (GV)	Horizontal Stabilizer - Front Spar to Rear Spar - Right
55-842-02	55-842-02	55-842-02-01		ZONAL (GV)	Horizontal Stabilizer - Rear Spar to Trailing Edge - Right
55-844-02	55-844-02	55-844-02-01		ZONAL (GV)	Horizontal Stabilizer - Rear Spar to Trailing Edge - Right
55-846-02	55-846-02	55-846-02-01		ZONAL (GV)	Horizontal Stabilizer - Elevator - Right
55-848-02	55-848-02	55-848-02-01		ZONAL (GV)	Horizontal Stabilizer - Stabilizer Tip - Right
56-010-00	56-010-00	56-010-00-01		LUBRICATE	Control Cabin Sliding Windows
56-020-00	56-020-00	56-020-00-01		LUBRICATE	Control Cabin Sliding Windows



**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
56-030-00	56-030-00	56-030-00-01		OPERATIONAL	Control Cabin Sliding Windows
56-040-00	56-040-00	56-040-00-01		OPERATIONAL	Control Cabin Sliding Windows
56-050-00	56-050-00	56-050-00-01		INSPECTION - GEN VISUAL	Control Cabin Sliding Windows
56-060-00	56-060-00	56-060-00-01		INSPECTION - GEN VISUAL	Control Cabin Sliding Windows
57-010-00	57-010-00	57-010-00-01		GENERAL VISUAL	Wing Center Section
57-020-00	57-020-00	57-020-00-01		GENERAL VISUAL	Wing Center Section
57-030-00	57-030-00	57-030-00-01		GENERAL VISUAL	Wing Center Section
57-040-00	57-040-00	57-040-00-01		GENERAL VISUAL	Wing Center Section
57-050-00	57-050-00	57-050-00-01		GENERAL VISUAL	Wing Center Section
57-060-01	57-060-01	57-060-01-01		GENERAL VISUAL	Left Outboard Wing
57-060-02	57-060-02	57-060-02-01		GENERAL VISUAL	Right Outboard Wing
57-070-01	57-070-01	57-070-01-01		GENERAL VISUAL	Left Outboard Wing
57-070-02	57-070-02	57-070-02-01		GENERAL VISUAL	Right Outboard Wing
57-090-00	57-090-00	57-090-00-01		GENERAL VISUAL	Wing Center Section
57-100-01	57-100-01	57-100-01-01		GENERAL VISUAL	Left Nacelle Support Fittings
57-100-02	57-100-02	57-100-02-01		GENERAL VISUAL	Right Nacelle Support Fittings



**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
57-110-01	57-110-01	57-110-01-01		GENERAL VISUAL	Left Outboard Wing Lower Surface
57-110-02	57-110-02	57-110-02-01		GENERAL VISUAL	Right Outboard Wing Lower Surface
57-120-01	57-120-01	57-120-01-01		GENERAL VISUAL	Left Outboard Wing Front Spar
57-120-02	57-120-02	57-120-02-01		GENERAL VISUAL	Right Outboard Wing Front Spar
57-130-01	57-130-01	57-130-01-01		GENERAL VISUAL	Left Outboard Wing Leading Edge Structure
57-130-02	57-130-02	57-130-02-01		GENERAL VISUAL	Right Outboard Wing Leading Edge Structure
57-140-01	57-140-01	57-140-01-01		DETAILED	Left Wing Slat Tracks
57-140-02	57-140-02	57-140-02-01		DETAILED	Right Wing Slat Tracks
57-160-01	57-160-01	57-160-01-01		GENERAL VISUAL	Left Outboard Wing Access Holes
57-160-02	57-160-02	57-160-02-01		GENERAL VISUAL	Right Outboard Wing Access Holes
57-170-01	57-170-01	57-170-01-01	W-57-180-01-01 W-57-190-01-01	GENERAL VISUAL	Left Outboard Wing
57-170-02	57-170-02	57-170-02-01	W-57-180-02-01 W-57-190-02-01	GENERAL VISUAL	Right Outboard Wing
57-180-01	57-180-01	57-180-01-01	W-57-170-01-01 W-57-190-01-01	GENERAL VISUAL	Left Outboard Wing
57-180-02	57-180-02	57-180-02-01	W-57-170-02-01 W-57-190-02-01	GENERAL VISUAL	Right Outboard Wing
57-190-01	57-190-01	57-190-01-01	W-57-170-01-01 W-57-180-01-01	GENERAL VISUAL	Left Outboard Wing
57-190-02	57-190-02	57-190-02-01	W-57-170-02-01 W-57-180-02-01	GENERAL VISUAL	Right Outboard Wing



**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
57-200-01	57-200-01	57-200-01-01		GENERAL VISUAL	Left Flap Support No. 4
57-200-02	57-200-02	57-200-02-01		GENERAL VISUAL	Right Flap Support No. 5
57-210-01	57-210-01	57-210-01-01		GENERAL VISUAL	Left Flap Support No. 3
57-210-02	57-210-02	57-210-02-01		GENERAL VISUAL	Right Flap Support No. 6
57-220-01	57-220-01	57-220-01-01		GENERAL VISUAL	Left Outboard Wing Lower Surface
57-220-02	57-220-02	57-220-02-01		GENERAL VISUAL	Right Outboard Wing Lower Surface
57-230-01	57-230-01	57-230-01-01		GENERAL VISUAL	Flap Supports No. 1 & 2
57-230-02	57-230-02	57-230-02-01		GENERAL VISUAL	Flap Supports No.7 & 8
57-240-01	57-240-01	57-240-01-01		GENERAL VISUAL	Left Outboard Wing Lower Surface
57-240-02	57-240-02	57-240-02-01		GENERAL VISUAL	Right Outboard Wing Lower Surface
57-250-01	57-250-01	57-250-01-01		GENERAL VISUAL	Left Main Landing Gear Support Structure
57-250-02	57-250-02	57-250-02-01		GENERAL VISUAL	Right Main Landing Gear Support Structure
57-260-01	57-260-01	57-260-01-01		GENERAL VISUAL	Left Wing Outboard Rear Spar
57-260-02	57-260-02	57-260-02-01		GENERAL VISUAL	Right Wing Outboard Rear Spar
57-270-01	57-270-01	57-270-01-01		GENERAL VISUAL	Left Wing Outboard Trailing Edge Structure





**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
57-270-02	57-270-02	57-270-02-01		GENERAL VISUAL	Right Wing Outboard Trailing Edge Structure
57-280-01	57-280-01	57-280-01-01		GENERAL VISUAL	Left Inboard Ground Spoiler
57-280-02	57-280-02	57-280-02-01		GENERAL VISUAL	Right Inboard Ground Spoiler
57-300-01	57-300-01	57-300-01-01		GENERAL VISUAL	Left Inboard Flap
57-300-02	57-300-02	57-300-02-01		GENERAL VISUAL	Right Inboard Flap
57-310-01	57-310-01	57-310-01-01		GENERAL VISUAL	Left Outboard Wing Rear Spar
57-310-02	57-310-02	57-310-02-01		GENERAL VISUAL	Right Outboard Wing Rear Spar
57-330-01	57-330-01	57-330-01-01		GENERAL VISUAL	Left Outboard Flap
57-330-02	57-330-02	57-330-02-01		GENERAL VISUAL	Right Outboard Flap
57-340-01	57-340-01	57-340-01-01		SPECIAL DETAILED	Left Winglet
57-340-02	57-340-02	57-340-02-01		SPECIAL DETAILED	Right Winglet
57-351-01	57-351-01	57-351-01-01		DETAILED	Left Winglet
57-351-02	57-351-02	57-351-02-01		DETAILED	Right Winglet
57-800-00	57-800-00	57-800-00-01		ZONAL (GV)	Center Section Wing Box
57-802-01	57-802-01	57-802-01-01		ZONAL (GV)	Left Wing
57-804-01	57-804-01	57-804-01-01		ZONAL (GV)	Leading Edge to Front Spar - Inboard of Nacelle Strut - Left Wing
57-806-01	57-806-01	57-806-01-01		ZONAL (GV)	Leading Edge to Front Spar - Inboard of Nacelle Strut - Left Wing



**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
57-808-01	57-808-01	57-808-01-01		ZONAL (GV)	Krueger Flaps No. 1 and 2 - Left Wing
57-810-01	57-810-01	57-810-01-01		ZONAL (GV)	Krueger Flaps No. 1 and 2 - Left Wing
57-812-01	57-812-01	57-812-01-01		ZONAL (GV)	Leading Edge to Front Spar - Outboard of Nacelle Strut - Left Wing
57-814-01	57-814-01	57-814-01-01		ZONAL (GV)	Leading Edge to Front Spar - Outboard of Nacelle Strut - Left Wing
57-816-01	57-816-01	57-816-01-01		ZONAL (GV)	Slats No. 1, 2, 3, 4 - Left Wing
57-818-01	57-818-01	57-818-01-01		ZONAL (GV)	Left Wing Tip
57-820-01	57-820-01	57-820-01-01		ZONAL (GV)	Left Wing Tip
57-822-01	57-822-01	57-822-01-01		ZONAL (GV)	Center Fuel Tank - Left Wing
57-824-01	57-824-01	57-824-01-01		ZONAL (GV)	Center Fuel Tank - Left Wing
57-826-01	57-826-01	57-826-01-01		ZONAL (GV)	Main Fuel Tank - Left Wing
57-828-01	57-828-01	57-828-01-01		ZONAL (GV)	Main Fuel Tank - Left Wing
57-830-01	57-830-01	57-830-01-01		ZONAL (GV)	Surge Tank - Left Wing
57-832-01	57-832-01	57-832-01-01		ZONAL (GV)	Surge Tank - Left Wing
57-834-01	57-834-01	57-834-01-01		ZONAL (GV)	Dry Bay - Left Wing
57-836-01	57-836-01	57-836-01-01		ZONAL (GV)	Fairing Flap Support No. 3 - Left Wing
57-838-01	57-838-01	57-838-01-01		ZONAL (GV)	Fairing Flap Support No. 3 - Left Wing
57-840-01	57-840-01	57-840-01-01		ZONAL (GV)	Fairing Flap Support No. 2 - Left Wing
57-842-01	57-842-01	57-842-01-01		ZONAL (GV)	Fairing Flap Support No. 2 - Left Wing
57-844-01	57-844-01	57-844-01-01		ZONAL (GV)	Fairing Flap Support No. 1 - Left Wing
57-846-01	57-846-01	57-846-01-01		ZONAL (GV)	Fairing Flap Support No. 1 - Left Wing
57-848-01	57-848-01	57-848-01-01		ZONAL (GV)	Rear Spar to Landing Gear Support Beam - Left Wing
57-850-01	57-850-01	57-850-01-01		ZONAL (GV)	Rear Spar to Landing Gear Support Beam - Left Wing
57-852-01	57-852-01	57-852-01-01		ZONAL (GV)	Inboard Spoiler No. 6 - L. Wing
57-854-01	57-854-01	57-854-01-01		ZONAL (GV)	Inboard Flaps - Left Wing



**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
57-856-01	57-856-01	57-856-01-01	W-27-229-00-01	ZONAL (GV)	Inboard Main Flaps - Left Wing
57-858-01	57-858-01	57-858-01-01		ZONAL (GV)	Rear Spar to T.E. - Outbd of Inbd Flap - Inbd of Fixed T.E. - L. Wing
57-860-01	57-860-01	57-860-01-01		ZONAL (GV)	Spoilers No. 1, 2, 3, 4, 5 - Left Wing
57-862-01	57-862-01	57-862-01-01		ZONAL (GV)	Outboard Flaps - Left Wing
57-864-01	57-864-01	57-864-01-01		ZONAL (GV)	Fixed Trailing Edge - Left Wing
57-866-01	57-866-01	57-866-01-01		ZONAL (GV)	Fixed Trailing Edge - Left Wing
57-868-01	57-868-01	57-868-01-01		ZONAL (GV)	Fixed Trailing Edge - Left Wing
57-870-01	57-870-01	57-870-01-01		ZONAL (GV)	Aileron - Left Wing
57-872-02	57-872-02	57-872-02-01		ZONAL (GV)	Right Wing
57-874-02	57-874-02	57-874-02-01		ZONAL (GV)	Leading Edge to Front Spar - Inbd of Nacelle Strut - Right Wing
57-876-02	57-876-02	57-876-02-01		ZONAL (GV)	Leading Edge to Front Spar - Inbd of Nacelle Strut - Right Wing
57-878-02	57-878-02	57-878-02-01		ZONAL (GV)	Krueger Flaps No. 3 and 4 - Right Wing
57-880-02	57-880-02	57-880-02-01		ZONAL (GV)	Krueger Flaps No. 3 and 4 - Right Wing
57-882-02	57-882-02	57-882-02-01		ZONAL (GV)	Leading Edge to Front Spar - Outbd of Nacelle Strut - Right Wing
57-884-02	57-884-02	57-884-02-01		ZONAL (GV)	Leading Edge to Front Spar - Outbd of Nacelle Strut - Right Wing
57-886-02	57-886-02	57-886-02-01		ZONAL (GV)	Slats No. 5, 6, 7, 8, - Right Wing
57-888-02	57-888-02	57-888-02-01		ZONAL (GV)	Right Wing Tip
57-890-02	57-890-02	57-890-02-01		ZONAL (GV)	Right Wing Tip
57-892-02	57-892-02	57-892-02-01		ZONAL (GV)	Center Fuel Tank - Right Wing
57-894-02	57-894-02	57-894-02-01		ZONAL (GV)	Center Fuel Tank - Right Wing
57-896-02	57-896-02	57-896-02-01		ZONAL (GV)	Main Fuel Tank - Right Wing
57-898-02	57-898-02	57-898-02-01		ZONAL (GV)	Main Fuel Tank - Right Wing
57-900-02	57-900-02	57-900-02-01		ZONAL (GV)	Surge Tank - Right Wing
57-902-02	57-902-02	57-902-02-01		ZONAL (GV)	Surge Tank - Right Wing



**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
57-904-02	57-904-02	57-904-02-01	W-27-229-00-02	ZONAL (GV)	Dry Bay - Right Wing
57-906-02	57-906-02	57-906-02-01		ZONAL (GV)	Fairing Flap Support No. 6 - Right Wing
57-908-02	57-908-02	57-908-02-01		ZONAL (GV)	Fairing Flap Support No. 6 - Right Wing
57-910-02	57-910-02	57-910-02-01		ZONAL (GV)	Fairing Flap Support No. 7 - Right Wing
57-912-02	57-912-02	57-912-02-01		ZONAL (GV)	Fairing Flap Support No. 7 - Right Wing
57-914-02	57-914-02	57-914-02-01		ZONAL (GV)	Fairing Flap Support No. 8 - Right Wing
57-916-02	57-916-02	57-916-02-01		ZONAL (GV)	Fairing Flap Support No. 8 - Right Wing
57-918-02	57-918-02	57-918-02-01		ZONAL (GV)	Rear Spar to Landing Gear Support Beam - Right Wing
57-920-02	57-920-02	57-920-02-01		ZONAL (GV)	Rear Spar to Landing Gear Support Beam - Right Wing
57-922-02	57-922-02	57-922-02-01		ZONAL (GV)	Inboard Spoiler No. 7 - Right Wing
57-924-02	57-924-02	57-924-02-01		ZONAL (GV)	Inboard Flaps - Right Wing
57-926-02	57-926-02	57-926-02-01		ZONAL (GV)	Inboard Main Flap - Right Wing
57-928-02	57-928-02	57-928-02-01		ZONAL (GV)	Rear Spar to T.E. - Outbd of Inbd Flap - Inbd of Fixed T.E. - Right Wing
57-930-02	57-930-02	57-930-02-01		ZONAL (GV)	Spoiler No 8, 9, 10, 11, 12 - Right Wing
57-932-02	57-932-02	57-932-02-01		ZONAL (GV)	Outboard Flaps - Right Wing
57-934-02	57-934-02	57-934-02-01		ZONAL (GV)	Fixed Trailing Edge - Right Wing
57-936-02	57-936-02	57-936-02-01		ZONAL (GV)	Fixed Trailing Edge - Right Wing
57-938-02	57-938-02	57-938-02-01		ZONAL (GV)	Fixed Trailing Edge - Right Wing
57-940-02	57-940-02	57-940-02-01		ZONAL (GV)	Aileron - Right Wing
57-950-01	57-950-01	57-950-01-01		ZONAL (GV)	Winglet - Left Wing
57-952-01	57-952-01	57-952-01-01		ZONAL (GV)	Winglet - Left Wing
57-960-02	57-960-02	57-960-02-01		ZONAL (GV)	Winglet - Right Wing
57-962-02	57-962-02	57-962-02-01		ZONAL (GV)	Winglet - Right Wing
70-800-01	70-800-01	70-800-01-01		ZONAL (GV)	Powerplant No. 1



**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
70-802-01	70-802-01	70-802-01-01		ZONAL (GV)	Engine No. 1
70-804-01	70-804-01	70-804-01-01		ZONAL (GV)	Fan Cowl - Engine No. 1
70-806-01	70-806-01	70-806-01-01		ZONAL (GV)	Thrust Reverser - Engine No. 1
70-808-01	70-808-01	70-808-01-01		ZONAL (GV)	Thrust Reverser - Engine No. 1
70-810-02	70-810-02	70-810-02-01		ZONAL (GV)	Powerplant No. 2
70-812-02	70-812-02	70-812-02-01		ZONAL (GV)	Engine No. 2
70-814-02	70-814-02	70-814-02-01		ZONAL (GV)	Fan Cowl - Engine No. 2
70-816-02	70-816-02	70-816-02-01		ZONAL (GV)	Thrust Reverser - Engine No. 2
70-818-02	70-818-02	70-818-02-01		ZONAL (GV)	Thrust Reverser - Engine No. 2
71-010-01	71-010-01	71-010-01-01		INSPECTION - DETAILED	Inlet Cowl - Inner Surface
71-010-02	71-010-02	71-010-02-01		INSPECTION - DETAILED	Inlet Cowl - Inner Surface
71-040-01	71-040-01	71-040-01-01		OPERATIONAL	Check Left Engine Drain Lines
71-040-02	71-040-02	71-040-02-01		OPERATIONAL	Check Right Engine Drain Lines
72-020-01	72-020-01	72-020-01-01		INSPECTION - DETAILED	Left Engine Inlet and Fan Blades
72-020-02	72-020-02	72-020-02-01		INSPECTION - DETAILED	Right Engine Inlet and Fan Blades
72-025-01	72-025-01	72-025-01-01		LUBRICATE	Lubricate Left Engine Fan Blades Dovetail.
72-025-02	72-025-02	72-025-02-01		LUBRICATE	Lubricate Right Engine Fan Blades Dovetail.
72-030-01	72-030-01	72-030-01-01		REPLACE	Left Fan Disk
72-030-02	72-030-02	72-030-02-01		REPLACE	Right Fan Disk
72-040-01	72-040-01	72-040-01-01		REPLACE	Left Engine Booster Spool
72-040-02	72-040-02	72-040-02-01		REPLACE	Right Engine Booster Spool



**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
72-050-01	72-050-01	72-050-01-01		REPLACE	Left Engine Fan Shaft
72-050-02	72-050-02	72-050-02-01		REPLACE	Right Engine Fan Shaft
72-070-01	72-070-01	72-070-01-01		VISUAL CHECK	Left Engine AGB/TGB Mount Flanges and Fan Case/Frame Mounts
72-070-02	72-070-02	72-070-02-01		VISUAL CHECK	Right Engine AGB/TGB Mount Flanges and Fan Case/Frame Mounts
72-100-01	72-100-01	72-100-01-01		VISUAL CHECK	Left Engine Attachment Bolts for the Thrust Mount Fittings
72-100-02	72-100-02	72-100-02-01		VISUAL CHECK	Right Engine Attachment Bolts for the Thrust Mount Fittings
72-110-01	72-110-01	72-110-01-01		VISUAL CHECK	Left Engine Thrust Mount Fittings
72-110-02	72-110-02	72-110-02-01		VISUAL CHECK	Right Engine Thrust Mount Fittings
72-130-01	72-130-01	72-130-01-01		REPLACE	Left Engine Stage 1 and 2 Spool
72-130-02	72-130-02	72-130-02-01		REPLACE	Right Engine Stage 1 and 2 Spool
72-140-01	72-140-01	72-140-01-01		REPLACE	Left Engine Stage 3 Disk
72-140-02	72-140-02	72-140-02-01		REPLACE	Right Engine Stage 3 Disk
72-150-01	72-150-01	72-150-01-01		REPLACE	Left Engine Stages 4 - 9 Spool
72-150-02	72-150-02	72-150-02-01		REPLACE	Right Engine Stages 4 - 9 Spool
72-160-01	72-160-01	72-160-01-01		REPLACE	Left Engine Front Shaft
72-160-02	72-160-02	72-160-02-01		REPLACE	Right Engine Front Shaft
72-170-01	72-170-01	72-170-01-01		REPLACE	Left Engine Rear Rotating (CDP) Seal
72-170-02	72-170-02	72-170-02-01		REPLACE	Right Engine Rear Rotating (CDP) Seal
72-180-01	72-180-01	72-180-01-01		INSPECTION - DETAILED	Left Engine Combustion Chamber
72-180-02	72-180-02	72-180-02-01		INSPECTION - DETAILED	Right Engine Combustion Chamber
72-190-01	72-190-01	72-190-01-01		INSPECTION - DETAILED	Left Engine Double Annular Combustion Chamber



# 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

## TASKS SORTED BY MRB ITEM NUMBER

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
72-190-02	72-190-02	72-190-02-01		INSPECTION - DETAILED	Right Engine Double Annular Combustion Chamber
72-200-01	72-200-01	72-200-01-01 72-200-01-02		INSPECTION - DETAILED	Left Engine HPT Nozzle
72-200-02	72-200-02	72-200-02-01 72-200-02-02		INSPECTION - DETAILED	Right Engine HPT Nozzle
72-210-01	72-210-01	72-210-01-01		INSPECTION - DETAILED	Left Engine HPT Blades
72-210-02	72-210-02	72-210-02-01		INSPECTION - DETAILED	Right Engine HPT Blades
72-220-01	72-220-01	72-220-01-01		REPLACE	Left Engine HPT Front Shaft
72-220-02	72-220-02	72-220-02-01		REPLACE	Right Engine HPT Front Shaft
72-230-01	72-230-01	72-230-01-01		REPLACE	Left HPT Front Rotating Air Seal
72-230-02	72-230-02	72-230-02-01		REPLACE	Right HPT Front Rotating Air Seal
72-240-01	72-240-01	72-240-01-01		REPLACE	Left Engine HPT Disk
72-240-02	72-240-02	72-240-02-01		REPLACE	Right Engine HPT Disk
72-250-01	72-250-01	72-250-01-01		REPLACE	Left Engine HPT Rear Shaft
72-250-02	72-250-02	72-250-02-01		REPLACE	Right Engine HPT Rear Shaft
72-270-01	72-270-01	72-270-01-01		REPLACE	Left Engine LPT Rotor Support
72-270-02	72-270-02	72-270-02-01		REPLACE	Right Engine LPT Rotor Support
72-280-01	72-280-01	72-280-01-01		REPLACE	Left Engine LPT Shaft
72-280-02	72-280-02	72-280-02-01		REPLACE	Right Engine LPT Shaft
72-290-01	72-290-01	72-290-01-01		REPLACE	Left Engine Stage 1, 2, 3, 4 LPT Disks
72-290-02	72-290-02	72-290-02-01		REPLACE	Right Engine Stage 1, 2, 3, 4 LPT Disks
72-300-01	72-300-01	72-300-01-01		VISUAL CHECK	Left Engine Stage Aft Mounts Clevis
72-300-02	72-300-02	72-300-02-01		VISUAL CHECK	Right Engine Stage Aft Mounts Clevis



**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
72-320-01	72-320-01	72-320-01-01		INSPECTION - DETAILED	Left Engine Fwd Sump, Aft Sump, AGB/TGB MCD or DMS detectors and scavenge screens
72-320-02	72-320-02	72-320-02-01		INSPECTION - DETAILED	Right Engine Fwd Sump, Aft Sump, AGB/TGB MCD or DMS detectors and scavenge screens
73-010-01	73-010-01	73-010-01-01		REPLACE	Replace the Left Engine Fuel Filter
73-010-02	73-010-02	73-010-02-01		REPLACE	Replace the Right Engine Fuel Filter
73-020-01	73-020-01	73-020-01-01		OPERATIONAL	FMC CDU for Left Engine Faults
73-020-02	73-020-02	73-020-02-01		OPERATIONAL	FMC CDU for Right Engine Faults
74-020-01	74-020-01	74-020-01-01		INSPECTION - DETAILED	Ignition Leads
74-020-02	74-020-02	74-020-02-01		INSPECTION - DETAILED	Ignition Leads
78-011-01	78-011-01	78-011-01-01		INSPECTION - DETAILED	Left Engine Exhaust Plug
78-011-02	78-011-02	78-011-02-01		INSPECTION - DETAILED	Right Engine Exhaust Plug
78-050-01	78-050-01	78-050-01-01		VISUAL CHECK	Left Engine T/R Fan Duct Walls
78-050-02	78-050-02	78-050-02-01		VISUAL CHECK	Right Engine T/R Fan Duct Walls
78-060-01	78-060-01	78-060-01-01		INSPECTION - DETAILED	Left Engine Drag Link's Spherical Bearing
78-060-02	78-060-02	78-060-02-01		INSPECTION - DETAILED	Right Engine Drag Link's Spherical Bearing
78-070-01	78-070-01	78-070-01-01		VISUAL CHECK	Left Engine Blocker Doors
78-070-02	78-070-02	78-070-02-01		VISUAL CHECK	Right Engine Blocker Doors
78-080-01	78-080-01	78-080-01-01		VISUAL CHECK	Left Engine Bullnose Seal and Retainer
78-080-02	78-080-02	78-080-02-01		VISUAL CHECK	Right Engine Bullnose Seal and Retainer





**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY MRB ITEM NUMBER**

MRB ITEM NUMBER	MPD ITEM NUMBER	TASK CARD NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
78-100-01	78-100-01	78-100-01-01		INSPECTION - DETAILED	Left Engine T/R Fire Seal
78-100-02	78-100-02	78-100-02-01		INSPECTION - DETAILED	Right Engine T/R Fire Seal
78-110-01	78-110-01	78-110-01-01		OPERATIONAL	Left Engine T/R Sync Lock
78-110-02	78-110-02	78-110-02-01		OPERATIONAL	Right Engine T/R Sync Lock
78-120-01	78-120-01	78-120-01-01		OPERATIONAL	Left Engine Bite Check the EAU
78-120-02	78-120-02	78-120-02-01		OPERATIONAL	Right Engine Bite Check the EAU
78-130-01	78-130-01	78-130-01-01		OPERATIONAL	Left Engine "Reverser" Light Indication System
78-130-02	78-130-02	78-130-02-01		OPERATIONAL	Right Engine "Reverser" Light Indication System
79-010-01	79-010-01	79-010-01-01		REPLACE	Oil Supply Filter Element - Left Engine
79-010-02	79-010-02	79-010-02-01		REPLACE	Oil Supply Filter Element - Right Engine
79-040-01	79-040-01	79-040-01-01		REPLACE	Oil Scavenge Filter Element - Left Engine
79-040-02	79-040-02	79-040-02-01		REPLACE	Oil Scavenge Filter Element - Right Engine
80-010-01	80-010-01	80-010-01-01		INSPECTION - DETAILED	Magnetic Chip Detector - Left Engine Starter
80-010-02	80-010-02	80-010-02-01		INSPECTION - DETAILED	Magnetic Chip Detector - Right Engine Starter





## 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

### TASKS SORTED BY TASK CARD NUMBER

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
20-010-01-01	20-010-01	20-010-01		INSPECTION - GEN VISUAL	GVI of HIRF/L Sensitive Wire Runs Outside Pressure Vessel - Left
20-010-02-01	20-010-02	20-010-02		INSPECTION - GEN VISUAL	GVI of HIRF/L Sensitive Wire Runs Outside Pressure Vessel - Right
20-020-00-01	20-020-00	20-020-00		INSPECTION - GEN VISUAL	GVI of HIRF/L Sensitive Wire Runs Inside the Pressure Vessel
20-030-01-01	20-030-01	20-030-01		INSPECTION - DETAILED	DET of L/HIRF protection components Outside the Pressure Vessel - Left
20-030-02-01	20-030-02	20-030-02		INSPECTION - DETAILED	DET of L/HIRF protection components Outside the Pressure Vessel- Right
20-040-01-01	20-040-01	20-040-01		FUNCTIONAL	H/L Sensitive Connectors Outside the Pressure Vessel - Left
20-040-02-01	20-040-02	20-040-02		FUNCTIONAL	HIRF/L Sensitive Connectors Outside the Pressure Vessel - Right
20-040-04-01	20-040-04	20-040-04		FUNCTIONAL	L/HIRF Protection Components Outside the Pressure Vessel - Vertical Stabilizer
20-040-05-01	20-040-05	20-040-05		FUNCTIONAL	Lightning/HIRF Protection Components - Wing to Body Fairing, Left
20-040-05-02	20-040-05	20-040-05		FUNCTIONAL	Lightning/HIRF Protection Components - Wing to Body Fairing, Right
20-040-06-01	20-040-06	20-040-06		FUNCTIONAL	Lightning/HIRF Protection Components - Wing to Body Fairing, Left
20-040-06-02	20-040-06	20-040-06		FUNCTIONAL	Lightning/HIRF Protection Components - Wing to Body Fairing, Right
20-050-00-01	20-050-00	20-050-00		INSPECTION - DETAILED	DVI of HIRF/L Sensitive Connectors Inside Pressure Vessel
20-060-00-01	20-060-00	20-060-00		FUNCTIONAL	H/L Sensitive Connectors Inside Pressure Vessel
20-070-00-01	20-070-00	20-070-00		INSPECTION - DETAILED	DVI of HIRF/L Sensitive Pig Tails Inside the Pressure Vessel
20-100-00-01	20-100-00	20-100-00		INSPECTION - GEN VISUAL	GVI of HIRF/L Sensitive Bonding Straps (Flight Controls, Door)
20-110-01-01	20-110-01	20-110-01		INSPECTION - GEN VISUAL	Engine Harness (Cowl Open) - Left Engine
20-110-02-01	20-110-02	20-110-02		INSPECTION - GEN VISUAL	Engine Harness (Cowl Open) - Right Engine



# 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

## TASKS SORTED BY TASK CARD NUMBER

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
20-120-01-01	20-120-01	20-120-01		INSPECTION - DETAILED	Connector Tightness - Left Engine
20-120-02-01	20-120-02	20-120-02		INSPECTION - DETAILED	Connector Tightness - Right Engine
20-130-01-01	20-130-01	20-130-01		INSPECTION - GEN VISUAL	Bonding Straps GVI - Left Engine
20-130-02-01	20-130-02	20-130-02		INSPECTION - GEN VISUAL	Bonding Straps GVI - Right Engine
20-140-00-01	20-140-00	20-140-00		FUNCTIONAL	H/L Sensitive Connectors Inside the Empennage
20-141-00-01	20-141-00	20-141-00		FUNCTIONAL	Lightning/HIRF Protection Components - Tail Cone (L/HIRF)
20-142-01-01	20-142-01	20-142-01		FUNCTIONAL	Lightning/HIRF Protection Components Aft of E/E rack in the FWD Cargo Compartment
20-142-02-01	20-142-02	20-142-02		FUNCTIONAL	Lightning/HIRF Protection Components Aft of E/E rack in the FWD Cargo Compartment
20-142-03-01	20-142-03	20-142-03		FUNCTIONAL	Lightning/HIRF Protection Components Aft of E/E rack in the FWD Cargo Compartment
20-290-00-01	20-290-00	20-290-00		RESTORE	Area Forward of Nose Wheel Well
20-300-00-01	20-300-00	20-300-00		RESTORE	Area Above Nose Wheel Well And Outbd of Nose Wheel Well
20-305-00-01	20-305-00	20-305-00		INSPECTION - DETAILED	External power feeder wiring and connected EWIS
20-310-00-01	20-310-00	20-310-00		RESTORE	Electrical and Electronics Compartment
20-320-00-01	20-320-00	20-320-00		INSPECTION - DETAILED	Electrical and Electronics Compartment
20-325-00-01	20-325-00	20-325-00		INSPECTION - GEN VISUAL	Exposed EWIS in the Electrical and Electronics Compartment
20-330-00-01	20-330-00	20-330-00		RESTORE	Forward Cargo Compartment
20-335-00-01	20-335-00	20-335-00		INSPECTION - GEN VISUAL	Exposed EWIS in the Forward Cargo Compartment. (EZAP)



## 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

### TASKS SORTED BY TASK CARD NUMBER

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
20-340-00-01	20-340-00	20-340-00		RESTORE	Area Below Forward Cargo Compartment
20-350-00-01	20-350-00	20-350-00		RESTORE	Area AFT of Forward Cargo Compartment
20-360-00-01	20-360-00	20-360-00		INSPECTION - GEN VISUAL	Main Landing Gear Wheel Well
20-370-00-01	20-370-00	20-370-00		RESTORE	Aft Cargo Compartment
20-375-00-01	20-375-00	20-375-00		INSPECTION - GEN VISUAL	Exposed EWIS in Aft Cargo Compartment
20-380-00-01	20-380-00	20-380-00		RESTORE	Area Below Aft Cargo Compartment
20-390-00-01	20-390-00	20-390-00		RESTORE	Aft Cargo Compartment Equipment Bay
20-400-00-01	20-400-00	20-400-00		RESTORE	Flight Compartment
20-410-00-01	20-410-00	20-410-00		INSPECTION - DETAILED	Flight Compartment
20-415-00-01	20-415-00	20-415-00		INSPECTION - GEN VISUAL	Exposed EWIS in Flight Compartment
20-420-00-01	20-420-00	20-420-00		RESTORE	Passenger Compartment - Aft of Control Compartment to Fwd Entry Door
20-430-00-01	20-430-00	20-430-00		RESTORE	Fwd Passenger Compartment - Fwd Entry Door to STA 663.75
20-435-00-01	20-435-00	20-435-00		RESTORE	Restore Passenger Compartment, Sta. 360 to 663.75
20-440-00-01	20-440-00	20-440-00		RESTORE	Aft Passenger Compartment - STA 663.75 to Aft Pressure Bulkhead
20-445-00-01	20-445-00	20-445-00		RESTORE	Restore Passenger Compartment STA 663.75 to Aft Pressure Bulkhead
20-450-00-01	20-450-00	20-450-00		INSPECTION - DETAILED	Area Aft of Pressure Bulkhead
20-460-00-01	20-460-00	20-460-00		INSPECTION - DETAILED	APU Compartment
20-465-00-01	20-465-00	20-465-00		INSPECTION - GEN VISUAL	Exposed EWIS in the tail cone
20-470-00-01	20-470-00	20-470-00		INSPECTION - DETAILED	Engine No. 1



## 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

### TASKS SORTED BY TASK CARD NUMBER

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
20-480-00-01	20-480-00	20-480-00		INSPECTION - DETAILED	Engine No. 2
20-490-00-01	20-490-00	20-490-00		INSPECTION - DETAILED	Fwd Strut Fairing - Engine No. 1
20-500-00-01	20-500-00	20-500-00		INSPECTION - DETAILED	Fan Cowl Support Beam - Engine No. 1
20-510-00-01	20-510-00	20-510-00		INSPECTION - DETAILED	Strut Torque Box - Engine No. 1
20-520-00-01	20-520-00	20-520-00		INSPECTION - DETAILED	Fwd Strut Fairing - Engine No. 2
20-530-00-01	20-530-00	20-530-00		INSPECTION - DETAILED	Fan Cowl Support Beam - Engine No. 2
20-540-00-01	20-540-00	20-540-00		INSPECTION - DETAILED	Strut Torque Box - Engine No. 2
20-550-00-01	20-550-00	20-550-00		INSPECTION - DETAILED	Leading Edge to Front Spar - Inboard of Nacelle Strut - Left Wing
20-560-00-01	20-560-00	20-560-00		INSPECTION - DETAILED	Leading Edge to Front Spar - Outboard of Nacelle Strut - Left Wing
20-570-00-01	20-570-00	20-570-00		INSPECTION - DETAILED	Rear Spar to Landing Gear Support Beam - Left Wing
20-580-00-01	20-580-00	20-580-00		INSPECTION - DETAILED	Rear Spar to T.E. - Outbd of Inbd Flap - Inbd of Fixed T.E. - Left Wing
20-590-00-01	20-590-00	20-590-00		INSPECTION - DETAILED	Leading Edge to Front Spar - Inboard of Nacelle Strut - Right Wing
20-600-00-01	20-600-00	20-600-00		INSPECTION - DETAILED	Leading Edge to Front Spar - Outboard of Nacelle Strut - Right Wing
20-610-00-01	20-610-00	20-610-00		INSPECTION - DETAILED	Rear Spar to Landing Gear Support Beam - Right Wing
20-620-00-01	20-620-00	20-620-00		INSPECTION - DETAILED	Rear Spar to T.E. - Outbd of Inbd Flap - Inbd of Fixed T.E. - Right Wing



# 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

## TASKS SORTED BY TASK CARD NUMBER

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
20-630-00-01	20-630-00			RESTORE	Main Deck Cargo Compartment - STA 360 to STA 1016
20-640-00-01	20-640-00			RESTORE	Restore Main Deck Cargo Compartment, Sta. 360 to 1016
21-010-00-01	21-010-00	21-010-00		REPLACE	Recirculation Fan Hepa Filter(s)
21-015-00-01	21-015-00	21-015-00		INSPECTION - DETAILED	Recirculation Fan Check Valve(s)
21-020-00-01	21-020-00	21-020-00		OPERATIONAL	Alternate E/E Cooling Supply Fan
21-030-00-01	21-030-00	21-030-00		OPERATIONAL	Alternate E/E Cooling Exhaust Fan
21-040-00-01	21-040-00	21-040-00		REPLACE	E/E Cooling Supply Fan Filter
21-050-00-01	21-050-00	21-050-00		OPERATIONAL	Overboard Exhaust Valve Check
21-060-00-01	21-060-00	21-060-00		OPERATIONAL	Outflow Valve Motor, Selector Panel, Indicator, Feed Back Module
21-070-00-01	21-070-00	21-070-00		FUNCTIONAL	Positive Pressure Relief Valves
21-080-00-01	21-080-00	21-080-00		REPLACE	Positive Pressure Relief Valves Filters
21-090-00-01	21-090-00	21-090-00		FUNCTIONAL	Negative Pressure Relief Door
21-100-00-01	21-100-00	21-100-00		RESTORE	Primary and Secondary Heat Exchangers
21-100-00-03	21-100-00	21-100-00		RESTORE	Primary and Secondary Heat Exchangers
21-100-00-04	21-100-00	21-100-00		RESTORE	Primary and Secondary Heat Exchangers
21-110-01-01	21-110-01	21-110-01		FUNCTIONAL	Compressor Discharge and Turbine Inlet Overheat Switches
21-110-02-01	21-110-02	21-110-02		FUNCTIONAL	Compressor Discharge and Turbine Inlet Overheat Switches
21-120-00-01	21-120-00	21-120-00		OPERATIONAL	Pack Overheat Switch
21-120-00-02	21-120-00	21-120-00		OPERATIONAL	Pack Overheat Switch
21-130-00-01	21-130-00	21-130-00		OPERATIONAL	Trim Air Pressure Regulator and Shutoff Valve
21-140-01-01	21-140-01	21-140-01		OPERATIONAL	Water Separator Indication Disk
21-140-02-01	21-140-02	21-140-02		OPERATIONAL	Water Separator Indication Disk
21-150-00-01	21-150-00	21-150-00		RESTORE	Cabin Temperature Sensor Filters



## 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

### TASKS SORTED BY TASK CARD NUMBER

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
21-160-00-01	21-160-00	21-160-00		RESTORE	Ozone Converters
21-170-00-01	21-170-00	21-170-00		INSPECTION - DETAILED	Pack Supply Air Cleaner System
21-180-00-01	21-180-00	21-180-00		OPERATIONAL	Pack Supply Air Cleaner System
21-190-00-01	21-190-00	21-190-00		DISCARD	APU Boot Pressure Seal
23-030-00-01	23-030-00	23-030-00		FUNCTIONAL	Resistance of Static Discharges
23-040-00-01	23-040-00	23-040-00		OPERATIONAL	Voice Recorder
23-050-00-01	23-050-00	23-050-00		FUNCTIONAL	Voice Recorder for Audio Fidelity
23-052-00-01	23-052-00	23-052-00		DISCARD	RIPS System Battery
23-054-00-01	23-054-00	23-054-00		FUNCTIONAL	RIPS Capacity
23-056-00-01	23-056-00	23-056-00		FUNCTIONAL	RIPS Maintenance Port
23-060-00-01	23-060-00	23-060-00	W-23-070-00-01	OPERATIONAL	ULB (Underwater Locator Beacon) for Voice Recorder
23-070-00-01	23-070-00	23-070-00	W-23-060-00-01	REPLACE	ULB (Underwater Locator Beacon) for Voice Recorder
23-080-00-01	23-080-00	23-080-00		OPERATIONAL	Oxygen Mask Microphone
23-100-00-01	23-100-00	23-100-00		OPERATIONAL	Emergency Locator Transmitter (Automatic / Fixed Type)
23-100-00-02	23-100-00	23-100-00		OPERATIONAL	Emergency Locator Transmitter (Automatic / Fixed Type)
23-100-00-03	23-100-00	23-100-00		OPERATIONAL	Emergency Locator Transmitter (Automatic / Fixed Type)
23-110-00-01	23-110-00	23-110-00		DISCARD	Emergency Locator Transmitter (Automatic / Fixed Type) Battery
23-110-00-02	23-110-00	23-110-00		DISCARD	Emergency Locator Transmitter (Automatic / Fixed Type) Battery
23-110-00-03	23-110-00	23-110-00		DISCARD	Emergency Locator Transmitter (Automatic / Fixed Type) Battery
23-120-00-01	23-120-00	23-120-00		FUNCTIONAL	Functionally check the underwater locator device
23-130-00-01	23-130-00	23-130-00		DISCARD	Discard the underwater locator device battery
24-010-01-01	24-010-01	24-010-01	W-24-040-01-01	SERVICE	IDG Oil - Left IDG
24-010-02-01	24-010-02	24-010-02	W-24-040-02-01	SERVICE	IDG Oil - Right IDG





## 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

### TASKS SORTED BY TASK CARD NUMBER

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
24-020-01-01	24-020-01	24-020-01	W-24-010-01-01 W-24-010-02-01	INSPECTION - DETAILED	Left IDG Delta P Indicator (DPI)
24-020-02-01	24-020-02	24-020-02		INSPECTION - DETAILED	Right IDG Delta P Indicator (DPI)
24-030-01-01	24-030-01	24-030-01		INSPECTION - DETAILED	Left IDG Oil Level
24-030-02-01	24-030-02	24-030-02		INSPECTION - DETAILED	Right IDG Oil Level
24-040-01-01	24-040-01	24-040-01		REPLACE	Left IDG Charge and Scavenge Filters
24-040-02-01	24-040-02	24-040-02		REPLACE	Right IDG Charge and Scavenge Filters
24-050-01-01	24-050-01	24-050-01		FUNCTIONAL	Left QAD
24-050-02-01	24-050-02	24-050-02		FUNCTIONAL	Right QAD
24-060-01-01	24-060-01	24-060-01		INSPECTION - GEN VISUAL	Left Engine IDG Surface Air Cooled Oil Cooler
24-060-02-01	24-060-02	24-060-02		INSPECTION - GEN VISUAL	Right Engine IDG Surface Air Cooled Oil Cooler
24-080-00-01	24-080-00	24-080-00		OPERATIONAL	Standby Power Control Unit (SPCU)
24-090-00-02	24-090-00	24-090-00		RESTORE	Restore the Main Battery
24-100-00-01	24-100-00	24-100-00		OPERATIONAL	Standby Power Control Unit (SPCU)
24-110-00-01	24-110-00	24-110-00		OPERATIONAL	Remote Control Circuit Breaker
24-120-00-01	24-120-00	24-120-00		RESTORE	Restore the Main and Auxiliary Batteries
24-130-00-01	24-130-00	24-130-00		FUNCTIONAL	External Power Receptacle (Wear Check)
24-140-00-01	24-140-00	24-140-00		INSPECTION - DETAILED	External Power Receptacle (Inspection)
25-010-01-01	25-010-01	25-010-01		INSPECTION - DETAILED	Captains Seat Tracks and Locking Mechanism
25-010-02-01	25-010-02	25-010-02		INSPECTION - DETAILED	First Officer seat tracks and locking mechanism



**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
25-020-00-01	25-020-00	25-020-00		INSPECTION - DETAILED	Flight Compartment Crew Seat Harnesses, Straps, and Belts
25-030-00-01	25-030-00	25-030-00		OPERATIONAL	Check Captain, First Officer, & First Observer Seat Harness Inertia Reels
25-040-00-01	25-040-00	25-040-00		INSPECTION - DETAILED	Inspect Passenger Seat Belts
25-041-00-01	25-041-00	25-041-00		OPERATIONAL	Inflatable Seat Restraint System Operational Check
25-042-00-01	25-042-00	25-042-00		INSPECTION - DETAILED	Inflatable Seat Restraint System Detailed Inspection
25-043-00-01	25-043-00	25-043-00		DISCARD	Inflatable Seat Restraint System Inflator
25-044-00-01	25-044-00	25-044-00		RESTORE	Inflatable Seat Restraint System Electronics Module Assembly
25-045-00-01	25-045-00	25-045-00		INSPECTION - DETAILED	Passenger Compartment Seats
25-050-00-01	25-050-00	25-050-00		OPERATIONAL	Check Passenger Seat Break-Over Feature
25-070-00-01	25-070-00	25-070-00		FUNCTIONAL	Inspect Passenger Seat Back Recline Mechanisms
25-090-00-01	25-090-00	25-090-00		INSPECTION - DETAILED	Inspect Attendant Seat Harness
25-100-00-01	25-100-00	25-100-00		OPERATIONAL	Check Attendant Seat Harness
25-130-00-01	25-130-00	25-130-00		INSPECTION - DETAILED	Lavatory Waste Compartment Flapper Door and Spring and Access Door
25-160-00-01	25-160-00	25-160-00		INSPECTION - GEN VISUAL	Inspect Fwd Cargo Compartment Panels/Liners
25-160-00-02	25-160-00	25-160-00		INSPECTION - GEN VISUAL	Inspect Aft Cargo Compartment Panels/Liners
25-165-00-01	25-165-00	25-165-00		INSPECTION - GEN VISUAL	Inspect Main Deck Cargo Compartment Panels/Liners
25-170-00-01	25-170-00	25-170-00		INSPECTION - GEN VISUAL	Inspect Forward Cargo Door Restraint System



## 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

### TASKS SORTED BY TASK CARD NUMBER

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
25-170-00-02	25-170-00	25-170-00	W-25-390-00-01 W-25-395-00-01	INSPECTION - GEN VISUAL	Inspect Aft Cargo Door Restraint System
25-190-01-01	25-190-01	25-190-01		INSPECTION - DETAILED	Left Emergency Exit Hatch Escape Straps
25-190-02-01	25-190-02	25-190-02		INSPECTION - DETAILED	Right Emergency Exit Hatch Escape Straps
25-210-00-01	25-210-00	25-210-00		INSPECTION - DETAILED	Inspect Flight Compartment Escape Lanyards
25-220-00-01	25-220-00	25-220-00		OPERATIONAL	Emergency Escape System Operational Check
25-225-00-01	25-225-00	25-225-00		OPERATIONAL	Mid-Exit Door Emergency Escape System Operational Check
25-240-00-01	25-240-00	25-240-00		RESTORE	Fwd Entry Emergency Escape Slide
25-240-00-02	25-240-00	25-240-00		RESTORE	Fwd Galley Emergency Escape Slide
25-240-00-03	25-240-00	25-240-00		RESTORE	Aft Entry Emergency Escape Slide
25-240-00-04	25-240-00	25-240-00		RESTORE	Aft Galley Emergency Escape Slide
25-245-00-01	25-245-00	25-245-00		RESTORE	Left Mid-Exit Doors Emergency Escape Slide
25-245-00-02	25-245-00	25-245-00		RESTORE	Right Mid-Exit Door Emergency Escape Slide
25-290-00-01	25-290-00	25-290-00		RESTORE	Restore Life Jackets
25-300-00-01	25-300-00	25-300-00		RESTORE	Restore Life Rafts
25-305-00-01	25-305-00	25-305-00		RESTORE	Restore Flight Deck Life Raft
25-330-00-01	25-330-00	25-330-00		OPERATIONAL	Power Megaphones
25-340-00-01	25-340-00	25-340-00		REPLACE	Power Megaphones Batteries
25-350-00-01	25-350-00	25-350-00		OPERATIONAL	Emergency Locator Transmitter (Survival / Portable Type)
25-360-00-01	25-360-00	25-360-00		DISCARD	Emergency Locator Transmitter (Survival / Portable Type) - Batteries
25-370-00-01	25-370-00	25-370-00		VISUAL CHECK	Detachable Emergency Equipment
25-380-00-01	25-380-00	25-380-00		OPERATIONAL	Emergency Flashlights



## 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

### TASKS SORTED BY TASK CARD NUMBER

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
25-380-00-02	25-380-00	25-380-00		OPERATIONAL	Emergency Flashlights
25-390-00-01	25-390-00	25-390-00	W-25-380-00-01	REPLACE	Emergency Flashlights Batteries
25-395-00-01	25-395-00	25-395-00	W-25-380-00-01	RESTORE	Restore Emergency Flashlight Batteries
25-400-00-01	25-400-00	25-400-00		INSPECTION - DETAILED	Smoke Hoods
25-410-00-01	25-410-00	25-410-00		DISCARD	Smoke Hoods
25-420-00-01	25-420-00	25-420-00		RESTORE	First Aid Kits
25-430-00-01	25-430-00	25-430-00		RESTORE	Medical Kits
25-440-00-01	25-440-00	25-440-00		OPERATIONAL	Emergency Alert Panels
25-450-00-01	25-450-00	25-450-00		INSPECTION - GEN VISUAL	Pallet Locks, Forward End Stops, and Aft End Stops
25-450-00-02	25-450-00	25-450-00		INSPECTION - GEN VISUAL	Pallet Locks, Forward End Stops, and Aft End Stops
25-460-00-01	25-460-00	25-460-00		INSPECTION - GEN VISUAL	Main Deck Cargo Barrier Net Receptacle Fittings
25-470-00-01	25-470-00	25-470-00		INSPECTION - DETAILED	Main Deck Cargo Barrier Net and Fittings
25-480-00-01	25-480-00	25-480-00		FUNCTIONAL	Main Deck Cargo Barrier Net Test Strap
26-010-00-01	26-010-00	26-010-00		OPERATIONAL	Lavatory Smoke Detector
26-018-00-01	26-018-00	26-018-00		OPERATIONAL	Wing and Lower Aft Body Overheat Detection
26-020-00-01	26-020-00	26-020-00		RESTORE	Lavatory Smoke Detector Grill Cleaning
26-030-00-01	26-030-00	26-030-00		OPERATIONAL	APU Remote Fire Detection System
26-050-00-01	26-050-00	26-050-00		VISUAL CHECK	Engine Fire Bottle Pressure Gauges
26-070-00-01	26-070-00	26-070-00		REPLACE	Engine Fire Bottle Squib
26-080-00-01	26-080-00	26-080-00		FUNCTIONAL	Engine Fire Extinguishing System Squib Circuit



# 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

## TASKS SORTED BY TASK CARD NUMBER

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
26-090-00-01	26-090-00	26-090-00	W-26-100-00-01 W-26-120-00-01 W-26-130-00-01	OPERATIONAL	Engine Fire Extinguishing System Check Valve
26-100-00-01	26-100-00	26-100-00	W-26-090-00-01 W-26-120-00-01 W-26-130-00-01	FUNCTIONAL	Engine Fire Bottle Pressure Switch
26-110-00-01	26-110-00	26-110-00	W-29-100-00-01	OPERATIONAL	Engine Fire Handle for Engine Shutdown and Isolation
26-120-00-01	26-120-00	26-120-00	W-26-090-00-01 W-26-100-00-01 W-26-130-00-01	FUNCTIONAL	Engine Fire Bottle Pressure Gauge
26-130-00-01	26-130-00	26-130-00	W-26-090-00-01 W-26-100-00-01 W-26-120-00-01	DISCARD	Engine Fire Bottle Pressure Relief Disc.
26-140-00-01	26-140-00	26-140-00		FUNCTIONAL	Engine Fire Bottle Weight Check
26-150-00-01	26-150-00	26-150-00		FUNCTIONAL	Engine Fire Extinguisher Distribution System
26-170-00-01	26-170-00	26-170-00		INSPECTION - GEN VISUAL	Engine Fire Extinguisher Distribution System
26-210-00-01	26-210-00	26-210-00		REPLACE	APU Fire Bottle Squib
26-220-00-01	26-220-00	26-220-00		FUNCTIONAL	APU Fire Extinguishing System Squib Circuit
26-230-00-01	26-230-00	26-230-00		OPERATIONAL	APU Fire Handle for APU Shutdown and Isolation
26-250-00-01	26-250-00	26-250-00		INSPECTION - GEN VISUAL	APU Remote Control Panel
26-260-00-01	26-260-00	26-260-00		FUNCTIONAL	APU Fire Bottle Pressure Switch
26-265-00-01	26-265-00	26-265-00		FUNCTIONAL	APU Fire Bottle Pressure Gauge
26-270-00-01	26-270-00	26-270-00		DISCARD	APU Fire Bottle Over Pressure Relief Disc
26-275-00-01	26-275-00	26-275-00		FUNCTIONAL	APU Fire Bottle Weight Check
26-280-00-01	26-280-00	26-280-00		INSPECTION - DETAILED	APU Fire Extinguisher Distribution System



**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
26-290-00-01	26-290-00	26-290-00		FUNCTIONAL	Lavatory Fire Bottle Weight Check
26-300-00-01	26-300-00	26-300-00		INSPECTION - DETAILED	Lavatory Fire Bottle Fusible Tips and Discharge
26-310-00-01	26-310-00	26-310-00		VISUAL CHECK	Lavatory Heat Sensitive Tape
26-330-00-01	26-330-00	26-330-00		REPLACE	Cargo Fire Bottle Squib
26-330-00-02	26-330-00	26-330-00		REPLACE	Cargo Fire Bottle Squib
26-340-00-01	26-340-00	26-340-00		FUNCTIONAL	Cargo Fire Extinguishing Tubing
26-340-00-02	26-340-00	26-340-00		FUNCTIONAL	Cargo Fire Extinguishing Tubing
26-340-00-03	26-340-00	26-340-00		FUNCTIONAL	Cargo Fire Extinguishing Tubing
26-340-00-04	26-340-00	26-340-00		FUNCTIONAL	Cargo Fire Extinguishing Tubing
26-360-00-01	26-360-00	26-360-00		FUNCTIONAL	Cargo Fire Bottle Pressure Switch
26-360-00-02	26-360-00	26-360-00		FUNCTIONAL	Cargo Fire Bottle Pressure Switch
26-365-00-01	26-365-00	26-365-00		FUNCTIONAL	Cargo Fire Bottle(s) Weight Check
26-365-00-02	26-365-00	26-365-00		FUNCTIONAL	Cargo Fire Bottle(s) Weight Check
26-370-00-01	26-370-00	26-370-00		OPERATIONAL	Cargo Fire Extinguishing Arm/Discharge Switches
26-370-00-02	26-370-00	26-370-00	W-26-400-00-01	OPERATIONAL	Cargo Fire Extinguishing Arm/Discharge Switches
26-370-00-03	26-370-00	26-370-00	W-26-400-00-03	OPERATIONAL	Cargo Fire Extinguishing Arm/Discharge Switches
26-370-00-04	26-370-00	26-370-00	W-26-400-00-04	OPERATIONAL	Cargo Fire Extinguishing Arm/Discharge Switches
26-390-00-01	26-390-00	26-390-00		REPLACE	Cargo Fire Extinguishing System
26-400-00-01	26-400-00	26-400-00	W-26-370-00-02	FUNCTIONAL	Cargo Fire Extinguishing 60-Minute Timer
26-400-00-03	26-400-00	26-400-00	W-26-370-00-03	FUNCTIONAL	Cargo Fire Extinguishing 60-Minute Timer
26-400-00-04	26-400-00	26-400-00	W-26-370-00-04	FUNCTIONAL	Cargo Fire Extinguishing 60-Minute Timer
26-410-00-01	26-410-00	26-410-00		OPERATIONAL	Cargo Fire Protection Operation Check
26-411-00-01	26-411-00	26-411-00		OPERATIONAL	Cargo Fire Protection Air supply Shutoff Valves Operational Check



**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
26-412-00-01	26-412-00	26-412-00		OPERATIONAL	Cargo Fire Protection Mix Manifold Exhaust Shutoff Valves Operational Check
26-414-00-01	26-414-00	26-414-00		OPERATIONAL	Pressurization Control Panel Outflow Valve Operational Check
26-420-00-01	26-420-00	26-420-00		RESTORE	Main Deck Cargo Compartment Ceiling Grill Cleaning
26-430-00-01	26-430-00	26-430-00		OPERATIONAL	Operationally Check the Forward Galley Smoke Detector
26-440-00-01	26-440-00	26-440-00		RESTORE	Forward Galley Smoke Detector Grill Cleaning
26-450-00-01	26-450-00	26-450-00		INSPECTION - DETAILED	Portable Halon Fire Extinguishers Inspection
26-470-00-01	26-470-00	26-470-00		INSPECTION - DETAILED	Portable Water Fire Extinguisher Inspection
26-510-00-01	26-510-00	26-510-00		INSPECTION - DETAILED	Inspect Portable Chemical Fire Extinguishers
26-550-02-01	26-550-02			INSPECTION - DETAILED	Center Wing Rear Spar Vapor Web
27-011-00-01	27-011-00	27-011-00		INSPECTION - GEN VISUAL	Aileron Mechanical Components
27-012-00-01	27-012-00	27-012-00		INSPECTION - GEN VISUAL	Aileron Transfer Mechanism
27-013-01-01	27-013-01	27-013-01		INSPECTION - GEN VISUAL	Left Wing Aileron Mechanical Components
27-013-02-01	27-013-02	27-013-02		INSPECTION - GEN VISUAL	Right Wing Aileron Mechanical Components
27-016-00-01	27-016-00	27-016-00		OPERATIONAL	Aileron Spring Cartridge and Transfer Mechanism
27-018-00-01	27-018-00	27-018-00		FUNCTIONAL	Aileron Spring Cartridge and Transfer Mechanism
27-022-00-01	27-022-00	27-022-00		FUNCTIONAL	Aileron Power Control Units
27-024-00-01	27-024-00	27-024-00		FUNCTIONAL	Aileron PCU Internal Leakage Test
27-026-01-01	27-026-01	27-026-01		LUBRICATE	Left Wing Aileron Lubrication



# 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

## TASKS SORTED BY TASK CARD NUMBER

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
27-026-02-01	27-026-02	27-026-02		LUBRICATE	Right Wing Aileron Lubrication
27-028-00-01	27-028-00	27-028-00		INSPECTION - DETAILED	Aileron Feel and Centering Springs
27-030-00-01	27-030-00	27-030-00		OPERATIONAL	Full Range Aileron Travel
27-032-00-01	27-032-00	27-032-00		FUNCTIONAL	Aileron Wheel Forces
27-033-00-01	27-033-00	27-033-00	W-27-035-00-01	FUNCTIONAL	Left Wing Aileron Tab Freeplay Inspection
27-033-00-02	27-033-00	27-033-00	W-27-035-00-02	FUNCTIONAL	Right Wing Aileron Tab Freeplay Inspection
27-034-01-01	27-034-01	27-034-01		INSPECTION - DETAILED	Left Wing Aileron Balance Bay Seals
27-034-02-01	27-034-02	27-034-02		INSPECTION - DETAILED	Right Wing Aileron Balance Bay Seals
27-035-00-01	27-035-00	27-035-00	W-27-033-00-01	FUNCTIONAL	Left Wing Aileron Surface Freeplay Inspection
27-035-00-02	27-035-00	27-035-00	W-27-033-00-02	FUNCTIONAL	Right Wing Aileron Surface Freeplay Inspection
27-036-00-01	27-036-00	27-036-00		INSPECTION - DETAILED	RUDDER AFT COMPONENTS
27-038-00-01	27-038-00	27-038-00		INSPECTION - DETAILED	Forward Rudder Mechanical Control Path
27-040-00-01	27-040-00	27-040-00		LUBRICATE	Feel and Centering Spring Lubrication
27-041-00-01	27-041-00	27-041-00		OPERATIONAL	Operational Check of the Main Rudder PCU Force Fight Monitor
27-043-00-01	27-043-00	27-043-00		OPERATIONAL	Operational Check of Rudder PCU Overrides
27-044-00-01	27-044-00	27-044-00		FUNCTIONAL	Rudder PCU Internal Leakage Check
27-046-00-01	27-046-00	27-046-00		LUBRICATE	Rudder PCU and Hinge Lubrication
27-047-00-01	27-047-00	27-047-00	W-27-048-00-01	FUNCTIONAL	Rudder PCU Internal Leakage Check
27-048-00-01	27-048-00	27-048-00	W-27-047-00-01	FUNCTIONAL	RUDDER AUTHORITY LIMITER
27-050-00-01	27-050-00	27-050-00		OPERATIONAL	Rudder PCU Pressure Reducing Valve
27-054-00-01	27-054-00	27-054-00		FUNCTIONAL	Standby Rudder PCU Internal Leakage Test





# 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

## TASKS SORTED BY TASK CARD NUMBER

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
27-056-00-01	27-056-00	27-056-00	W-27-024-00-01 W-27-210-00-01 W-27-212-00-01	INSPECTION - GEN VISUAL	Standby Rudder Power Control Unit
27-058-00-01	27-058-00	27-058-00		INSPECTION - DETAILED	Standby Rudder PCU Attachment Points
27-060-00-01	27-060-00	27-060-00		OPERATIONAL	Wheel to Rudder Interconnect
27-060-00-02	27-060-00	27-060-00		OPERATIONAL	Wheel to Rudder Interconnect
27-062-00-01	27-062-00	27-062-00		OPERATIONAL	Rudder Trim Travel
27-062-00-02	27-062-00	27-062-00		OPERATIONAL	Rudder Trim Travel
27-064-00-01	27-064-00	27-064-00		FUNCTIONAL	Rudder Surface Freeplay
27-064-00-02	27-064-00	27-064-00		FUNCTIONAL	Rudder Surface Freeplay
27-068-00-01	27-068-00	27-068-00		OPERATIONAL	Elevator Feel Shift Function
27-070-00-01	27-070-00	27-070-00		LUBRICATE	Left Elevator Lubrication
27-070-00-02	27-070-00	27-070-00		LUBRICATE	Right Elevator Lubrication
27-073-00-01	27-073-00	27-073-00		INSPECTION - GEN VISUAL	Elevator Mechanical Control Path
27-074-00-01	27-074-00	27-074-00		OPERATIONAL	Elevator Range of Travel
27-075-01-01	27-075-01	27-075-01		INSPECTION - GEN VISUAL	Left Elevator Balance Weight and Tab Control Mechanism
27-075-02-01	27-075-02	27-075-02		INSPECTION - GEN VISUAL	Right Elevator Balance Weight and Tab Control Mechanism
27-076-00-01	27-076-00	27-076-00		INSPECTION - GEN VISUAL	Elevator Power Control Unit Inspection
27-078-00-01	27-078-00	27-078-00		FUNCTIONAL	Elevator PCU Internal Leakage Test
27-080-00-01	27-080-00	27-080-00		FUNCTIONAL	Elevator Pitot Static Tube
27-084-00-01	27-084-00	27-084-00		FUNCTIONAL	Elevator Control Column Override



# 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

## TASKS SORTED BY TASK CARD NUMBER

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
27-086-00-01	27-086-00	27-086-00		OPERATIONAL	Elevator Tab Control
27-088-00-01	27-088-00	27-088-00		FUNCTIONAL	Stall Warning System
27-092-00-01	27-092-00	27-092-00		FUNCTIONAL	Elevator Input Rod Pogo's
27-093-00-01	27-093-00	27-093-00		INSPECTION - DETAILED	Left Elevator Tab and Tab Mechanism Inspection
27-093-00-02	27-093-00	27-093-00		INSPECTION - DETAILED	Right Elevator Tab and Tab Mechanism Inspection
27-094-00-01	27-094-00	27-094-00		OPERATIONAL	Elevator Autopilot Servo Pressure Regulator
27-095-00-01	27-095-00	27-095-00		INSPECTION - DETAILED	Left Elevator Tab and Tab Mechanism Inspection
27-095-00-02	27-095-00	27-095-00		INSPECTION - DETAILED	Right Elevator Tab and Tab Mechanism Inspection
27-097-00-01	27-097-00	27-097-00		FUNCTIONAL	Left Elevator Balance Tab Freeplay Check
27-097-00-02	27-097-00	27-097-00		FUNCTIONAL	Right Elevator Balance Tab Freeplay Check
27-098-01-01	27-098-01	27-098-01		FUNCTIONAL	Left and Right Elevator Surface Freeplay Check
27-099-00-01	27-099-00	27-099-00		FUNCTIONAL	Elevator Balance Tab Freeplay Check
27-099-00-02	27-099-00	27-099-00		FUNCTIONAL	Elevator Balance Tab Freeplay Check
27-100-00-01	27-100-00	27-100-00		INSPECTION - DETAILED	Elevator Pushrods
27-101-00-01	27-101-00	27-101-00		INSPECTION - DETAILED	Feel and Centering Single Element Dual Load Path Components
27-102-00-01	27-102-00	27-102-00		LUBRICATE	Stabilizer Trim Actuator Lubrication
27-104-00-01	27-104-00	27-104-00		LUBRICATE	Forward Stabilizer Trim Drive Train
27-106-00-01	27-106-00	27-106-00	W-27-107-00-01	FUNCTIONAL	Secondary Stabilizer Trim Brake
27-107-00-01	27-107-00	27-107-00	W-27-106-00-01	SERVICE	Stabilizer Trim Brake Servicing
27-108-00-01	27-108-00	27-108-00		RESTORE	Stabilizer Trim Restoration



## 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

### TASKS SORTED BY TASK CARD NUMBER

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
27-110-00-01	27-110-00	27-110-00		INSPECTION - DETAILED	Stabilizer Trim Jackscrew Inspection
27-112-00-01	27-112-00	27-112-00		OPERATIONAL	Stabilizer Trim Limit Switches
27-114-00-01	27-114-00	27-114-00		OPERATIONAL	Control Column Switching Module
27-116-00-01	27-116-00	27-116-00		OPERATIONAL	Control Column Cutout Switches
27-118-00-01	27-118-00	27-118-00		OPERATIONAL	Stabilizer Trim Override Switch
27-120-00-01	27-120-00	27-120-00		INSPECTION - DETAILED	Stabilizer Trim Forward Mechanism
27-121-00-01	27-121-00	27-121-00		INSPECTION - GEN VISUAL	Forward Stabilizer Trim Mechanism and the Speedbrake Lever Assembly
27-122-00-01	27-122-00	27-122-00		OPERATIONAL	Stabilizer Trim Switches
27-132-00-01	27-132-00	27-132-00		SERVICE	Flap Power Drive Unit
27-134-00-01	27-134-00	27-134-00		SERVICE	Flap Power Drive Unit
27-136-01-01	27-136-01	27-136-01		LUBRICATE	Left Wing Flap Skew Sensor Mechanism Lubrication
27-136-02-01	27-136-02	27-136-02		LUBRICATE	Right Wing Flap Skew Sensor Mechanism Lubrication
27-138-00-01	27-138-00	27-138-00		LUBRICATE	Left Wing Flap Drive Torque Tubes
27-138-00-02	27-138-00	27-138-00		LUBRICATE	Right Wing Flap Drive Torque Tubes
27-140-01-01	27-140-01	27-140-01		SERVICE	Left Wing Flap Transmission Oil Level
27-140-02-01	27-140-02	27-140-02		SERVICE	Right Wing Flap Transmission Oil Level
27-142-01-01	27-142-01	27-142-01		SERVICE	Left Wing Flap Transmission Oil
27-142-02-01	27-142-02	27-142-02		SERVICE	Right Wing Flap Transmission Universal Oil
27-144-00-01	27-144-00	27-144-00		LUBRICATE	Left Wing Flap Ballscrew Assemblies and Transmission Universal Joints
27-144-00-02	27-144-00	27-144-00		LUBRICATE	Right Wing Flap Ballscrew Assemblies and Transmission Universal Joints
27-148-03-01	27-148-03	27-148-03		INSPECTION - DETAILED	Left Wing Ballscrew Assembly



# 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

## TASKS SORTED BY TASK CARD NUMBER

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
27-148-04-01	27-148-04	27-148-04		INSPECTION - DETAILED	Right Wing Ballscrew Assembly
27-152-01-01	27-152-01	27-152-01		LUBRICATE	#4 Flap Transmission Angle/Tee GearBox Universal Joints
27-152-02-01	27-152-02	27-152-02		LUBRICATE	#5 Flap Transmission Angle/Tee GearBox Universal Joints
27-154-00-01	27-154-00	27-154-00		OPERATIONAL	Flap Load Relief System
27-156-00-01	27-156-00	27-156-00		FUNCTIONAL	Flap Load Relief System
27-158-00-01	27-158-00	27-158-00		FUNCTIONAL	Alternate Flap Drive System
27-162-00-01	27-162-00	27-162-00		OPERATIONAL	Flap Skew and Asymmetry System
27-164-00-01	27-164-00	27-164-00		OPERATIONAL	Flap Uncommanded Motion Protection
27-166-00-01	27-166-00	27-166-00		INSPECTION - DETAILED	Flap Lever Sensor
27-168-01-01	27-168-01	27-168-01		OPERATIONAL	Left Wing Flap Transmission No-Back Brake
27-168-02-01	27-168-02	27-168-02		OPERATIONAL	Right Wing Flap Transmission No-Back Brake
27-170-01-01	27-170-01	27-170-01		LUBRICATE	Left Wing Flap Actuation Mechanism Lubrication
27-170-02-01	27-170-02	27-170-02		LUBRICATE	Right Wing Flap Actuation Mechanism Lubrication
27-171-01-01	27-171-01	27-171-01		INSPECTION - GEN VISUAL	Left Wing Flap Drive System
27-171-02-01	27-171-02	27-171-02		INSPECTION - GEN VISUAL	Right Wing Flap Drive System
27-172-01-01	27-172-01	27-172-01		INSPECTION - DETAILED	Left Wing Flap Actuation System
27-172-02-01	27-172-02	27-172-02		INSPECTION - DETAILED	Right Wing Flap Actuation System
27-174-01-01	27-174-01	27-174-01		LUBRICATE	Left Wing Forward Flap Track Attachment Pin
27-174-02-01	27-174-02	27-174-02		LUBRICATE	Right Wing Forward Flap Track Attachment Pin
27-176-01-01	27-176-01	27-176-01		LUBRICATE	Left Wing Inboard Flap Track Attachment Fitting



## 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

### TASKS SORTED BY TASK CARD NUMBER

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
27-176-02-01	27-176-02	27-176-02		LUBRICATE	Right Wing Inboard Flap Track Attachment Fitting
27-178-00-01	27-178-00	27-178-00		SERVICE	Alternate Flap Drive Gearbox Servicing
27-182-00-01	27-182-00	27-182-00		LUBRICATE	Lubricate the Spoiler Mechanical Control Path (Spoiler Mixer)
27-182-01-01	27-182-01	27-182-01		LUBRICATE	Left Wing Spoiler Mechanical Control Path Lubrication
27-182-02-01	27-182-02	27-182-02		LUBRICATE	Right Wing Spoiler Mechanical Control Path Lubrication
27-184-00-01	27-184-00	27-184-00		FUNCTIONAL	Spoiler Ratio Changer No-Back Assembly
27-186-00-01	27-186-00	27-186-00		LUBRICATE	Speedbrake Lever No-Back Brake
27-187-00-01	27-187-00	27-187-00		OPERATIONAL	Operationally Check the Speedbrake Handle Stop
27-188-00-01	27-188-00	27-188-00		OPERATIONAL	Speedbrake RTO System
27-188-00-02	27-188-00	27-188-00		OPERATIONAL	Operationally check the speedbrake refused takeoff (RTO) system for Short Field Performance option.
27-190-00-01	27-190-00	27-190-00		OPERATIONAL	Speedbrake Extended Light
27-191-00-01	27-191-00	27-191-00		FUNCTIONAL	Speedbrake Autostow System Functional Check
27-192-01-01	27-192-01	27-192-01		OPERATIONAL	Left Wing Spoiler Actuator Override Quadrants
27-192-02-01	27-192-02	27-192-02		OPERATIONAL	Right Wing Spoiler Actuator Override Quadrants
27-194-00-01	27-194-00	27-194-00		OPERATIONAL	Spoiler Mixer Centering Mechanism
27-196-00-01	27-196-00	27-196-00		FUNCTIONAL	Functionally Check the Spoiler Electrical Control System Relays for Continuity
27-210-00-01	27-210-00	27-210-00		FUNCTIONAL	Leading Edge Slat Actuators Internal Leakage Test
27-212-00-01	27-212-00	27-212-00		FUNCTIONAL	Leading Edge Flap Actuators Internal Leakage Test
27-214-00-01	27-214-00	27-214-00		OPERATIONAL	Leading Edge Standby Actuation
27-215-01-01	27-215-01	27-215-01		INSPECTION - GEN VISUAL	Left Wing Spoiler Actuators



**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

<b>TASK CARD NUMBER</b>	<b>MPD ITEM NUMBER</b>	<b>MRB ITEM NUMBER</b>	<b>RELATED TASK CARD NUMBER</b>	<b>TASK</b>	<b>TASK TITLE</b>
27-215-02-01	27-215-02	27-215-02		INSPECTION - GEN VISUAL	Right Wing Spoiler Actuators
27-215-03-01	27-215-03	27-215-03		INSPECTION - GEN VISUAL	Spoiler Mechanical Control Path
27-216-00-01	27-216-00	27-216-00		FUNCTIONAL	Autoslat System
27-218-00-01	27-218-00	27-218-00		OPERATIONAL	Leading Edge Uncommanded Motion Protection
27-220-01-01	27-220-01	27-220-01		LUBRICATE	Left Wing Leading Edge Slat Roller Lubrication
27-220-02-01	27-220-02	27-220-02		LUBRICATE	Right Wing Leading Edge Slat Roller Lubrication
27-222-01-01	27-222-01	27-222-01		LUBRICATE	Left Wing Leading Edge Slat Tracks
27-222-02-01	27-222-02	27-222-02		LUBRICATE	Right Wing Leading Edge Slat Tracks
27-224-00-01	27-224-00	27-224-00		OPERATIONAL	Standby Hydraulic System Leading Edge Uncommanded Motion
27-225-01-01	27-225-01	27-225-01		INSPECTION - GEN VISUAL	Left Wing Leading Edge Flap and Slat Actuators and Actuation Mechanism
27-225-02-01	27-225-02	27-225-02		INSPECTION - GEN VISUAL	Right Wing Leading Edge Flap and Slat Actuators and Actuation Mechanism
27-226-00-01	27-226-00	27-226-00	W-32-440-00-02	INSPECTION - DETAILED	Flight Control Cables - Left Main Gear Well
27-226-00-02	27-226-00	27-226-00	W-32-440-00-03	INSPECTION - DETAILED	Flight Control Cables - Right Main Gear Well
27-226-00-03	27-226-00	27-226-00		INSPECTION - DETAILED	Control Cables - Left Wing Aft Spar
27-226-00-04	27-226-00	27-226-00		INSPECTION - DETAILED	Control Cables - Right Wing Aft Spar Area
27-228-00-01	27-228-00	27-228-00		INSPECTION - DETAILED	Flight Control Cables - Area Above Main Landing Gear Wheel Well
27-228-00-02	27-228-00	27-228-00		INSPECTION - DETAILED	Flight Control Cables - Lower Nose Compartment



# 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

## TASKS SORTED BY TASK CARD NUMBER

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
27-228-00-03	27-228-00	27-228-00		INSPECTION - DETAILED	Flight Control Cables - EE Compartment
27-228-00-04	27-228-00	27-228-00		INSPECTION - DETAILED	Flight Control Cables - Air Conditioning Distribution Bay
27-228-00-05	27-228-00	27-228-00		INSPECTION - DETAILED	Flight Control Cables - Forward Cargo Compartment
27-228-00-06	27-228-00	27-228-00		INSPECTION - DETAILED	Flight Control Cables - Aft Cargo Compartment
27-228-00-07	27-228-00	27-228-00		INSPECTION - DETAILED	Flight Control Cables - Aft Cargo Compartment Equipment Bay
27-228-00-08	27-228-00	27-228-00		INSPECTION - DETAILED	Flight Control Cables - Tail Compartment
27-229-00-01	27-229-00	27-229-00	W-57-856-01-01	INSPECTION - DETAILED	Inboard Trailing Edge Aft Flap Drive Cable Inspection (Left Wing)
27-229-00-02	27-229-00	27-229-00	W-57-926-02-01	INSPECTION - DETAILED	Inboard Trailing Edge Aft Flap Drive Cable Inspection (Right Wing)
27-230-00-01	27-230-00	27-230-00	W-32-460-00-02	INSPECTION - DETAILED	Control Cables - Over Wing Center Section
27-230-00-02	27-230-00	27-230-00	W-32-460-00-01	INSPECTION - DETAILED	Control Cables - Control Quadrant
27-235-00-01	27-235-00	27-235-00		FUNCTIONAL	Flight Control Cable Tension
27-235-00-02	27-235-00	27-235-00		FUNCTIONAL	Flight Control Cable Tension
28-010-00-01	28-010-00	28-010-00		INSPECTION - GEN VISUAL	Inspect Fuel Tanks Lower Surface - External
28-020-01-01	28-020-01	28-020-01		OPERATIONAL	Operationally Check Left Surge Tank Pressure Relief Valves
28-020-02-01	28-020-02	28-020-02		OPERATIONAL	Operationally Check Right Surge Tank Pressure Relief Valves
28-030-01-01	28-030-01	28-030-01		INSPECTION - DETAILED	Inspect (Detailed) the Left Surge Tank Vent Flame Arrestor



## 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

### TASKS SORTED BY TASK CARD NUMBER

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
28-030-02-01	28-030-02	28-030-02		INSPECTION - DETAILED	Inspect (Detailed) the Right Surge Tank Vent Flame Arrestor
28-040-00-01	28-040-00	28-040-00		OPERATIONAL	Operationally Check Center Tank Fuel Scavenge System
28-050-00-01	28-050-00	28-050-00		OPERATIONAL	ENGINE FUEL SUCTION FEED
28-054-00-01	28-054-00	28-054-00		OPERATIONAL	GFI Relay Check
28-056-00-01	28-056-00	28-056-00		FUNCTIONAL	Center Tank Fuel Pump Power Failed On Protection System
28-060-01-01	28-060-01	28-060-01		RESTORE	Restore (Clean) Left Main Fuel Tank Scavenger Jet Pump
28-060-02-01	28-060-02	28-060-02		RESTORE	Restore (Clean) Right Main Fuel Tank Scavenger Jet Pump
28-060-03-01	28-060-03	28-060-03		RESTORE	Restore (Clean) the Center Fuel Tank Left and Right Water Scavenger Jet Pump
28-070-00-01	28-070-00	28-070-00		FUNCTIONAL	Functionally (Pressure Decay) Check the APU Fuel Line Shroud
28-080-00-01	28-080-00	28-080-00		OPERATIONAL	Operationally (Bite) Check the Fuel Quantity Indicating System
28-090-00-01	28-090-00			INSPECTION - DETAILED	Detailed inspection of the out of tank wire bundles
28-100-00-01	28-100-00		W-28-110-00-01	INSPECTION - DETAILED	Visual Inspection of Fuel Pumps
28-110-00-01	28-110-00		W-28-100-00-01	FUNCTIONAL	Insulation Resistance Test of Fuel Pumps
28-115-00-01	28-115-00	28-115-00		FUNCTIONAL	Center Tank Boost Pump Auto Shutoff Test
28-125-00-01	28-125-00	28-125-00		OPERATIONAL	Engine Fuel Spar and APU Shutoff Valve Battery
28-130-00-01	28-130-00	28-130-00		DISCARD	Engine Spar and APU Fuel Shut-Off Valve Battery Restoration
28-140-00-01	28-140-00	28-140-00		INSPECTION - DETAILED	Inspect (Detailed) the Tubing, Static Ground Straps and Clamps, No. 1 Tank (SFAR 88)
28-140-00-02	28-140-00	28-140-00		INSPECTION - DETAILED	Inspect (Detailed) the Tubing, Static Ground Straps and Clamps, No. 2 Tank (SFAR 88)
28-140-00-03	28-140-00	28-140-00		INSPECTION - DETAILED	Inspect (Detailed) the Tubing Static Ground Straps and Clamps, Center Tank (SFAR 88)
28-150-00-01	28-150-00	28-150-00		FUNCTIONAL	FUNCTIONAL CHECK OF THE FUEL PUMP BONDING TO STRUCTURE - LEFT WING (SFAR 88)





## 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

### TASKS SORTED BY TASK CARD NUMBER

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
28-150-00-02	28-150-00	28-150-00		FUNCTIONAL	FUNCTIONAL CHECK OF THE FUEL PUMP BONDING TO STRUCTURE - RIGHT WING (SFAR 88)
28-160-00-01	28-160-00	28-160-00		FUNCTIONAL	FUNCTIONAL CHECK OF BONDING RESISTANCE OF APU DC FUEL PUMP (SFAR 88)
28-170-00-01	28-170-00	28-170-00	W-28-171-00-01	INSPECTION - DETAILED	DETAILED INSPECTION IN-TANK FQIS -LEFT WING (SFAR 88) (EZAP)
28-170-00-02	28-170-00	28-170-00	W-28-171-00-02	INSPECTION - DETAILED	DETAILED INSPECTION IN-TANK FQIS -RIGHT WING (SFAR 88) (EZAP)
28-170-00-03	28-170-00	28-170-00	W-28-171-00-03	INSPECTION - DETAILED	DETAILED INSPECTION IN-TANK FQIS -CENTER TANK (SFAR 88) (EZAP)
28-171-00-01	28-171-00	28-171-00	W-28-170-00-01	INSPECTION - DETAILED	Detailed Inspection FQIS In Tank components - Left Side (SFAR 88)
28-171-00-02	28-171-00	28-171-00	W-28-170-00-02	INSPECTION - DETAILED	Detailed Inspection FQIS In Tank components - Right Side (SFAR 88)
28-171-00-03	28-171-00	28-171-00	W-28-170-00-03	INSPECTION - DETAILED	Detailed Inspection FQIS In Tank components - Center Tank (SFAR 88)
28-173-00-01	28-173-00	28-173-00		FUNCTIONAL	Functional Check of FQIS wire bundle lightning shield to ground termination (SFAR 88)
28-180-00-01	28-180-00	28-180-00		FUNCTIONAL	Functional Check of the Equipment Fault Current Ground Strap for HSP (SFAR 88)
28-181-00-01	28-181-00	28-181-00		INSPECTION - DETAILED	Inspect (detailed) the equipment current ground straps for the Densitometer Hot Short Protector (SFAR 88)
28-199-00-01	28-199-00			FUNCTIONAL	Motor Operated Valve (MOV) Actuator
28-200-00-01	28-200-00			INSPECTION - DETAILED	Wire Bundles Routed on Main Deck over Center Fuel Tank
28-201-00-01	28-201-00	28-201-00		FUNCTIONAL	Functional check of bonding resistance between the hydraulic line fitting and structure (SFAR 88)
28-204-00-01	28-204-00	28-204-00		FUNCTIONAL	Functional Check of the Bonding of Air Vent to the Door Structure (SFAR 88)



# 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

## TASKS SORTED BY TASK CARD NUMBER

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
28-205-00-01	28-205-00	28-205-00		FUNCTIONAL	Functional Check the Bonding of Pressure Relief Valve to the Structure (SFAR 88)
28-207-00-01	28-207-00	28-207-00		FUNCTIONAL	Functional Check of Shutoff Valves Actuator to structure (SFAR 88)
28-208-00-01	28-208-00	28-208-00		FUNCTIONAL	Functional Check of the Bonding of the Fueling Receptacle to Structure (SFAR 88)
28-211-00-01	28-211-00	28-211-00		FUNCTIONAL	Functional Check of the Bonding of MOV actuator to the Structure (SFAR 88)
28-211-00-02	28-211-00	28-211-00		FUNCTIONAL	Functional Check of the Bonding of MOV actuator to the Structure (SFAR 88)
28-213-00-01	28-213-00	28-213-00		FUNCTIONAL	Functional check of the Bonding of APU Shutoff valve to Structure (SFAR 88)
29-005-00-01	29-005-00	29-005-00		OPERATIONAL	A & B Engine Driven Pump Depressurization Solenoid Valve
29-010-00-01	29-010-00	29-010-00		FUNCTIONAL	Internal Hydraulic System Leakage
29-020-00-01	29-020-00	29-020-00		REPLACE	Hydraulic System "A" Pressure Filter Elements (EMDP and EDP Pumps)
29-020-00-02	29-020-00	29-020-00		REPLACE	Hydraulic System "B" Pressure Filter Elements (EMDP and EDP Pumps)
29-030-01-01	29-030-01	29-030-01		REPLACE	EMDP Case Drain Filter
29-030-02-01	29-030-02	29-030-02		REPLACE	EMDP Case Drain Filter
29-050-01-01	29-050-01	29-050-01		REPLACE	EDP Case Drain Filter
29-050-02-01	29-050-02	29-050-02		REPLACE	EDP Case Drain Filter
29-070-00-01	29-070-00	29-070-00		RESTORE	Reservoir Pressurization Module Filter
29-070-00-02	29-070-00	29-070-00		RESTORE	Reservoir Pressurization Module Filter
29-080-00-01	29-080-00	29-080-00		FUNCTIONAL	EMDP Ground Fault Protection System
29-090-00-01	29-090-00	29-090-00	W-26-110-00-01	VISUAL CHECK	A & B System Return Filter Module
29-100-00-01	29-100-00	29-100-00		OPERATIONAL	A & B System Engine Pump (EDP) Shutoff Valves
29-110-00-01	29-110-00	29-110-00		FUNCTIONAL	Nose Landing Gear (NLG) Down Line Fuse
29-120-00-01	29-120-00	29-120-00	W-29-300-00-01	FUNCTIONAL	Nose Landing Gear (NLG) up Line Fuse
29-130-00-01	29-130-00	29-130-00		FUNCTIONAL	Thrust Reverser A System EMDP Fuse
29-140-00-01	29-140-00	29-140-00	W-29-290-00-01	FUNCTIONAL	Leading Edge B System Fuses



# 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

## TASKS SORTED BY TASK CARD NUMBER

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
29-150-00-01	29-150-00	29-150-00	W-29-160-00-01	FUNCTIONAL	B System Brake Fuses
29-160-00-01	29-160-00	29-160-00	W-29-150-00-01	FUNCTIONAL	A System Brake Fuses
29-170-00-01	29-170-00	29-170-00		FUNCTIONAL	B System Rudder Fuse
29-180-00-01	29-180-00	29-180-00		REPLACE	Reservoir Fill Filter
29-200-00-01	29-200-00	29-200-00		OPERATIONAL	Standby Hydraulic Electric Motor Driven Pump
29-210-00-01	29-210-00	29-210-00		REPLACE	Standby Hydraulic Pressure Filter
29-220-00-01	29-220-00	29-220-00		REPLACE	Standby Hydraulic System Case Drain Filter
29-230-00-01	29-230-00	29-230-00		OPERATIONAL	Standby Rudder System
29-240-00-01	29-240-00	29-240-00	W-27-214-00-01	OPERATIONAL	Leading Edge Standby Actuation
29-250-00-01	29-250-00	29-250-00		OPERATIONAL	Power Transfer Unit Control System
29-260-00-01	29-260-00	29-260-00		FUNCTIONAL	Power Transfer Unit
29-270-00-01	29-270-00	29-270-00		REPLACE	Power Transfer Unit Pressure Filter
29-290-00-01	29-290-00	29-290-00	W-29-140-00-01	FUNCTIONAL	Leading Edge Standby Fuse
29-300-00-01	29-300-00	29-300-00	W-29-130-00-01	FUNCTIONAL	Thrust Reverser Standby Fuse
29-310-00-01	29-310-00	29-310-00		FUNCTIONAL	Case Drain Warning Switches
30-010-00-01	30-010-00	30-010-00		OPERATIONAL	Automatic Air Data Sensor Heat
31-010-00-01	31-010-00	31-010-00		FUNCTIONAL	Aural Warning System
31-020-00-01	31-020-00	31-020-00		FUNCTIONAL	Cabin Pressure Switch
31-030-00-01	31-030-00	31-030-00		OPERATIONAL	Mach/Airspeed System 1 and 2 Discrete Outputs
31-040-00-01	31-040-00	31-040-00		OPERATIONAL	Landing Gear Logic Module to the AWM Systems 1 and 2
31-050-00-01	31-050-00	31-050-00		FUNCTIONAL	Takeoff Warning for the Aural Warning System
31-120-00-01	31-120-00	31-120-00		FUNCTIONAL	Download FDR Data Req'd Parameters to Check Interfacing Systems
31-120-00-02	31-120-00	31-120-00		FUNCTIONAL	Download FDR Data Req'd Parameters to Check Interfacing Systems
31-120-00-03	31-120-00	31-120-00		FUNCTIONAL	Download FDR Data Req'd Parameters to Check Interfacing Systems



# 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

## TASKS SORTED BY TASK CARD NUMBER

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
31-120-00-04	31-120-00	31-120-00		FUNCTIONAL	Download FDR Data Req'd Parameters to Check Interfacing Systems
31-120-00-05	31-120-00	31-120-00		FUNCTIONAL	Download FDR Data Req'd Parameters to Check Interfacing Systems
31-140-00-01	31-140-00	31-140-00	W-31-150-00-01	OPERATIONAL	DFDR ULB OPS Check
31-150-00-01	31-150-00	31-150-00	W-31-140-00-01	REPLACE	DFDR ULB Battery Replacement
31-160-01-01	31-160-01	31-160-01		RESTORE	Captain's Display Units Ventilation Hole Cleaning
31-160-02-01	31-160-02	31-160-02		RESTORE	First Officer's Display Units Ventilation Hole Cleaning
32-010-01-01	32-010-01	32-010-01		CLEAN/INSP	Left Main Gear Shock Strut Cleaning
32-010-02-01	32-010-02	32-010-02		CLEAN/INSP	Right Main Gear Shock Strut Cleaning
32-020-01-01	32-020-01	32-020-01		SERVICE	Left Main Landing Gear Servicing
32-020-02-01	32-020-02	32-020-02		SERVICE	Right Main Landing Gear Servicing
32-030-01-01	32-030-01	32-030-01		LUBRICATE	Left Main Landing Gear Lubrication
32-030-02-01	32-030-02	32-030-02		LUBRICATE	Right Main Landing Gear Lubrication
32-040-01-01	32-040-01	32-040-01	W-32-720-01-01	RESTORE	Left Main Landing Gear Restoration
32-040-02-01	32-040-02	32-040-02	W-32-720-02-01	RESTORE	Right Main Landing Gear Restoration
32-050-01-01	32-050-01	32-050-01		REPLACE	Left Main Landing Gear Discard
32-050-02-01	32-050-02	32-050-02		REPLACE	Right Main Landing Gear Discard
32-060-00-01	32-060-00	32-060-00		CLEAN/INSP	Clean Nose Gear Shock Strut
32-070-00-01	32-070-00	32-070-00		SERVICE	Nose Gear Shock Strut Service
32-080-00-01	32-080-00	32-080-00		LUBRICATE	Nose Gear Lubrication
32-085-00-01	32-085-00	32-085-00		INSPECTION - DETAILED	Nose Landing Gear Axle inspection
32-090-00-01	32-090-00	32-090-00	W-32-750-00-01	RESTORE	Restore Nose Landing Gear
32-100-00-01	32-100-00	32-100-00		REPLACE	Discard Nose Gear
32-110-00-01	32-110-00	32-110-00		INSPECTION - DETAILED	Landing Gear Selector Valve



## 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

### TASKS SORTED BY TASK CARD NUMBER

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
32-120-00-01	32-120-00	32-120-00		INSPECTION - DETAILED	Nose Landing Gear Inspection
32-150-00-01	32-150-00	32-150-00		INSPECTION - DETAILED	Left Main Landing Gear Inspection
32-150-00-02	32-150-00	32-150-00		INSPECTION - DETAILED	Right Main Landing Gear Inspection
32-200-00-01	32-200-00	32-200-00		FUNCTIONAL	Nose Gear Manual Extension
32-220-00-01	32-220-00	32-220-00		FUNCTIONAL	Left Main Gear Manual Extension
32-220-00-02	32-220-00	32-220-00		FUNCTIONAL	RIGHT MAIN GEAR MANUAL EXTENSION
32-230-00-01	32-230-00	32-230-00		FUNCTIONAL	Left Main Gear Wheel Well Protection Retract Pressure Fuse
32-230-00-02	32-230-00	32-230-00		FUNCTIONAL	Right Main Gear Wheel Well Protection Retract Pressure Fuse
32-240-00-01	32-240-00	32-240-00		OPERATIONAL	Landing Gear Transfer Valve
32-250-00-01	32-250-00	32-250-00		INSPECTION - DETAILED	Brake Control Linkage and Quadrants
32-260-00-01	32-260-00	32-260-00		INSPECTION - DETAILED	Brake Metering Valve Inspection
32-270-01-01	32-270-01	32-270-01		INSPECTION - GEN VISUAL	Left Main Gear Brake Wear Pins
32-270-02-01	32-270-02	32-270-02		INSPECTION - GEN VISUAL	Right Main Gear Brake Wear Pins
32-290-00-01	32-290-00	32-290-00		OPERATIONAL	Alternate Brake System
32-300-00-01	32-300-00	32-300-00		SERVICE	Brake Accumulator Precharge Pressure
32-310-00-01	32-310-00	32-310-00		OPERATIONAL	Brake Accumulator Isolation Valve
32-330-00-01	32-330-00	32-330-00		INSPECTION - DETAILED	Parking Brake Mechanical Control Path
32-340-00-01	32-340-00	32-340-00		FUNCTIONAL	Parking Brake System
32-350-00-01	32-350-00	32-350-00	W-32-360-00-01	SERVICE	Tire Inflation Check



## 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

### TASKS SORTED BY TASK CARD NUMBER

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
32-360-00-01	32-360-00	32-360-00	W-32-350-00-01	INSPECTION - GEN VISUAL	Nose and Main Gear Tires and Wheels
32-380-00-01	32-380-00	32-380-00		RESTORE	Nose Wheel Assemblies
32-380-01-01	32-380-01	32-380-01		RESTORE	Left Main Gear Wheel Assemblies
32-380-02-01	32-380-02	32-380-02		RESTORE	Right Main Gear Wheel Assemblies
32-390-00-01	32-390-00	32-390-00		INSPECTION - DETAILED	Nose Wheel Steering Control Path
32-400-00-01	32-400-00	32-400-00		INSPECTION - DETAILED	Steering Actuator Rod Ends
32-420-00-01	32-420-00	32-420-00		OPERATIONAL	PSEU Operational Check
32-430-00-01	32-430-00	32-430-00		VISUAL CHECK	Tail Skid Inspection
32-440-00-01	32-440-00	32-440-00	W-27-226-00-01	INSPECTION - DETAILED	Control Cables - NLG
32-440-00-02	32-440-00	32-440-00		INSPECTION - DETAILED	Landing Gear Control Cables - Left MLG Wheel Well
32-440-00-03	32-440-00	32-440-00		INSPECTION - DETAILED	Landing Gear Control Cables - Right MLG Wheel Well
32-450-00-01	32-450-00	32-450-00		INSPECTION - DETAILED	Landing Gear Control Cables - Area Above Main Landing Gear Wheel Well
32-450-00-02	32-450-00	32-450-00		INSPECTION - DETAILED	Landing Gear Control Cables - Lower Nose Compartment
32-450-00-03	32-450-00	32-450-00		INSPECTION - DETAILED	Landing Gear Control Cables - Electronics Compartment
32-450-00-04	32-450-00	32-450-00		INSPECTION - DETAILED	Landing Gear Control Cables - Air Conditioning Distribution Bay
32-450-00-05	32-450-00	32-450-00		INSPECTION - DETAILED	Landing Gear Control Cables - Forward Cargo Compartment
32-460-00-01	32-460-00	32-460-00	W-27-230-00-02	INSPECTION - DETAILED	Landing Gear Control Cables - Control Cabin



## 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

### TASKS SORTED BY TASK CARD NUMBER

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
32-460-00-02	32-460-00	32-460-00	W-27-230-00-01	INSPECTION - DETAILED	Landing Gear Control Cables - Over Wing Center Section
32-480-00-01	32-480-00	32-480-00		OPERATIONAL	Operationally BITE-check the SPSEU
32-490-00-01	32-490-00	32-490-00		OPERATIONAL	Tailskid Actuator and Mechanism
32-720-01-01	32-720-01	32-720-01	W-32-040-01-01	GENERAL VISUAL	Left Main Landing Gear Assembly
32-720-02-01	32-720-02	32-720-02	W-32-040-02-01	GENERAL VISUAL	Right Main Landing Gear Assembly
32-750-00-01	32-750-00	32-750-00	W-32-090-00-01	GENERAL VISUAL	Nose Landing Gear Assembly
32-800-00-01	32-800-00	32-800-00		ZONAL (GV)	Nose Landing Gear and Landing Gear Doors (from Ground)
32-804-01-01	32-804-01	32-804-01		ZONAL (GV)	Left Main Landing Gear and Landing Gear Doors (from Ground)
32-806-01-01	32-806-01	32-806-01		ZONAL (GV)	Left Main Landing Gear and Landing Gear Doors
32-808-02-01	32-808-02	32-808-02		ZONAL (GV)	Right Main Landing Gear and Landing Gear Doors (From Ground)
32-810-02-01	32-810-02	32-810-02		ZONAL (GV)	Right Main Landing Gear and Landing Gear Doors
33-010-00-01	33-010-00	33-010-00		OPERATIONAL	Emergency Lights
33-010-00-02	33-010-00	33-010-00		OPERATIONAL	Emergency Lights
33-010-00-03	33-010-00	33-010-00		OPERATIONAL	Emergency Lights
33-020-00-01	33-020-00	33-020-00		OPERATIONAL	Emergency Lighting Switch Operational Test
33-020-00-02	33-020-00	33-020-00		OPERATIONAL	Emergency Lighting Switch Operational Test
33-020-00-03	33-020-00	33-020-00		OPERATIONAL	Emergency Lighting Switch Operational Test
33-055-00-01	33-055-00	33-055-00		FUNCTIONAL	Emergency Battery Pack Capacity Functional Check
33-055-00-02	33-055-00	33-055-00		FUNCTIONAL	Emergency Battery Pack Capacity Functional Check
33-060-00-01	33-060-00	33-060-00		RESTORE	Emergency Lighting - Battery Pack Restoration
33-060-00-02	33-060-00	33-060-00		RESTORE	Emergency Lighting - Battery Pack Restoration



## 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

### TASKS SORTED BY TASK CARD NUMBER

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
33-065-00-01	33-065-00	33-065-00		FUNCTIONAL	Self Illuminating Exit Signs
33-070-00-01	33-070-00	33-070-00		FUNCTIONAL	Photoluminescent Floor Proximity Lighting
33-080-00-01	33-080-00	33-080-00		REPLACE	Replace Photoluminescent Floor Proximity Lighting
33-090-00-01	33-090-00	33-090-00		INSPECTION - GEN VISUAL	Winglet Leading Edge Lens
33-090-01-01	33-090-01			INSPECTION - GEN VISUAL	Winglet Leading Edge Lens
34-030-00-01	34-030-00	34-030-00		FUNCTIONAL	Pitot Static System Leak Check
34-030-00-10	34-030-00	34-030-00		FUNCTIONAL	Pitot Static System Leak Check
34-060-00-01	34-060-00	34-060-00		FUNCTIONAL	Pitot Static System Leak Check
34-060-00-10	34-060-00	34-060-00		FUNCTIONAL	Pitot Static System Leak Check
34-060-10-01	34-060-10	34-060-10		FUNCTIONAL	Air Data System - Altimetry System
34-060-10-02	34-060-10	34-060-10		FUNCTIONAL	Air Data System - Altimetry System
34-070-00-01	34-070-00	34-070-00		INSPECTION - DETAILED	Pitot Probes
34-070-00-10	34-070-00	34-070-00		INSPECTION - DETAILED	Pitot Probes
34-070-01-01	34-070-01	34-070-01		INSPECTION - DETAILED	Pitot Probes
34-080-00-01	34-080-00	34-080-00		INSPECTION - DETAILED	Static Ports
34-090-00-01	34-090-00	34-090-00		INSPECTION - DETAILED	Pitot Systems
34-090-00-02	34-090-00	34-090-00		INSPECTION - DETAILED	Pitot Systems
34-100-00-01	34-100-00	34-100-00		INSPECTION - DETAILED	Static Systems





# 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

## TASKS SORTED BY TASK CARD NUMBER

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
34-100-00-02	34-100-00	34-100-00	R-35-USF-02-01 R-35-USK-02-01	INSPECTION - DETAILED	Static Systems
34-105-00-01	34-105-00	34-105-00		OPERATIONAL	Source Select Panel Inertial Reference System Transfer Switch
34-110-01-01	34-110-01			FUNCTIONAL	ATC System Functional Check
34-110-01-02	34-110-01			FUNCTIONAL	ATC System Functional Check
34-110-01-03	34-110-01			FUNCTIONAL	ATC System Functional Check
34-110-01-04	34-110-01			FUNCTIONAL	ATC System Functional Check
34-130-00-01	34-130-00	34-130-00		REPLACE	Integrated Standby Flight Display
34-140-00-01	34-140-00	34-140-00		OPERATIONAL	Integrated Standby Flight Display
35-010-00-01	35-010-00	35-010-00		OPERATIONAL	Flight Crew Oxygen Mask/Regulator
35-011-00-01	35-011-00	35-011-00		OPERATIONAL	Gaseous Oxygen Mask/Regulator Operational Check
35-012-00-01	35-012-00	35-012-00		OPERATIONAL	Operational Check Each Cylinder Oxygen Mask/Regulator
35-020-00-01	35-020-00	35-020-00		FUNCTIONAL	Flight Crew Oxygen Mask/Regulator
35-021-00-01	35-021-00	35-021-00		FUNCTIONAL	Gaseous Oxygen Mask/Regulator Functional Check
35-040-00-01	35-040-00	35-040-00		REPLACE	Flight Crew Oxygen Cylinder
35-040-00-02	35-040-00	35-040-00		REPLACE	Flight Crew Oxygen Cylinder
35-041-00-01	35-041-00	35-041-00		REPLACE	Flight Crew Oxygen Cylinder
35-050-00-01	35-050-00	35-050-00		VISUAL CHECK	Flight Crew Oxygen Cylinder
35-052-00-01	35-052-00	35-052-00		VISUAL CHECK	Flight Crew Oxygen Cylinder
35-060-00-01	35-060-00	35-060-00		VISUAL CHECK	Chemical Oxygen Generator Temperature Sensitive Tape
35-060-00-02	35-060-00	35-060-00		VISUAL CHECK	Chemical Oxygen Generator Temperature Sensitive Tape
35-065-00-01	35-065-00	35-065-00		VISUAL CHECK	Lavatory Oxygen Constant Dispensing System (CDS).
35-065-00-02	35-065-00	35-065-00		VISUAL CHECK	Lavatory Oxygen Constant Dispensing System (CDS).
35-070-00-01	35-070-00	35-070-00		REPLACE	Chemical Oxygen Generators



# 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

## TASKS SORTED BY TASK CARD NUMBER

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
35-070-00-02	35-070-00	35-070-00		REPLACE	Chemical Oxygen Generators
35-070-00-03	35-070-00	35-070-00		REPLACE	Chemical Oxygen Generators
35-070-00-04	35-070-00	35-070-00		REPLACE	Chemical Oxygen Generators
35-070-00-05	35-070-00	35-070-00		REPLACE	Chemical Oxygen Generators
35-075-00-01	35-075-00	35-075-00		DISCARD	Lavatory Oxygen CDS system cylinder
35-080-00-01	35-080-00	35-080-00	W-35-085-00-01	FUNCTIONAL	Passenger Oxygen System
35-080-00-02	35-080-00	35-080-00	W-35-085-00-02	FUNCTIONAL	Passenger Oxygen System
35-080-00-03	35-080-00	35-080-00	W-35-085-00-03	FUNCTIONAL	Passenger Oxygen System
35-085-00-01	35-085-00	35-085-00	W-35-080-00-01	OPERATIONAL	Passenger Oxygen System Manual Actuation
35-085-00-02	35-085-00	35-085-00	W-35-080-00-02	OPERATIONAL	Passenger Oxygen System Manual Actuation
35-085-00-03	35-085-00	35-085-00	W-35-080-00-03	OPERATIONAL	Passenger Oxygen System Manual Actuation
35-090-00-01	35-090-00	35-090-00		INSPECTION - DETAILED	Passenger Oxygen Masks
35-090-00-02	35-090-00	35-090-00		INSPECTION - DETAILED	Passenger Oxygen Masks
35-090-00-03	35-090-00	35-090-00		INSPECTION - DETAILED	Passenger Oxygen Masks
35-090-00-04	35-090-00	35-090-00		INSPECTION - DETAILED	Passenger Oxygen Masks
35-100-00-01	35-100-00	35-100-00		INSPECTION - GEN VISUAL	Portable Oxygen Cylinders
35-120-00-01	35-120-00	35-120-00		REPLACE	Portable Oxygen Cylinders
35-120-00-02	35-120-00	35-120-00		REPLACE	Portable Oxygen Cylinders
35-150-00-01	35-150-00	35-150-00		OPERATIONAL	Manual Shutoff Valve Sensor
35-163-00-01	35-163-00	35-163-00		DISCARD	GASEOUS PASSENGER OXYGEN SYSTEM
35-163-00-02	35-163-00	35-163-00		DISCARD	GASEOUS PASSENGER OXYGEN SYSTEM



## 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

### TASKS SORTED BY TASK CARD NUMBER

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
35-164-00-01	35-164-00	35-164-00		FUNCTIONAL	Gaseous passenger oxygen flow control units.
35-165-00-01	35-165-00	35-165-00		FUNCTIONAL	Passenger gaseous oxygen low pressure distribution system
35-166-00-01	35-166-00	35-166-00		FUNCTIONAL	Passenger gaseous oxygen system pressure regulators.
35-167-00-01	35-167-00	35-167-00		OPERATIONAL	Check Valve Operational Check
36-020-01-01	36-020-01	36-020-01		FUNCTIONAL	Precooler Control Valve and Wing TAI Solenoid - Left
36-020-02-01	36-020-02	36-020-02		FUNCTIONAL	Precooler Control Valve and Wing TAI Solenoid - Right
36-030-01-01	36-030-01	36-030-01		FUNCTIONAL	Precooler Control Valve Sensor - Left
36-030-02-01	36-030-02	36-030-02		FUNCTIONAL	Precooler Control Valve Sensor - Right
38-015-00-01	38-015-00	38-015-00		OPERATIONAL	Forward Gray Water Drain Valve
38-030-00-01	38-030-00	38-030-00		RESTORE	Restore Vacuum Blower Filter
38-040-00-01	38-040-00	38-040-00		RESTORE	Restore Waste Drain Ball-Valve
38-060-00-01	38-060-00	38-060-00		REPLACE	Replace Bleed Air In-Line Filter
38-070-00-01	38-070-00	38-070-00		DISINFECT	Disinfect Potable Water System
38-090-00-01	38-090-00	38-090-00		RESTORE	Waste Tank Water Separator
38-100-00-01	38-100-00	38-100-00		RESTORE	Waste Tank Water Separator
47-200-00-02	47-200-00	47-200-00		VISUAL CHECK	NGS Drain - Fluid Accumulation
47-210-00-01	47-210-00	47-210-00		OPERATIONAL	Center Tank Cross Vent Check Valve
47-220-00-01	47-220-00	47-220-00		INSPECTION - DETAILED	NEA distribution lines inspection
47-300-00-01	47-300-00	47-300-00		RESTORE	Ozone Converter
47-310-00-01	47-310-00	47-310-00		CLEAN	Nitrogen generation system heat exchanger
47-320-00-01	47-320-00			RESTORE	Nitrogen generation system oxygen sensor
47-330-00-01	47-330-00			DISCARD	Nitrogen Generation System Filter Element
47-400-00-01	47-400-00	47-400-00		FUNCTIONAL	Thermal switch



## 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

### TASKS SORTED BY TASK CARD NUMBER

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
49-010-00-01	49-010-00	49-010-00		INSPECTION - GEN VISUAL	APU Mounts
49-020-00-01	49-020-00	49-020-00		INSPECTION - DETAILED	APU Mounts
49-030-00-01	49-030-00	49-030-00		INSPECTION - DETAILED	Sigma Seal
49-040-00-01	49-040-00	49-040-00		INSPECTION - DETAILED	APU Insulation Panels
49-052-00-01	49-052-00	49-052-00	W-49-062-00-01 W-49-072-00-01 W-49-082-00-01	REPLACE	Engine Compressor Impeller
49-062-00-01	49-062-00	49-062-00	W-49-052-00-01 W-49-072-00-01 W-49-082-00-01	REPLACE	First Stage Turbine Disk
49-072-00-01	49-072-00	49-072-00	W-49-052-00-01 W-49-062-00-01 W-49-082-00-01	REPLACE	Second Stage Turbine Rotor
49-082-00-01	49-082-00	49-082-00	W-49-052-00-01 W-49-062-00-01 W-49-072-00-01	REPLACE	Turbine Shaft
49-102-00-01	49-102-00	49-102-00		REPLACE	Fuel Inlet Filter Element
49-140-00-01	49-140-00	49-140-00		OPERATIONAL	CDU'S APU Maintenance Pages
49-172-00-01	49-172-00	49-172-00		INSPECTION - DETAILED	APU Exhaust Seal
49-212-00-01	49-212-00	49-212-00		INSPECTION - GEN VISUAL	APU Eductor
49-220-00-01	49-220-00	49-220-00		INSPECTION - DETAILED	APU Eductor Inlet Duct
49-240-00-01	49-240-00	49-240-00		LUBRICATE	APU Vortex Generator Hinge Pin
52-010-00-01	52-010-00	52-010-00		LUBRICATE	Forward Entry Door Lubrication



**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
52-010-00-02	52-010-00	52-010-00		LUBRICATE	Forward Service Door Lubrication
52-010-00-03	52-010-00	52-010-00		LUBRICATE	Aft Entry Door Lubrication
52-010-00-04	52-010-00	52-010-00		LUBRICATE	Aft Service Door Lubrication
52-020-00-01	52-020-00	52-020-00		LUBRICATE	Forward Entry Door Lubrication
52-020-00-02	52-020-00	52-020-00		LUBRICATE	Forward Service Door Lubrication
52-020-00-03	52-020-00	52-020-00		LUBRICATE	Aft Entry Door Lubrication
52-020-00-04	52-020-00	52-020-00		LUBRICATE	Aft Service Door Lubrication
52-030-00-01	52-030-00	52-030-00		INSPECTION - DETAILED	Forward Entry Door Inspection
52-040-00-01	52-040-00	52-040-00		INSPECTION - DETAILED	Fwd Service Door Inspection
52-040-00-02	52-040-00	52-040-00		INSPECTION - DETAILED	Aft Entry Door Inspection
52-040-00-03	52-040-00	52-040-00		INSPECTION - DETAILED	Aft Service Door Inspection
52-050-00-01	52-050-00	52-050-00		INSPECTION - GEN VISUAL	Forward Entry Door Seals
52-050-00-02	52-050-00	52-050-00		INSPECTION - GEN VISUAL	Forward Service Door Seal
52-050-00-03	52-050-00	52-050-00		INSPECTION - GEN VISUAL	Aft Entry Door Seal
52-050-00-04	52-050-00	52-050-00		INSPECTION - GEN VISUAL	Aft Service Door Seal
52-090-00-01	52-090-00	52-090-00		LUBRICATE	Forward Cargo Compartment Door Lubrication
52-090-00-02	52-090-00	52-090-00		LUBRICATE	Aft Cargo Compartment Door Lubrication
52-100-00-01	52-100-00	52-100-00		INSPECTION - GEN VISUAL	Forward Cargo Door Seal



## 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

### TASKS SORTED BY TASK CARD NUMBER

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
52-100-00-02	52-100-00	52-100-00		INSPECTION - GEN VISUAL	Aft Cargo Door Seal
52-120-00-01	52-120-00	52-120-00		LUBRICATE	E/E Access Door Lubrication
52-130-00-01	52-130-00	52-130-00		INSPECTION - GEN VISUAL	E/E Access Door Seal
52-140-00-01	52-140-00	52-140-00		INSPECTION - GEN VISUAL	Forward Access Door Seal
52-150-00-01	52-150-00	52-150-00		LUBRICATE	Airstair Door System Lubrication
52-160-00-01	52-160-00	52-160-00		LUBRICATE	Airstair System Lubrication
52-170-00-01	52-170-00	52-170-00		INSPECTION - DETAILED	Airstair System Inspection
52-180-00-01	52-180-00	52-180-00		INSPECTION - GEN VISUAL	Airstair Door Pressure Seal Inspection
52-200-00-01	52-200-00	52-200-00		OPERATIONAL	Door Sensor Check
52-200-00-02	52-200-00	52-200-00		OPERATIONAL	Air Stair Door Sensor Check
52-202-00-01	52-202-00	52-202-00		OPERATIONAL	MID EXIT DOOR LATCH AND LOCK SWITCHES
52-220-00-01	52-220-00	52-220-00		OPERATIONAL	Automatic Emergency Door Operational Check
52-222-00-01	52-222-00	52-222-00		OPERATIONAL	MID EXIT DOOR OPERATIONAL CHECK
52-230-00-01	52-230-00	52-230-00		INSPECTION - DETAILED	Inspection of Automatic Emergency Exit Door Components
52-232-00-01	52-232-00	52-232-00		INSPECTION - DETAILED	MID EXIT DOOR INSPECTION
52-240-00-01	52-240-00	52-240-00		OPERATIONAL	Automatic Emergency Exit Door Flight Lock Operational Check
52-242-00-01	52-242-00	52-242-00		OPERATIONAL	MID EXIT DOOR FLIGHT LOCK OPERATIONAL CHECK
52-250-00-01	52-250-00	52-250-00		INSPECTION - DETAILED	Automatic Emergency Door Flight Lock Inspection
52-262-00-01	52-262-00	52-262-00		INSPECTION - DETAILED	MID EXIT DOOR PRESSURE SEAL INSPECTION



**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

<b>TASK CARD NUMBER</b>	<b>MPD ITEM NUMBER</b>	<b>MRB ITEM NUMBER</b>	<b>RELATED TASK CARD NUMBER</b>	<b>TASK</b>	<b>TASK TITLE</b>
52-263-00-01	52-263-00	52-263-00		INSPECTION - DETAILED	MID EXIT DOOR VENT DOOR SEAL INSPECTION
52-264-00-01	52-264-00	52-264-00		INSPECTION - DETAILED	MID EXIT DOOR PRESSURE SEAL INSPECTION
52-264-00-02	52-264-00	52-264-00		INSPECTION - DETAILED	MID EXIT DOOR PRESSURE SEAL INSPECTION
52-265-00-01	52-265-00	52-265-00		INSPECTION - DETAILED	MID EXIT DOOR VENT DOOR SEAL INSPECTION
52-280-00-01	52-280-00	52-280-00		INSPECTION - DETAILED	Crew Door Seals
52-290-00-01	52-290-00	52-290-00		INSPECTION - GEN VISUAL	Main Deck Cargo Door
52-300-00-01	52-300-00	52-300-00		LUBRICATE	Main Deck Cargo Door Lubrication
52-305-00-01	52-305-00	52-305-00		LUBRICATE	Lift Linkages, Latch Cams and Lock Torque Tube Lubrications
52-310-00-01	52-310-00	52-310-00		INSPECTION - DETAILED	Main Deck Cargo Door Lift Actuator Linkage
52-320-00-01	52-320-00	52-320-00		OPERATIONAL	Main Deck Cargo Door Manual Pump
52-320-00-02	52-320-00	52-320-00		OPERATIONAL	Main Deck Cargo Door Manual Pump
52-325-00-01	52-325-00	52-325-00		OPERATIONAL	Operationally check the manual operation of PULL-IN/LATCH ACTUATOR and LOCK ACTUATOR
52-330-00-01	52-330-00	52-330-00		INSPECTION - DETAILED	Main Deck Cargo Door Lift Actuator Attachment Points
52-340-00-01	52-340-00	52-340-00		OPERATIONAL	Main Deck Cargo Door Unlock Switch
52-350-00-01	52-350-00	52-350-00		OPERATIONAL	Main Deck Cargo Door Control Panel Operational Check
52-360-00-01	52-360-00	52-360-00		FUNCTIONAL	Flight Deck Door Decompression Panel Latches/Pressure Switches
52-370-00-01	52-370-00	52-370-00		OPERATIONAL	Flight Deck Door Decompression Panel Hinges
52-380-00-01	52-380-00	52-380-00		INSPECTION - GEN VISUAL	Flight Deck Door Decompression Panel Hinges



# 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

## TASKS SORTED BY TASK CARD NUMBER

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
52-390-00-01	52-390-00	52-390-00		INSPECTION - GEN VISUAL	Flight Deck Door Seals for Condition and Security
52-400-00-01	52-400-00	52-400-00		INSPECTION - GEN VISUAL	Flight Deck Door Decompression Panel Seals
52-410-00-01	52-410-00	52-410-00		FUNCTIONAL	Deny Time Delay and Deny Function
52-450-00-01	52-450-00			DETAILED	Flight Deck Security Door Panel Assembly
52-460-00-01	52-460-00			GENERAL VISUAL	Flight Deck Security Door Surround Assembly
52-470-00-01	52-470-00			DETAILED	Flight Deck Security Door Surround Assembly
52-490-00-01	52-490-00			DETAILED	Flight Deck Door Latch and Hinge Support Assemblies
52-510-00-01	52-510-00	52-510-00		DETAILED	Forward Access Door Stop Fittings and Pins
52-530-00-01	52-530-00	52-530-00		GENERAL VISUAL	Forward Access Door
52-540-00-01	52-540-00	52-540-00		DETAILED	E/E Equipment Compartment Access Door Stop Fittings and Pins
52-550-00-01	52-550-00	52-550-00		DETAILED	E/E Equipment Compartment Access Door
52-570-00-01	52-570-00	52-570-00		GENERAL VISUAL	E/E Equipment Compartment Access Door
52-580-00-01	52-580-00	52-580-00		DETAILED	Forward Airstairs Door Stop Fittings and Pins
52-590-00-01	52-590-00	52-590-00		GENERAL VISUAL	Forward Airstairs Door
52-600-00-01	52-600-00	52-600-00		GENERAL VISUAL	Forward Airstairs Door
52-610-00-01	52-610-00	52-610-00		DETAILED	Forward Entry Door Stop Fittings and Pins
52-610-00-02	52-610-00	52-610-00		DETAILED	Forward Galley Service Door Stop Fittings and Pins
52-610-00-03	52-610-00	52-610-00		DETAILED	Aft Entry Door Stop Fittings and Pins
52-610-00-04	52-610-00	52-610-00		DETAILED	Aft Galley Service Door Stop Fittings and Pins
52-620-00-01	52-620-00	52-620-00		DETAILED	Forward Entry Door





**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

<b>TASK CARD NUMBER</b>	<b>MPD ITEM NUMBER</b>	<b>MRB ITEM NUMBER</b>	<b>RELATED TASK CARD NUMBER</b>	<b>TASK</b>	<b>TASK TITLE</b>
52-620-00-02	52-620-00	52-620-00		DETAILED	Forward Galley Service Door
52-620-00-03	52-620-00	52-620-00		DETAILED	Aft Entry Door
52-620-00-04	52-620-00	52-620-00		DETAILED	Aft Galley Service Door
52-650-00-01	52-650-00	52-650-00		GENERAL VISUAL	Forward Entry Door
52-650-00-02	52-650-00	52-650-00		GENERAL VISUAL	Forward Galley Service Door
52-650-00-03	52-650-00	52-650-00		GENERAL VISUAL	Aft Entry Door
52-650-00-04	52-650-00	52-650-00		GENERAL VISUAL	Aft Galley Service Door
52-670-00-01	52-670-00	52-670-00		DETAILED	Forward Cargo Door Stop Fittings and Pins
52-670-00-02	52-670-00	52-670-00		DETAILED	Aft Cargo Door Stop Fittings and Pins
52-680-00-01	52-680-00	52-680-00		DETAILED	Forward Cargo Door
52-680-00-02	52-680-00	52-680-00		DETAILED	Aft Cargo Door
52-710-00-01	52-710-00	52-710-00		GENERAL VISUAL	Forward Cargo Door
52-710-00-02	52-710-00	52-710-00		GENERAL VISUAL	Aft Cargo Door
52-730-00-01	52-730-00	52-730-00		DETAILED	Left Overwing Emergency Exit Door Stop Fittings and Pins
52-730-00-02	52-730-00	52-730-00		DETAILED	Right Overwing Emergency Exit Door Stop Fittings and Pins
52-740-00-01	52-740-00	52-740-00		DETAILED	Left Overwing Emergency Exit Hatch/Automatic Overwing Exit
52-740-00-02	52-740-00	52-740-00		DETAILED	Right Overwing Emergency Exit Hatch/Automatic Overwing Exit
52-760-00-01	52-760-00	52-760-00		GENERAL VISUAL	Left Overwing Emergency Exit Hatch/Automatic Overwing Exit
52-760-00-02	52-760-00	52-760-00		GENERAL VISUAL	Right Overwing Emergency Exit Hatch/Automatic Overwing Exit



# 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

## TASKS SORTED BY TASK CARD NUMBER

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
52-762-00-01	52-762-00	52-762-00		GENERAL VISUAL	Left Mid Exit Door
52-762-00-02	52-762-00	52-762-00		GENERAL VISUAL	Right Mid Exit Door
52-764-00-01	52-764-00	52-764-00		DETAILED	Left Mid Emergency exit door stop fitting and pins.
52-764-00-02	52-764-00	52-764-00		DETAILED	Right Mid emergency exit door stop fitting and pins.
52-766-00-01	52-766-00	52-766-00		GENERAL VISUAL	Left Mid Emergency Exit Door
52-766-00-02	52-766-00	52-766-00		GENERAL VISUAL	Right Mid Emergency Exit Door
52-768-00-01	52-768-00	52-768-00		DETAILED	Left Mid emergency exit door stop fitting and pins.
52-768-00-02	52-768-00	52-768-00		DETAILED	Right mid emergency exit door stop fitting and pins.
52-770-00-01	52-770-00	52-770-00		DETAILED	Main Deck Cargo Door
52-780-00-01	52-780-00	52-780-00		DETAILED	Main Deck Cargo Door
52-790-00-01	52-790-00	52-790-00		GENERAL VISUAL	Main Deck Cargo Door
52-795-00-01	52-795-00			SPECIAL DETAILED	Main Deck Cargo Door
52-795-10-01	52-795-10			SPECIAL DETAILED	Main Deck Cargo Door
52-796-00-01	52-796-00			DETAILED	Electronic Equipment Access Door Aluminum Casting only
52-800-00-01	52-800-00	52-800-00		ZONAL (GV)	Entry Doors, Service Doors, Automatic Overwing Exits, Mid-Exit Doors, and Cargo Doors
52-802-02-01	52-802-02	52-802-02		ZONAL (GV)	Forward Cargo Door
52-804-02-01	52-804-02	52-804-02		ZONAL (GV)	Forward Cargo Door
52-806-02-01	52-806-02	52-806-02		ZONAL (GV)	Aft Cargo Door
52-808-02-01	52-808-02	52-808-02		ZONAL (GV)	Aft Cargo Door



**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

<b>TASK CARD NUMBER</b>	<b>MPD ITEM NUMBER</b>	<b>MRB ITEM NUMBER</b>	<b>RELATED TASK CARD NUMBER</b>	<b>TASK</b>	<b>TASK TITLE</b>
52-810-01-01	52-810-01	52-810-01		ZONAL (GV)	Forward Passenger Door
52-812-01-01	52-812-01	52-812-01		ZONAL (GV)	Forward Passenger Door
52-814-01-01	52-814-01	52-814-01		ZONAL (GV)	Automatic Overwing Exit
52-816-01-01	52-816-01	52-816-01		ZONAL (GV)	Automatic Overwing Exit
52-818-01-01	52-818-01	52-818-01		ZONAL (GV)	Automatic Overwing Exit
52-820-01-01	52-820-01	52-820-01		ZONAL (GV)	Automatic Overwing Exit
52-822-01-01	52-822-01	52-822-01		ZONAL (GV)	Aft Passenger Door
52-822-01-02	52-822-01	52-822-01		ZONAL (GV)	Aft Passenger Door
52-824-01-01	52-824-01	52-824-01		ZONAL (GV)	Aft Passenger Door
52-826-02-01	52-826-02	52-826-02		ZONAL (GV)	Forward Galley Service Door
52-828-02-01	52-828-02	52-828-02		ZONAL (GV)	Forward Galley Service Door
52-830-02-01	52-830-02	52-830-02		ZONAL (GV)	Automatic Overwing Exit
52-832-02-01	52-832-02	52-832-02		ZONAL (GV)	Automatic Overwing Exit
52-834-02-01	52-834-02	52-834-02		ZONAL (GV)	Automatic Overwing Exit
52-836-02-01	52-836-02	52-836-02		ZONAL (GV)	Automatic Overwing Exit
52-838-02-01	52-838-02	52-838-02		ZONAL (GV)	Aft Galley Service Door
52-838-02-02	52-838-02	52-838-02		ZONAL (GV)	Aft Galley Service Door
52-840-02-01	52-840-02	52-840-02		ZONAL (GV)	Aft Galley Service Door
52-842-01-01	52-842-01	52-842-01		ZONAL (GV)	Main Deck Cargo Door
52-844-01-01	52-844-01	52-844-01		ZONAL (GV)	Main Deck Cargo Door
52-846-01-01	52-846-01	52-846-01		ZONAL (GV)	Mid-Exit Door
52-846-02-01	52-846-02	52-846-02		ZONAL (GV)	Mid-Exit Door
52-846-03-01	52-846-03	52-846-03		ZONAL (GV)	Mid-Exit Door
52-846-04-01	52-846-04	52-846-04		ZONAL (GV)	Mid-Exit Door



**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

<b>TASK CARD NUMBER</b>	<b>MPD ITEM NUMBER</b>	<b>MRB ITEM NUMBER</b>	<b>RELATED TASK CARD NUMBER</b>	<b>TASK</b>	<b>TASK TITLE</b>
52-846-05-01	52-846-05	52-846-05		ZONAL (GV)	Mid-Exit Door
52-846-06-01	52-846-06	52-846-06		ZONAL (GV)	Mid-Exit Door
53-010-00-01	53-010-00	53-010-00		GENERAL VISUAL	Fuselage Lower Lobe, Forward Access Door Cutout
53-010-00-02	53-010-00	53-010-00		GENERAL VISUAL	Fuselage Lower Lobe, EE Compartment Door Cutout
53-010-00-03	53-010-00	53-010-00		GENERAL VISUAL	Fuselage Lower Lobe, Fwd Airstair Door Cutout
53-020-00-01	53-020-00	53-020-00		GENERAL VISUAL	Nose Wheel Well
53-030-00-01	53-030-00	53-030-00		DETAILED	Forward Cargo Door Surround Structure, Fittings and Stops
53-030-00-02	53-030-00	53-030-00		DETAILED	Aft Cargo Door Surround Structure, Fittings and Stops
53-050-00-01	53-050-00	53-050-00		GENERAL VISUAL	Main Landing Gear Wheel Well
53-060-00-01	53-060-00	53-060-00		GENERAL VISUAL	Forward Pressure Bulkhead
53-070-00-01	53-070-00	53-070-00		GENERAL VISUAL	Area Forward of Nose Wheel Well
53-080-00-01	53-080-00	53-080-00		GENERAL VISUAL	Flight Compartment Floor Structure
53-090-00-01	53-090-00	53-090-00		GENERAL VISUAL	Area Above and Outboard of Nose Wheel Well
53-100-00-01	53-100-00	53-100-00		GENERAL VISUAL	Passenger Compartment Floor Structure - Dry Area
53-110-00-01	53-110-00	53-110-00		GENERAL VISUAL	Passenger Compartment Floor Structure - Wet Area
53-120-00-01	53-120-00	53-120-00		GENERAL VISUAL	Electrical and Electronics Compartment



**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

<b>TASK CARD NUMBER</b>	<b>MPD ITEM NUMBER</b>	<b>MRB ITEM NUMBER</b>	<b>RELATED TASK CARD NUMBER</b>	<b>TASK</b>	<b>TASK TITLE</b>
53-130-00-01	53-130-00	53-130-00		GENERAL VISUAL	Forward Cargo Compartment
53-140-00-01	53-140-00	53-140-00		GENERAL VISUAL	Forward Cargo Compartment - Floor Structure
53-140-00-02	53-140-00	53-140-00		GENERAL VISUAL	Aft Cargo Compartment - Floor Structure
53-150-00-01	53-150-00	53-150-00		DETAILED	Forward Cargo Door Cutout
53-160-00-01	53-160-00	53-160-00		GENERAL VISUAL	Forward Bilge
53-170-00-01	53-170-00	53-170-00		GENERAL VISUAL	Area Aft of Forward Cargo Compartment
53-180-00-01	53-180-00	53-180-00		GENERAL VISUAL	Area Under Lower Wing-To-Body Fairing (forward of wing box)
53-190-00-01	53-190-00	53-190-00		GENERAL VISUAL	Area Above Wing Box Center Section
53-200-00-01	53-200-00	53-200-00		GENERAL VISUAL	Area Above Main Landing Gear Wheel Well
53-210-00-01	53-210-00	53-210-00		GENERAL VISUAL	Keel Beam Under Wing-To-Body Fairing (under wing box)
53-220-00-01	53-220-00	53-220-00		GENERAL VISUAL	Keel Beam In Wheel Well
53-230-00-01	53-230-00	53-230-00		GENERAL VISUAL	Aft Cargo Compartment
53-235-00-01	53-235-00	53-235-00		GENERAL VISUAL	Left Mid Emergency Exit Door Cutout
53-235-00-02	53-235-00	53-235-00		GENERAL VISUAL	Right Mid Emergency Exit Door Cutout
53-240-00-01	53-240-00	53-240-00		DETAILED	Aft Cargo Door Cutout
53-250-00-01	53-250-00	53-250-00		GENERAL VISUAL	Aft Bilge



## 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

### TASKS SORTED BY TASK CARD NUMBER

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
53-260-00-01	53-260-00	53-260-00		GENERAL VISUAL	Area Aft of Cargo Compartment
53-262-00-01	53-262-00	53-262-00		GENERAL VISUAL	Area Aft of Cargo Compartment
53-270-00-01	53-270-00	53-270-00		GENERAL VISUAL	Area Under Lower Wing-To-Body Fairing (aft of Wheel Well)
53-280-00-01	53-280-00	53-280-00		GENERAL VISUAL	Area Under Wing-To-Body Fairing (above wing)
53-290-00-01	53-290-00	53-290-00		GENERAL VISUAL	Overwing Emergency Exit Cutout
53-310-00-01	53-310-00	53-310-00		DETAILED	Forward Entry Door Frame, Stops, Latches and Hinges
53-310-00-02	53-310-00	53-310-00		DETAILED	Forward Galley Service Door Frame, Stops, Latches and Hinges
53-310-00-03	53-310-00	53-310-00		DETAILED	Aft Entry Door Frame, Stops, Latches and Hinges
53-310-00-04	53-310-00	53-310-00		DETAILED	Aft Galley Service Door Frame, Stops, Latches and Hinges
53-330-00-01	53-330-00	53-330-00		GENERAL VISUAL	Flight Compartment from Sta 178 to 270
53-335-00-01	53-335-00	53-335-00		GENERAL VISUAL	Flight Compartment from Sta 178 to 270
53-340-00-01	53-340-00	53-340-00		GENERAL VISUAL	Flight Compartment Floor Structure
53-350-00-01	53-350-00	53-350-00		GENERAL VISUAL	Passenger Compartment from Sta 270 to 360
53-360-00-01	53-360-00	53-360-00		DETAILED	Passenger Compartment Door Cutouts
53-360-00-02	53-360-00	53-360-00		DETAILED	Passenger Compartment Door Cutouts
53-360-00-03	53-360-00	53-360-00		DETAILED	Passenger Compartment Door Cutouts
53-360-00-04	53-360-00	53-360-00		DETAILED	Passenger Compartment Door Cutouts
53-370-00-01	53-370-00	53-370-00		GENERAL VISUAL	Passenger Compartment Floor Structure - Dry Area



## 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

### TASKS SORTED BY TASK CARD NUMBER

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
53-370-00-02	53-370-00	53-370-00		GENERAL VISUAL	Passenger Compartment Floor Structure - Dry Area
53-380-00-01	53-380-00	53-380-00		GENERAL VISUAL	Passenger Compartment Floor Structure - Wet Area
53-380-00-02	53-380-00	53-380-00		GENERAL VISUAL	Passenger Compartment Floor Structure - Wet Area
53-390-00-01	53-390-00	53-390-00		GENERAL VISUAL	Passenger Compartment Floor Structure - Wet Area
53-400-00-01	53-400-00	53-400-00		GENERAL VISUAL	Forward Passenger Compartment, Sta 360 to 663.75
53-410-00-01	53-410-00	53-410-00		GENERAL VISUAL	Aft Passenger Compartment, STA 663.75 to 1016
53-412-00-01	53-412-00	53-412-00		GENERAL VISUAL	Aft Passenger Compartment, STA 663.75 to 1042
53-414-00-01	53-414-00	53-414-00		GENERAL VISUAL	Left Mid Emergency Exit Surround Structure
53-414-00-02	53-414-00	53-414-00		GENERAL VISUAL	Right Mid Emergency Exit Surround Structure
53-415-00-01	53-415-00	53-415-00		DETAILED	Left Mid Exit Structural Plug Surround
53-415-00-02	53-415-00	53-415-00		DETAILED	Right Mid Exit Structural Plug Surround
53-416-00-01	53-416-00	53-416-00		GENERAL VISUAL	Left Mid Emergency Exit Door
53-416-00-02	53-416-00	53-416-00		GENERAL VISUAL	Right Mid Emergency Exit Door
53-417-00-01	53-417-00	53-417-00		DETAILED	Left Mid Exit Structural Plug
53-417-00-02	53-417-00	53-417-00		DETAILED	Right Mid Exit Structural Plug
53-418-00-01	53-418-00	53-418-00		GENERAL VISUAL	Left Mid Exit Structural Plug



## 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

### TASKS SORTED BY TASK CARD NUMBER

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
53-418-00-02	53-418-00	53-418-00		GENERAL VISUAL	Right Mid Exit Structural Plug
53-419-00-01	53-419-00	53-419-00		GENERAL VISUAL	Left Mid Exit Structural Plug
53-419-00-02	53-419-00	53-419-00		GENERAL VISUAL	Right Mid Exit Structural Plug
53-420-00-01	53-420-00	53-420-00		GENERAL VISUAL	Area Aft of STA 1016 Bulkhead
53-422-00-01	53-422-00	53-422-00		GENERAL VISUAL	Area Aft of STA 1042 Bulkhead
53-430-00-01	53-430-00	53-430-00		GENERAL VISUAL	Stabilizer Torsion Box Compartment and APU Compartment
53-440-00-01	53-440-00	53-440-00		GENERAL VISUAL	STA 1156 Bulkhead
53-450-00-01	53-450-00	53-450-00		GENERAL VISUAL	Fuselage Skin Under Dorsal Fin
53-460-00-01	53-460-00	53-460-00		GENERAL VISUAL	Vertical Fin Front Spar Fitting
53-470-00-01	53-470-00	53-470-00		GENERAL VISUAL	Vertical Fin Front Spar Fitting
53-480-00-01	53-480-00	53-480-00		GENERAL VISUAL	Vertical Fin Rear Spar Fitting
53-490-00-01	53-490-00	53-490-00		DETAILED	Main Deck Cargo Door Cutout Frames, Fittings, Pins, and Hinges
53-495-00-01	53-495-00	53-495-00		DETAILED	Main Deck Cargo Door Cutout Frames, Fittings, Pins, and Hinges
53-500-00-01	53-500-00	53-500-00		DETAILED	Main Deck Cargo Door Cutout and Surround Structure
53-505-00-01	53-505-00	53-505-00		DETAILED	Main Deck Cargo Door Cutout and Surround Structure
53-510-00-01	53-510-00	53-510-00		GENERAL VISUAL	Crown Skin Panel
53-510-10-01	53-510-10			DETAILED	KU Band Antenna Installation





**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

<b>TASK CARD NUMBER</b>	<b>MPD ITEM NUMBER</b>	<b>MRB ITEM NUMBER</b>	<b>RELATED TASK CARD NUMBER</b>	<b>TASK</b>	<b>TASK TITLE</b>
53-520-00-01	53-520-00	53-520-00		DETAILED	Seat Track to Frame Attachment, Sta 540 to 727
53-530-00-01	53-530-00	53-530-00		GENERAL VISUAL	Crown Skin Panel, Sta 360 to 500H
53-600-00-01	53-600-00			SPECIAL DETAILED	Left Longitudinal Lap Splice
53-600-00-02	53-600-00			SPECIAL DETAILED	Right Longitudinal Lap Splice
53-600-01-01	53-600-01			SPECIAL DETAILED	Left Longitudinal Lap Splice
53-600-01-02	53-600-01			SPECIAL DETAILED	Right Longitudinal Lap Splice
53-600-20-01	53-600-20			SPECIAL DETAILED	Left Longitudinal Lap Splice
53-600-20-02	53-600-20			SPECIAL DETAILED	Right Longitudinal Lap Splice
53-600-21-01	53-600-21			SPECIAL DETAILED	Left Longitudinal Lap Splice
53-600-21-02	53-600-21			SPECIAL DETAILED	Right Longitudinal Lap Splice
53-600-30-01	53-600-30			SPECIAL DETAILED	Left Longitudinal Lap Splice
53-600-30-02	53-600-30			SPECIAL DETAILED	Right Longitudinal Lap Splice
53-600-40-01	53-600-40			SPECIAL DETAILED	Left Longitudinal Lap Splice
53-600-40-02	53-600-40			SPECIAL DETAILED	Right Longitudinal Lap Splice
53-600-41-01	53-600-41			GENERAL VISUAL	Left Longitudinal Lap Splice



**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
53-600-41-02	53-600-41			GENERAL VISUAL	Right Longitudinal Lap Splice
53-600-50-01	53-600-50			SPECIAL DETAILED	Left Longitudinal Lap Splice
53-600-50-02	53-600-50			SPECIAL DETAILED	Right Longitudinal Lap Splice
53-601-00-01	53-601-00			SPECIAL DETAILED	Cutout - Crew Cab Windows
53-601-01-01	53-601-01			SPECIAL DETAILED	Cutout - Crew Cab Windows
53-601-20-01	53-601-20			DETAILED	Left Cutout - Crew Cab Windows
53-601-20-02	53-601-20			DETAILED	Right Cutout - Crew Cab Windows
53-601-21-01	53-601-21			DETAILED	Left Cutout - Crew Cab Windows
53-601-21-02	53-601-21			DETAILED	Right Cutout - Crew Cab Windows
53-601-30-01	53-601-30			DETAILED	Left Cutout - Crew Cab Windows
53-601-30-02	53-601-30			DETAILED	Right Cutout - Crew Cab Windows
53-601-40-01	53-601-40			SPECIAL DETAILED	Left Cutout - Crew Cabin Windows
53-601-40-02	53-601-40			SPECIAL DETAILED	Right Cutout - Crew Cabin Windows
53-601-41-01	53-601-41			SPECIAL DETAILED	Left Cutout - Crew Cabin Windows
53-601-41-02	53-601-41			SPECIAL DETAILED	Right Cutout - Crew Cabin Windows
53-601-50-01	53-601-50			SPECIAL DETAILED	Left Cutout - Crew Cabin Windows
53-601-50-02	53-601-50			SPECIAL DETAILED	Right Cutout - Crew Cabin Windows



## 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

### TASKS SORTED BY TASK CARD NUMBER

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
53-601-60-01	53-601-60			SPECIAL DETAILED	Left Cutout - Crew Cabin Windows
53-601-60-02	53-601-60			SPECIAL DETAILED	Right Cutout - Crew Cabin Windows
53-602-10-01	53-602-10			SPECIAL DETAILED	Left Crown Skin Panel - FWD of STA 259.5
53-602-10-02	53-602-10			SPECIAL DETAILED	Right Crown Skin Panel - FWD of STA 259.5
53-602-20-01	53-602-20			DETAILED	Crown Skin Panel - STA 259.5 to 360
53-603-10-01	53-603-10			SPECIAL DETAILED	Cutout - Forward Access Door, Forward Edge of Cutout
53-605-10-01	53-605-10			DETAILED	Cutout - Electronic Equipment Door
53-606-40-01	53-606-40			SPECIAL DETAILED	Cutout - Forward Entry Door Frame
53-606-50-01	53-606-50			SPECIAL DETAILED	Cutout - Forward Entry Door Frame
53-606-70-01	53-606-70			DETAILED	FWD Entry Door, FWD Edge Frame Stops
53-618-00-01	53-618-00			SPECIAL DETAILED	FWD Entry Door FWD Edge Frame Stops
53-619-00-01	53-619-00			SPECIAL DETAILED	FWD Entry Door, FWD Edge Frame Stops
53-620-00-01	53-620-00			DETAILED	FWD Entry Door, AFT Edge Frame Stops
53-621-00-01	53-621-00			DETAILED	FWD Entry Door, AFT Edge Frame Stops
53-622-00-01	53-622-00			SPECIAL DETAILED	FWD Entry Door Cutout
53-623-00-01	53-623-00			SPECIAL DETAILED	FWD Galley Door Cutout
53-624-00-01	53-624-00			SPECIAL DETAILED	Forward Galley Door Surround Structure, Door Stop Backup Structure



**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
53-625-00-01	53-625-00			SPECIAL DETAILED	Cutout - FWD Galley Door
53-626-00-01	53-626-00			SPECIAL DETAILED	Left Bulkhead, STA 294.5
53-626-00-02	53-626-00			SPECIAL DETAILED	Right Bulkhead, STA 294.5
53-627-00-01	53-627-00			DETAILED	Left Nose Wheel Well Side and Top Panels
53-627-00-02	53-627-00			DETAILED	Right Nose Wheel Well Side and Top Panels
53-628-00-01	53-628-00			DETAILED	Left Nose Landing Gear Support Fittings
53-628-00-02	53-628-00			DETAILED	Right Nose Landing Gear Support Fittings
53-629-00-01	53-629-00			DETAILED	Left Nose Landing Gear Trunnion Support Fittings
53-629-00-02	53-629-00			DETAILED	Right Landing Gear Trunnion Support Fittings
53-630-00-01	53-630-00			DETAILED	Air Stair Door Cutout
53-630-01-01	53-630-01			GENERAL VISUAL	Air Stair Door Cutout
53-631-00-01	53-631-00			SPECIAL DETAILED	Air Stair Door Cutout
53-631-01-01	53-631-01			GENERAL VISUAL	Air Stair Door Cutout
53-632-00-01	53-632-00			SPECIAL DETAILED	Forward Nose Wheel Well Cutout Outer Chord
53-633-00-01	53-633-00			DETAILED	Crown Skin Panel, STA 360 to 540
53-634-00-01	53-634-00			DETAILED	Crown Skin Panel, STA 360 to 540
53-634-10-01	53-634-10			SPECIAL DETAILED	Crown Skin Panel, STA 360 to 540
53-635-00-01	53-635-00			DETAILED	Left SATCOM AERO - H Antenna Installation
53-635-00-02	53-635-00			DETAILED	Right SATCOM AERO - H Antenna Installation



**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

<b>TASK CARD NUMBER</b>	<b>MPD ITEM NUMBER</b>	<b>MRB ITEM NUMBER</b>	<b>RELATED TASK CARD NUMBER</b>	<b>TASK</b>	<b>TASK TITLE</b>
53-636-00-01	53-636-00			GENERAL VISUAL	Left Fuselage Side Skin Panels
53-636-00-02	53-636-00			GENERAL VISUAL	Right Fuselage Side Skin Panels
53-636-10-01	53-636-10			DETAILED	Left Fuselage Side Skin Panels Under the Wing-to-Body Fairing
53-636-10-02	53-636-10			DETAILED	Right Fuselage Side Skin Panels Under the Wing-to-Body Fairing
53-636-20-01	53-636-20			SPECIAL DETAILED	Left Fuselage Skin Under the Upper Wing-to-Body Drag Angle
53-636-20-02	53-636-20			SPECIAL DETAILED	Right Fuselage Skin Under the Upper Wing-to-Body Drag Angle
53-637-00-01	53-637-00			SPECIAL DETAILED	Left Longitudinal Lap Splice
53-637-00-02	53-637-00			SPECIAL DETAILED	Right Longitudinal Lap Splice
53-637-10-01	53-637-10			SPECIAL DETAILED	Left Longitudinal Lap Splice
53-637-10-02	53-637-10			SPECIAL DETAILED	Right Longitudinal Lap Splice
53-638-00-01	53-638-00			SPECIAL DETAILED	Left Longitudinal Lap Splice
53-638-00-02	53-638-00			SPECIAL DETAILED	Right Longitudinal Lap Splice
53-638-10-01	53-638-10			SPECIAL DETAILED	Left Longitudinal Lap Splice
53-638-10-02	53-638-10			SPECIAL DETAILED	Right Longitudinal Lap Splice
53-639-00-01	53-639-00			SPECIAL DETAILED	Left Longitudinal Skin Splice
53-639-00-02	53-639-00			SPECIAL DETAILED	Right Longitudinal Skin Splice



# 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

## TASKS SORTED BY TASK CARD NUMBER

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
53-639-10-02	53-639-10			SPECIAL DETAILED	Right Longitudinal Skin Splice
53-640-00-01	53-640-00			DETAILED	Left Longitudinal Lap Splice
53-640-00-02	53-640-00			DETAILED	Right Longitudinal Lap Splice
53-640-10-01	53-640-10			DETAILED	Right Longitudinal Lap Splice
53-641-00-01	53-641-00			DETAILED	Left Longitudinal Lap Splice
53-641-00-02	53-641-00			DETAILED	Right Longitudinal Lap Splice
53-641-10-01	53-641-10			DETAILED	Left Longitudinal Lap Splice
53-641-10-02	53-641-10			DETAILED	Right Longitudinal Lap Splice
53-642-00-01	53-642-00			SPECIAL DETAILED	Left Longitudinal Lap Splice
53-642-00-02	53-642-00			SPECIAL DETAILED	Right Longitudinal Lap Splice
53-642-10-01	53-642-10			SPECIAL DETAILED	Left Longitudinal Lap Splice
53-642-10-02	53-642-10			SPECIAL DETAILED	Right Longitudinal Lap Splice
53-643-00-01	53-643-00			SPECIAL DETAILED	Left Longitudinal Lap Splice
53-643-00-02	53-643-00			SPECIAL DETAILED	Right Longitudinal Lap Splice
53-644-00-01	53-644-00			DETAILED	Left Longitudinal Lap Splice
53-644-00-02	53-644-00			DETAILED	Right Longitudinal Lap Splice
53-645-00-01	53-645-00			DETAILED	Left Window Belt STA 360 to 540
53-645-00-02	53-645-00			DETAILED	Right Window Belt STA 360 to 540
53-645-01-01	53-645-01			DETAILED	Left Window Belt STA 360 to STA 540
53-645-01-02	53-645-01			DETAILED	Right Window Belt STA 360 to STA 540



# 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

## TASKS SORTED BY TASK CARD NUMBER

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
53-646-00-01	53-646-00			SPECIAL DETAILED	Forward Cargo Door Surround Structure
53-646-10-01	53-646-10			SPECIAL DETAILED	Forward Cargo Door Surround, Forward and Aft Edge Frames at STA 440 and 492.4
53-646-20-01	53-646-20			SPECIAL DETAILED	Forward Cargo Door Surround, Forward and Aft Edge Frames at STA 440 and 492.4
53-646-30-01	53-646-30			SPECIAL DETAILED	Forward Cargo Door Surround
53-646-40-01	53-646-40			SPECIAL DETAILED	Forward Cargo Door Surround Structure
53-646-50-01	53-646-50			SPECIAL DETAILED	Forward Cargo Door Surround Structure
53-646-60-01	53-646-60			SPECIAL DETAILED	Forward Cargo Door Surround Structure
53-646-61-01	53-646-61			SPECIAL DETAILED	Forward Cargo Door Surround Structure
53-646-62-01	53-646-62			DETAILED	Forward Cargo Door Surround Structure
53-646-63-01	53-646-63			GENERAL VISUAL	Forward Cargo Door Surround Structure
53-646-70-01	53-646-70			SPECIAL DETAILED	Forward Cargo Door Surround Structure
53-646-71-01	53-646-71			SPECIAL DETAILED	Forward Cargo Door Surround Structure
53-646-75-01	53-646-75			DETAILED	Forward Cargo Door Surround Structure
53-646-80-01	53-646-80			SPECIAL DETAILED	Forward Cargo Door Surround Structure
53-647-00-01	53-647-00			SPECIAL DETAILED	Forward Cargo Door Fittings and Stops at the Forward and Aft Edge Frames
53-648-00-01	53-648-00			SPECIAL DETAILED	Left Wing to Body Lower Drag Angle



**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

<b>TASK CARD NUMBER</b>	<b>MPD ITEM NUMBER</b>	<b>MRB ITEM NUMBER</b>	<b>RELATED TASK CARD NUMBER</b>	<b>TASK</b>	<b>TASK TITLE</b>
53-648-00-02	53-648-00			SPECIAL DETAILED	Right Wing to Body Lower Drag Angle
53-649-00-01	53-649-00			SPECIAL DETAILED	Left Wing to Body Upper Drag Angle
53-649-00-02	53-649-00			SPECIAL DETAILED	Right Wing to Body Upper Drag Angle
53-649-01-01	53-649-01			SPECIAL DETAILED	Left Wing to Body Upper Drag Angle
53-649-01-02	53-649-01			SPECIAL DETAILED	Right Wing to Body Upper Drag Angle
53-650-00-01	53-650-00			SPECIAL DETAILED	Left Wing to Body Upper Drag Angle
53-650-00-02	53-650-00			SPECIAL DETAILED	Right Wing to Body Upper Drag Angle
53-651-00-01	53-651-00			SPECIAL DETAILED	Left Floor Beam to Frame Joint
53-651-00-02	53-651-00			SPECIAL DETAILED	Right Floor Beam to Frame Joint
53-652-00-01	53-652-00			DETAILED	Crown Skin Panel - STA 540 to 727
53-653-00-01	53-653-00			SPECIAL DETAILED	Left Longitudinal Lap Splice
53-653-00-02	53-653-00			SPECIAL DETAILED	Right Longitudinal Lap Splice
53-653-10-01	53-653-10			SPECIAL DETAILED	Left Longitudinal Lap Splice
53-653-10-02	53-653-10			SPECIAL DETAILED	Right Longitudinal Lap Splice
53-654-00-01	53-654-00			SPECIAL DETAILED	Left Longitudinal Lap Splice





# 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

## TASKS SORTED BY TASK CARD NUMBER

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
53-654-00-02	53-654-00			SPECIAL DETAILED	Right Longitudinal Lap Splice
53-654-10-01	53-654-10			SPECIAL DETAILED	Left Longitudinal Lap Splice
53-654-10-02	53-654-10			SPECIAL DETAILED	Right Longitudinal Lap Splice
53-655-00-01	53-655-00			SPECIAL DETAILED	Left Longitudinal Lap Splice
53-655-00-02	53-655-00			SPECIAL DETAILED	Right Longitudinal Lap Splice
53-655-10-01	53-655-10			SPECIAL DETAILED	Left Longitudinal Skin Splice
53-655-10-02	53-655-10			SPECIAL DETAILED	Right Longitudinal Skin Splice
53-656-00-01	53-656-00			DETAILED	Left Window Belt, STA 540 to 727
53-656-00-02	53-656-00			DETAILED	Right Window Belt, STA 540 TO 727
53-657-00-01	53-657-00			DETAILED	Left Window Belt, STA 540 to 727
53-657-00-02	53-657-00			DETAILED	Right Window Belt, STA 540 to 727
53-658-00-01	53-658-00			DETAILED	Left Stringer Splice, STA 663
53-658-00-02	53-658-00			DETAILED	Right Stringer Splice, STA 663
53-659-00-01	53-659-00			DETAILED	Left Keel Beam Chords, Stiffeners and Splice
53-659-00-02	53-659-00			DETAILED	Right Keel Beam Chords, Stiffeners and Splice
53-660-00-01	53-660-00			SPECIAL DETAILED	Left Stiffener Attachment to Floor Beam, STA 727, LBL 45, WL 202.6
53-660-00-02	53-660-00			SPECIAL DETAILED	Right Stiffener Attachment to Floor Beam, STA 727, RBL 45, WL 202.6
53-661-00-01	53-661-00			SPECIAL DETAILED	Left Stringer 18 Strap Side of Body



**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
53-661-00-02	53-661-00			SPECIAL DETAILED	Right Stringer 18 Strap Side of Body
53-662-00-01	53-662-00			SPECIAL DETAILED	Left Stringer 18A Chord and Links
53-662-00-02	53-662-00			SPECIAL DETAILED	Right Stringer 18A Chord and Links
53-663-00-01	53-663-00			SPECIAL DETAILED	Left Frame Splice at STA 540
53-663-00-02	53-663-00			SPECIAL DETAILED	Right Frame Splice at STA 540
53-664-00-01	53-664-00			DETAILED	BS 540 Bulkhead
53-665-00-01	53-665-00			DETAILED	Left BS 663 Bulkhead
53-665-00-02	53-665-00			DETAILED	Right BS 663 Bulkhead
53-666-00-01	53-666-00			SPECIAL DETAILED	Left BS 663 Bulkhead
53-666-00-02	53-666-00			SPECIAL DETAILED	Right BS 663 Bulkhead
53-667-00-01	53-667-00			SPECIAL DETAILED	Left Aft Wheel Well Bulkhead STA 727
53-667-00-02	53-667-00			SPECIAL DETAILED	Right Aft Wheel Well Bulkhead STA 727
53-667-10-01	53-667-10			SPECIAL DETAILED	Left Aft Wheel Well Bulkhead STA 727
53-667-10-02	53-667-10			SPECIAL DETAILED	Right Aft Wheel Well Bulkhead STA 727
53-668-00-01	53-668-00			SPECIAL DETAILED	Left Wheel Well Aft Bulkhead
53-668-00-02	53-668-00			SPECIAL DETAILED	Right Wheel Well Aft Bulkhead



## 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

### TASKS SORTED BY TASK CARD NUMBER

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
53-668-10-01	53-668-10			SPECIAL DETAILED	Left Wheel Well Aft Bulkhead
53-668-10-02	53-668-10			SPECIAL DETAILED	Right Wheel Well Aft Bulkhead
53-669-00-01	53-669-00			SPECIAL DETAILED	Left Wheel Well Aft Bulkhead and Pressure Web STA 727
53-669-00-02	53-669-00			SPECIAL DETAILED	Right Wheel Well Aft Bulkhead and Pressure Web STA 727
53-670-00-01	53-670-00			DETAILED	Aft Wheel Well Bulkhead and Pressure Web, STA 727
53-671-00-01	53-671-00			SPECIAL DETAILED	Left Aft Wheel Well Bulkhead Frame STA 727
53-671-00-02	53-671-00			SPECIAL DETAILED	Right Aft Wheel Well Bulkhead Frame STA 727
53-672-00-01	53-672-00			SPECIAL DETAILED	Left Side Strut Support Frame STA 706
53-672-00-02	53-672-00			SPECIAL DETAILED	Right Side Strut Support Frame STA 706
53-673-00-01	53-673-00			GENERAL VISUAL	Left Main Landing Gear Support Frame, STA 695
53-673-00-02	53-673-00			GENERAL VISUAL	Right Main Landing Gear Support Frame, STA 695
53-674-00-01	53-674-00			SPECIAL DETAILED	Left Main Landing Gear Support Frame STA 716
53-674-00-02	53-674-00			SPECIAL DETAILED	Right Main Landing Gear Support Frame STA 716
53-675-00-01	53-675-00			SPECIAL DETAILED	Left Main Landing Gear Support Frame STA 716
53-675-00-02	53-675-00			SPECIAL DETAILED	Right Main Landing Gear Support Frame STA 716



**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

<b>TASK CARD NUMBER</b>	<b>MPD ITEM NUMBER</b>	<b>MRB ITEM NUMBER</b>	<b>RELATED TASK CARD NUMBER</b>	<b>TASK</b>	<b>TASK TITLE</b>
53-676-00-01	53-676-00			SPECIAL DETAILED	Left Main Landing Gear Support Frame STA 716
53-676-00-02	53-676-00			SPECIAL DETAILED	Right Main Landing Gear Support Frame STA 716
53-676-10-01	53-676-10			SPECIAL DETAILED	Left Main Landing Gear Support Frame STA 716
53-676-10-02	53-676-10			SPECIAL DETAILED	Right Main Landing Gear Support Frame STA 716
53-677-00-01	53-677-00			DETAILED	Left Wheel Well Frame, STA 685
53-677-00-02	53-677-00			DETAILED	Right Wheel Well Frame, STA 685
53-678-00-01	53-678-00			SPECIAL DETAILED	Left Wheel Well Frame STA 685
53-678-00-02	53-678-00			SPECIAL DETAILED	Right Wheel Well Frame STA 685
53-679-00-01	53-679-00			SPECIAL DETAILED	Left Wheel Well Frame At STA 685
53-679-00-02	53-679-00			SPECIAL DETAILED	Right Wheel Well Frame At STA 685
53-680-00-01	53-680-00			SPECIAL DETAILED	Left Overwing Emergency Exit Cutout
53-680-00-02	53-680-00			SPECIAL DETAILED	Right Overwing Emergency Exit Cutout
53-681-00-01	53-681-00			SPECIAL DETAILED	Left Overwing Emergency Exit Cutout
53-681-00-02	53-681-00			SPECIAL DETAILED	Right Overwing Emergency Exit Cutout
53-681-01-01	53-681-01			SPECIAL DETAILED	Left Overwing Emergency Exit Cutout
53-681-01-02	53-681-01			SPECIAL DETAILED	Right Overwing Emergency Exit Cutout



## 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

### TASKS SORTED BY TASK CARD NUMBER

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
53-681-02-01	53-681-02			SPECIAL DETAILED	Left Overwing Emergency Exit Cutout
53-681-02-02	53-681-02			SPECIAL DETAILED	Right Overwing Emergency Exit Cutout
53-682-00-01	53-682-00			SPECIAL DETAILED	Left Overwing Emergency Exit Cutout Skin Assembly & Frame Outer Chord
53-682-00-02	53-682-00			SPECIAL DETAILED	Right Overwing Emergency Exit Cutout Skin Assembly & Frame Outer Chord
53-682-01-01	53-682-01			SPECIAL DETAILED	Left Overwing Emergency Exit Cutout Skin Assembly & Frame Outer Chord
53-682-01-02	53-682-01			SPECIAL DETAILED	Right Overwing Emergency Exit Cutout Skin Assembly & Frame Outer Chord
53-682-03-01	53-682-03			SPECIAL DETAILED	Left Overwing Emergency Exit Cutout Skin Assembly & Frame Outer Chord
53-682-03-02	53-682-03			SPECIAL DETAILED	Right Overwing Emergency Exit Cutout Skin Assembly & Frame Outer Chord
53-683-00-01	53-683-00			SPECIAL DETAILED	Left Overwing Emergency Exit Cutout
53-683-00-02	53-683-00			SPECIAL DETAILED	Right Overwing Emergency Exit Cutout
53-684-00-01	53-684-00			SPECIAL DETAILED	Left Overwing Emergency Exit Cutout
53-684-00-02	53-684-00			SPECIAL DETAILED	Right Overwing Emergency Exit Cutout
53-684-01-01	53-684-01			SPECIAL DETAILED	Left Overwing Emergency Exit Cutout
53-684-01-02	53-684-01			SPECIAL DETAILED	Right Overwing Emergency Exit Cutout
53-684-02-01	53-684-02			SPECIAL DETAILED	Left Overwing Emergency Exit Cutout



**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

<b>TASK CARD NUMBER</b>	<b>MPD ITEM NUMBER</b>	<b>MRB ITEM NUMBER</b>	<b>RELATED TASK CARD NUMBER</b>	<b>TASK</b>	<b>TASK TITLE</b>
53-684-02-02	53-684-02			SPECIAL DETAILED	Right Overwing Emergency Exit Cutout
53-685-00-01	53-685-00			SPECIAL DETAILED	Left Overwing Emergency Exit Cutout - Door Cutout Corners
53-685-00-02	53-685-00			SPECIAL DETAILED	Right Overwing Emergency Exit Cutout - Door Cutout Corners
53-685-01-01	53-685-01			SPECIAL DETAILED	Left Overwing Emergency Exit Cutout - Door Cutout Corners
53-685-01-02	53-685-01			SPECIAL DETAILED	Right Overwing Emergency Exit Cutout - Door Cutout Corners
53-686-00-01	53-686-00			SPECIAL DETAILED	Left Overwing Emergency Exit Cutout
53-686-00-02	53-686-00			SPECIAL DETAILED	Right Overwing Emergency Exit Cutout
53-687-00-01	53-687-00			SPECIAL DETAILED	Left Overwing Emergency Exit Cutout
53-687-00-02	53-687-00			SPECIAL DETAILED	Right Overwing Emergency Exit Cutout
53-687-10-01	53-687-10			SPECIAL DETAILED	Left Overwing Emergency Exit Cutout
53-687-10-02	53-687-10			SPECIAL DETAILED	Right Overwing Emergency Exit Cutout
53-688-00-01	53-688-00			SPECIAL DETAILED	Left Overwing Emergency Exit Cutout
53-688-00-02	53-688-00			SPECIAL DETAILED	Right Overwing Emergency Exit Cutout - Door Cutout Corners
53-689-00-01	53-689-00			SPECIAL DETAILED	Left Overwing Emergency Exit Cutout Skin and Frame Assembly Section at STA 616 and Stringer S-13
53-689-00-02	53-689-00			SPECIAL DETAILED	Right Overwing Emergency Exit Cutout Skin and Frame Assembly Section at STA 616 and Stringer S-13



# 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

## TASKS SORTED BY TASK CARD NUMBER

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
53-690-00-01	53-690-00			SPECIAL DETAILED	Left Overwing Emergency Exit Cutout Skin Assembly and Frame Outer Chord
53-690-00-02	53-690-00			SPECIAL DETAILED	Right Overwing Emergency Exit Cutout Skin Assembly and Frame Outer Chord
53-691-00-01	53-691-00			DETAILED	Left Overwing Emergency Exit Cutout
53-691-00-02	53-691-00			DETAILED	Right Overwing Emergency Exit Cutout
53-692-00-01	53-692-00			GENERAL VISUAL	Left Overwing Emergency Exit Cutout
53-692-00-02	53-692-00			GENERAL VISUAL	Right Overwing Emergency Exit Cutout
53-693-00-01	53-693-00			SPECIAL DETAILED	Left Overwing Emergency Exit Cutout Structure
53-693-00-02	53-693-00			SPECIAL DETAILED	Right Overwing Emergency Exit Cutout Structure
53-693-01-01	53-693-01			SPECIAL DETAILED	Left Overwing Emergency Exit Cutout Structure
53-693-01-02	53-693-01			SPECIAL DETAILED	Right Overwing Emergency Exit Cutout Structure
53-694-00-01	53-694-00			SPECIAL DETAILED	Left Overwing Emergency Exit Cutout Structure
53-694-00-02	53-694-00			SPECIAL DETAILED	Right Overwing Emergency Exit Cutout Structure
53-695-00-01	53-695-00			DETAILED	Left Overwing Emergency Exit Door Stops and Fittings
53-695-00-02	53-695-00			DETAILED	Right Overwing Emergency Exit Door Stops and Fittings
53-696-00-01	53-696-00			DETAILED	Left Overwing Emergency Exit Door Stops and Fittings
53-696-00-02	53-696-00			DETAILED	Right Overwing Emergency Exit Door Stops and Fittings
53-697-00-01	53-697-00			SPECIAL DETAILED	Left Overwing Emergency Exit Door Stops and Fittings



## 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

### TASKS SORTED BY TASK CARD NUMBER

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
53-697-00-02	53-697-00			SPECIAL DETAILED	Right Overwing Emergency Exit Door Stops and Fittings
53-697-10-01	53-697-10			GENERAL VISUAL	Pressure Deck Attachments to Rear Spar Extension
53-698-00-01	53-698-00			DETAILED	Crown Skin Panel - STA 727 to 887
53-699-00-01	53-699-00			DETAILED	Crown Skin Panel STA 727 to 887
53-700-00-01	53-700-00			SPECIAL DETAILED	SATCOM Antenna Installation (Canadian Marconi and Honeywell)
53-701-00-01	53-701-00			DETAILED	SATCOM Antenna Installation (Canadian Marconi and Honeywell)
53-702-00-01	53-702-00			SPECIAL DETAILED	SATCOM Antenna Installation (All except those covered by PSE 53-60-01-5)
53-702-01-01	53-702-01			DETAILED	SATCOM Antenna Installation (All except those covered by PSE 53-60-01-5)
53-703-00-01	53-703-00			GENERAL VISUAL	Left Fuselage Side Skin Panels
53-703-00-02	53-703-00			GENERAL VISUAL	Right Fuselage Side Skin Panels
53-703-10-01	53-703-10			DETAILED	Left Fuselage Side Skin Panels Under the Wing-to-Body Fairing
53-703-10-02	53-703-10			DETAILED	Right Fuselage Side Skin Panels Under the Wing-to-Body Fairing
53-704-00-01	53-704-00			SPECIAL DETAILED	Left Longitudinal Lap Splice
53-704-00-02	53-704-00			SPECIAL DETAILED	Right Longitudinal Lap Splice
53-704-10-01	53-704-10			SPECIAL DETAILED	Left Longitudinal Lap Splice
53-704-10-02	53-704-10			SPECIAL DETAILED	Right Longitudinal Lap Splice
53-705-00-01	53-705-00			SPECIAL DETAILED	Left Longitudinal Lap Splice





## 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

### TASKS SORTED BY TASK CARD NUMBER

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
53-705-00-02	53-705-00			SPECIAL DETAILED	Right Longitudinal Lap Splice
53-705-10-01	53-705-10			SPECIAL DETAILED	Left Longitudinal Lap Splice
53-705-10-02	53-705-10			SPECIAL DETAILED	Right Longitudinal Lap Splice
53-706-00-01	53-706-00			SPECIAL DETAILED	Left Longitudinal Lap Splice, Stringer S-10L
53-706-00-02	53-706-00			SPECIAL DETAILED	Right Longitudinal Lap Splice, Stringer S-10R
53-706-10-01	53-706-10			SPECIAL DETAILED	Left Longitudinal Skin Splice
53-706-10-02	53-706-10			SPECIAL DETAILED	Right Longitudinal Skin Splice
53-707-00-01	53-707-00			DETAILED	Left Longitudinal Lap Splice
53-707-00-02	53-707-00			DETAILED	Right Longitudinal Lap Splice
53-707-10-01	53-707-10			DETAILED	Left Longitudinal Lap Splice
53-707-10-02	53-707-10			DETAILED	Right Longitudinal Lap Splice
53-708-00-01	53-708-00			DETAILED	Left Longitudinal Lap Splice
53-708-00-02	53-708-00			DETAILED	Right Longitudinal Lap Splice
53-708-10-01	53-708-10			DETAILED	Left Longitudinal Lap Splice
53-708-10-02	53-708-10			DETAILED	Right Longitudinal Lap Splice
53-709-00-01	53-709-00			SPECIAL DETAILED	Left Longitudinal Lap Splice
53-709-00-02	53-709-00			SPECIAL DETAILED	Right Longitudinal Lap Splice
53-709-10-01	53-709-10			SPECIAL DETAILED	Left Longitudinal Lap Splice



**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
53-709-10-02	53-709-10			SPECIAL DETAILED	Right Longitudinal Lap Splice
53-710-00-01	53-710-00			SPECIAL DETAILED	Left Longitudinal Lap Splice
53-710-00-02	53-710-00			SPECIAL DETAILED	Right Longitudinal Lap Splice
53-711-00-01	53-711-00			DETAILED	Left Window Belt STA 727 to 888
53-711-00-02	53-711-00			DETAILED	Right Window Belt STA 727 to 888
53-711-01-01	53-711-01			DETAILED	Left Window Belt STA 727 to 888
53-711-01-02	53-711-01			DETAILED	Right Window Belt STA 727 to 888
53-712-00-01	53-712-00			SPECIAL DETAILED	Aft Cargo Door Surround Structure
53-713-00-01	53-713-00			SPECIAL DETAILED	Aft Cargo Door Surround Structure
53-713-01-01	53-713-01			SPECIAL DETAILED	Aft Cargo Door Surround Structure
53-714-00-01	53-714-00			SPECIAL DETAILED	Aft Cargo Door Surround Structure
53-714-01-01	53-714-01			SPECIAL DETAILED	Aft Cargo Door Surround Structure
53-715-00-01	53-715-00			SPECIAL DETAILED	Aft Cargo Door Surround Structure
53-716-00-01	53-716-00			SPECIAL DETAILED	Aft Cargo Door Surround Structure
53-717-00-01	53-717-00			SPECIAL DETAILED	Aft Cargo Door Surround Structure
53-718-00-01	53-718-00			SPECIAL DETAILED	Aft Cargo Door Surround Forward and Aft Edge Frames at BS 794.37 and 847



# 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

## TASKS SORTED BY TASK CARD NUMBER

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
53-719-00-01	53-719-00			SPECIAL DETAILED	Aft Cargo Door Surround Forward and Aft Edge Frames at BS 794.37 and 847
53-720-00-01	53-720-00			SPECIAL DETAILED	Aft Cargo Door Surround Structure
53-721-00-01	53-721-00			DETAILED	Aft Cargo Door Surround Structure
53-721-10-01	53-721-10			GENERAL VISUAL	Aft Cargo Door Surround Structure
53-721-20-01	53-721-20			DETAILED	Aft Cargo Door Surround Structure
53-722-00-01	53-722-00			SPECIAL DETAILED	Aft Cargo Door Fittings and Stops at the Forward and Aft Edge Frames
53-722-10-01	53-722-10			DETAILED	Left Mid Exit Door Surround Structure
53-722-10-02	53-722-10			DETAILED	Right Mid Exit Door Surround Structure
53-722-15-01	53-722-15			DETAILED	Left Mid Exit Door Surround Structure
53-722-15-02	53-722-15			DETAILED	Right Mid Exit Door Surround Structure
53-723-00-01	53-723-00			SPECIAL DETAILED	Left Longitudinal Lap Splice
53-723-00-02	53-723-00			SPECIAL DETAILED	Right Longitudinal Lap Splice
53-723-10-01	53-723-10			SPECIAL DETAILED	Left Longitudinal Lap Splice
53-723-10-02	53-723-10			SPECIAL DETAILED	Right Longitudinal Lap Splice
53-724-00-01	53-724-00			SPECIAL DETAILED	Left Longitudinal Lap Splice
53-724-00-02	53-724-00			SPECIAL DETAILED	Right Longitudinal Lap Splice
53-725-00-01	53-725-00			DETAILED	Left Longitudinal Lap Splice
53-725-00-02	53-725-00			DETAILED	Right Longitudinal Lap Splice



# 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

## TASKS SORTED BY TASK CARD NUMBER

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
53-726-00-01	53-726-00			SPECIAL DETAILED	Left Longitudinal Lap Splice
53-726-00-02	53-726-00			SPECIAL DETAILED	Right Longitudinal Lap Splice
53-727-00-01	53-727-00			DETAILED	Crown Skin Panel - STA 887 to 1016
53-728-00-01	53-728-00			SPECIAL DETAILED	Aft Entry Door, Forward Edge Frame Door Stop Backup Structure
53-729-00-01	53-729-00			SPECIAL DETAILED	Aft Entry Door, Aft Edge Frame Door Stop Backup Intercostals
53-729-01-01	53-729-01			GENERAL VISUAL	Aft Entry Door, Aft Edge Frame Door Stop Backup Intercostals
53-730-00-01	53-730-00			DETAILED	Cutout, Aft Entry Door Surround Structure
53-731-00-01	53-731-00			DETAILED	Aft Entry Door Surround Structure
53-731-01-01	53-731-01			SPECIAL DETAILED	Aft Entry Door Surround Structure
53-732-00-01	53-732-00			DETAILED	Aft Entry Door Surround Structure
53-732-01-01	53-732-01			DETAILED	Aft Entry Door Surround Structure
53-732-10-01	53-732-10			SPECIAL DETAILED	Aft Entry Door Surround Structure
53-733-00-01	53-733-00			DETAILED	Aft Galley Door Surround Structure
53-733-01-01	53-733-01			DETAILED	Aft Galley Door Surround Structure
53-734-00-01	53-734-00			SPECIAL DETAILED	Aft Galley Door Forward Edge Frame Door Stop Backup Structure
53-734-01-01	53-734-01			SPECIAL DETAILED	Aft Galley Door Forward Edge Frame Door Stop Backup Structure
53-735-00-01	53-735-00			SPECIAL DETAILED	Aft Galley Door Aft Edge Frame Door Stop Backup Intercostals



# 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

## TASKS SORTED BY TASK CARD NUMBER

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
53-735-01-01	53-735-01			GENERAL VISUAL	Aft Galley Door Aft Edge Frame Door Stop Backup Intercostals
53-736-00-01	53-736-00			DETAILED	Cutout, Aft Galley Door Surround Structure
53-737-00-01	53-737-00			DETAILED	Aft Galley Door Surround Structure
53-737-01-01	53-737-01			SPECIAL DETAILED	Aft Galley Door Surround Structure
53-737-10-01	53-737-10			SPECIAL DETAILED	Aft Galley Door Surround Structure
53-738-00-01	53-738-00			DETAILED	Left Window Belt STA 888 to 927
53-738-00-02	53-738-00			DETAILED	Right Window Belt STA 888 to 927
53-738-01-01	53-738-01			DETAILED	Left Window Belt STA 888 to 927
53-738-01-02	53-738-01			DETAILED	Right Window Belt STA 888 to 927
53-739-00-01	53-739-00			DETAILED	Bulkhead STA 1016
53-740-00-01	53-740-00			DETAILED	Bulkhead STA 1016
53-741-00-01	53-741-00			SPECIAL DETAILED	Bulkhead STA 1016
53-742-00-01	53-742-00			SPECIAL DETAILED	Bulkhead STA 1016
53-743-00-01	53-743-00			SPECIAL DETAILED	Bulkhead STA 1016
53-743-01-01	53-743-01			SPECIAL DETAILED	Bulkhead STA 1016
53-744-00-01	53-744-00			SPECIAL DETAILED	Bulkhead STA 1016
53-745-00-01	53-745-00			SPECIAL DETAILED	Bulkhead STA 1016
53-746-00-01	53-746-00			SPECIAL DETAILED	Bulkhead STA 1016



**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

<b>TASK CARD NUMBER</b>	<b>MPD ITEM NUMBER</b>	<b>MRB ITEM NUMBER</b>	<b>RELATED TASK CARD NUMBER</b>	<b>TASK</b>	<b>TASK TITLE</b>
53-747-00-01	53-747-00			SPECIAL DETAILED	Bulkhead STA 1016
53-747-10-01	53-747-10			SPECIAL DETAILED	Bulkhead STA 1016
53-748-00-01	53-748-00			SPECIAL DETAILED	Bulkhead STA 1016
53-749-00-01	53-749-00			SPECIAL DETAILED	Bulkhead STA 1016
53-749-10-01	53-749-10			DETAILED	Bulkhead STA 1016
53-750-00-01	53-750-00			DETAILED	Vertical Fin Front Spar Fitting Bulkhead Attachment - STA 1016
53-750-10-01	53-750-10			SPECIAL DETAILED	Vertical Fin Front Spar Fitting Bulkhead Attachment - STA 1016
53-751-00-01	53-751-00			SPECIAL DETAILED	Vertical Fin Front Spar Fitting - STA 1016
53-752-00-01	53-752-00			SPECIAL DETAILED	Stringer Splice Fittings
53-753-00-01	53-753-00			SPECIAL DETAILED	Jackscrew Fitting Lugs
53-754-00-01	53-754-00			SPECIAL DETAILED	Vertical Fin Rear Spar Attachment Fittings
53-755-00-01	53-755-00			DETAILED	Vertical Fin Rear Spar Attachment Fittings
53-756-00-01	53-756-00			SPECIAL DETAILED	Bulkhead Station 1156
53-757-00-01	53-757-00			SPECIAL DETAILED	Integrated Bulkhead STA 1156
53-758-00-01	53-758-00			SPECIAL DETAILED	Left Horizontal Stabilizer Pivot Fitting
53-758-00-02	53-758-00			SPECIAL DETAILED	Right Horizontal Stabilizer Pivot Fitting



# 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

## TASKS SORTED BY TASK CARD NUMBER

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
53-759-00-01	53-759-00			SPECIAL DETAILED	Left Horizontal Stabilizer Pivot Pins
53-759-00-02	53-759-00			SPECIAL DETAILED	Right Horizontal Stabilizer Pivot Pins
53-760-00-01	53-760-00			DETAILED	Left Section 48 Skin Panels, STA 1088 to 1156
53-760-00-02	53-760-00			DETAILED	Right Section 48 Skin Panels, STA 1088 to 1156
53-761-00-01	53-761-00			DETAILED	STA 1042 Bulkhead Straps
53-762-00-01	53-762-00			DETAILED	STA 1042 Bulkhead Intercostals
53-763-00-01	53-763-00			DETAILED	STA 1042 Bulkhead Lugs, Links and Fittings Bulkhead Lugs
53-764-00-01	53-764-00			SPECIAL DETAILED	STA 1042 Bulkhead Lugs, Links and Fittings End Beam Lugs
53-765-00-01	53-765-00			SPECIAL DETAILED	STA 1042 Bulkhead Lugs, Links and Fittings End Beam Lug Attachment at Diagonal Beam
53-766-00-01	53-766-00			DETAILED	STA 1042 Bulkhead Link Fittings
53-767-00-01	53-767-00			DETAILED	STA 1042 Bulkhead Lugs, Links and Fittings Link Attach Fittings
53-768-00-01	53-768-00			DETAILED	STA 1042 Bulkhead Chord Splice
53-769-00-01	53-769-00			SPECIAL DETAILED	APU Inlet Cutout Enclosure Forward Panel
53-770-00-01	53-770-00			DETAILED	APU Inlet Enclosure Installation - Pressure Panels
53-771-00-01	53-771-00			SPECIAL DETAILED	APU Inlet Enclosure Installation Pressure Panels
53-772-00-01	53-772-00			SPECIAL DETAILED	APU Enclosure Installation Pressure Panels
53-773-00-01	53-773-00			SPECIAL DETAILED	APU Enclosure Installation Pressure Panels
53-774-00-01	53-774-00			SPECIAL DETAILED	APU Inlet Enclosure Installation - Pressure Panels



**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
53-775-00-01	53-775-00			SPECIAL DETAILED	APU Enclosure Installation
53-776-00-01	53-776-00			SPECIAL DETAILED	Left Section 48 Longitudinal Lap Splices S-4 Lap Splice, STA 1016 to 1042
53-776-00-02	53-776-00			SPECIAL DETAILED	Right Section 48 Longitudinal Lap Splices S-4 Lap Splice, STA 1016 to 1042
53-777-00-01	53-777-00			SPECIAL DETAILED	Left Section 48 Longitudinal Lap Splices S-4 Lap Splice, STA 1016 to 1042
53-777-00-02	53-777-00			SPECIAL DETAILED	Right Section 48 Longitudinal Lap Splices S-4 Lap Splice, STA 1016 to 1042
53-778-00-01	53-778-00			SPECIAL DETAILED	Left Section 48 Longitudinal Lap Splices S-24 Lap Splice, STA 1016 to 1042
53-778-00-02	53-778-00			SPECIAL DETAILED	Right Section 48 Longitudinal Lap Splices S-24 Lap Splice, STA 1016 to 1042
53-779-00-01	53-779-00			SPECIAL DETAILED	Left Section 48 Butt Splice at S-9R and S-9L BS 1016 - BS 1042
53-779-00-02	53-779-00			SPECIAL DETAILED	Right Section 48 Butt Splice at S-9R and S-9L BS 1016 - BS 1042
53-780-00-01	53-780-00			SPECIAL DETAILED	Left Section 48 Butt Splice at S-9R and 9L BS 1016 - BS 1042
53-780-00-02	53-780-00			SPECIAL DETAILED	Right Section 48 Butt Splice at S-9R and 9L BS 1016 - BS 1042
53-781-00-01	53-781-00			SPECIAL DETAILED	Left Section 48 Butt Splice at S-9R and 9L BS 1016 - BS 1042
53-781-00-02	53-781-00			SPECIAL DETAILED	Right Section 48 Butt Splice at S-9R and 9L BS 1016 - BS 1042
53-782-00-01	53-782-00			DETAILED	Side Skin Panel, STA 1016 to 1042 S-9R to S-16R - APU Inlet Cutout
53-790-00-01	53-790-00			GENERAL VISUAL	Left Section 48 Longitudinal Lap Splices S-24 Lap Splice, STA 1016 to 1042





# 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

## TASKS SORTED BY TASK CARD NUMBER

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
53-790-00-02	53-790-00			GENERAL VISUAL	Right Section 48 Longitudinal Lap Splices S-24 Lap Splice, STA 1016 to 1042
53-791-00-01	53-791-00			DETAILED	Crown Skin Panel - STA 540 to 727
53-800-00-01	53-800-00	53-800-00		ZONAL (GV)	Lower Fuselage
53-802-00-01	53-802-00	53-802-00		ZONAL (GV)	Radome
53-804-00-01	53-804-00	53-804-00		ZONAL (GV)	Area Forward of Nose Wheel Well
53-806-00-01	53-806-00	53-806-00		ZONAL (GV)	Area Above and Outboard of Nose Wheel Well
53-808-00-01	53-808-00	53-808-00		ZONAL (GV)	Electrical and Electronics Compartment
53-810-00-01	53-810-00	53-810-00		ZONAL (GV)	Electrical and Electronics Compartment Access Door
53-812-00-01	53-812-00	53-812-00		ZONAL (GV)	Forward Cargo Compartment
53-814-00-01	53-814-00	53-814-00		ZONAL (GV)	Forward Cargo Compartment
53-816-00-01	53-816-00	53-816-00		ZONAL (GV)	Forward Cargo Compartment
53-818-00-01	53-818-00	53-818-00		ZONAL (GV)	Forward Cargo Door Surround Structure Fittings and Stops
53-820-00-01	53-820-00	53-820-00		ZONAL (GV)	Area Below Forward Cargo Compartment
53-822-00-01	53-822-00	53-822-00		ZONAL (GV)	Air Conditioning Distribution Bay
53-824-01-01	53-824-01	53-824-01		ZONAL (GV)	Area Above Center Section Wing Box
53-826-00-01	53-826-00	53-826-00		ZONAL (GV)	Pressure Deck Above Main Landing Gear Wheel Well
53-828-00-01	53-828-00	53-828-00		ZONAL (GV)	Keel Beam (Part) Sta 540 to 727
53-830-00-01	53-830-00	53-830-00		ZONAL (GV)	Aft Cargo Compartment
53-832-00-01	53-832-00	53-832-00		ZONAL (GV)	Aft Cargo Compartment
53-834-00-01	53-834-00	53-834-00		ZONAL (GV)	Aft Cargo Compartment
53-836-00-01	53-836-00	53-836-00		ZONAL (GV)	Aft Cargo Door Surround Structure Fittings and Stops
53-838-00-01	53-838-00	53-838-00		ZONAL (GV)	Aft Cargo Compartment Vacuum Waste Compartment
53-840-00-01	53-840-00	53-840-00		ZONAL (GV)	Area Below Aft Cargo Compartment



## 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

### TASKS SORTED BY TASK CARD NUMBER

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
53-842-00-01	53-842-00	53-842-00		ZONAL (GV)	Aft Cargo Compartment Equipment Bay
53-844-00-01	53-844-00	53-844-00		ZONAL (GV)	Wing to Body Fairing
53-846-00-01	53-846-00	53-846-00		ZONAL (GV)	Lower Wing to Body Fairing - Forward of Wing Box
53-848-00-01	53-848-00	53-848-00		ZONAL (GV)	Lower Wing to Body Fairing - Under Wing Box
53-850-00-01	53-850-00	53-850-00		ZONAL (GV)	Lower Wing to Body Fairing - Aft of Wheel Well
53-852-00-01	53-852-00	53-852-00		ZONAL (GV)	Lower Wing to Body Fairing - Aft of Wheel Well
53-854-02-01	53-854-02	53-854-02		ZONAL (GV)	Above Wing, Wing to Body Fairing - Right
53-856-01-01	53-856-01	53-856-01		ZONAL (GV)	Above Wing, Wing to Body Fairing - Left
53-858-00-01	53-858-00	53-858-00		ZONAL (GV)	Flight Control Compartment
53-860-00-01	53-860-00	53-860-00		ZONAL (GV)	Flight Control Compartment
53-862-00-01	53-862-00	53-862-00		ZONAL (GV)	Flight Control Compartment
53-864-00-01	53-864-00	53-864-00		ZONAL (GV)	Passenger Compartment - Aft of Control Compartment to Fwd Entry Door
53-866-00-01	53-866-00	53-866-00		ZONAL (GV)	Passenger Compartment - Section 41, STA 270 to STA 360
53-868-00-01	53-868-00	53-868-00		ZONAL (GV)	Passenger Compartment - Aft of Control Compartment to Fwd Entry Door
53-870-00-01	53-870-00	53-870-00		ZONAL (GV)	Forward Passenger Entry Door Stops, Latches and Hinges
53-872-00-01	53-872-00	53-872-00		ZONAL (GV)	Forward Galley Service Door Stops, Latches, and Hinges
53-874-00-01	53-874-00	53-874-00		ZONAL (GV)	Forward Passenger Compartment - Sta 360 to Sta 663.75
53-876-00-01	53-876-00	53-876-00		ZONAL (GV)	Forward Passenger Compartment - Sta 360 to Sta 663.75
53-878-00-01	53-878-00	53-878-00		ZONAL (GV)	Forward Passenger Compartment - Sta 360 to Sta 663.75 Wet Areas
53-880-00-01	53-880-00	53-880-00		ZONAL (GV)	Forward Passenger Compartment - Sta 360 to Sta 663.75 Dry Areas
53-882-00-01	53-882-00	53-882-00		ZONAL (GV)	Aft Passenger Compartment - Sta 663.75 to Aft Pressure Bulkhead
53-882-00-02	53-882-00	53-882-00		ZONAL (GV)	Aft Passenger Compartment - Sta 663.75 to Aft Pressure Bulkhead
53-884-00-01	53-884-00	53-884-00		ZONAL (GV)	Aft Passenger Compartment - STA 663.75 to Aft Pressure Bulkhead
53-884-00-02	53-884-00	53-884-00		ZONAL (GV)	Aft Passenger Compartment - STA 663.75 to Aft Pressure Bulkhead



## 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

### TASKS SORTED BY TASK CARD NUMBER

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
53-886-00-01	53-886-00	53-886-00	W-20-445-00-01	ZONAL (GV)	Aft Passenger Compartment - Sta 663.75 to Aft Pressure Bulkhead Wet Area
53-886-00-02	53-886-00	53-886-00	W-20-445-00-01	ZONAL (GV)	Aft Passenger Compartment - Sta 663.75 to Aft Pressure Bulkhead Wet Area
53-888-00-01	53-888-00	53-888-00	W-20-440-00-01	ZONAL (GV)	Aft Passenger Compartment - Sta 663.75 to Aft Pressure Bulkhead Dry Area
53-888-00-02	53-888-00	53-888-00		ZONAL (GV)	Aft Passenger Compartment - Sta 663.75 to Aft Pressure Bulkhead Dry Area
53-890-00-01	53-890-00	53-890-00		ZONAL (GV)	Aft Passenger Entry Door Stops, Latches, and Hinges
53-892-00-01	53-892-00	53-892-00		ZONAL (GV)	Aft Galley Service Door Stops, Latches, and Hinges
53-894-00-01	53-894-00	53-894-00		ZONAL (GV)	Area Aft of the Pressure Bulkhead
53-894-00-02	53-894-00	53-894-00		ZONAL (GV)	Area Aft of the Pressure Bulkhead
53-896-00-01	53-896-00	53-896-00		ZONAL (GV)	Area Aft of Pressure Bulkhead
53-896-00-02	53-896-00	53-896-00		ZONAL (GV)	Area Aft of Pressure Bulkhead
53-898-00-01	53-898-00	53-898-00		ZONAL (GV)	Stabilizer Torsion Box Compartment
53-900-00-01	53-900-00	53-900-00		ZONAL (GV)	APU Compartment
53-902-00-01	53-902-00	53-902-00		ZONAL (GV)	Tail Cone
53-904-01-01	53-904-01	53-904-01		ZONAL (GV)	Flap Support No. 4 - Left Wing
53-906-02-01	53-906-02	53-906-02		ZONAL (GV)	Flap Support No. 5 - Right Wing
53-908-01-01	53-908-01	53-908-01		ZONAL (GV)	Main Deck Cargo Door Stops, Latches, Hinges and Fittings
53-910-00-01	53-910-00	53-910-00		ZONAL (GV)	Main Deck Cargo Compartment - Sta 360 to Sta 1016
53-914-00-01	53-914-00	53-914-00		ZONAL (GV)	Main Deck Cargo Compartment - Sta 360 to Sta 1016 Wet Areas
54-010-01-01	54-010-01	54-010-01		GENERAL VISUAL	Left Forward Engine Mount Assembly
54-010-02-01	54-010-02	54-010-02		GENERAL VISUAL	Right Forward Engine Mount Assembly
54-015-01-01	54-015-01	54-015-01		GENERAL VISUAL	Left Strut Attach Bolts at Forward Engine Mount



**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

<b>TASK CARD NUMBER</b>	<b>MPD ITEM NUMBER</b>	<b>MRB ITEM NUMBER</b>	<b>RELATED TASK CARD NUMBER</b>	<b>TASK</b>	<b>TASK TITLE</b>
54-015-02-01	54-015-02	54-015-02		GENERAL VISUAL	Right Strut Attach Bolts at Forward Engine Mounts
54-020-01-01	54-020-01	54-020-01		GENERAL VISUAL	Left Strut Forward and Aft Engine Mount to Strut Shear Pins
54-020-02-01	54-020-02	54-020-02		GENERAL VISUAL	Right Strut Forward and Aft Engine Mount to Strut Shear Pins
54-030-01-01	54-030-01	54-030-01		GENERAL VISUAL	Left Strut Aft Engine Mount Assembly
54-030-02-01	54-030-02	54-030-02		GENERAL VISUAL	Right Strut Aft Engine Mount Assembly
54-040-01-01	54-040-01	54-040-01		GENERAL VISUAL	Left Strut to Wing Attachments
54-040-02-01	54-040-02	54-040-02		GENERAL VISUAL	Right Strut to Wing Attachments
54-050-01-01	54-050-01	54-050-01		DETAILED	Left Strut to Wing Attachments - Pins and Fuse Pins
54-050-02-01	54-050-02	54-050-02		DETAILED	Right Strut to Wing Attachments - Pins and Fuse Pins
54-060-01-01	54-060-01	54-060-01		DETAILED	Left Strut to Wing Attachments
54-060-02-01	54-060-02	54-060-02		DETAILED	Right Strut to Wing Attachments
54-070-01-01	54-070-01	54-070-01		GENERAL VISUAL	Left Strut Box
54-070-02-01	54-070-02	54-070-02		GENERAL VISUAL	Right Strut Box
54-080-01-01	54-080-01	54-080-01		GENERAL VISUAL	Left Strut Box
54-080-02-01	54-080-02	54-080-02		GENERAL VISUAL	Right Strut Box
54-090-01-01	54-090-01	54-090-01		FUNCTIONAL	Functional Check Left Engine Forward Strut and Aft Strut Fairing Drains
54-090-02-01	54-090-02	54-090-02		FUNCTIONAL	Functional Check Right Engine Forward Strut and Aft Strut Fairing Drains



**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

<b>TASK CARD NUMBER</b>	<b>MPD ITEM NUMBER</b>	<b>MRB ITEM NUMBER</b>	<b>RELATED TASK CARD NUMBER</b>	<b>TASK</b>	<b>TASK TITLE</b>
54-600-00-01	54-600-00			GENERAL VISUAL	Left Strut to Wing Attachments
54-600-00-02	54-600-00			GENERAL VISUAL	Right Strut to Wing Attachments
54-610-00-01	54-610-00			SPECIAL DETAILED	Left Lower Spar Chord - Typical Exposed Detail
54-610-00-02	54-610-00			SPECIAL DETAILED	Right Lower Spar Chord - Typical Exposed Detail
54-611-00-01	54-611-00			SPECIAL DETAILED	Left Lower Spar Chord at Fire Seal Depressor Bracket
54-611-00-02	54-611-00			SPECIAL DETAILED	Right Lower Spar Chord at Fire Seal Depressor Bracket
54-611-01-01	54-611-01			SPECIAL DETAILED	Left Lower Spar Chord at Fire Seal Depressor Bracket
54-611-01-02	54-611-01			SPECIAL DETAILED	Right Lower Spar Chord at Fire Seal Depressor Bracket
54-612-00-01	54-612-00			SPECIAL DETAILED	Left Lower Spar Chord - Bracket
54-612-00-02	54-612-00			SPECIAL DETAILED	Right Lower Spar Chord - Bracket
54-613-00-01	54-613-00			SPECIAL DETAILED	Left Lower Spar Chord at Frame with Brackets
54-613-00-02	54-613-00			SPECIAL DETAILED	Right Lower Spar Chord at Frame with Bracket
54-614-00-01	54-614-00			SPECIAL DETAILED	Left Lower Spar Chord (Direction 1)
54-614-00-02	54-614-00			SPECIAL DETAILED	Right Lower Spar Chord (Direction 1)
54-614-01-01	54-614-01			SPECIAL DETAILED	Left Lower Spar Chord (Direction 2)



**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

<b>TASK CARD NUMBER</b>	<b>MPD ITEM NUMBER</b>	<b>MRB ITEM NUMBER</b>	<b>RELATED TASK CARD NUMBER</b>	<b>TASK</b>	<b>TASK TITLE</b>
54-614-01-02	54-614-01			SPECIAL DETAILED	Right Lower Spar Chord (Direction 2)
54-615-00-01	54-615-00			SPECIAL DETAILED	Left Lower Spar Chord, Web Only
54-615-00-02	54-615-00			SPECIAL DETAILED	Right Lower Spar Chord, Web Only
54-616-00-01	54-616-00			SPECIAL DETAILED	Left Lower Spar Chord, Chord Only
54-616-00-02	54-616-00			SPECIAL DETAILED	Right Lower Spar Chord, Chord Only
54-617-00-01	54-617-00			SPECIAL DETAILED	Left Lower Spar Chord - Compression Pad Bracket, Horizontal Leg
54-617-00-02	54-617-00			SPECIAL DETAILED	Right Lower Spar Chord - Compression Pad Bracket, Horizontal Leg
54-617-01-01	54-617-01			SPECIAL DETAILED	Left Lower Spar Chord - Compression Pad Bracket, Horizontal Leg
54-617-01-02	54-617-01			SPECIAL DETAILED	Right Lower Spar Chord - Compression Pad Bracket, Horizontal Leg
54-618-00-01	54-618-00			SPECIAL DETAILED	Left Lower Spar Chord - Compression Pad Bracket, Vertical Leg
54-618-00-02	54-618-00			SPECIAL DETAILED	Right Lower Spar Chord - Compression Pad Bracket, Vertical Leg
54-619-00-01	54-619-00			SPECIAL DETAILED	Left Lower Spar Chord - Typical Frame Detail, Vertical Leg
54-619-00-02	54-619-00			SPECIAL DETAILED	Right Lower Spar Chord - Typical Frame Detail, Vertical Leg
54-619-01-01	54-619-01			SPECIAL DETAILED	Left Lower Spar Chord - Typical Frame Detail, Vertical Leg
54-619-01-02	54-619-01			SPECIAL DETAILED	Right Lower Spar Chord - Typical Frame Detail, Vertical Leg



**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
54-620-00-01	54-620-00			SPECIAL DETAILED	Left Lower Spar Chord - Typical Frame Detail, Horizontal Leg
54-620-00-02	54-620-00			SPECIAL DETAILED	Right Lower Spar Chord - Typical Frame Detail, Horizontal Leg
54-621-00-01	54-621-00			DETAILED	Left Lower Spar Chord
54-621-00-02	54-621-00			DETAILED	Right Lower Spar Chord
54-622-00-01	54-622-00			SPECIAL DETAILED	Left Forward Engine Mount Bulkhead
54-622-00-02	54-622-00			SPECIAL DETAILED	Right Forward Engine Mount Bulkhead
54-623-00-01	54-623-00			SPECIAL DETAILED	Left Mid Strut Bulkhead
54-623-00-02	54-623-00			SPECIAL DETAILED	Right Mid Strut Bulkhead
54-624-00-01	54-624-00			SPECIAL DETAILED	Left Engine Strut Side Skin Cutouts
54-624-00-02	54-624-00			SPECIAL DETAILED	Right Engine Strut Side Skin Cutouts
54-625-00-01	54-625-00			SPECIAL DETAILED	Left Strut Side Skin
54-625-00-02	54-625-00			SPECIAL DETAILED	Right Strut Side Skin
54-626-00-01	54-626-00			SPECIAL DETAILED	Left Upper Spar Chord
54-626-00-02	54-626-00			SPECIAL DETAILED	Right Upper Spar Chord
54-627-00-01	54-627-00			SPECIAL DETAILED	Left Upper Spar Chord near Cutouts (Direction 1)
54-627-00-02	54-627-00			SPECIAL DETAILED	Right Upper Spar Chord near Cutouts (Direction 1)



## 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

### TASKS SORTED BY TASK CARD NUMBER

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
54-627-01-01	54-627-01			SPECIAL DETAILED	Left Upper Spar Chord near Cutouts (Direction 2)
54-627-01-02	54-627-01			SPECIAL DETAILED	Right Upper Spar Chord near Cutouts (Direction 2)
54-628-00-01	54-628-00			SPECIAL DETAILED	Left Upper Spar, R1 - Fitting and Upper Spar Web Joints, Chord Only (Direction 1)
54-628-00-02	54-628-00			SPECIAL DETAILED	Right Upper Spar, R1 - Fitting and Upper Spar Web Joints, Chord Only (Direction 1)
54-628-01-01	54-628-01			SPECIAL DETAILED	Left Upper Spar, R1 - Fitting and Upper Spar Web Joints, Chord Only (Direction 2)
54-628-01-02	54-628-01			SPECIAL DETAILED	Right Upper Spar, R1 - Fitting and Upper Spar Web Joints, Chord Only (Direction 2)
54-629-00-01	54-629-00			SPECIAL DETAILED	Left Upper Spar, R1 - Fitting and Upper Spar Joints, Web Only
54-629-00-02	54-629-00			SPECIAL DETAILED	Right Upper Spar, R1 - Fitting and Upper Spar Joints, Web Only
54-630-00-01	54-630-00			SPECIAL DETAILED	Left Upper and Lower Spar Chords (Direction 1)
54-630-00-02	54-630-00			SPECIAL DETAILED	Right Upper and Lower Spar Chords (Direction 1)
54-630-01-01	54-630-01			SPECIAL DETAILED	Left Upper and Lower Spar Chords (Direction 2)
54-630-01-02	54-630-01			SPECIAL DETAILED	Right Upper and Lower Spar Chords (Direction 2)
54-631-00-01	54-631-00			SPECIAL DETAILED	Left Upper Spar Chord
54-631-00-02	54-631-00			SPECIAL DETAILED	Right Upper Spar Chord
54-632-00-01	54-632-00			SPECIAL DETAILED	Left Upper Spar Chord





**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

<b>TASK CARD NUMBER</b>	<b>MPD ITEM NUMBER</b>	<b>MRB ITEM NUMBER</b>	<b>RELATED TASK CARD NUMBER</b>	<b>TASK</b>	<b>TASK TITLE</b>
54-632-00-02	54-632-00			SPECIAL DETAILED	Right Upper Spar Chord
54-632-01-01	54-632-01			SPECIAL DETAILED	Left Upper Spar Chord
54-632-01-02	54-632-01			SPECIAL DETAILED	Right Upper Spar Chord
54-633-00-01	54-633-00			SPECIAL DETAILED	Left R3/R4 First Fastener Row - Vertical Leg
54-633-00-02	54-633-00			SPECIAL DETAILED	Right R3/R4 First Fastener Row - Vertical Leg
54-634-00-01	54-634-00			SPECIAL DETAILED	Left Forward Engine Mount Hanger
54-634-00-02	54-634-00			SPECIAL DETAILED	Right Forward Engine Mount Hanger
54-635-00-01	54-635-00			GENERAL VISUAL	Left Thrust Link Assembly
54-635-00-02	54-635-00			GENERAL VISUAL	Right Thrust Link Assembly
54-636-00-01	54-636-00			GENERAL VISUAL	Left Thrust Link Pin
54-636-00-02	54-636-00			GENERAL VISUAL	Right Thrust Link Pin
54-637-00-01	54-637-00			SPECIAL DETAILED	Left Aft Engine Mount Assembly
54-637-00-02	54-637-00			SPECIAL DETAILED	Right Aft Engine Mount Assembly
54-638-00-01	54-638-00			GENERAL VISUAL	Left Evener Bar Assembly - Outboard Lugs
54-638-00-02	54-638-00			GENERAL VISUAL	Right Evener Bar Assembly - Outboard Lugs



## 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

### TASKS SORTED BY TASK CARD NUMBER

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
54-639-00-01	54-639-00			SPECIAL DETAILED	Left Aft Engine Mount Evener Bar - Mid Span
54-639-00-02	54-639-00			SPECIAL DETAILED	Right Aft Engine Mount Evener Bar - Mid Span
54-640-00-01	54-640-00			SPECIAL DETAILED	Left Strut Attach Bolts (Forward and Aft Mounts)
54-640-00-02	54-640-00			SPECIAL DETAILED	Right Strut Attach Bolts (Forward and Aft Mounts)
54-640-01-01	54-640-01			SPECIAL DETAILED	Left Strut Attach Bolts (Forward and Aft Mounts)
54-640-01-02	54-640-01			SPECIAL DETAILED	Right Strut Attach Bolts (Forward and Aft Mounts)
54-800-01-01	54-800-01	54-800-01		ZONAL (GV)	Forward Strut Fairing - Engine No. 1
54-802-01-01	54-802-01	54-802-01		ZONAL (GV)	Fan Cowl Support Beam - Engine No. 1
54-804-01-01	54-804-01	54-804-01		ZONAL (GV)	Strut Torque Box - Engine No. 1
54-806-01-01	54-806-01	54-806-01		ZONAL (GV)	Aft Strut Fairing - Engine No. 1
54-808-02-01	54-808-02	54-808-02		ZONAL (GV)	Forward Strut Fairing - Engine No. 2
54-810-02-01	54-810-02	54-810-02		ZONAL (GV)	Fan Cowl Support Beam - Engine No. 2
54-812-02-01	54-812-02	54-812-02		ZONAL (GV)	Strut Torque Box - Engine No. 2
54-814-02-01	54-814-02	54-814-02		ZONAL (GV)	Aft Strut Fairing - Engine No. 2
55-010-00-01	55-010-00	55-010-00		GENERAL VISUAL	Horizontal Stabilizer Center Section
55-020-00-01	55-020-00	55-020-00		GENERAL VISUAL	Stabilizer Torsion Box Compartment
55-030-00-01	55-030-00	55-030-00		GENERAL VISUAL	Vertical Fin Leading Edge
55-050-00-01	55-050-00	55-050-00		GENERAL VISUAL	Vertical Fin



# 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

## TASKS SORTED BY TASK CARD NUMBER

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
55-060-00-01	55-060-00	55-060-00		GENERAL VISUAL	Vertical Fin Trailing Edge
55-070-01-01	55-070-01	55-070-01		GENERAL VISUAL	Left Horizontal Stabilizer Leading Edge
55-070-02-01	55-070-02	55-070-02		GENERAL VISUAL	Right Horizontal Stabilizer Leading Edge
55-080-01-01	55-080-01	55-080-01		GENERAL VISUAL	Left Horizontal Stabilizer Leading Edge
55-080-02-01	55-080-02	55-080-02		GENERAL VISUAL	Right Horizontal Stabilizer Leading Edge
55-100-01-01	55-100-01	55-100-01		GENERAL VISUAL	Left Horizontal Stabilizer
55-100-02-01	55-100-02	55-100-02		GENERAL VISUAL	Right Horizontal Stabilizer
55-110-01-01	55-110-01	55-110-01		GENERAL VISUAL	Left Horizontal Stabilizer Trailing Edge and Elevator Tab Leading Edge
55-110-02-01	55-110-02	55-110-02		GENERAL VISUAL	Right Horizontal Stabilizer Trailing Edge and Elevator Tab Leading Edge
55-115-01-01	55-115-01	55-115-01		DETAILED	Left Elevator Tab Supt Ftgs on Front Spar and Tab Spar at Leading Edge
55-115-02-01	55-115-02	55-115-02		DETAILED	Right Elevator Tab Supt Ftgs on Front Spar and Tab Spar at Leading Edge
55-120-01-01	55-120-01	55-120-01		GENERAL VISUAL	Left Horizontal Stabilizer Trailing Edge
55-120-02-01	55-120-02	55-120-02		GENERAL VISUAL	Right Horizontal Stabilizer Trailing Edge
55-130-00-01	55-130-00	55-130-00		GENERAL VISUAL	Rudder, Elevator and Elevator Tab Attach Fittings
55-135-01-01	55-135-01	55-135-01		DETAILED	Left Elevator Hinge, Actuator, and Tab Mast Arm Ftgs and Balance Wt Suppt Struct.
55-135-02-01	55-135-02	55-135-02		DETAILED	Right Elevator Hinge, Actuator, and Tab Mast Arm Ftgs and Balance Wt Suppt Struct.



**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

<b>TASK CARD NUMBER</b>	<b>MPD ITEM NUMBER</b>	<b>MRB ITEM NUMBER</b>	<b>RELATED TASK CARD NUMBER</b>	<b>TASK</b>	<b>TASK TITLE</b>
55-600-00-01	55-600-00			SPECIAL DETAILED	Left Horizontal Stabilizer Center Section Rear Spar Upper Chord
55-600-00-02	55-600-00			SPECIAL DETAILED	Right Horizontal Stabilizer Center Section Rear Spar Upper Chord
55-601-00-01	55-601-00			SPECIAL DETAILED	Left Horizontal Stabilizer Center Section Rear Spar Upper Chord
55-601-00-02	55-601-00			SPECIAL DETAILED	Right Horizontal Stabilizer Center Section Rear Spar Upper Chord
55-602-00-01	55-602-00			SPECIAL DETAILED	Left Horizontal Stabilizer Center Section Rear Spar Upper Chord
55-602-00-02	55-602-00			SPECIAL DETAILED	Right Horizontal Stabilizer Center Section Rear Spar Upper Chord
55-603-00-01	55-603-00			SPECIAL DETAILED	Left Horizontal Stabilizer Center Section Rear Spar Upper Chord
55-603-00-02	55-603-00			SPECIAL DETAILED	Right Horizontal Stabilizer Center Section Rear Spar Upper Chord
55-604-00-01	55-604-00			SPECIAL DETAILED	Left Horizontal Stabilizer Center Section Pivot Fitting
55-604-00-02	55-604-00			SPECIAL DETAILED	Right Horizontal Stabilizer Center Section Pivot Fitting
55-605-00-01	55-605-00			SPECIAL DETAILED	Left Horizontal Stabilizer Center Section Pivot Fitting
55-605-00-02	55-605-00			SPECIAL DETAILED	Right Horizontal Stabilizer Center Section Pivot Fitting
55-606-00-01	55-606-00			SPECIAL DETAILED	Left Horizontal Stabilizer Center Section Thrust Link Fittings
55-606-00-02	55-606-00			SPECIAL DETAILED	Right Horizontal Stabilizer Center Section Thrust Link Fittings
55-607-00-01	55-607-00			SPECIAL DETAILED	Left Horizontal Stabilizer Center Section Jackscrew Fitting



**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

<b>TASK CARD NUMBER</b>	<b>MPD ITEM NUMBER</b>	<b>MRB ITEM NUMBER</b>	<b>RELATED TASK CARD NUMBER</b>	<b>TASK</b>	<b>TASK TITLE</b>
55-607-00-02	55-607-00			SPECIAL DETAILED	Right Horizontal Stabilizer Center Section Jackscrew Fitting
55-608-00-01	55-608-00			SPECIAL DETAILED	Left Horizontal Stabilizer Rear Spar Lower Chord
55-608-00-02	55-608-00			SPECIAL DETAILED	Right Horizontal Stabilizer Rear Spar Lower Chord
55-609-00-01	55-609-00			SPECIAL DETAILED	Left Horizontal Stabilizer Rear Spar Lower Chord
55-609-00-02	55-609-00			SPECIAL DETAILED	Right Horizontal Stabilizer Rear Spar Lower Chord
55-610-00-01	55-610-00			SPECIAL DETAILED	Left Horizontal Stabilizer Rear Spar Lower Chord
55-610-00-02	55-610-00			SPECIAL DETAILED	Right Horizontal Stabilizer Rear Spar Lower Chord
55-611-00-01	55-611-00			SPECIAL DETAILED	Left Horizontal Stabilizer Rear Spar Lower Chord
55-611-00-02	55-611-00			SPECIAL DETAILED	Right Horizontal Stabilizer Rear Spar Lower Chord
55-611-10-01	55-611-10			SPECIAL DETAILED	Left Horizontal Stabilizer Rear Spar Lower Chord
55-611-10-02	55-611-10			SPECIAL DETAILED	Right Horizontal Stabilizer Rear Spar Lower Chord
55-611-12-01	55-611-12			SPECIAL DETAILED	Left Horizontal Stabilizer Rear Spar Lower Chord
55-611-12-02	55-611-12			SPECIAL DETAILED	Right Horizontal Stabilizer Rear Spar Lower Chord
55-611-14-01	55-611-14			SPECIAL DETAILED	Left Horizontal Stabilizer Rear Spar Lower Chord
55-611-14-02	55-611-14			SPECIAL DETAILED	Right Horizontal Stabilizer Rear Spar Lower Chord



**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

<b>TASK CARD NUMBER</b>	<b>MPD ITEM NUMBER</b>	<b>MRB ITEM NUMBER</b>	<b>RELATED TASK CARD NUMBER</b>	<b>TASK</b>	<b>TASK TITLE</b>
55-611-16-01	55-611-16			SPECIAL DETAILED	Left Horizontal Stabilizer Rear Spar Lower Chord
55-611-16-02	55-611-16			SPECIAL DETAILED	Right Horizontal Stabilizer Rear Spar Lower Chord
55-611-18-01	55-611-18			SPECIAL DETAILED	Left Horizontal Stabilizer Rear Spar Lower Chord
55-611-18-02	55-611-18			SPECIAL DETAILED	Right Horizontal Stabilizer Rear Spar Lower Chord
55-611-20-01	55-611-20			SPECIAL DETAILED	Left Horizontal Stabilizer Rear Spar Upper Chord at Side-of-Body
55-611-20-02	55-611-20			SPECIAL DETAILED	Right Horizontal Stabilizer Rear Spar Upper Chord at Side-of-Body
55-611-22-01	55-611-22			SPECIAL DETAILED	Left Horizontal Stabilizer Rear Spar Upper Chord at Side-of-Body
55-611-22-02	55-611-22			SPECIAL DETAILED	Right Horizontal Stabilizer Rear Spar Upper Chord at Side-of-Body
55-611-23-01	55-611-23			SPECIAL DETAILED	Left Horizontal Stabilizer Rear Spar Upper Chord at Side-of-Body
55-611-23-02	55-611-23			SPECIAL DETAILED	Right Horizontal Stabilizer Rear Spar Upper Chord at Side-of-Body
55-611-24-01	55-611-24			SPECIAL DETAILED	Left Horizontal Stabilizer Rear Spar Upper Chord at Side-of-Body
55-611-24-02	55-611-24			SPECIAL DETAILED	Right Horizontal Stabilizer Rear Spar Upper Chord at Side-of-Body
55-611-25-01	55-611-25			SPECIAL DETAILED	Left Horizontal Stabilizer Rear Spar Upper Chord at Side-of-Body
55-611-25-02	55-611-25			SPECIAL DETAILED	Right Horizontal Stabilizer Rear Spar Upper Chord at Side-of-Body
55-611-26-01	55-611-26			SPECIAL DETAILED	Left Horizontal Stabilizer Rear Spar Upper Chord



**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

<b>TASK CARD NUMBER</b>	<b>MPD ITEM NUMBER</b>	<b>MRB ITEM NUMBER</b>	<b>RELATED TASK CARD NUMBER</b>	<b>TASK</b>	<b>TASK TITLE</b>
55-611-26-02	55-611-26			SPECIAL DETAILED	Right Horizontal Stabilizer Rear Spar Upper Chord
55-611-27-01	55-611-27			SPECIAL DETAILED	Left Horizontal Stabilizer Rear Spar Upper Chord
55-611-27-02	55-611-27			SPECIAL DETAILED	Right Horizontal Stabilizer Rear Spar Upper Chord
55-611-28-01	55-611-28			SPECIAL DETAILED	Left Horizontal Stabilizer Rear Spar Upper Chord
55-611-28-02	55-611-28			SPECIAL DETAILED	Right Horizontal Stabilizer Rear Spar Upper Chord
55-611-30-01	55-611-30			SPECIAL DETAILED	Left Horizontal Stabilizer Rear Spar Upper Chord
55-611-30-02	55-611-30			SPECIAL DETAILED	Right Horizontal Stabilizer Rear Spar Upper Chord
55-611-32-01	55-611-32			SPECIAL DETAILED	Left Horizontal Stabilizer Rear Spar Upper Chord
55-611-32-02	55-611-32			SPECIAL DETAILED	Right Horizontal Stabilizer Rear Spar Upper Chord
55-611-34-01	55-611-34			SPECIAL DETAILED	Left Horizontal Stabilizer Rear Spar Upper Chord
55-611-34-02	55-611-34			SPECIAL DETAILED	Right Horizontal Stabilizer Rear Spar Upper Chord
55-611-36-01	55-611-36			SPECIAL DETAILED	Left Horizontal Stabilizer Rear Spar Upper Chord
55-611-36-02	55-611-36			SPECIAL DETAILED	Right Horizontal Stabilizer Rear Spar Upper Chord
55-611-38-01	55-611-38			SPECIAL DETAILED	Left Horizontal Stabilizer Rear Spar Upper Chord
55-611-38-02	55-611-38			SPECIAL DETAILED	Right Horizontal Stabilizer Rear Spar Upper Chord



**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

<b>TASK CARD NUMBER</b>	<b>MPD ITEM NUMBER</b>	<b>MRB ITEM NUMBER</b>	<b>RELATED TASK CARD NUMBER</b>	<b>TASK</b>	<b>TASK TITLE</b>
55-611-40-01	55-611-40			SPECIAL DETAILED	Left Horizontal Stabilizer Rear Spar Upper Chord
55-611-40-02	55-611-40			SPECIAL DETAILED	Right Horizontal Stabilizer Rear Spar Upper Chord
55-611-42-01	55-611-42			SPECIAL DETAILED	Left Horizontal Stabilizer Rear Spar Upper Chord
55-611-42-02	55-611-42			SPECIAL DETAILED	Right Horizontal Stabilizer Rear Spar Upper Chord
55-611-44-01	55-611-44			SPECIAL DETAILED	Left Horizontal Stabilizer Rear Spar Web
55-611-44-02	55-611-44			SPECIAL DETAILED	Right Horizontal Stabilizer Rear Spar Web
55-611-46-01	55-611-46			SPECIAL DETAILED	Left Horizontal Stabilizer Rear Spar Web
55-611-46-02	55-611-46			SPECIAL DETAILED	Right Horizontal Stabilizer Rear Spar Web
55-611-48-01	55-611-48			SPECIAL DETAILED	Left Horizontal Stabilizer Rear Spar Web
55-611-48-02	55-611-48			SPECIAL DETAILED	Right Horizontal Stabilizer Rear Spar Web
55-611-50-01	55-611-50			SPECIAL DETAILED	Left Horizontal Stabilizer Rear Spar Web
55-611-50-02	55-611-50			SPECIAL DETAILED	Right Horizontal Stabilizer Rear Spar Web
55-611-52-01	55-611-52			SPECIAL DETAILED	Left Horizontal Stabilizer Rear Spar Web
55-611-52-02	55-611-52			SPECIAL DETAILED	Right Horizontal Stabilizer Rear Spar Web
55-612-00-01	55-612-00			SPECIAL DETAILED	Left Horizontal Stabilizer Rear Spar Upper and Failsafe Chord Lugs





**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

<b>TASK CARD NUMBER</b>	<b>MPD ITEM NUMBER</b>	<b>MRB ITEM NUMBER</b>	<b>RELATED TASK CARD NUMBER</b>	<b>TASK</b>	<b>TASK TITLE</b>
55-612-00-02	55-612-00			SPECIAL DETAILED	Right Horizontal Stabilizer Rear Spar Upper and Failsafe Chord Lugs
55-613-00-01	55-613-00			SPECIAL DETAILED	Left Horizontal Stabilizer Rear Spar Upper Chord Terminal Fitting
55-613-00-02	55-613-00			SPECIAL DETAILED	Right Horizontal Stabilizer Rear Spar Upper Chord Terminal Fitting
55-613-01-01	55-613-01			SPECIAL DETAILED	Left Horizontal Stabilizer Rear Spar Upper Chord Terminal Fitting
55-613-01-02	55-613-01			SPECIAL DETAILED	Right Horizontal Stabilizer Rear Spar Upper Chord Terminal Fitting
55-613-10-01	55-613-10			DETAILED	Left Horizontal Stabilizer Rear Spar Upper Chord Terminal Fitting
55-613-10-02	55-613-10			DETAILED	Right Horizontal Stabilizer Rear Spar Upper Chord Terminal Fitting
55-614-00-01	55-614-00			SPECIAL DETAILED	Left Horizontal Stabilizer Rear Spar Terminal Fitting
55-614-00-02	55-614-00			SPECIAL DETAILED	Right Horizontal Stabilizer Rear Spar Terminal Fitting
55-614-10-01	55-614-10			SPECIAL DETAILED	Left Horizontal Stabilizer Rear Spar Terminal Fitting (L3)
55-614-10-02	55-614-10			SPECIAL DETAILED	Right Horizontal Stabilizer Rear Spar Terminal Fitting (L3)
55-614-12-01	55-614-12			SPECIAL DETAILED	Left Horizontal Stabilizer Rear Spar Lower Chord
55-614-12-02	55-614-12			SPECIAL DETAILED	Right Horizontal Stabilizer Rear Spar Lower Chord
55-615-00-01	55-615-00			SPECIAL DETAILED	Left Horizontal Stabilizer Front Spar Upper Chord
55-615-00-02	55-615-00			SPECIAL DETAILED	Right Horizontal Stabilizer Front Spar Upper Chord
55-616-00-01	55-616-00			SPECIAL DETAILED	Left Horizontal Stabilizer Front Spar Upper Chord, Aft Flange



# 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

## TASKS SORTED BY TASK CARD NUMBER

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
55-616-00-02	55-616-00			SPECIAL DETAILED	Right Horizontal Stabilizer Front Spar Upper Chord, Aft Flange
55-616-05-01	55-616-05			SPECIAL DETAILED	Left Horizontal Stabilizer Front Spar Upper Chord, Web Flange
55-616-05-02	55-616-05			SPECIAL DETAILED	Right Horizontal Stabilizer Front Spar Upper Chord, Web Flange
55-616-06-01	55-616-06			SPECIAL DETAILED	Left Horizontal Stabilizer Front Spar Upper Chord, Web Flange
55-616-06-02	55-616-06			SPECIAL DETAILED	Right Horizontal Stabilizer Front Spar Upper Chord, Web Flange
55-616-07-01	55-616-07			SPECIAL DETAILED	Left Horizontal Stabilizer Front Spar Upper Chord, Web Flange
55-616-07-02	55-616-07			SPECIAL DETAILED	Right Horizontal Stabilizer Front Spar Upper Chord, Web Flange
55-616-08-01	55-616-08			SPECIAL DETAILED	Left Horizontal Stabilizer Front Spar Upper Chord, Web Flange
55-616-08-02	55-616-08			SPECIAL DETAILED	Right Horizontal Stabilizer Front Spar Upper Chord, Web Flange
55-616-09-01	55-616-09			SPECIAL DETAILED	Left Horizontal Stabilizer Front Spar Upper Chord, Web Flange
55-616-09-02	55-616-09			SPECIAL DETAILED	Right Horizontal Stabilizer Front Spar Upper Chord, Web Flange
55-616-10-01	55-616-10			SPECIAL DETAILED	Left Horizontal Stabilizer Front Spar Upper Chord, Forward Flange
55-616-10-02	55-616-10			SPECIAL DETAILED	Right Horizontal Stabilizer Front Spar Upper Chord, Forward Flange
55-616-11-01	55-616-11			SPECIAL DETAILED	Left Horizontal Stabilizer Front Spar Upper Chord, Forward Flange
55-616-11-02	55-616-11			SPECIAL DETAILED	Right Horizontal Stabilizer Front Spar Upper Chord, Forward Flange



## 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

### TASKS SORTED BY TASK CARD NUMBER

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
55-616-12-01	55-616-12			SPECIAL DETAILED	Left Horizontal Stabilizer Front Spar Upper Chord - Web Flange
55-616-12-02	55-616-12			SPECIAL DETAILED	Right Horizontal Stabilizer Front Spar Upper Chord - Web Flange
55-616-14-01	55-616-14			SPECIAL DETAILED	Left Horizontal Stabilizer Front Spar Upper Chord - Web Flange
55-616-14-02	55-616-14			SPECIAL DETAILED	Right Horizontal Stabilizer Front Spar Upper Chord - Web Flange
55-616-16-01	55-616-16			DETAILED	Left Horizontal Stabilizer Front Spar Lower Chord - Forward Flange
55-616-16-02	55-616-16			DETAILED	Right Horizontal Stabilizer Front Spar Lower Chord - Forward Flange
55-616-18-01	55-616-18			SPECIAL DETAILED	Left Horizontal Stabilizer Front Spar Lower Chord, Aft Flange
55-616-18-02	55-616-18			SPECIAL DETAILED	Right Horizontal Stabilizer Front Spar Lower Chord, Aft Flange
55-616-20-01	55-616-20			SPECIAL DETAILED	Left Horizontal Stabilizer Front Spar Lower Chord, Forward Flange
55-616-20-02	55-616-20			SPECIAL DETAILED	Right Horizontal Stabilizer Front Spar Lower Chord, Forward Flange
55-616-22-01	55-616-22			SPECIAL DETAILED	Left Horizontal Stabilizer Front Spar Lower Chord, Aft Flange
55-616-22-02	55-616-22			SPECIAL DETAILED	Right Horizontal Stabilizer Front Spar Lower Chord, Aft Flange
55-616-24-01	55-616-24			SPECIAL DETAILED	Left Horizontal Stabilizer Front Spar Lower Chord, Forward Flange
55-616-24-02	55-616-24			SPECIAL DETAILED	Right Horizontal Stabilizer Front Spar Lower Chord, Forward Flange
55-616-26-01	55-616-26			SPECIAL DETAILED	Left Horizontal Stabilizer Front Spar Lower Chord, Aft Flange
55-616-26-02	55-616-26			SPECIAL DETAILED	Right Horizontal Stabilizer Front Spar Lower Chord, Aft Flange



**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

<b>TASK CARD NUMBER</b>	<b>MPD ITEM NUMBER</b>	<b>MRB ITEM NUMBER</b>	<b>RELATED TASK CARD NUMBER</b>	<b>TASK</b>	<b>TASK TITLE</b>
55-616-28-01	55-616-28			SPECIAL DETAILED	Left Horizontal Stabilizer Front Spar Web
55-616-28-02	55-616-28			SPECIAL DETAILED	Right Horizontal Stabilizer Front Spar Web
55-616-30-01	55-616-30			SPECIAL DETAILED	Left Horizontal Stabilizer Front Spar Web
55-616-30-02	55-616-30			SPECIAL DETAILED	Right Horizontal Stabilizer Front Spar Web
55-616-32-01	55-616-32			SPECIAL DETAILED	Left Horizontal Stabilizer Front Spar Web
55-616-32-02	55-616-32			SPECIAL DETAILED	Right Horizontal Stabilizer Front Spar Web
55-616-34-01	55-616-34			SPECIAL DETAILED	Left Horizontal Stabilizer Front Spar Web
55-616-34-02	55-616-34			SPECIAL DETAILED	Right Horizontal Stabilizer Front Spar Web
55-616-36-01	55-616-36			SPECIAL DETAILED	Left Horizontal Stabilizer Front Spar Web
55-616-36-02	55-616-36			SPECIAL DETAILED	Right Horizontal Stabilizer Front Spar Web
55-617-00-01	55-617-00			DETAILED	Left Horizontal Stabilizer Front Spar Upper Chord
55-617-00-02	55-617-00			DETAILED	Right Horizontal Stabilizer Front Spar Upper Chord
55-618-00-01	55-618-00			SPECIAL DETAILED	Left Horizontal Stabilizer Front Spar Terminal Fitting
55-618-00-02	55-618-00			SPECIAL DETAILED	Right Horizontal Stabilizer Front Spar Terminal Fitting
55-618-10-01	55-618-10			SPECIAL DETAILED	Left Horizontal Stabilizer Front Spar Lower Chord
55-618-10-02	55-618-10			SPECIAL DETAILED	Right Horizontal Stabilizer Front Spar Lower Chord



## 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

### TASKS SORTED BY TASK CARD NUMBER

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
55-619-00-01	55-619-00			SPECIAL DETAILED	Left Horizontal Stabilizer Elevator Hinge Ribs
55-619-00-02	55-619-00			SPECIAL DETAILED	Right Horizontal Stabilizer Elevator Hinge Ribs
55-620-00-01	55-620-00			SPECIAL DETAILED	Left Horizontal Stabilizer Elevator Hinge Ribs
55-620-00-02	55-620-00			SPECIAL DETAILED	Right Horizontal Stabilizer Elevator Hinge Ribs
55-621-00-01	55-621-00			SPECIAL DETAILED	Left Horizontal Stabilizer Trailing Edge Hinge Plate Lower Forward Lug
55-621-00-02	55-621-00			SPECIAL DETAILED	Right Horizontal Stabilizer Trailing Edge Hinge Plate Lower Forward Lug
55-622-00-01	55-622-00			SPECIAL DETAILED	Left Horizontal Stabilizer Elevator Hinge Ribs
55-622-00-02	55-622-00			SPECIAL DETAILED	Right Horizontal Stabilizer Elevator Hinge Ribs
55-623-00-01	55-623-00			SPECIAL DETAILED	Left Horizontal Stabilizer Elevator Hinge Ribs
55-623-00-02	55-623-00			SPECIAL DETAILED	Right Horizontal Stabilizer Elevator Hinge Ribs
55-623-01-01	55-623-01			SPECIAL DETAILED	Left Horizontal Stabilizer Elevator Hinge Ribs Trailing Edge Clevis
55-623-01-02	55-623-01			SPECIAL DETAILED	Right Horizontal Stabilizer Elevator Hinge Ribs Trailing Edge Clevis
55-624-00-01	55-624-00			SPECIAL DETAILED	Left Horizontal Stabilizer Elevator Hinge Ribs
55-624-00-02	55-624-00			SPECIAL DETAILED	Right Horizontal Stabilizer Elevator Hinge Ribs
55-625-00-01	55-625-00			SPECIAL DETAILED	Left Horizontal Stabilizer Elevator Hinge Ribs



**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

<b>TASK CARD NUMBER</b>	<b>MPD ITEM NUMBER</b>	<b>MRB ITEM NUMBER</b>	<b>RELATED TASK CARD NUMBER</b>	<b>TASK</b>	<b>TASK TITLE</b>
55-625-00-02	55-625-00			SPECIAL DETAILED	Right Horizontal Stabilizer Elevator Hinge Ribs
55-626-00-01	55-626-00			SPECIAL DETAILED	Left Horizontal Stabilizer Elevator Hinge Ribs
55-626-00-02	55-626-00			SPECIAL DETAILED	Right Horizontal Stabilizer Elevator Hinge Ribs
55-627-00-01	55-627-00			SPECIAL DETAILED	Left Horizontal Stabilizer Trailing Edge Elevator Hinge Rib
55-627-00-02	55-627-00			SPECIAL DETAILED	Right Horizontal Stabilizer Trailing Edge Elevator Hinge Rib
55-628-00-01	55-628-00			SPECIAL DETAILED	Left Horizontal Stabilizer, Trailing Edge Hinge Rib to Rear Spar Attachment
55-628-00-02	55-628-00			SPECIAL DETAILED	Right Horizontal Stabilizer, Trailing Edge Hinge Rib to Rear Spar Attachment
55-629-00-01	55-629-00			SPECIAL DETAILED	Left Horizontal Stabilizer Elevator Hinge Ribs
55-629-00-02	55-629-00			SPECIAL DETAILED	Right Horizontal Stabilizer Elevator Hinge Ribs
55-630-00-01	55-630-00			SPECIAL DETAILED	Left Horizontal Stabilizer Elevator Hinge Ribs
55-630-00-02	55-630-00			SPECIAL DETAILED	Right Horizontal Stabilizer Elevator Hinge Ribs
55-631-00-01	55-631-00			SPECIAL DETAILED	Left Horizontal Stabilizer Elevator Hinge Ribs
55-631-00-02	55-631-00			SPECIAL DETAILED	Right Horizontal Stabilizer Elevator Hinge Ribs
55-631-10-01	55-631-10			SPECIAL DETAILED	Left Horizontal Stabilizer Upper Inspar Skins
55-631-10-02	55-631-10			SPECIAL DETAILED	Right Horizontal Stabilizer Upper Inspar Skin



# 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

## TASKS SORTED BY TASK CARD NUMBER

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
55-633-00-01	55-633-00			DETAILED	Left Horizontal Stabilizer Lower Inspar Skin
55-633-00-02	55-633-00			DETAILED	Right Horizontal Stabilizer Lower Inspar Skin
55-634-00-01	55-634-00			DETAILED	Left Horizontal Stabilizer Center Section Front Spar Upper Chord
55-634-00-02	55-634-00			DETAILED	Right Horizontal Stabilizer Center Section Front Spar Upper Chord
55-635-00-01	55-635-00			SPECIAL DETAILED	Left Horizontal Stabilizer Center Section Rear Spar Lugs
55-635-00-02	55-635-00			SPECIAL DETAILED	Right Horizontal Stabilizer Center Section Rear Spar Lugs
55-636-00-01	55-636-00			SPECIAL DETAILED	Left Horizontal Stabilizer Center Section Rear Spar Upper Chord
55-636-00-02	55-636-00			SPECIAL DETAILED	Right Horizontal Stabilizer Center Section Rear Spar Upper Chord
55-637-00-01	55-637-00			DETAILED	Left Horizontal Stabilizer Center Section Front Spar Upper Chord
55-637-00-02	55-637-00			DETAILED	Right Horizontal Stabilizer Center Section Front Spar Upper Chord
55-638-00-01	55-638-00			SPECIAL DETAILED	Left Horizontal Stabilizer Center Section Primary and Thrust Beams
55-638-00-02	55-638-00			SPECIAL DETAILED	Right Horizontal Stabilizer Center Section Primary and Thrust Beams
55-639-00-01	55-639-00			SPECIAL DETAILED	Left Horizontal Stabilizer Center Section Primary and Thrust Beams
55-639-00-02	55-639-00			SPECIAL DETAILED	Right Horizontal Stabilizer Center Section Primary and Thrust Beams
55-640-00-01	55-640-00			SPECIAL DETAILED	Left Horizontal Stabilizer Center Section Primary and Thrust Beams
55-640-00-02	55-640-00			SPECIAL DETAILED	Right Horizontal Stabilizer Center Section Primary and Thrust Beams
55-641-00-01	55-641-00			SPECIAL DETAILED	Left Horizontal Stabilizer Center Section Thrust Beams



**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

<b>TASK CARD NUMBER</b>	<b>MPD ITEM NUMBER</b>	<b>MRB ITEM NUMBER</b>	<b>RELATED TASK CARD NUMBER</b>	<b>TASK</b>	<b>TASK TITLE</b>
55-641-00-02	55-641-00			SPECIAL DETAILED	Right Horizontal Stabilizer Center Section Thrust Beams
55-642-00-01	55-642-00			SPECIAL DETAILED	Left Horizontal Stabilizer Center Section Thrust Beams
55-642-00-02	55-642-00			SPECIAL DETAILED	Right Horizontal Stabilizer Center Section Thrust Beams
55-643-00-01	55-643-00			SPECIAL DETAILED	Left Horizontal Stabilizer Center Section Thrust Beams
55-643-00-02	55-643-00			SPECIAL DETAILED	Right Horizontal Stabilizer Center Section Thrust Beams
55-644-00-01	55-644-00			SPECIAL DETAILED	Left Horizontal Stabilizer Center Section Thrust Beam Intersection
55-644-00-02	55-644-00			SPECIAL DETAILED	Right Horizontal Stabilizer Center Section Thrust Beam Intersection
55-645-00-01	55-645-00			SPECIAL DETAILED	Left Horizontal Stabilizer Center Section Thrust Beam
55-645-00-02	55-645-00			SPECIAL DETAILED	Right Horizontal Stabilizer Center Section Thrust Beam
55-646-00-01	55-646-00			SPECIAL DETAILED	Left Horizontal Stabilizer Center Section Primary Beam Chord to Web Attachment
55-646-00-02	55-646-00			SPECIAL DETAILED	Right Horizontal Stabilizer Center Section Primary Beam Chord to Web Attachment
55-647-00-01	55-647-00			SPECIAL DETAILED	Left Elevator Hinge Fittings
55-647-00-02	55-647-00			SPECIAL DETAILED	Right Elevator Hinge Fittings
55-648-00-01	55-648-00			SPECIAL DETAILED	Left Elevator Mast Arm Assembly (Elevator Actuator Fitting)
55-648-00-02	55-648-00			SPECIAL DETAILED	Right Elevator Mast Arm Assembly (Elevator Actuator Fitting)





**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

<b>TASK CARD NUMBER</b>	<b>MPD ITEM NUMBER</b>	<b>MRB ITEM NUMBER</b>	<b>RELATED TASK CARD NUMBER</b>	<b>TASK</b>	<b>TASK TITLE</b>
55-649-00-01	55-649-00			GENERAL VISUAL	Left Elevator Horn Balance Weight Support Structure
55-649-00-02	55-649-00			GENERAL VISUAL	Right Elevator Horn Balance Weight Support Structure
55-650-00-01	55-650-00			SPECIAL DETAILED	Left Elevator Tab Mast Fitting
55-650-00-02	55-650-00			SPECIAL DETAILED	Right Elevator Tab Mast Fitting
55-651-00-01	55-651-00			SPECIAL DETAILED	Left 183A8700 Hinge/Mast Arm Fitting Upper Flange
55-651-00-02	55-651-00			SPECIAL DETAILED	Right 183A8700 Hinge/Mast Arm Fitting Upper Flange
55-652-00-01	55-652-00			SPECIAL DETAILED	Left 183A8700 Hinge/Mast Arm Fitting Upper Flange
55-652-00-02	55-652-00			SPECIAL DETAILED	Right 183A8700 Hinge/Mast Arm Fitting Upper Flange
55-653-00-01	55-653-00			SPECIAL DETAILED	Left Elevator Tab Hinge Fittings 183A4211 Lug Assembly
55-653-00-02	55-653-00			SPECIAL DETAILED	Right Elevator Tab Hinge Fittings 183A4211 Lug Assembly
55-654-00-01	55-654-00			SPECIAL DETAILED	Left 183A8300 Bridge Fitting Upper/Lower Flange
55-654-00-02	55-654-00			SPECIAL DETAILED	Right 183A8300 Bridge Fitting Upper/Lower Flange
55-655-00-01	55-655-00			SPECIAL DETAILED	Left 183A8300 Bridge Fitting Upper/Lower Flange
55-655-00-02	55-655-00			SPECIAL DETAILED	Right 183A8300 Bridge Fitting Upper/Lower Flange
55-656-00-01	55-656-00			SPECIAL DETAILED	Left 183A1400 - Bracket Assy - Tab Control Mechanism, Elevator



**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
55-656-00-02	55-656-00			SPECIAL DETAILED	Right 183A1400 - Bracket Assy - Tab Control Mechanism, Elevator
55-657-00-01	55-657-00			SPECIAL DETAILED	Left 183A1400 - Bracket Assy - Tab Control Mechanism, Elevator
55-657-00-02	55-657-00			SPECIAL DETAILED	Right 183A1400 - Bracket Assy - Tab Control Mechanism, Elevator
55-658-00-01	55-658-00			SPECIAL DETAILED	Left Vertical Fin - Rear Spar
55-658-00-02	55-658-00			SPECIAL DETAILED	Right Vertical Fin - Rear Spar
55-659-00-01	55-659-00			SPECIAL DETAILED	Left Vertical Fin - Rear Spar
55-659-00-02	55-659-00			SPECIAL DETAILED	Right Vertical Fin - Rear Spar
55-660-00-01	55-660-00			DETAILED	Left Vertical Fin - Closure Rib
55-660-00-02	55-660-00			DETAILED	Right Vertical Fin - Closure Rib
55-661-00-01	55-661-00			SPECIAL DETAILED	Vertical Fin - Closure Rib
55-662-00-01	55-662-00			DETAILED	Rudder Hinge Ribs
55-663-00-01	55-663-00			DETAILED	Rudder Hinge Ribs
55-664-00-01	55-664-00			DETAILED	Rudder Hinge Fittings
55-665-00-01	55-665-00			SPECIAL DETAILED	Rudder Actuator Fittings
55-666-00-01	55-666-00			DETAILED	737NG Rudder Balance Arm
55-800-00-01	55-800-00	55-800-00		ZONAL (GV)	Vertical Fin and Horizontal Stabilizer
55-802-00-01	55-802-00	55-802-00		ZONAL (GV)	Vertical Fin - Dorsal Fin
55-804-00-01	55-804-00	55-804-00		ZONAL (GV)	Vertical Fin - Leading Edge (Only if HF System Installed)
55-806-00-01	55-806-00	55-806-00		ZONAL (GV)	Vertical Fin - Leading Edge



**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

<b>TASK CARD NUMBER</b>	<b>MPD ITEM NUMBER</b>	<b>MRB ITEM NUMBER</b>	<b>RELATED TASK CARD NUMBER</b>	<b>TASK</b>	<b>TASK TITLE</b>
55-808-00-01	55-808-00	55-808-00		ZONAL (GV)	Vertical Fin - Leading Edge
55-810-00-01	55-810-00	55-810-00		ZONAL (GV)	Vertical Fin - Front Spar to Rear Spar
55-812-00-01	55-812-00	55-812-00		ZONAL (GV)	Vertical Fin - Front Spar to Rear Spar
55-814-00-01	55-814-00	55-814-00		ZONAL (GV)	Vertical Fin - Rear Spar to Trailing Edge
55-816-00-01	55-816-00	55-816-00		ZONAL (GV)	Vertical Fin - Rear Spar to Trailing Edge
55-818-00-01	55-818-00	55-818-00		ZONAL (GV)	Rudder
55-820-00-01	55-820-00	55-820-00		ZONAL (GV)	Vertical Fin Tip
55-822-01-01	55-822-01	55-822-01		ZONAL (GV)	Horizontal Stabilizer - Leading Edge - Left
55-824-01-01	55-824-01	55-824-01		ZONAL (GV)	Horizontal Stabilizer - Front Spar to Rear Spar - Left
55-826-01-01	55-826-01	55-826-01		ZONAL (GV)	Horizontal Stabilizer - Front Spar to Rear Spar - Left
55-828-01-01	55-828-01	55-828-01		ZONAL (GV)	Horizontal Stabilizer - Rear Spar to Trailing Edge - Left
55-830-01-01	55-830-01	55-830-01		ZONAL (GV)	Horizontal Stabilizer - Rear Spar to Trailing Edge - Left
55-832-01-01	55-832-01	55-832-01		ZONAL (GV)	Horizontal Stabilizer - Elevator - Left
55-834-01-01	55-834-01	55-834-01		ZONAL (GV)	Horizontal Stabilizer - Stabilizer Tip - Left
55-836-02-01	55-836-02	55-836-02		ZONAL (GV)	Horizontal Stabilizer - Leading Edge - Right
55-838-02-01	55-838-02	55-838-02		ZONAL (GV)	Horizontal Stabilizer - Front Spar to Rear Spar - Right
55-840-02-01	55-840-02	55-840-02		ZONAL (GV)	Horizontal Stabilizer - Front Spar to Rear Spar - Right
55-842-02-01	55-842-02	55-842-02		ZONAL (GV)	Horizontal Stabilizer - Rear Spar to Trailing Edge - Right
55-844-02-01	55-844-02	55-844-02		ZONAL (GV)	Horizontal Stabilizer - Rear Spar to Trailing Edge - Right
55-846-02-01	55-846-02	55-846-02		ZONAL (GV)	Horizontal Stabilizer - Elevator - Right
55-848-02-01	55-848-02	55-848-02		ZONAL (GV)	Horizontal Stabilizer - Stabilizer Tip - Right
56-010-00-01	56-010-00	56-010-00		LUBRICATE	Control Cabin Sliding Windows
56-020-00-01	56-020-00	56-020-00		LUBRICATE	Control Cabin Sliding Windows
56-030-00-01	56-030-00	56-030-00		OPERATIONAL	Control Cabin Sliding Windows



**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

<b>TASK CARD NUMBER</b>	<b>MPD ITEM NUMBER</b>	<b>MRB ITEM NUMBER</b>	<b>RELATED TASK CARD NUMBER</b>	<b>TASK</b>	<b>TASK TITLE</b>
56-040-00-01	56-040-00	56-040-00		OPERATIONAL	Control Cabin Sliding Windows
56-050-00-01	56-050-00	56-050-00		INSPECTION - GEN VISUAL	Control Cabin Sliding Windows
56-060-00-01	56-060-00	56-060-00		INSPECTION - GEN VISUAL	Control Cabin Sliding Windows
57-010-00-01	57-010-00	57-010-00		GENERAL VISUAL	Wing Center Section
57-020-00-01	57-020-00	57-020-00		GENERAL VISUAL	Wing Center Section
57-030-00-01	57-030-00	57-030-00		GENERAL VISUAL	Wing Center Section
57-040-00-01	57-040-00	57-040-00		GENERAL VISUAL	Wing Center Section
57-050-00-01	57-050-00	57-050-00		GENERAL VISUAL	Wing Center Section
57-060-01-01	57-060-01	57-060-01		GENERAL VISUAL	Left Outboard Wing
57-060-02-01	57-060-02	57-060-02		GENERAL VISUAL	Right Outboard Wing
57-070-01-01	57-070-01	57-070-01		GENERAL VISUAL	Left Outboard Wing
57-070-02-01	57-070-02	57-070-02		GENERAL VISUAL	Right Outboard Wing
57-090-00-01	57-090-00	57-090-00		GENERAL VISUAL	Wing Center Section
57-100-01-01	57-100-01	57-100-01		GENERAL VISUAL	Left Nacelle Support Fittings
57-100-02-01	57-100-02	57-100-02		GENERAL VISUAL	Right Nacelle Support Fittings



**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

<b>TASK CARD NUMBER</b>	<b>MPD ITEM NUMBER</b>	<b>MRB ITEM NUMBER</b>	<b>RELATED TASK CARD NUMBER</b>	<b>TASK</b>	<b>TASK TITLE</b>
57-110-01-01	57-110-01	57-110-01		GENERAL VISUAL	Left Outboard Wing Lower Surface
57-110-02-01	57-110-02	57-110-02		GENERAL VISUAL	Right Outboard Wing Lower Surface
57-120-01-01	57-120-01	57-120-01		GENERAL VISUAL	Left Outboard Wing Front Spar
57-120-02-01	57-120-02	57-120-02		GENERAL VISUAL	Right Outboard Wing Front Spar
57-130-01-01	57-130-01	57-130-01		GENERAL VISUAL	Left Outboard Wing Leading Edge Structure
57-130-02-01	57-130-02	57-130-02		GENERAL VISUAL	Right Outboard Wing Leading Edge Structure
57-140-01-01	57-140-01	57-140-01		DETAILED	Left Wing Slat Tracks
57-140-02-01	57-140-02	57-140-02		DETAILED	Right Wing Slat Tracks
57-160-01-01	57-160-01	57-160-01		GENERAL VISUAL	Left Outboard Wing Access Holes
57-160-02-01	57-160-02	57-160-02		GENERAL VISUAL	Right Outboard Wing Access Holes
57-170-01-01	57-170-01	57-170-01	W-57-180-01-01 W-57-190-01-01	GENERAL VISUAL	Left Outboard Wing
57-170-02-01	57-170-02	57-170-02	W-57-180-02-01 W-57-190-02-01	GENERAL VISUAL	Right Outboard Wing
57-180-01-01	57-180-01	57-180-01	W-57-170-01-01 W-57-190-01-01	GENERAL VISUAL	Left Outboard Wing
57-180-02-01	57-180-02	57-180-02	W-57-170-02-01 W-57-190-02-01	GENERAL VISUAL	Right Outboard Wing
57-190-01-01	57-190-01	57-190-01	W-57-170-01-01 W-57-180-01-01	GENERAL VISUAL	Left Outboard Wing
57-190-02-01	57-190-02	57-190-02	W-57-170-02-01 W-57-180-02-01	GENERAL VISUAL	Right Outboard Wing



**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

<b>TASK CARD NUMBER</b>	<b>MPD ITEM NUMBER</b>	<b>MRB ITEM NUMBER</b>	<b>RELATED TASK CARD NUMBER</b>	<b>TASK</b>	<b>TASK TITLE</b>
57-200-01-01	57-200-01	57-200-01		GENERAL VISUAL	Left Flap Support No. 4
57-200-02-01	57-200-02	57-200-02		GENERAL VISUAL	Right Flap Support No. 5
57-210-01-01	57-210-01	57-210-01		GENERAL VISUAL	Left Flap Support No. 3
57-210-02-01	57-210-02	57-210-02		GENERAL VISUAL	Right Flap Support No. 6
57-220-01-01	57-220-01	57-220-01		GENERAL VISUAL	Left Outboard Wing Lower Surface
57-220-02-01	57-220-02	57-220-02		GENERAL VISUAL	Right Outboard Wing Lower Surface
57-230-01-01	57-230-01	57-230-01		GENERAL VISUAL	Flap Supports No. 1 & 2
57-230-02-01	57-230-02	57-230-02		GENERAL VISUAL	Flap Supports No.7 & 8
57-240-01-01	57-240-01	57-240-01		GENERAL VISUAL	Left Outboard Wing Lower Surface
57-240-02-01	57-240-02	57-240-02		GENERAL VISUAL	Right Outboard Wing Lower Surface
57-250-01-01	57-250-01	57-250-01		GENERAL VISUAL	Left Main Landing Gear Support Structure
57-250-02-01	57-250-02	57-250-02		GENERAL VISUAL	Right Main Landing Gear Support Structure
57-260-01-01	57-260-01	57-260-01		GENERAL VISUAL	Left Wing Outboard Rear Spar
57-260-02-01	57-260-02	57-260-02		GENERAL VISUAL	Right Wing Outboard Rear Spar
57-270-01-01	57-270-01	57-270-01		GENERAL VISUAL	Left Wing Outboard Trailing Edge Structure



**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

<b>TASK CARD NUMBER</b>	<b>MPD ITEM NUMBER</b>	<b>MRB ITEM NUMBER</b>	<b>RELATED TASK CARD NUMBER</b>	<b>TASK</b>	<b>TASK TITLE</b>
57-270-02-01	57-270-02	57-270-02		GENERAL VISUAL	Right Wing Outboard Trailing Edge Structure
57-280-01-01	57-280-01	57-280-01		GENERAL VISUAL	Left Inboard Ground Spoiler
57-280-02-01	57-280-02	57-280-02		GENERAL VISUAL	Right Inboard Ground Spoiler
57-300-01-01	57-300-01	57-300-01		GENERAL VISUAL	Left Inboard Flap
57-300-02-01	57-300-02	57-300-02		GENERAL VISUAL	Right Inboard Flap
57-310-01-01	57-310-01	57-310-01		GENERAL VISUAL	Left Outboard Wing Rear Spar
57-310-02-01	57-310-02	57-310-02		GENERAL VISUAL	Right Outboard Wing Rear Spar
57-330-01-01	57-330-01	57-330-01		GENERAL VISUAL	Left Outboard Flap
57-330-02-01	57-330-02	57-330-02		GENERAL VISUAL	Right Outboard Flap
57-340-01-01	57-340-01	57-340-01		SPECIAL DETAILED	Left Winglet
57-340-02-01	57-340-02	57-340-02		SPECIAL DETAILED	Right Winglet
57-351-01-01	57-351-01	57-351-01		DETAILED	Left Winglet
57-351-02-01	57-351-02	57-351-02		DETAILED	Right Winglet
57-600-00-01	57-600-00			SPECIAL DETAILED	Left Upper Side of Body Splice
57-600-00-02	57-600-00			SPECIAL DETAILED	Right Upper Side of Body Splice
57-601-00-01	57-601-00			SPECIAL DETAILED	Left Double Plus Chord at Stringer 18A Interface



# 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

## TASKS SORTED BY TASK CARD NUMBER

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
57-601-00-02	57-601-00			SPECIAL DETAILED	Right Double Plus Chord at Stringer 18A Interface
57-601-10-01	57-601-10			SPECIAL DETAILED	Left Double Plus Chord Vertical Flange at Body Stringer 18A Interface
57-601-10-02	57-601-10			SPECIAL DETAILED	Right Double Plus Chord Vertical Flange at Body Stringer 18A Interface
57-601-20-01	57-601-20			SPECIAL DETAILED	Left Double Plus Chord Upper Vertical Flange at Body Stringer 18A Interface
57-601-20-02	57-601-20			SPECIAL DETAILED	Right Double Plus Chord Upper Vertical Flange at Body Stringer 18A Interface
57-601-22-01	57-601-22			GENERAL VISUAL	Left Double Plus Chord Upper Horizontal Flange
57-601-22-02	57-601-22			GENERAL VISUAL	Right Double Plus Chord Upper Horizontal Flange
57-601-25-01	57-601-25			SPECIAL DETAILED	Left Double Plus Chord Upper Horizontal Flange at Stub Beams
57-601-25-02	57-601-25			SPECIAL DETAILED	Right Double Plus Chord Upper Horizontal Flange at Stub Beams
57-601-27-01	57-601-27			GENERAL VISUAL	Left Double Plus Chord Upper Vertical Flange
57-601-27-02	57-601-27			GENERAL VISUAL	Right Double Plus Chord Upper Vertical Flange
57-601-28-01	57-601-28			SPECIAL DETAILED	Left Double Plus Chord Upper Vertical Flange
57-601-28-02	57-601-28			SPECIAL DETAILED	Right Double Plus Chord Upper Vertical Flange
57-601-30-01	57-601-30			SPECIAL DETAILED	Left Wing Center Section Upper Skin at Floor Beams and Shear Ties
57-601-30-02	57-601-30			SPECIAL DETAILED	Right Wing Center Section Upper Skin at Floor Beams and Shear Ties





**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

<b>TASK CARD NUMBER</b>	<b>MPD ITEM NUMBER</b>	<b>MRB ITEM NUMBER</b>	<b>RELATED TASK CARD NUMBER</b>	<b>TASK</b>	<b>TASK TITLE</b>
57-602-00-01	57-602-00			DETAILED	Left Wing Center Section Lower Panel Typical Stringers
57-602-00-02	57-602-00			DETAILED	Right Wing Center Section Lower Panel Typical Stringers
57-602-10-01	57-602-10			DETAILED	Left Wing Center Section Lower Panel Skin
57-602-10-02	57-602-10			DETAILED	Right Wing Center Section Lower Panel Skin
57-603-00-01	57-603-00			DETAILED	Left Wing Center Section Lower Panel
57-603-00-02	57-603-00			DETAILED	Right Wing Center Section Lower Panel
57-603-10-01	57-603-10			SPECIAL DETAILED	Left Wing Center Section Lower Panel
57-603-10-02	57-603-10			SPECIAL DETAILED	Right Wing Center Section Lower Panel
57-604-00-01	57-604-00			GENERAL VISUAL	Left Wing Center Section Lower Panel
57-604-00-02	57-604-00			GENERAL VISUAL	Right Wing Center Section Lower Panel
57-605-00-01	57-605-00			SPECIAL DETAILED	Left Side of Body Splice, Lower Surface
57-605-00-02	57-605-00			SPECIAL DETAILED	Right Side of Body Splice, Lower Surface
57-605-01-01	57-605-01			SPECIAL DETAILED	Left Side of Body Splice, Lower Surface
57-605-01-02	57-605-01			SPECIAL DETAILED	Right Side of Body Splice, Lower Surface
57-605-10-01	57-605-10			SPECIAL DETAILED	Left Side of Body Splice, Lower Surface Skin
57-605-10-02	57-605-10			SPECIAL DETAILED	Right Side of Body Splice, Lower Surface Skin
57-605-20-01	57-605-20			SPECIAL DETAILED	Left Side of Body Splice, Lower Surface Skin



## 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

### TASKS SORTED BY TASK CARD NUMBER

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
57-605-20-02	57-605-20			SPECIAL DETAILED	Right Side of Body Splice, Lower Surface Skin
57-606-00-01	57-606-00			SPECIAL DETAILED	Left Wing Center Section Lower Panel
57-606-00-02	57-606-00			SPECIAL DETAILED	Right Wing Center Section Lower Panel
57-606-01-01	57-606-01			SPECIAL DETAILED	Wing Center Section Lower Panel
57-607-00-01	57-607-00			SPECIAL DETAILED	Left Wing Center Section Lower Panel
57-607-00-02	57-607-00			SPECIAL DETAILED	Right Wing Center Section Lower Panel
57-607-10-01	57-607-10			DETAILED	Left Wing Center Section Rear Spar Typical Web (Crack initially hidden)
57-607-10-02	57-607-10			DETAILED	Right Wing Center Section Rear Spar Typical Web (Crack initially hidden)
57-607-11-01	57-607-11			SPECIAL DETAILED	Left Wing Center Section Rear Spar Typical Web (Crack initially hidden)
57-607-11-02	57-607-11			SPECIAL DETAILED	Right Wing Center Section Rear Spar Typical Web (Crack initially hidden)
57-607-20-01	57-607-20			DETAILED	Left Wing Center Section Rear Spar Typical Web (Non-Hidden Locations)
57-607-20-02	57-607-20			DETAILED	Right Wing Center Section Rear Spar Typical Web (Non-Hidden Locations)
57-607-21-01	57-607-21			SPECIAL DETAILED	Left Wing Center Section Rear Spar Typical Web (Non-Hidden Locations)
57-607-21-02	57-607-21			SPECIAL DETAILED	Right Wing Center Section Rear Spar Typical Web (Non-Hidden Locations)
57-607-30-01	57-607-30			SPECIAL DETAILED	Left Wing Center Section Rear Spar Keel Beam Stiffeners
57-607-30-02	57-607-30			SPECIAL DETAILED	Right Wing Center Section Rear Spar Keel Beam Stiffeners



**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

<b>TASK CARD NUMBER</b>	<b>MPD ITEM NUMBER</b>	<b>MRB ITEM NUMBER</b>	<b>RELATED TASK CARD NUMBER</b>	<b>TASK</b>	<b>TASK TITLE</b>
57-608-00-01	57-608-00			SPECIAL DETAILED	Left Side of Body Splice Upper and Lower Rear Spar
57-608-00-02	57-608-00			SPECIAL DETAILED	Right Side of Body Splice Upper and Lower Rear Spar
57-609-00-01	57-609-00			SPECIAL DETAILED	Left Side of Body Splice Upper and Lower Front Spar
57-609-00-02	57-609-00			SPECIAL DETAILED	Right Side of Body Splice Upper and Lower Front Spar
57-609-10-01	57-609-10			SPECIAL DETAILED	Left Wing Center Section Floor Beam Upper Chord
57-609-10-02	57-609-10			SPECIAL DETAILED	Right Wing Center Section Floor Beam Upper Chord
57-610-00-01	57-610-00			DETAILED	Left Wing Center Section Floor Beam Upper Chord
57-610-00-02	57-610-00			DETAILED	Right Wing Center Section Floor Beam Upper Chord
57-610-01-01	57-610-01			SPECIAL DETAILED	Left Wing Center Section Floor Beam Lower Chord Over Pressure Deck
57-610-01-02	57-610-01			SPECIAL DETAILED	Right Wing Center Section Floor Beam Lower Chord Over Pressure Deck
57-611-00-01	57-611-00			SPECIAL DETAILED	Left Wing Center Section Floor Beams Lower Chord - Overwing
57-611-00-02	57-611-00			SPECIAL DETAILED	Right Wing Center Section Floor Beams Lower Chord - Overwing
57-611-10-01	57-611-10			DETAILED	Left Wing Center Section Floor Beams Lower Chord - Overwing
57-611-10-02	57-611-10			DETAILED	Right Wing Center Section Floor Beams Lower Chord - Overwing
57-611-20-01	57-611-20			DETAILED	Left Side of Body Rib (Direction 1)
57-611-20-02	57-611-20			DETAILED	Right Side of Body Rib (Direction 1)
57-611-21-01	57-611-21			DETAILED	Left Side of Body Rib (Direction 2)
57-611-21-02	57-611-21			DETAILED	Right Side of Body Rib (Direction 2)



**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
57-612-00-01	57-612-00			GENERAL VISUAL	Left Lower Wing Panel, Typical Stringer
57-612-00-02	57-612-00			GENERAL VISUAL	Right Lower Wing Panel, Typical Stringer
57-612-01-01	57-612-01			GENERAL VISUAL	Left Lower Wing Panel, Typical Stringers
57-612-01-02	57-612-01			GENERAL VISUAL	Right Lower Wing Panel, Typical Stringers
57-613-00-01	57-613-00			SPECIAL DETAILED	Left Lower Wing Panel, Typical Stringers
57-613-00-02	57-613-00			SPECIAL DETAILED	Right Lower Wing Panel, Typical Stringers
57-614-00-01	57-614-00			SPECIAL DETAILED	Left Lower Wing Panel Skin; Under the Flap Track Fairings and Nacelle Fairings
57-614-00-02	57-614-00			SPECIAL DETAILED	Right Lower Wing Panel Skin; Under the Flap Track Fairings and Nacelle Fairings
57-614-10-01	57-614-10			GENERAL VISUAL	Left Lower Wing Panel Skin
57-614-10-02	57-614-10			GENERAL VISUAL	Right Lower Wing Panel Skin
57-614-20-01	57-614-20			DETAILED	Left Lower Wing Panel Skin
57-614-20-02	57-614-20			DETAILED	Right Lower Wing Panel Skin
57-614-30-01	57-614-30			GENERAL VISUAL	Left Lower Wing Panel Skin
57-614-30-02	57-614-30			GENERAL VISUAL	Right Lower Wing Panel Skin
57-614-40-01	57-614-40			DETAILED	Left Lower Wing Panel, Rail Stringers
57-614-40-02	57-614-40			DETAILED	Right Lower Wing Panel, Rail Stringers



# 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

## TASKS SORTED BY TASK CARD NUMBER

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
57-615-00-01	57-615-00			SPECIAL DETAILED	Left Lower Wing Panel, Rail Stringers
57-615-00-02	57-615-00			SPECIAL DETAILED	Right Lower Wing Panel, Rail Stringers
57-615-01-01	57-615-01			SPECIAL DETAILED	Left Lower Wing Panel, Rail Stringers
57-615-01-02	57-615-01			SPECIAL DETAILED	Right Lower Wing Panel, Rail Stringers
57-616-00-01	57-616-00			GENERAL VISUAL	Left Lower Wing Panel, Rail Stringer
57-616-00-02	57-616-00			GENERAL VISUAL	Right Lower Wing Panel, Rail Stringer
57-616-10-01	57-616-10			SPECIAL DETAILED	Left Lower Wing Panel, Rail Stringer
57-616-10-02	57-616-10			SPECIAL DETAILED	Right Lower Wing Panel, Rail Stringer
57-617-00-01	57-617-00			GENERAL VISUAL	Left Lower Wing Panel, Splice Stringers
57-617-00-02	57-617-00			GENERAL VISUAL	Right Lower Wing Panel, Splice Stringers
57-617-01-01	57-617-01			SPECIAL DETAILED	Left Lower Wing Panel, Splice Stringers
57-617-01-02	57-617-01			SPECIAL DETAILED	Right Lower Wing Panel, Splice Stringers
57-618-00-01	57-618-00			SPECIAL DETAILED	Left Lower Wing Panel, Splice Stringers (Direction 3)
57-618-00-02	57-618-00			SPECIAL DETAILED	Right Lower Wing Panel, Splice Stringers (Direction 3)
57-618-01-01	57-618-01			SPECIAL DETAILED	Left Lower Wing Panel, Splice Stringers (Direction 4)



**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
57-618-01-02	57-618-01			SPECIAL DETAILED	Right Lower Wing Panel, Splice Stringers (Direction 4)
57-619-00-01	57-619-00			SPECIAL DETAILED	Left Lower Wing Panel, Splice Stringers
57-619-00-02	57-619-00			SPECIAL DETAILED	Right Lower Wing Panel, Splice Stringers
57-619-01-01	57-619-01			SPECIAL DETAILED	Left Lower Wing Panel, Splice Stringers
57-619-01-02	57-619-01			SPECIAL DETAILED	Right Lower Wing Panel, Splice Stringers
57-620-00-01	57-620-00			DETAILED	Left Wing Lower Panel, Splice Stringers
57-620-00-02	57-620-00			DETAILED	Right Wing Lower Panel, Splice Stringers
57-620-01-01	57-620-01			SPECIAL DETAILED	Left Wing Lower Panel, Splice Stringer
57-620-01-02	57-620-01			SPECIAL DETAILED	Right Wing Lower Panel, Splice Stringer
57-621-00-01	57-621-00			DETAILED	Left Wing Lower Wing Panel, Splice Stringers
57-621-00-02	57-621-00			DETAILED	Right Wing Lower Wing Panel, Splice Stringers
57-621-01-01	57-621-01			SPECIAL DETAILED	Left Wing Lower Panel, Splice Stringer
57-621-01-02	57-621-01			SPECIAL DETAILED	Right Wing Lower Panel, Splice Stringer
57-621-02-01	57-621-02			SPECIAL DETAILED	Left Wing Lower Panel, Splice Stringer
57-621-02-02	57-621-02			SPECIAL DETAILED	Right Wing Lower Panel, Splice Stringer
57-621-10-01	57-621-10			SPECIAL DETAILED	Left Lower Wing Panel, Splice Stringers (Direction 3)



**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

<b>TASK CARD NUMBER</b>	<b>MPD ITEM NUMBER</b>	<b>MRB ITEM NUMBER</b>	<b>RELATED TASK CARD NUMBER</b>	<b>TASK</b>	<b>TASK TITLE</b>
57-621-10-02	57-621-10			SPECIAL DETAILED	Right Lower Wing Panel, Splice Stringers (Direction 3)
57-621-11-01	57-621-11			SPECIAL DETAILED	Left Lower Wing Panel, Splice Stringers (Direction 4)
57-621-11-02	57-621-11			SPECIAL DETAILED	Right Lower Wing Panel, Splice Stringers (Direction 4)
57-621-20-01	57-621-20			SPECIAL DETAILED	Left Splice Stringers at Chordwise Skin Splices (Upper and Lower Panel)
57-621-20-02	57-621-20			SPECIAL DETAILED	Right Splice Stringers at Chordwise Skin Splices (Upper and Lower Panel)
57-622-00-01	57-622-00			SPECIAL DETAILED	Left Front Spar Lower Chord (Skin Flange Inspections)
57-622-00-02	57-622-00			SPECIAL DETAILED	Right Front Spar Lower Chord (Skin Flange Inspections)
57-623-00-01	57-623-00			DETAILED	Left Front Spar Lower Chord (Skin Flange Inspections)
57-623-00-02	57-623-00			DETAILED	Right Front Spar Lower Chord (Skin Flange Inspections)
57-624-00-01	57-624-00			SPECIAL DETAILED	Left Front Spar Lower Chord (Web Flange Inspections)
57-624-00-02	57-624-00			SPECIAL DETAILED	Right Front Spar Lower Chord (Web Flange Inspections)
57-625-00-01	57-625-00			SPECIAL DETAILED	Left Front Spar Lower Chord (Skin Flange Inspections)
57-625-00-02	57-625-00			SPECIAL DETAILED	Right Front Spar Lower Chord (Skin Flange Inspections)
57-626-00-01	57-626-00			DETAILED	Left Front Spar Lower Chord (Web Flange Inspections)
57-626-00-02	57-626-00			DETAILED	Right Front Spar Lower Chord (Web Flange Inspections)
57-627-00-01	57-627-00			SPECIAL DETAILED	Left Front Spar Lower Chord (Web Flange Inspections)



**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

<b>TASK CARD NUMBER</b>	<b>MPD ITEM NUMBER</b>	<b>MRB ITEM NUMBER</b>	<b>RELATED TASK CARD NUMBER</b>	<b>TASK</b>	<b>TASK TITLE</b>
57-627-00-02	57-627-00			SPECIAL DETAILED	Right Front Spar Lower Chord (Web Flange Inspections)
57-627-01-01	57-627-01			SPECIAL DETAILED	Left Front Spar Lower Chord (Web Flange Inspections)
57-627-01-02	57-627-01			SPECIAL DETAILED	Right Front Spar Lower Chord (Web Flange Inspections)
57-628-00-01	57-628-00			SPECIAL DETAILED	Left Front Spar Lower Chord (Web Flange Inspections)
57-628-00-02	57-628-00			SPECIAL DETAILED	Right Front Spar Lower Chord (Web Flange Inspections)
57-628-01-01	57-628-01			SPECIAL DETAILED	Left Front Spar Lower Chord (Web Flange Inspections)
57-628-01-02	57-628-01			SPECIAL DETAILED	Right Front Spar Lower Chord (Web Flange Inspections)
57-628-10-01	57-628-10			GENERAL VISUAL	Left Front Spar Lower Chord (Web Flange Inspections)
57-628-10-02	57-628-10			GENERAL VISUAL	Right Front Spar Lower Chord (Web Flange Inspections)
57-629-00-01	57-629-00			SPECIAL DETAILED	Left Front Spar Lower Chord (Direction 1)
57-629-00-02	57-629-00			SPECIAL DETAILED	Right Front Spar Lower Chord (Direction 1)
57-630-00-01	57-630-00			SPECIAL DETAILED	Left Front Spar Lower Chord (Direction 2)
57-630-00-02	57-630-00			SPECIAL DETAILED	Right Front Spar Lower Chord (Direction 2)
57-631-00-01	57-631-00			SPECIAL DETAILED	Left Front Spar Lower Chord (Direction 3)
57-631-00-02	57-631-00			SPECIAL DETAILED	Right Front Spar Lower Chord (Direction 3)





## 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

### TASKS SORTED BY TASK CARD NUMBER

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
57-632-00-01	57-632-00			SPECIAL DETAILED	Left Front Spar Lower Chord (Direction 4)
57-632-00-02	57-632-00			SPECIAL DETAILED	Right Front Spar Lower Chord (Direction 4)
57-632-10-01	57-632-10			SPECIAL DETAILED	Left Front Spar Lower Chord (Skin and Web Flange Inspections)
57-632-10-02	57-632-10			SPECIAL DETAILED	Right Front Spar Lower Chord (Skin and Web Flange Inspections)
57-633-00-01	57-633-00			SPECIAL DETAILED	Left Spar Chords at Chordwise Skin Splices (Upper and Lower Panel)
57-633-00-02	57-633-00			SPECIAL DETAILED	Right Spar Chords at Chordwise Skin Splices (Upper and Lower Panel)
57-633-01-01	57-633-01			SPECIAL DETAILED	Left Spar Chords at Chordwise Skin Splices (Upper and Lower Panel)
57-633-01-02	57-633-01			SPECIAL DETAILED	Right Spar Chords at Chordwise Skin Splices (Upper and Lower Panel)
57-634-00-01	57-634-00			GENERAL VISUAL	Left Rear Spar Lower Chord (Skin Flange Inspections)
57-634-00-02	57-634-00			GENERAL VISUAL	Right Rear Spar Lower Chord (Skin Flange Inspections)
57-635-00-01	57-635-00			GENERAL VISUAL	Left Rear Spar Lower Chord (Web Flange Inspections)
57-635-00-02	57-635-00			GENERAL VISUAL	Right Rear Spar Lower Chord (Web Flange Inspections)
57-636-00-01	57-636-00			SPECIAL DETAILED	Left Rear Spar Lower Chord (Web Flange Inspections)
57-636-00-02	57-636-00			SPECIAL DETAILED	Right Rear Spar Lower Chord (Web Flange Inspections)
57-637-00-01	57-637-00			DETAILED	Left Rear Spar Lower Chord Non-hidden
57-637-00-02	57-637-00			DETAILED	Right Rear Spar Lower Chord Non-hidden



# 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

## TASKS SORTED BY TASK CARD NUMBER

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
57-638-00-01	57-638-00			SPECIAL DETAILED	Left Rear Spar Lower Chord (Skin Flange Inspections)
57-638-00-02	57-638-00			SPECIAL DETAILED	Right Rear Spar Lower Chord (Skin Flange Inspections)
57-639-00-01	57-639-00			DETAILED	Left Rear Spar Lower Chord (Skin Flange Inspections)
57-639-00-02	57-639-00			DETAILED	Right Rear Spar Lower Chord (Skin Flange Inspections)
57-640-00-01	57-640-00			DETAILED	Left Rear Spar Lower Chord (Web Flange Inspections)
57-640-00-02	57-640-00			DETAILED	Right Rear Spar Lower Chord (Web Flange Inspections)
57-641-00-01	57-641-00			SPECIAL DETAILED	Left Rear Spar Lower Chord (Skin and Web Flange Inspections)
57-641-00-02	57-641-00			SPECIAL DETAILED	Right Rear Spar Lower Chord (Skin and Web Flange Inspections)
57-641-10-01	57-641-10			SPECIAL DETAILED	Left Rear Spar Lower Chord (Skin Flange and Web Flange Inspections)
57-641-10-02	57-641-10			SPECIAL DETAILED	Right Rear Spar Lower Chord (Skin Flange and Web Flange Inspections)
57-642-00-01	57-642-00			SPECIAL DETAILED	Left Lower Skin Panel at Main Landing Gear Outboard Support Fittings
57-642-00-02	57-642-00			SPECIAL DETAILED	Right Lower Skin Panel at Main Landing Gear Outboard Support Fittings
57-642-10-01	57-642-10			SPECIAL DETAILED	Left Lower Skin Panel at Main Landing Gear Outboard Support Fittings
57-642-10-02	57-642-10			SPECIAL DETAILED	Right Lower Skin Panel at Main Landing Gear Outboard Support Fittings
57-643-00-01	57-643-00			SPECIAL DETAILED	Left Skin at Nacelle Support Fitting Attachments
57-643-00-02	57-643-00			SPECIAL DETAILED	Right Skin at Nacelle Support Fitting Attachments



## 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

### TASKS SORTED BY TASK CARD NUMBER

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
57-643-01-01	57-643-01			SPECIAL DETAILED	Left Skin at Nacelle Support Fitting Attachments
57-643-01-02	57-643-01			SPECIAL DETAILED	Right Skin at Nacelle Support Fitting Attachments
57-643-10-01	57-643-10			SPECIAL DETAILED	Left Lower Wing Panel Skin at Shear Tied Rib Attachments
57-643-10-02	57-643-10			SPECIAL DETAILED	Right Lower Wing Panel Skin at Shear Tied Rib Attachments
57-644-00-01	57-644-00			SPECIAL DETAILED	Left Lower Wing Panel Under Flap Track Fittings (Direction 1)
57-644-00-02	57-644-00			SPECIAL DETAILED	Right Lower Wing Panel Under Flap Track Fittings Direction 1)
57-644-01-01	57-644-01			SPECIAL DETAILED	Left Lower Wing Panel Under Flap Track Fittings (Direction 1)
57-644-01-02	57-644-01			SPECIAL DETAILED	Right Lower Wing Panel Under Flap Track Fittings (Direction 1)
57-644-02-01	57-644-02			SPECIAL DETAILED	Left Lower Wing Panel Under Flap Track Fittings (Direction 2)
57-644-02-02	57-644-02			SPECIAL DETAILED	Right Lower Wing Panel Under Flap Track Fittings (Direction 2)
57-645-00-01	57-645-00			DETAILED	Left Upper Wing Panel Typical Stringers
57-645-00-02	57-645-00			DETAILED	Right Upper Wing Panel Typical Stringers
57-645-05-01	57-645-05			SPECIAL DETAILED	Left Upper Wing Panel At Side-of-Body Double Plus Chord
57-645-05-02	57-645-05			SPECIAL DETAILED	Right Upper Wing Panel At Side-of-Body Double Plus Chord
57-645-10-01	57-645-10			SPECIAL DETAILED	Left Upper Wing Panel At Side-of-Body Double Plus Chord (Direction 2)
57-645-10-02	57-645-10			SPECIAL DETAILED	Right Upper Wing Panel At Side-of-Body Double Plus Chord (Direction 2)



## 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

### TASKS SORTED BY TASK CARD NUMBER

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
57-645-11-01	57-645-11			SPECIAL DETAILED	Left Upper Wing Panel At Side-of-Body Double Plus Chord (Direction 2)
57-645-11-02	57-645-11			SPECIAL DETAILED	Right Upper Wing Panel At Side-of-Body Double Plus Chord (Direction 2)
57-645-12-01	57-645-12			SPECIAL DETAILED	Left Upper Wing Panel At Side-of-Body Double Plus Chord (Direction 3)
57-645-12-02	57-645-12			SPECIAL DETAILED	Right Upper Wing Panel At Side-of-Body Double Plus Chord (Direction 3)
57-645-13-01	57-645-13			SPECIAL DETAILED	Left Upper Wing Panel At Side-of-Body Double Plus Chord (Direction 3)
57-645-13-02	57-645-13			SPECIAL DETAILED	Right Upper Wing Panel At Side-of-Body Double Plus Chord (Direction 3)
57-645-15-01	57-645-15			GENERAL VISUAL	Left Upper Wing Panel Splice Stringer
57-645-15-02	57-645-15			GENERAL VISUAL	Right Upper Wing Panel Splice Stringer
57-646-00-01	57-646-00			DETAILED	Left Rear Spar Upper Chord Skin Flange Inspections
57-646-00-02	57-646-00			DETAILED	Right Rear Spar Upper Chord Skin Flange Inspections
57-647-00-01	57-647-00			SPECIAL DETAILED	Left Rear Spar Upper Chord (Skin Flange Inspections)
57-647-00-02	57-647-00			SPECIAL DETAILED	Right Rear Spar Upper Chord (Skin Flange Inspections)
57-647-10-01	57-647-10			SPECIAL DETAILED	Left Rear Spar Upper Chord (Web Flange Inspections)
57-647-10-02	57-647-10			SPECIAL DETAILED	Right Rear Spar Upper Chord (Web Flange Inspections)
57-647-20-01	57-647-20			SPECIAL DETAILED	Left Rear Spar Upper Chord (Web Flange Inspections)
57-647-20-02	57-647-20			SPECIAL DETAILED	Right Rear Spar Upper Chord (Web Flange Inspections)



## 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

### TASKS SORTED BY TASK CARD NUMBER

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
57-647-30-01	57-647-30			SPECIAL DETAILED	Left Rear Spar Upper Chord (Skin Flange and Web Flange Inspections)
57-647-30-02	57-647-30			SPECIAL DETAILED	Right Rear Spar Upper Chord (Skin Flange and Web Flange Inspections)
57-648-00-01	57-648-00			SPECIAL DETAILED	Left Wing Upper Skin Tab at R1 Nacelle Fitting
57-648-00-02	57-648-00			SPECIAL DETAILED	Right Wing Upper Skin Tab At R1 Nacelle Fitting
57-649-00-01	57-649-00			DETAILED	Left Front Spar Web Crack - Typical Details
57-649-00-02	57-649-00			DETAILED	Right Front Spar Web Crack - Typical Details
57-650-00-01	57-650-00			DETAILED	Left Outboard Wing Rear Spar Web Typical Details
57-650-00-02	57-650-00			DETAILED	Right Outboard Wing Rear Spar Web Typical Details
57-650-10-01	57-650-10			SPECIAL DETAILED	Left Outboard Wing Rear Spar Web Typical Details
57-650-10-02	57-650-10			SPECIAL DETAILED	Right Outboard Wing Rear Spar Web Typical Details
57-651-00-01	57-651-00			SPECIAL DETAILED	Left Rear Spar Web at Trunnion Attachment, MLG and T.E Fittings
57-651-00-02	57-651-00			SPECIAL DETAILED	Right Rear Spar Web at Trunnion Attachment, MLG and T.E Fittings
57-651-10-01	57-651-10			SPECIAL DETAILED	Left Rib 25 Upper and Lower Horizontal Flange
57-651-10-02	57-651-10			SPECIAL DETAILED	Right Rib 25 Upper and Lower Horizontal Flange
57-652-00-01	57-652-00			SPECIAL DETAILED	Left RIB 27, Upper and Lower Rib Flange to Skin Attachment
57-652-00-02	57-652-00			SPECIAL DETAILED	Right RIB 27, Upper and Lower Rib Flange to Skin Attachment



**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

<b>TASK CARD NUMBER</b>	<b>MPD ITEM NUMBER</b>	<b>MRB ITEM NUMBER</b>	<b>RELATED TASK CARD NUMBER</b>	<b>TASK</b>	<b>TASK TITLE</b>
57-653-00-01	57-653-00			SPECIAL DETAILED	Left Rib 27, Front and Rear Spar Tension Fittings
57-653-00-02	57-653-00			SPECIAL DETAILED	Right Rib 27, Front and Rear Spar Tension Fittings
57-654-00-01	57-654-00			DETAILED	Left Strut to Wing Attachments
57-654-00-02	57-654-00			DETAILED	Right Strut to Wing Attachments
57-655-00-01	57-655-00			SPECIAL DETAILED	Left In-Spar Rib, Section 0, Winglet
57-655-00-02	57-655-00			SPECIAL DETAILED	Right In-Spar Rib, Section 0, Winglet
57-656-00-01	57-656-00			SPECIAL DETAILED	Left In-Spar Rib, Sta 0 Bolt Holes
57-656-00-02	57-656-00			SPECIAL DETAILED	Right In-Spar Rib, Sta 0 Bolt Holes
57-658-00-01	57-658-00			DETAILED	Left Inboard Actuator Support Fittings
57-658-00-02	57-658-00			DETAILED	Right Inboard Actuator Support Fittings
57-659-00-01	57-659-00			SPECIAL DETAILED	Left Gear Beam Inboard Support Fitting
57-659-00-02	57-659-00			SPECIAL DETAILED	Right Gear Beam Inboard Support Fitting
57-660-00-01	57-660-00			DETAILED	Left Track #1- Outboard Main Flap Outboard Track
57-660-00-02	57-660-00			DETAILED	Right Track #8- Outboard Main Flap Outboard Track
57-660-10-01	57-660-10			SPECIAL DETAILED	Left Track #1- Outboard Main Flap Outboard Track
57-660-10-02	57-660-10			SPECIAL DETAILED	Right Track #8 - Outboard Main Flap Outboard Track
57-661-00-01	57-661-00			DETAILED	Left Support, Forward Fitting Assy Flap Tracks 1, 2, 3,
57-661-00-02	57-661-00			DETAILED	Right Support, Forward Fitting Assy Flap Tracks 6, 7, 8



# 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

## TASKS SORTED BY TASK CARD NUMBER

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
57-662-00-01	57-662-00			DETAILED	Left Track #2 Outboard Main Flap, Inboard Track
57-662-00-02	57-662-00			DETAILED	Right Track #7 Outboard Main Flap, Inboard Track
57-663-00-01	57-663-00			SPECIAL DETAILED	Left Track #2 - Outboard Main Flap, Inboard Track
57-663-00-02	57-663-00			SPECIAL DETAILED	Right Track #7 - Outboard Main Flap, Inboard Track
57-664-00-01	57-664-00			DETAILED	Left Track #3 - Inboard Main Flap, Outboard Track
57-664-00-02	57-664-00			DETAILED	Right Track #6 - Inboard Main Flap, Outboard Track
57-665-00-01	57-665-00			SPECIAL DETAILED	Left Track #3 - Inboard Main Flap, Outboard Track
57-665-00-02	57-665-00			SPECIAL DETAILED	Right Track #6 - Inboard Main Flap, Outboard Track
57-666-00-01	57-666-00			SPECIAL DETAILED	Left No. 4 Support, Aft Link Pins
57-666-00-02	57-666-00			SPECIAL DETAILED	Right No. 5 Support, Aft Link Pins
57-667-00-01	57-667-00			DETAILED	Left Track #4 - Inboard Flap Support, Inboard Track
57-667-00-02	57-667-00			DETAILED	Right Track #5 - Inboard Flap Support, Inboard Track
57-667-10-01	57-667-10			SPECIAL DETAILED	Left Track #4 - Inboard Main Flap, Inboard Track
57-667-10-02	57-667-10			SPECIAL DETAILED	Right Track #5 - Inboard Main Flap, Inboard Track
57-668-00-01	57-668-00			SPECIAL DETAILED	Left Inboard Main Flap Fitting Assembly Fwd, Inboard Track
57-668-00-02	57-668-00			SPECIAL DETAILED	Right Inboard Main Flap Fitting Assembly Fwd, Inboard Track
57-669-00-01	57-669-00			DETAILED	Left Front Spar Upper Chord
57-669-00-02	57-669-00			DETAILED	Right Front Spar Upper Chord



# 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

## TASKS SORTED BY TASK CARD NUMBER

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
57-669-10-01	57-669-10			SPECIAL DETAILED	Left Spar Upper and Lower Chord
57-669-10-02	57-669-10			SPECIAL DETAILED	Right Spar Upper and Lower Chord
57-669-20-01	57-669-20			GENERAL VISUAL	Left Front Spar Cutout/ Front Spar Fitting
57-669-20-02	57-669-20			GENERAL VISUAL	Right Front Spar Cutout/ Front Spar Fitting
57-670-00-01	57-670-00			DETAILED	Left Rear Spar Chord at Inbd and Outbd Cutout
57-670-00-02	57-670-00			DETAILED	Right Rear Spar Chord at Inbd and Outbd Cutout
57-670-10-01	57-670-10			DETAILED	Left Rear Spar Chord at Inbd and Outbd Pushrod Cutout
57-670-10-02	57-670-10			DETAILED	Right Rear Spar Chord at Inbd and Outbd Pushrod Cutout
57-670-11-01	57-670-11			DETAILED	Left Rear Spar Chord at Inbd and Outbd Pushrod Cutout
57-670-11-02	57-670-11			DETAILED	Right Rear Spar Chord at Inbd and Outbd Pushrod Cutout
57-670-20-01	57-670-20			DETAILED	Left Rear Spar Upper Chord
57-670-20-02	57-670-20			DETAILED	Right Rear Spar Upper Chord
57-670-30-01	57-670-30			SPECIAL DETAILED	Left Rear Spar Upper Chord
57-670-30-02	57-670-30			SPECIAL DETAILED	Right Rear Spar Upper Chord
57-671-00-01	57-671-00			DETAILED	Left Inboard Main Flap, In-Spar Upper Skin Panels
57-671-00-02	57-671-00			DETAILED	Right Inboard Main Flap, In-Spar Upper Skin Panels
57-672-00-01	57-672-00			SPECIAL DETAILED	Left Inbd Main Flap, Inbd Torque Tube Rib
57-672-00-02	57-672-00			SPECIAL DETAILED	Right Inbd Main Flap, Inbd Torque Tube Rib
57-673-00-01	57-673-00			GENERAL VISUAL	Left Inbd Main Flap - Torque Tube





## 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

### TASKS SORTED BY TASK CARD NUMBER

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
57-673-00-02	57-673-00			GENERAL VISUAL	Right Inbd Main Flap - Torque Tube
57-674-00-01	57-674-00			SPECIAL DETAILED	Left Inbd Main Flap, Rear Spar
57-674-00-02	57-674-00			SPECIAL DETAILED	Right Inbd Main Flap, Rear Spar
57-675-00-01	57-675-00			SPECIAL DETAILED	Left Inbd Flap - No. 3 Carriage Assy
57-675-00-02	57-675-00			SPECIAL DETAILED	Right Inbd Flap - No. 6 Carriage Assy
57-676-00-01	57-676-00			SPECIAL DETAILED	Left Inbd Flap - No. 4 Carriage Assy
57-676-00-02	57-676-00			SPECIAL DETAILED	Right Inbd Flap - No.5 Carriage Assy
57-676-10-01	57-676-10			DETAILED	Left Inbd Flap - No. 4 Carriage Assy
57-676-10-02	57-676-10			DETAILED	Right Inbd Flap - No. 5 Carriage Assy
57-676-20-01	57-676-20			DETAILED	Left #4 Inboard Main Flap
57-676-20-02	57-676-20			DETAILED	Right #5 Inboard Main Flap
57-677-00-01	57-677-00			SPECIAL DETAILED	Left No. 1 Carriage Assembly
57-677-00-02	57-677-00			SPECIAL DETAILED	Right No. 8 Carriage Assembly
57-677-10-01	57-677-10			SPECIAL DETAILED	Left No. 1 Carriage Assembly
57-677-10-02	57-677-10			SPECIAL DETAILED	Right No. 8 Carriage Assembly
57-678-00-01	57-678-00			SPECIAL DETAILED	Left No. 2 Carriage Assembly



# 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

## TASKS SORTED BY TASK CARD NUMBER

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
57-678-00-02	57-678-00			SPECIAL DETAILED	Right No. 7 Carriage Assembly
57-678-10-01	57-678-10			SPECIAL DETAILED	Left No. 2 Carriage Assembly
57-678-10-02	57-678-10			SPECIAL DETAILED	Right No. 7 Carriage Assembly
57-679-00-01	57-679-00			SPECIAL DETAILED	Left Front Spar Assembly - Outbd Main Flap
57-679-00-02	57-679-00			SPECIAL DETAILED	Right Front Spar Assembly - Outbd Main Flap
57-680-00-01	57-680-00			SPECIAL DETAILED	Left Front Spar Assembly - Outbd Main Flap
57-680-00-02	57-680-00			SPECIAL DETAILED	Right Front Spar Assembly - Outbd Main Flap
57-681-00-01	57-681-00			SPECIAL DETAILED	Left Rear Spar - Outbd Main Flap
57-681-00-02	57-681-00			SPECIAL DETAILED	Right Rear Spar - Outbd Main Flap
57-682-00-01	57-682-00			SPECIAL DETAILED	Left Rear Spar - Outbd Main Flap
57-682-00-02	57-682-00			SPECIAL DETAILED	Right Rear Spar - Outbd Main Flap
57-683-00-01	57-683-00			SPECIAL DETAILED	Left Rear Spar - Outbd Main Flap
57-683-00-02	57-683-00			SPECIAL DETAILED	Right Rear Spar - Outbd Main Flap
57-684-00-01	57-684-00			SPECIAL DETAILED	Left Lower Skin - Outbd Main Flap, Front Spar and Rear Spar LWR Chord - LWR Skin Interface
57-684-00-02	57-684-00			SPECIAL DETAILED	Right Lower Skin - Outbd Main Flap, Front Spar and Rear Spar LWR Chord - LWR Skin Interface



**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
57-685-00-01	57-685-00			SPECIAL DETAILED	Left Front Spar Spigot Fitting - Outbd Main Flap
57-685-00-02	57-685-00			SPECIAL DETAILED	Right Front Spar Spigot Fitting - Outbd Main Flap
57-686-00-01	57-686-00			DETAILED	Left Rear Spar Spigot Fitting - Outbd Main Flap
57-686-00-02	57-686-00			DETAILED	Right Rear Spar Spigot Fitting - Outbd Main Flap
57-688-00-01	57-688-00			DETAILED	Left Hinge / Actuator Fittings Inboard Spoiler #6
57-688-00-02	57-688-00			DETAILED	Right Hinge / Actuator Fittings Inboard Spoiler #7
57-800-00-01	57-800-00	57-800-00		ZONAL (GV)	Center Section Wing Box
57-802-01-01	57-802-01	57-802-01		ZONAL (GV)	Left Wing
57-804-01-01	57-804-01	57-804-01		ZONAL (GV)	Leading Edge to Front Spar - Inboard of Nacelle Strut - Left Wing
57-806-01-01	57-806-01	57-806-01		ZONAL (GV)	Leading Edge to Front Spar - Inboard of Nacelle Strut - Left Wing
57-808-01-01	57-808-01	57-808-01		ZONAL (GV)	Krueger Flaps No. 1 and 2 - Left Wing
57-810-01-01	57-810-01	57-810-01		ZONAL (GV)	Krueger Flaps No. 1 and 2 - Left Wing
57-812-01-01	57-812-01	57-812-01		ZONAL (GV)	Leading Edge to Front Spar - Outboard of Nacelle Strut - Left Wing
57-814-01-01	57-814-01	57-814-01		ZONAL (GV)	Leading Edge to Front Spar - Outboard of Nacelle Strut - Left Wing
57-816-01-01	57-816-01	57-816-01		ZONAL (GV)	Slats No. 1, 2, 3, 4 - Left Wing
57-818-01-01	57-818-01	57-818-01		ZONAL (GV)	Left Wing Tip
57-820-01-01	57-820-01	57-820-01		ZONAL (GV)	Left Wing Tip
57-822-01-01	57-822-01	57-822-01		ZONAL (GV)	Center Fuel Tank - Left Wing
57-824-01-01	57-824-01	57-824-01		ZONAL (GV)	Center Fuel Tank - Left Wing
57-826-01-01	57-826-01	57-826-01		ZONAL (GV)	Main Fuel Tank - Left Wing
57-828-01-01	57-828-01	57-828-01		ZONAL (GV)	Main Fuel Tank - Left Wing
57-830-01-01	57-830-01	57-830-01		ZONAL (GV)	Surge Tank - Left Wing
57-832-01-01	57-832-01	57-832-01		ZONAL (GV)	Surge Tank - Left Wing



**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
57-834-01-01	57-834-01	57-834-01	W-27-229-00-01	ZONAL (GV)	Dry Bay - Left Wing
57-836-01-01	57-836-01	57-836-01		ZONAL (GV)	Fairing Flap Support No. 3 - Left Wing
57-838-01-01	57-838-01	57-838-01		ZONAL (GV)	Fairing Flap Support No. 3 - Left Wing
57-840-01-01	57-840-01	57-840-01		ZONAL (GV)	Fairing Flap Support No. 2 - Left Wing
57-842-01-01	57-842-01	57-842-01		ZONAL (GV)	Fairing Flap Support No. 2 - Left Wing
57-844-01-01	57-844-01	57-844-01		ZONAL (GV)	Fairing Flap Support No. 1 - Left Wing
57-846-01-01	57-846-01	57-846-01		ZONAL (GV)	Fairing Flap Support No. 1 - Left Wing
57-848-01-01	57-848-01	57-848-01		ZONAL (GV)	Rear Spar to Landing Gear Support Beam - Left Wing
57-850-01-01	57-850-01	57-850-01		ZONAL (GV)	Rear Spar to Landing Gear Support Beam - Left Wing
57-852-01-01	57-852-01	57-852-01		ZONAL (GV)	Inboard Spoiler No. 6 - L. Wing
57-854-01-01	57-854-01	57-854-01		ZONAL (GV)	Inboard Flaps - Left Wing
57-856-01-01	57-856-01	57-856-01		ZONAL (GV)	Inboard Main Flaps - Left Wing
57-858-01-01	57-858-01	57-858-01		ZONAL (GV)	Rear Spar to T.E. - Outbd of Inbd Flap - Inbd of Fixed T.E. - L. Wing
57-860-01-01	57-860-01	57-860-01		ZONAL (GV)	Spoilers No. 1, 2, 3, 4, 5 - Left Wing
57-862-01-01	57-862-01	57-862-01		ZONAL (GV)	Outboard Flaps - Left Wing
57-864-01-01	57-864-01	57-864-01		ZONAL (GV)	Fixed Trailing Edge - Left Wing
57-866-01-01	57-866-01	57-866-01		ZONAL (GV)	Fixed Trailing Edge - Left Wing
57-868-01-01	57-868-01	57-868-01		ZONAL (GV)	Fixed Trailing Edge - Left Wing
57-870-01-01	57-870-01	57-870-01		ZONAL (GV)	Aileron - Left Wing
57-872-02-01	57-872-02	57-872-02		ZONAL (GV)	Right Wing
57-874-02-01	57-874-02	57-874-02		ZONAL (GV)	Leading Edge to Front Spar - Inbd of Nacelle Strut - Right Wing
57-876-02-01	57-876-02	57-876-02		ZONAL (GV)	Leading Edge to Front Spar - Inbd of Nacelle Strut - Right Wing
57-878-02-01	57-878-02	57-878-02		ZONAL (GV)	Krueger Flaps No. 3 and 4 - Right Wing
57-880-02-01	57-880-02	57-880-02		ZONAL (GV)	Krueger Flaps No. 3 and 4 - Right Wing



**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

<b>TASK CARD NUMBER</b>	<b>MPD ITEM NUMBER</b>	<b>MRB ITEM NUMBER</b>	<b>RELATED TASK CARD NUMBER</b>	<b>TASK</b>	<b>TASK TITLE</b>
57-882-02-01	57-882-02	57-882-02		ZONAL (GV)	Leading Edge to Front Spar - Outbd of Nacelle Strut - Right Wing
57-884-02-01	57-884-02	57-884-02		ZONAL (GV)	Leading Edge to Front Spar - Outbd of Nacelle Strut - Right Wing
57-886-02-01	57-886-02	57-886-02		ZONAL (GV)	Slats No. 5, 6, 7, 8, - Right Wing
57-888-02-01	57-888-02	57-888-02		ZONAL (GV)	Right Wing Tip
57-890-02-01	57-890-02	57-890-02		ZONAL (GV)	Right Wing Tip
57-892-02-01	57-892-02	57-892-02		ZONAL (GV)	Center Fuel Tank - Right Wing
57-894-02-01	57-894-02	57-894-02		ZONAL (GV)	Center Fuel Tank - Right Wing
57-896-02-01	57-896-02	57-896-02		ZONAL (GV)	Main Fuel Tank - Right Wing
57-898-02-01	57-898-02	57-898-02		ZONAL (GV)	Main Fuel Tank - Right Wing
57-900-02-01	57-900-02	57-900-02		ZONAL (GV)	Surge Tank - Right Wing
57-902-02-01	57-902-02	57-902-02		ZONAL (GV)	Surge Tank - Right Wing
57-904-02-01	57-904-02	57-904-02		ZONAL (GV)	Dry Bay - Right Wing
57-906-02-01	57-906-02	57-906-02		ZONAL (GV)	Fairing Flap Support No. 6 - Right Wing
57-908-02-01	57-908-02	57-908-02		ZONAL (GV)	Fairing Flap Support No. 6 - Right Wing
57-910-02-01	57-910-02	57-910-02		ZONAL (GV)	Fairing Flap Support No. 7 - Right Wing
57-912-02-01	57-912-02	57-912-02		ZONAL (GV)	Fairing Flap Support No. 7 - Right Wing
57-914-02-01	57-914-02	57-914-02		ZONAL (GV)	Fairing Flap Support No. 8 - Right Wing
57-916-02-01	57-916-02	57-916-02		ZONAL (GV)	Fairing Flap Support No. 8 - Right Wing
57-918-02-01	57-918-02	57-918-02		ZONAL (GV)	Rear Spar to Landing Gear Support Beam - Right Wing
57-920-02-01	57-920-02	57-920-02		ZONAL (GV)	Rear Spar to Landing Gear Support Beam - Right Wing
57-922-02-01	57-922-02	57-922-02		ZONAL (GV)	Inboard Spoiler No. 7 - Right Wing
57-924-02-01	57-924-02	57-924-02		ZONAL (GV)	Inboard Flaps - Right Wing
57-926-02-01	57-926-02	57-926-02	W-27-229-00-02	ZONAL (GV)	Inboard Main Flap - Right Wing
57-928-02-01	57-928-02	57-928-02		ZONAL (GV)	Rear Spar to T.E. - Outbd of Inbd Flap - Inbd of Fixed T.E. - Right Wing



## 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

### TASKS SORTED BY TASK CARD NUMBER

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
57-930-02-01	57-930-02	57-930-02		ZONAL (GV)	Spoiler No 8, 9, 10, 11, 12 - Right Wing
57-932-02-01	57-932-02	57-932-02		ZONAL (GV)	Outboard Flaps - Right Wing
57-934-02-01	57-934-02	57-934-02		ZONAL (GV)	Fixed Trailing Edge - Right Wing
57-936-02-01	57-936-02	57-936-02		ZONAL (GV)	Fixed Trailing Edge - Right Wing
57-938-02-01	57-938-02	57-938-02		ZONAL (GV)	Fixed Trailing Edge - Right Wing
57-940-02-01	57-940-02	57-940-02		ZONAL (GV)	Aileron - Right Wing
57-950-01-01	57-950-01	57-950-01		ZONAL (GV)	Winglet - Left Wing
57-952-01-01	57-952-01	57-952-01		ZONAL (GV)	Winglet - Left Wing
57-960-02-01	57-960-02	57-960-02		ZONAL (GV)	Winglet - Right Wing
57-962-02-01	57-962-02	57-962-02		ZONAL (GV)	Winglet - Right Wing
70-800-01-01	70-800-01	70-800-01		ZONAL (GV)	Powerplant No. 1
70-802-01-01	70-802-01	70-802-01		ZONAL (GV)	Engine No. 1
70-804-01-01	70-804-01	70-804-01		ZONAL (GV)	Fan Cowl - Engine No. 1
70-806-01-01	70-806-01	70-806-01		ZONAL (GV)	Thrust Reverser - Engine No. 1
70-808-01-01	70-808-01	70-808-01		ZONAL (GV)	Thrust Reverser - Engine No. 1
70-810-02-01	70-810-02	70-810-02		ZONAL (GV)	Powerplant No. 2
70-812-02-01	70-812-02	70-812-02		ZONAL (GV)	Engine No. 2
70-814-02-01	70-814-02	70-814-02		ZONAL (GV)	Fan Cowl - Engine No. 2
70-816-02-01	70-816-02	70-816-02		ZONAL (GV)	Thrust Reverser - Engine No. 2
70-818-02-01	70-818-02	70-818-02		ZONAL (GV)	Thrust Reverser - Engine No. 2
71-010-01-01	71-010-01	71-010-01		INSPECTION - DETAILED	Inlet Cowl - Inner Surface
71-010-02-01	71-010-02	71-010-02		INSPECTION - DETAILED	Inlet Cowl - Inner Surface
71-040-01-01	71-040-01	71-040-01		OPERATIONAL	Check Left Engine Drain Lines



## 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

### TASKS SORTED BY TASK CARD NUMBER

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
71-040-02-01	71-040-02	71-040-02		OPERATIONAL	Check Right Engine Drain Lines
72-020-01-01	72-020-01	72-020-01		INSPECTION - DETAILED	Left Engine Inlet and Fan Blades
72-020-02-01	72-020-02	72-020-02		INSPECTION - DETAILED	Right Engine Inlet and Fan Blades
72-025-01-01	72-025-01	72-025-01		LUBRICATE	Lubricate Left Engine Fan Blades Dovetail.
72-025-02-01	72-025-02	72-025-02		LUBRICATE	Lubricate Right Engine Fan Blades Dovetail.
72-030-01-01	72-030-01	72-030-01		REPLACE	Left Fan Disk
72-030-02-01	72-030-02	72-030-02		REPLACE	Right Fan Disk
72-040-01-01	72-040-01	72-040-01		REPLACE	Left Engine Booster Spool
72-040-02-01	72-040-02	72-040-02		REPLACE	Right Engine Booster Spool
72-050-01-01	72-050-01	72-050-01		REPLACE	Left Engine Fan Shaft
72-050-02-01	72-050-02	72-050-02		REPLACE	Right Engine Fan Shaft
72-070-01-01	72-070-01	72-070-01		VISUAL CHECK	Left Engine AGB/TGB Mount Flanges and Fan Case/Frame Mounts
72-070-02-01	72-070-02	72-070-02		VISUAL CHECK	Right Engine AGB/TGB Mount Flanges and Fan Case/Frame Mounts
72-100-01-01	72-100-01	72-100-01		VISUAL CHECK	Left Engine Attachment Bolts for the Thrust Mount Fittings
72-100-02-01	72-100-02	72-100-02		VISUAL CHECK	Right Engine Attachment Bolts for the Thrust Mount Fittings
72-110-01-01	72-110-01	72-110-01		VISUAL CHECK	Left Engine Thrust Mount Fittings
72-110-02-01	72-110-02	72-110-02		VISUAL CHECK	Right Engine Thrust Mount Fittings
72-130-01-01	72-130-01	72-130-01		REPLACE	Left Engine Stage 1 and 2 Spool
72-130-02-01	72-130-02	72-130-02		REPLACE	Right Engine Stage 1 and 2 Spool
72-140-01-01	72-140-01	72-140-01		REPLACE	Left Engine Stage 3 Disk
72-140-02-01	72-140-02	72-140-02		REPLACE	Right Engine Stage 3 Disk
72-150-01-01	72-150-01	72-150-01		REPLACE	Left Engine Stages 4 - 9 Spool
72-150-02-01	72-150-02	72-150-02		REPLACE	Right Engine Stages 4 - 9 Spool



# 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

## TASKS SORTED BY TASK CARD NUMBER

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
72-160-01-01	72-160-01	72-160-01		REPLACE	Left Engine Front Shaft
72-160-02-01	72-160-02	72-160-02		REPLACE	Right Engine Front Shaft
72-170-01-01	72-170-01	72-170-01		REPLACE	Left Engine Rear Rotating (CDP) Seal
72-170-02-01	72-170-02	72-170-02		REPLACE	Right Engine Rear Rotating (CDP) Seal
72-180-01-01	72-180-01	72-180-01		INSPECTION - DETAILED	Left Engine Combustion Chamber
72-180-02-01	72-180-02	72-180-02		INSPECTION - DETAILED	Right Engine Combustion Chamber
72-190-01-01	72-190-01	72-190-01		INSPECTION - DETAILED	Left Engine Double Annular Combustion Chamber
72-190-02-01	72-190-02	72-190-02		INSPECTION - DETAILED	Right Engine Double Annular Combustion Chamber
72-200-01-01	72-200-01	72-200-01		INSPECTION - DETAILED	Left Engine HPT Nozzle. (SAC /1 and DAC engines)
72-200-01-02	72-200-01	72-200-01		INSPECTION - DETAILED	Left Engine HPT Nozzle. (Tech Insertion /3 and 7BE engines)
72-200-02-01	72-200-02	72-200-02		INSPECTION - DETAILED	Right Engine HPT Nozzle. (SAC /1 and DAC engines)
72-200-02-02	72-200-02	72-200-02		INSPECTION - DETAILED	Right Engine HPT Nozzle. (Tech Insertion /3 and 7BE engines)
72-210-01-01	72-210-01	72-210-01		INSPECTION - DETAILED	Left Engine HPT Blades
72-210-02-01	72-210-02	72-210-02		INSPECTION - DETAILED	Right Engine HPT Blades
72-220-01-01	72-220-01	72-220-01		REPLACE	Left Engine HPT Front Shaft
72-220-02-01	72-220-02	72-220-02		REPLACE	Right Engine HPT Front Shaft
72-230-01-01	72-230-01	72-230-01		REPLACE	Left HPT Front Rotating Air Seal
72-230-02-01	72-230-02	72-230-02		REPLACE	Right HPT Front Rotating Air Seal





## 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

### TASKS SORTED BY TASK CARD NUMBER

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
72-240-01-01	72-240-01	72-240-01		REPLACE	Left Engine HPT Disk
72-240-02-01	72-240-02	72-240-02		REPLACE	Right Engine HPT Disk
72-250-01-01	72-250-01	72-250-01		REPLACE	Left Engine HPT Rear Shaft
72-250-02-01	72-250-02	72-250-02		REPLACE	Right Engine HPT Rear Shaft
72-270-01-01	72-270-01	72-270-01		REPLACE	Left Engine LPT Rotor Support
72-270-02-01	72-270-02	72-270-02		REPLACE	Right Engine LPT Rotor Support
72-280-01-01	72-280-01	72-280-01		REPLACE	Left Engine LPT Shaft
72-280-02-01	72-280-02	72-280-02		REPLACE	Right Engine LPT Shaft
72-290-01-01	72-290-01	72-290-01		REPLACE	Left Engine Stage 1, 2, 3, 4 LPT Disks
72-290-02-01	72-290-02	72-290-02		REPLACE	Right Engine Stage 1, 2, 3, 4 LPT Disks
72-300-01-01	72-300-01	72-300-01		VISUAL CHECK	Left Engine Stage Aft Mounts Clevis
72-300-02-01	72-300-02	72-300-02		VISUAL CHECK	Right Engine Stage Aft Mounts Clevis
72-320-01-01	72-320-01	72-320-01		INSPECTION - DETAILED	Left Engine Fwd Sump, Aft Sump, AGB/TGB MCD or DMS detectors and scavenge screens
72-320-02-01	72-320-02	72-320-02		INSPECTION - DETAILED	Right Engine Fwd Sump, Aft Sump, AGB/TGB MCD or DMS detectors and scavenge screens
73-010-01-01	73-010-01	73-010-01		REPLACE	Replace the Left Engine Fuel Filter
73-010-02-01	73-010-02	73-010-02		REPLACE	Replace the Right Engine Fuel Filter
73-020-01-01	73-020-01	73-020-01		OPERATIONAL	FMC CDU for Left Engine Faults
73-020-02-01	73-020-02	73-020-02		OPERATIONAL	FMC CDU for Right Engine Faults
73-030-01-01	73-030-01			RESTORE	Remove the Left Engine Hydro Mechanical Unit for Inspection
73-030-02-01	73-030-02			RESTORE	Remove the Right Engine Hydro Mechanical Unit for Inspection
74-020-01-01	74-020-01	74-020-01		INSPECTION - DETAILED	Ignition Leads



## 737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

### TASKS SORTED BY TASK CARD NUMBER

TASK CARD NUMBER	MPD ITEM NUMBER	MRB ITEM NUMBER	RELATED TASK CARD NUMBER	TASK	TASK TITLE
74-020-02-01	74-020-02	74-020-02		INSPECTION - DETAILED	Ignition Leads
78-011-01-01	78-011-01	78-011-01		INSPECTION - DETAILED	Left Engine Exhaust Nozzle
78-011-02-01	78-011-02	78-011-02		INSPECTION - DETAILED	Right Engine Exhaust Nozzle
78-050-01-01	78-050-01	78-050-01		VISUAL CHECK	Left Engine T/R Fan Duct Walls
78-050-02-01	78-050-02	78-050-02		VISUAL CHECK	Right Engine T/R Fan Duct Walls
78-060-01-01	78-060-01	78-060-01		INSPECTION - DETAILED	Left Engine Drag Link's Spherical Bearing
78-060-02-01	78-060-02	78-060-02		INSPECTION - DETAILED	Right Engine Drag Link's Spherical Bearing
78-070-01-01	78-070-01	78-070-01		VISUAL CHECK	Left Engine Blocker Doors
78-070-02-01	78-070-02	78-070-02		VISUAL CHECK	Right Engine Blocker Doors
78-080-01-01	78-080-01	78-080-01		VISUAL CHECK	Left Engine Bullnose Seal and Retainer
78-080-02-01	78-080-02	78-080-02		VISUAL CHECK	Right Engine Bullnose Seal and Retainer
78-100-01-01	78-100-01	78-100-01		INSPECTION - DETAILED	Left Engine T/R Fire Seal
78-100-02-01	78-100-02	78-100-02		INSPECTION - DETAILED	Right Engine T/R Fire Seal
78-110-01-01	78-110-01	78-110-01		OPERATIONAL	Left Engine T/R Sync Lock
78-110-02-01	78-110-02	78-110-02		OPERATIONAL	Right Engine T/R Sync Lock
78-120-01-01	78-120-01	78-120-01		OPERATIONAL	Left Engine Bite Check the EAU
78-120-02-01	78-120-02	78-120-02		OPERATIONAL	Right Engine Bite Check the EAU
78-130-01-01	78-130-01	78-130-01		OPERATIONAL	Left Engine "Reverser" Light Indication System
78-130-02-01	78-130-02	78-130-02		OPERATIONAL	Right Engine "Reverser" Light Indication System
79-010-01-01	79-010-01	79-010-01		REPLACE	Oil Supply Filter Element - Left Engine



**737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT**  
**TASKS SORTED BY TASK CARD NUMBER**

<b>TASK CARD NUMBER</b>	<b>MPD ITEM NUMBER</b>	<b>MRB ITEM NUMBER</b>	<b>RELATED TASK CARD NUMBER</b>	<b>TASK</b>	<b>TASK TITLE</b>
79-010-02-01	79-010-02	79-010-02		REPLACE	Oil Supply Filter Element - Right Engine
79-040-01-01	79-040-01	79-040-01		REPLACE	Oil Scavenge Filter Element - Left Engine
79-040-02-01	79-040-02	79-040-02		REPLACE	Oil Scavenge Filter Element - Right Engine
80-010-01-01	80-010-01	80-010-01		INSPECTION - DETAILED	Magnetic Chip Detector - Left Engine Starter
80-010-02-01	80-010-02	80-010-02		INSPECTION - DETAILED	Magnetic Chip Detector - Right Engine Starter

