



APPENDIX C - MAINTENANCE TASKS SORTED BY INTERVAL

A. SCOPE

This appendix contains a listing of all MPD items with interval type and task title, sorted by the most frequent tasks to the less frequent. Tasks with a common interval are sorted by MPD Item Number. This list is generic and may contain tasks which are not applicable to all customer configurations. This listing can be utilized to assist maintenance planners in creating specific airline check packages. This appendix does not represent a comprehensive list of maintenance requirements that may exist in other documents such as, but not limited to, service bulletins and airworthiness directives.



737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT
TOTAL LABOR HOURS BY INTERVAL GROUP

INTERVAL	ITEMS	TOTAL LABOR HOURS



737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

TASKS SORTED BY INTERVAL

INTERVAL		MPD ITEM NUMBER	TASK TITLE
THRESHOLD	REPEAT		
1600 AH	1600 AH	49-140-00	CDU'S APU Maintenance Pages
4000 AH	4000 AH	49-102-00	Fuel Inlet Filter Element
10000 AH	10000 AH	49-212-00	APU Eductor
19000 AH	19000 AH	49-172-00	APU Exhaust Seal
APU CNG	APU CNG	49-030-00	Sigma Seal
APU CNG	APU CNG	49-040-00	APU Insulation Panels
15 DY	15 DY	24-080-00	Standby Power Control Unit (SPCU)
15 DY	15 DY	24-100-00	Standby Power Control Unit (SPCU)
120 DY	120 DY	32-800-00	Nose Landing Gear and Landing Gear Doors (from Ground)
120 DY 745 FC	120 DY 745 FC	32-804-01	Left Main Landing Gear and Landing Gear Doors (from Ground)
120 DY 745 FC	120 DY 745 FC	32-808-02	Right Main Landing Gear and Landing Gear Doors (From Ground)
120 DY	120 DY	38-070-00	Disinfect Potable Water System
120 DY	120 DY	52-800-00	Entry Doors, Service Doors, Automatic Overwing Exits, Mid-Exit Doors, and Cargo Doors
120 DY	120 DY	53-800-00	Lower Fuselage
120 DY	120 DY	53-812-00	Forward Cargo Compartment
120 DY	120 DY	53-830-00	Aft Cargo Compartment
120 DY	120 DY	53-844-00	Wing to Body Fairing
120 DY	120 DY	53-894-00	Area Aft of the Pressure Bulkhead
120 DY	120 DY	55-800-00	Vertical Fin and Horizontal Stabilizer
120 DY	120 DY	57-802-01	Left Wing
120 DY	120 DY	57-872-02	Right Wing
120 DY	120 DY	70-800-01	Powerplant No. 1
120 DY	120 DY	70-810-02	Powerplant No. 2



737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

INTERVAL		MPD ITEM NUMBER	TASK TITLE
THRESHOLD	REPEAT		
ENG CNG	ENG CNG	54-020-01	Left Strut Forward and Aft Engine Mount to Strut Shear Pins
ENG CNG	ENG CNG	54-020-02	Right Strut Forward and Aft Engine Mount to Strut Shear Pins
ENG CNG	ENG CNG	78-011-01	Left Engine Exhaust Plug
ENG CNG	ENG CNG	78-011-02	Right Engine Exhaust Plug
50 FC	50 FC	32-010-01	Left Main Gear Shock Strut Cleaning
50 FC	50 FC	32-010-02	Right Main Gear Shock Strut Cleaning
50 FC	50 FC	32-060-00	Clean Nose Gear Shock Strut
50 FC	50 FC	32-270-01	Left Main Gear Brake Wear Pins
50 FC	50 FC	32-270-02	Right Main Gear Brake Wear Pins
300 FC	300 FC	32-430-00	Tail Skid Inspection
450 FC	450 FC	25-160-00	Inspect Cargo Compartment Panels/Liners
560 FC 90 DY	560 FC 90 DY	32-030-01	Left Main Landing Gear Lubrication
560 FC 90 DY	560 FC 90 DY	32-030-02	Right Main Landing Gear Lubrication
560 FC 90 DY	560 FC 90 DY	32-080-00	Nose Gear Lubrication
600 FC 100 DY	600 FC 100 DY	52-842-01	Main Deck Cargo Door
1000 FC	1000 FC	27-144-00	Wing Flap Ballscrew Assemblies and Transmission Universal Joints Lubrication
1000 FC	1000 FC	27-176-01	Left Wing Inboard Flap Track Attachment Fitting
1000 FC	1000 FC	27-176-02	Right Wing Inboard Flap Track Attachment Fitting
1000 FC 100 DY	1000 FC 100 DY	53-908-01	Main Deck Cargo Door Stops, Latches, Hinges and Fittings
1250 FC 8 MO	1250 FC 8 MO	27-170-01	Left Wing Flap Actuation Mechanism Lubrication
1250 FC 8 MO	1250 FC 8 MO	27-170-02	Right Wing Flap Actuation Mechanism Lubrication



737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

INTERVAL		MPD ITEM NUMBER	TASK TITLE
THRESHOLD	REPEAT		
1250 FC 8 MO	1250 FC 8 MO	27-220-01	Left Wing Leading Edge Slat Roller Lubrication
1250 FC 8 MO	1250 FC 8 MO	27-220-02	Right Wing Leading Edge Slat Roller Lubrication
1600 FC	1600 FC	72-190-01	Left Engine Double Annular Combustion Chamber
1600 FC	1600 FC	72-190-02	Right Engine Double Annular Combustion Chamber
1600 FC	1600 FC	80-010-01	Magnetic Chip Detector - Left Engine Starter
1600 FC	1600 FC	80-010-02	Magnetic Chip Detector - Right Engine Starter
2000 FC	2000 FC	21-100-00	Primary and Secondary Heat Exchangers
2000 FC 4000 FH	2000 FC 4000 FH	27-093-00	Elevator Tab and Tab Mechanism Inspection Left and Right
2000 FC 4000 FH	2000 FC 4000 FH	27-095-00	Elevator Tab and Tab Mechanism Inspection
2000 FC 4000 FH	2000 FC 4000 FH	27-097-00	Elevator Balance Tab Freeplay Check
2000 FC 4000 FH	2000 FC 4000 FH	27-099-00	Elevator Balance Tab Freeplay Check
2000 FC 12 MO	2000 FC 12 MO	27-152-01	#4 Flap Transmission Angle/Tee GearBox Universal Joints
2000 FC 12 MO	2000 FC 12 MO	27-152-02	#5 Flap Transmission Angle/Tee GearBox Universal Joints
2000 FC 240 DY	2000 FC 240 DY	52-802-02	Forward Cargo Door
2000 FC 240 DY	2000 FC 240 DY	52-806-02	Aft Cargo Door
2000 FC 240 DY	2000 FC 240 DY	53-818-00	Forward Cargo Door Surround Structure Fittings and Stops
2000 FC 240 DY	2000 FC 240 DY	53-836-00	Aft Cargo Door Surround Structure Fittings and Stops
2000 FC 240 DY	2000 FC 240 DY	53-870-00	Forward Passenger Entry Door Stops, Latches and Hinges



737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

INTERVAL		MPD ITEM NUMBER	TASK TITLE
THRESHOLD	REPEAT		
2000 FC 240 DY	2000 FC 240 DY	53-872-00	Forward Galley Service Door Stops, Latches, and Hinges
2000 FC 240 DY	2000 FC 240 DY	53-890-00	Aft Passenger Entry Door Stops, Latches, and Hinges
2000 FC 240 DY	2000 FC 240 DY	53-892-00	Aft Galley Service Door Stops, Latches, and Hinges
2000 FC	2000 FC	70-802-01	Engine No. 1
2000 FC	2000 FC	70-808-01	Thrust Reverser - Engine No. 1
2000 FC	2000 FC	70-812-02	Engine No. 2
2000 FC	2000 FC	70-818-02	Thrust Reverser - Engine No. 2
2500 FC 16 MO	2500 FC 16 MO	27-222-01	Left Wing Leading Edge Slat Tracks
2500 FC 16 MO	2500 FC 16 MO	27-222-02	Right Wing Leading Edge Slat Tracks
3000 FC	3000 FC	25-170-00	Inspect Cargo Door Restraint System
3000 FC	3000 FC	32-070-00	Nose Gear Shock Strut Service
3500 FC 730 DY	3500 FC 730 DY	52-810-01	Forward Passenger Door
3500 FC 730 DY	3500 FC 730 DY	52-822-01	Aft Passenger Door
3500 FC 730 DY	3500 FC 730 DY	52-826-02	Forward Galley Service Door
3500 FC 730 DY	3500 FC 730 DY	52-838-02	Aft Galley Service Door
4000 FC 2 YR	4000 FC 2 YR	25-450-00	Pallet Locks, Forward End Stops, and Aft End Stops
4000 FC	4000 FC	27-174-01	Left Wing Forward Flap Track Attachment Pin
4000 FC	4000 FC	27-174-02	Right Wing Forward Flap Track Attachment Pin
4000 FC 24 MO	4000 FC 24 MO	27-226-00	Flight Control Cables



737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

INTERVAL		MPD ITEM NUMBER	TASK TITLE
THRESHOLD	REPEAT		
4000 FC	4000 FC	32-020-01	Left Main Landing Gear Servicing
4000 FC	4000 FC	32-020-02	Right Main Landing Gear Servicing
4000 FC	4000 FC	32-340-00	Parking Brake System
4000 FC	4000 FC	32-400-00	Steering Actuator Rod Ends
4000 FC 18 MO	4000 FC 18 MO	52-844-01	Main Deck Cargo Door
4000 FC 18 MO	4000 FC 18 MO	55-824-01	Horizontal Stabilizer - Front Spar to Rear Spar - Left
4000 FC 18 MO	4000 FC 18 MO	55-826-01	Horizontal Stabilizer - Front Spar to Rear Spar - Left
4000 FC 18 MO	4000 FC 18 MO	55-838-02	Horizontal Stabilizer - Front Spar to Rear Spar - Right
4000 FC 18 MO	4000 FC 18 MO	55-840-02	Horizontal Stabilizer - Front Spar to Rear Spar - Right
4000 FC	4000 FC	70-806-01	Thrust Reverser - Engine No. 1
4000 FC	4000 FC	70-816-02	Thrust Reverser - Engine No. 2
4000 FC	4000 FC	74-020-01	Ignition Leads
4000 FC	4000 FC	74-020-02	Ignition Leads
4800 FC 24 MO	4800 FC 24 MO	27-138-00	Wing Flap Drive Torque Tubes
4800 FC 24 MO	4800 FC 24 MO	53-866-00	Passenger Compartment - Section 41, STA 270 to STA 360
4800 FC 24 MO	4800 FC 24 MO	53-876-00	Forward Passenger Compartment - Sta 360 to Sta 663.75
4800 FC 24 MO	4800 FC 24 MO	53-884-00	Aft Passenger Compartment - STA 663.75 to Aft Pressure Bulkhead
4800 FC 24 MO	4800 FC 24 MO	55-810-00	Vertical Fin - Front Spar to Rear Spar
4800 FC 24 MO	4800 FC 24 MO	55-814-00	Vertical Fin - Rear Spar to Trailing Edge



737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

INTERVAL		MPD ITEM NUMBER	TASK TITLE
THRESHOLD	REPEAT		
4800 FC 24 MO	4800 FC 24 MO	55-828-01	Horizontal Stabilizer - Rear Spar to Trailing Edge - Left
4800 FC 24 MO	4800 FC 24 MO	55-830-01	Horizontal Stabilizer - Rear Spar to Trailing Edge - Left
4800 FC 24 MO	4800 FC 24 MO	55-842-02	Horizontal Stabilizer - Rear Spar to Trailing Edge - Right
4800 FC 24 MO	4800 FC 24 MO	55-844-02	Horizontal Stabilizer - Rear Spar to Trailing Edge - Right
5000 FC	5000 FC	24-130-00	External Power Receptacle (Wear Check)
5000 FC	5000 FC	24-140-00	External Power Receptacle (Inspection)
5000 FC	5000 FC	27-132-00	Flap Power Drive Unit
5000 FC	5000 FC	27-140-01	Left Wing Flap Transmission Oil Level
5000 FC	5000 FC	27-140-02	Right Wing Flap Transmission Oil Level
5500 FC 30 MO	5500 FC 30 MO	20-360-00	Main Landing Gear Wheel Well
5500 FC 30 MO	5500 FC 30 MO	20-460-00	APU Compartment
5500 FC 30 MO	5500 FC 30 MO	20-470-00	Engine No. 1
5500 FC 30 MO	5500 FC 30 MO	20-480-00	Engine No. 2
5500 FC 24 MO	5500 FC 24 MO	26-550-02	Center Wing Rear Spar Vapor Web
5500 FC 24 MO	5500 FC 24 MO	32-480-00	Operationally BITE-check the SPSEU
5500 FC 30 MO	5500 FC 30 MO	32-806-01	Left Main Landing Gear and Landing Gear Doors
5500 FC 30 MO	5500 FC 30 MO	32-810-02	Right Main Landing Gear and Landing Gear Doors
5500 FC 24 MO	5500 FC 24 MO	52-846-01	Mid-Exit Door



737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

INTERVAL		MPD ITEM NUMBER	TASK TITLE
THRESHOLD	REPEAT		
5500 FC 24 MO	5500 FC 24 MO	52-846-02	Mid-Exit Door
5500 FC 24 MO	5500 FC 24 MO	53-860-00	Flight Control Compartment
5500 FC 30 MO	5500 FC 30 MO	53-900-00	APU Compartment
5500 FC 30 MO	5500 FC 30 MO	53-904-01	Flap Support No. 4 - Left Wing
5500 FC 30 MO	5500 FC 30 MO	53-906-02	Flap Support No. 5 - Right Wing
5500 FC 24 MO	5500 FC 24 MO	57-854-01	Inboard Flaps - Left Wing
5500 FC 24 MO	5500 FC 24 MO	57-924-02	Inboard Flaps - Right Wing
6600 FC 15000 FH	1600 FC 4000 FH	72-180-01	Left Engine Combustion Chamber
6600 FC 15000 FH	1600 FC 4000 FH	72-180-02	Right Engine Combustion Chamber
6600 FC 15000 FH	1600 FC 4000 FH	72-200-01	Left Engine HPT Nozzle
6600 FC 15000 FH	1600 FC 4000 FH	72-200-02	Right Engine HPT Nozzle
6600 FC 15000 FH	1600 FC 4000 FH	72-210-01	Left Engine HPT Blades
6600 FC 15000 FH	1600 FC 4000 FH	72-210-02	Right Engine HPT Blades
6600 FC 3 YR	6600 FC 3 YR	27-228-00	Flight Control Cables
6600 FC 3 YR	6600 FC 3 YR	27-235-00	Flight Control Cable Tension
6600 FC	6600 FC	32-120-00	Nose Landing Gear Inspection
6600 FC	6600 FC	32-150-00	Main Landing Gear Inspection



737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

INTERVAL		MPD ITEM NUMBER	TASK TITLE
THRESHOLD	REPEAT		
6600 FC	6600 FC	32-250-00	Brake Control Linkage and Quadrants
6600 FC 36 MO	6600 FC 36 MO	32-440-00	Landing Gear Control Cables
6600 FC	6600 FC	32-490-00	Tailskid Actuator and Mechanism
6600 FC 36 MO	6600 FC 36 MO	52-804-02	Forward Cargo Door
6600 FC 36 MO	6600 FC 36 MO	52-808-02	Aft Cargo Door
6600 FC 36 MO	6600 FC 36 MO	52-812-01	Forward Passenger Door
6600 FC 36 MO	6600 FC 36 MO	52-814-01	Automatic Overwing Exit
6600 FC 36 MO	6600 FC 36 MO	52-818-01	Automatic Overwing Exit
6600 FC 36 MO	6600 FC 36 MO	52-824-01	Aft Passenger Door
6600 FC 36 MO	6600 FC 36 MO	52-828-02	Forward Galley Service Door
6600 FC 36 MO	6600 FC 36 MO	52-830-02	Automatic Overwing Exit
6600 FC 36 MO	6600 FC 36 MO	52-834-02	Automatic Overwing Exit
6600 FC 36 MO	6600 FC 36 MO	52-840-02	Aft Galley Service Door
6600 FC 36 MO	6600 FC 36 MO	53-802-00	Radome
6600 FC 36 MO	6600 FC 36 MO	53-804-00	Area Forward of Nose Wheel Well
6600 FC 36 MO	6600 FC 36 MO	53-806-00	Area Above and Outboard of Nose Wheel Well
6600 FC 36 MO	6600 FC 36 MO	53-808-00	Electrical and Electronics Compartment



737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

INTERVAL		MPD ITEM NUMBER	TASK TITLE
THRESHOLD	REPEAT		
6600 FC 36 MO	6600 FC 36 MO	53-810-00	Electrical and Electronics Compartment Access Door
6600 FC 36 MO	6600 FC 36 MO	53-822-00	Air Conditioning Distribution Bay
6600 FC 36 MO	6600 FC 36 MO	53-828-00	Keel Beam (Part) Sta 540 to 727
6600 FC 36 MO	6600 FC 36 MO	53-838-00	Aft Cargo Compartment Vacuum Waste Compartment
6600 FC 36 MO	6600 FC 36 MO	53-842-00	Aft Cargo Compartment Equipment Bay
6600 FC 36 MO	6600 FC 36 MO	53-846-00	Lower Wing to Body Fairing - Forward of Wing Box
6600 FC 36 MO	6600 FC 36 MO	53-848-00	Lower Wing to Body Fairing - Under Wing Box
6600 FC 36 MO	6600 FC 36 MO	53-852-00	Lower Wing to Body Fairing - Aft of Wheel Well
6600 FC 36 MO	6600 FC 36 MO	53-858-00	Flight Control Compartment
6600 FC 36 MO	6600 FC 36 MO	53-864-00	Passenger Compartment - Aft of Control Compartment to Fwd Entry Door
6600 FC 36 MO	6600 FC 36 MO	53-874-00	Forward Passenger Compartment - Sta 360 to Sta 663.75
6600 FC 36 MO	6600 FC 36 MO	53-882-00	Aft Passenger Compartment - Sta 663.75 to Aft Pressure Bulkhead
6600 FC 36 MO	6600 FC 36 MO	53-896-00	Area Aft of Pressure Bulkhead
6600 FC 36 MO	6600 FC 36 MO	53-898-00	Stabilizer Torsion Box Compartment
6600 FC 36 MO	6600 FC 36 MO	53-902-00	Tail Cone
6600 FC 36 MO	6600 FC 36 MO	53-910-00	Main Deck Cargo Compartment - Sta 360 to Sta 1016



737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

INTERVAL		MPD ITEM NUMBER	TASK TITLE
THRESHOLD	REPEAT		
6600 FC 36 MO	6600 FC 36 MO	54-802-01	Fan Cowl Support Beam - Engine No. 1
6600 FC 36 MO	6600 FC 36 MO	54-810-02	Fan Cowl Support Beam - Engine No. 2
6600 FC 36 MO	6600 FC 36 MO	55-802-00	Vertical Fin - Dorsal Fin
6600 FC 36 MO	6600 FC 36 MO	55-804-00	Vertical Fin - Leading Edge (Only if HF System Installed)
6600 FC 36 MO	6600 FC 36 MO	55-806-00	Vertical Fin - Leading Edge
6600 FC 36 MO	6600 FC 36 MO	55-816-00	Vertical Fin - Rear Spar to Trailing Edge
6600 FC 36 MO	6600 FC 36 MO	55-820-00	Vertical Fin Tip
6600 FC 36 MO	6600 FC 36 MO	55-822-01	Horizontal Stabilizer - Leading Edge - Left
6600 FC 36 MO	6600 FC 36 MO	55-832-01	Horizontal Stabilizer - Elevator - Left
6600 FC 36 MO	6600 FC 36 MO	55-834-01	Horizontal Stabilizer - Stabilizer Tip - Left
6600 FC 36 MO	6600 FC 36 MO	55-836-02	Horizontal Stabilizer - Leading Edge - Right
6600 FC 36 MO	6600 FC 36 MO	55-846-02	Horizontal Stabilizer - Elevator - Right
6600 FC 36 MO	6600 FC 36 MO	55-848-02	Horizontal Stabilizer - Stabilizer Tip - Right
6600 FC 36 MO	6600 FC 36 MO	57-804-01	Leading Edge to Front Spar - Inboard of Nacelle Strut - Left Wing
6600 FC 36 MO	6600 FC 36 MO	57-806-01	Leading Edge to Front Spar - Inboard of Nacelle Strut - Left Wing
6600 FC 36 MO	6600 FC 36 MO	57-808-01	Krueger Flaps No. 1 and 2 - Left Wing



737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

INTERVAL		MPD ITEM NUMBER	TASK TITLE
THRESHOLD	REPEAT		
6600 FC 36 MO	6600 FC 36 MO	57-810-01	Krueger Flaps No. 1 and 2 - Left Wing
6600 FC 36 MO	6600 FC 36 MO	57-812-01	Leading Edge to Front Spar - Outboard of Nacelle Strut - Left Wing
6600 FC 36 MO	6600 FC 36 MO	57-814-01	Leading Edge to Front Spar - Outboard of Nacelle Strut - Left Wing
6600 FC 36 MO	6600 FC 36 MO	57-816-01	Slats No. 1, 2, 3, 4 - Left Wing
6600 FC 36 MO	6600 FC 36 MO	57-818-01	Left Wing Tip
6600 FC 36 MO	6600 FC 36 MO	57-824-01	Center Fuel Tank - Left Wing
6600 FC 36 MO	6600 FC 36 MO	57-828-01	Main Fuel Tank - Left Wing
6600 FC 36 MO	6600 FC 36 MO	57-832-01	Surge Tank - Left Wing
6600 FC 36 MO	6600 FC 36 MO	57-834-01	Dry Bay - Left Wing
6600 FC 36 MO	6600 FC 36 MO	57-836-01	Fairing Flap Support No. 3 - Left Wing
6600 FC 36 MO	6600 FC 36 MO	57-838-01	Fairing Flap Support No. 3 - Left Wing
6600 FC 36 MO	6600 FC 36 MO	57-840-01	Fairing Flap Support No. 2 - Left Wing
6600 FC 36 MO	6600 FC 36 MO	57-842-01	Fairing Flap Support No. 2 - Left Wing
6600 FC 36 MO	6600 FC 36 MO	57-844-01	Fairing Flap Support No. 1 - Left Wing
6600 FC 36 MO	6600 FC 36 MO	57-846-01	Fairing Flap Support No. 1 - Left Wing
6600 FC 36 MO	6600 FC 36 MO	57-848-01	Rear Spar to Landing Gear Support Beam - Left Wing



737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

INTERVAL		MPD ITEM NUMBER	TASK TITLE
THRESHOLD	REPEAT		
6600 FC 36 MO	6600 FC 36 MO	57-852-01	Inboard Spoiler No. 6 - L. Wing
6600 FC 36 MO	6600 FC 36 MO	57-858-01	Rear Spar to T.E. - Outbd of Inbd Flap - Inbd of Fixed T.E. - L. Wing
6600 FC 36 MO	6600 FC 36 MO	57-860-01	Spoilers No. 1, 2, 3, 4, 5 - Left Wing
6600 FC 36 MO	6600 FC 36 MO	57-862-01	Outboard Flaps - Left Wing
6600 FC 36 MO	6600 FC 36 MO	57-864-01	Fixed Trailing Edge - Left Wing
6600 FC 36 MO	6600 FC 36 MO	57-868-01	Fixed Trailing Edge - Left Wing
6600 FC 36 MO	6600 FC 36 MO	57-870-01	Aileron - Left Wing
6600 FC 36 MO	6600 FC 36 MO	57-874-02	Leading Edge to Front Spar - Inbd of Nacelle Strut - Right Wing
6600 FC 36 MO	6600 FC 36 MO	57-876-02	Leading Edge to Front Spar - Inbd of Nacelle Strut - Right Wing
6600 FC 36 MO	6600 FC 36 MO	57-878-02	Krueger Flaps No. 3 and 4 - Right Wing
6600 FC 36 MO	6600 FC 36 MO	57-880-02	Krueger Flaps No. 3 and 4 - Right Wing
6600 FC 36 MO	6600 FC 36 MO	57-882-02	Leading Edge to Front Spar - Outbd of Nacelle Strut - Right Wing
6600 FC 36 MO	6600 FC 36 MO	57-884-02	Leading Edge to Front Spar - Outbd of Nacelle Strut - Right Wing
6600 FC 36 MO	6600 FC 36 MO	57-886-02	Slats No. 5, 6, 7, 8, - Right Wing
6600 FC 36 MO	6600 FC 36 MO	57-888-02	Right Wing Tip
6600 FC 36 MO	6600 FC 36 MO	57-894-02	Center Fuel Tank - Right Wing



737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

INTERVAL		MPD ITEM NUMBER	TASK TITLE
THRESHOLD	REPEAT		
6600 FC 36 MO	6600 FC 36 MO	57-898-02	Main Fuel Tank - Right Wing
6600 FC 36 MO	6600 FC 36 MO	57-902-02	Surge Tank - Right Wing
6600 FC 36 MO	6600 FC 36 MO	57-904-02	Dry Bay - Right Wing
6600 FC 36 MO	6600 FC 36 MO	57-906-02	Fairing Flap Support No. 6 - Right Wing
6600 FC 36 MO	6600 FC 36 MO	57-908-02	Fairing Flap Support No. 6 - Right Wing
6600 FC 36 MO	6600 FC 36 MO	57-910-02	Fairing Flap Support No. 7 - Right Wing
6600 FC 36 MO	6600 FC 36 MO	57-912-02	Fairing Flap Support No. 7 - Right Wing
6600 FC 36 MO	6600 FC 36 MO	57-914-02	Fairing Flap Support No. 8 - Right Wing
6600 FC 36 MO	6600 FC 36 MO	57-916-02	Fairing Flap Support No. 8 - Right Wing
6600 FC 36 MO	6600 FC 36 MO	57-918-02	Rear Spar to Landing Gear Support Beam - Right Wing
6600 FC 36 MO	6600 FC 36 MO	57-922-02	Inboard Spoiler No. 7 - Right Wing
6600 FC 36 MO	6600 FC 36 MO	57-928-02	Rear Spar to T.E. - Outbd of Inbd Flap - Inbd of Fixed T.E. - Right Wing
6600 FC 36 MO	6600 FC 36 MO	57-930-02	Spoiler No 8, 9, 10, 11, 12 - Right Wing
6600 FC 36 MO	6600 FC 36 MO	57-932-02	Outboard Flaps - Right Wing
6600 FC 36 MO	6600 FC 36 MO	57-934-02	Fixed Trailing Edge - Right Wing
6600 FC 36 MO	6600 FC 36 MO	57-938-02	Fixed Trailing Edge - Right Wing



737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

INTERVAL		MPD ITEM NUMBER	TASK TITLE
THRESHOLD	REPEAT		
6600 FC 36 MO	6600 FC 36 MO	57-940-02	Aileron - Right Wing
6600 FC	6600 FC	70-804-01	Fan Cowl - Engine No. 1
6600 FC	6600 FC	70-814-02	Fan Cowl - Engine No. 2
8000 FC	8000 FC	32-110-00	Landing Gear Selector Valve
8000 FC	8000 FC	32-260-00	Brake Metering Valve Inspection
8000 FC	8000 FC	32-330-00	Parking Brake Mechanical Control Path
8000 FC	8000 FC	32-390-00	Nose Wheel Steering Control Path
9000 FC 36 MO	9000 FC 36 MO	54-800-01	Forward Strut Fairing - Engine No. 1
9000 FC 36 MO	9000 FC 36 MO	54-806-01	Aft Strut Fairing - Engine No. 1
9000 FC 36 MO	9000 FC 36 MO	54-808-02	Forward Strut Fairing - Engine No. 2
9000 FC 36 MO	9000 FC 36 MO	54-814-02	Aft Strut Fairing - Engine No. 2
10000 FC 6 YR	10000 FC 6 YR	55-818-00	Rudder
10000 FC	10000 FC	72-100-01	Left Engine Attachment Bolts for the Thrust Mount Fittings
10000 FC	10000 FC	72-100-02	Right Engine Attachment Bolts for the Thrust Mount Fittings
10400 FC 6 YR	10400 FC 6 YR	32-450-00	Landing Gear Control System Cables
12000 FC	12000 FC	27-172-01	Left Wing Flap Actuation System
12000 FC	12000 FC	27-172-02	Right Wing Flap Actuation System
12000 FC	12000 FC	38-015-00	Forward Gray Water Drain Valve
12500 FC	12500 FC	32-310-00	Brake Accumulator Isolation Valve
13200 FC	6600 FC	27-148-03	Left Wing Ballscrew Assembly
13200 FC	6600 FC	27-148-04	Right Wing Ballscrew Assembly



737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

INTERVAL		MPD ITEM NUMBER	TASK TITLE
THRESHOLD	REPEAT		
13200 FC 72 MO	13200 FC 72 MO	53-814-00	Forward Cargo Compartment
13200 FC 72 MO	13200 FC 72 MO	53-820-00	Area Below Forward Cargo Compartment
13200 FC 72 MO	13200 FC 72 MO	53-826-00	Pressure Deck Above Main Landing Gear Wheel Well
13200 FC 72 MO	13200 FC 72 MO	53-832-00	Aft Cargo Compartment
13200 FC 72 MO	13200 FC 72 MO	53-840-00	Area Below Aft Cargo Compartment
13200 FC 6 YR	13200 FC 6 YR	55-812-00	Vertical Fin - Front Spar to Rear Spar
15000 FC	15000 FC	24-110-00	Remote Control Circuit Breaker
15000 FC	15000 FC	32-290-00	Alternate Brake System
18000 FC 6 YR	18000 FC 6 YR	20-310-00	Electrical and Electronics Compartment
18000 FC 6 YR	18000 FC 6 YR	20-320-00	Electrical and Electronics Compartment
18000 FC 6 YR	18000 FC 6 YR	20-325-00	Exposed EWIS in the Electrical and Electronics Compartment
18000 FC 6 YR	18000 FC 6 YR	20-330-00	Forward Cargo Compartment
18000 FC 6 YR	18000 FC 6 YR	20-335-00	Exposed EWIS in the Forward Cargo Compartment. (EZAP)
18000 FC 6 YR	18000 FC 6 YR	20-340-00	Area Below Forward Cargo Compartment
18000 FC 6 YR	18000 FC 6 YR	20-370-00	Aft Cargo Compartment
18000 FC 6 YR	18000 FC 6 YR	20-375-00	Exposed EWIS in Aft Cargo Compartment
18000 FC 6 YR	18000 FC 6 YR	20-380-00	Area Below Aft Cargo Compartment



737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

INTERVAL		MPD ITEM NUMBER	TASK TITLE
THRESHOLD	REPEAT		
18000 FC 6 YR	18000 FC 6 YR	20-390-00	Aft Cargo Compartment Equipment Bay
18000 FC 6 YR	18000 FC 6 YR	20-400-00	Flight Compartment
18000 FC 6 YR	18000 FC 6 YR	20-465-00	Exposed EWIS in the tail cone
18000 FC 6 YR	18000 FC 6 YR	20-490-00	Fwd Strut Fairing - Engine No. 1
18000 FC 6 YR	18000 FC 6 YR	20-500-00	Fan Cowl Support Beam - Engine No. 1
18000 FC 6 YR	18000 FC 6 YR	20-510-00	Strut Torque Box - Engine No. 1
18000 FC 6 YR	18000 FC 6 YR	20-520-00	Fwd Strut Fairing - Engine No. 2
18000 FC 6 YR	18000 FC 6 YR	20-530-00	Fan Cowl Support Beam - Engine No. 2
18000 FC 6 YR	18000 FC 6 YR	20-540-00	Strut Torque Box - Engine No. 2
18000 FC 6 YR	18000 FC 6 YR	20-550-00	Leading Edge to Front Spar - Inboard of Nacelle Strut - Left Wing
18000 FC 6 YR	18000 FC 6 YR	20-570-00	Rear Spar to Landing Gear Support Beam - Left Wing
18000 FC 6 YR	18000 FC 6 YR	20-580-00	Rear Spar to T.E. - Outbd of Inbd Flap - Inbd of Fixed T.E. - Left Wing
18000 FC 6 YR	18000 FC 6 YR	20-590-00	Leading Edge to Front Spar - Inboard of Nacelle Strut - Right Wing
18000 FC 6 YR	18000 FC 6 YR	20-610-00	Rear Spar to Landing Gear Support Beam - Right Wing
18000 FC 6 YR	18000 FC 6 YR	20-620-00	Rear Spar to T.E. - Outbd of Inbd Flap - Inbd of Fixed T.E. - Right Wing
18000 FC 10 YR	18000 FC 10 YR	32-090-00	Restore Nose Landing Gear



737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

INTERVAL		MPD ITEM NUMBER	TASK TITLE
THRESHOLD	REPEAT		
18000 FC 9 YR	18000 FC 8 YR	52-816-01	Automatic Overwing Exit
18000 FC 9 YR	18000 FC 8 YR	52-820-01	Automatic Overwing Exit
18000 FC 9 YR	18000 FC 8 YR	52-832-02	Automatic Overwing Exit
18000 FC 9 YR	18000 FC 8 YR	52-836-02	Automatic Overwing Exit
18000 FC 8 YR	18000 FC 8 YR	52-846-03	Mid-Exit Door
18000 FC 8 YR	18000 FC 8 YR	52-846-04	Mid-Exit Door
18000 FC 8 YR	18000 FC 8 YR	52-846-05	Mid-Exit Door
18000 FC 8 YR	18000 FC 8 YR	52-846-06	Mid-Exit Door
18000 FC 6 YR	18000 FC 6 YR	54-804-01	Strut Torque Box - Engine No. 1
18000 FC 6 YR	18000 FC 6 YR	54-812-02	Strut Torque Box - Engine No. 2
18000 FC	18000 FC	55-650-00	Elevator Tab Mast Fitting
18000 FC	18000 FC	55-653-00	Elevator Tab Hinge Fittings 183A4211 Lug Assembly
21000 FC 10 YR	21000 FC 10 YR	32-040-01	Left Main Landing Gear Restoration
21000 FC 10 YR	21000 FC 10 YR	32-040-02	Right Main Landing Gear Restoration
21600 FC 6 YR	21600 FC 6 YR	27-229-00	Inboard Trailing Edge Aft Flap Drive Cable Inspection
21600 FC 6 YR	21600 FC 6 YR	57-820-01	Left Wing Tip
21600 FC 6 YR	21600 FC 6 YR	57-850-01	Rear Spar to Landing Gear Support Beam - Left Wing



737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

INTERVAL		MPD ITEM NUMBER	TASK TITLE
THRESHOLD	REPEAT		
21600 FC 6 YR	21600 FC 6 YR	57-856-01	Inboard Main Flaps - Left Wing
21600 FC 6 YR	21600 FC 6 YR	57-890-02	Right Wing Tip
21600 FC 6 YR	21600 FC 6 YR	57-920-02	Rear Spar to Landing Gear Support Beam - Right Wing
21600 FC 6 YR	21600 FC 6 YR	57-926-02	Inboard Main Flap - Right Wing
24000 FC 9 YR	24000 FC 8 YR	53-850-00	Lower Wing to Body Fairing - Aft of Wheel Well
24000 FC 9 YR	24000 FC 8 YR	53-854-02	Above Wing, Wing to Body Fairing - Right
24000 FC 9 YR	24000 FC 8 YR	53-856-01	Above Wing, Wing to Body Fairing - Left
25000 FC	25000 FC	27-134-00	Flap Power Drive Unit
25000 FC	25000 FC	27-142-01	Left Wing Flap Transmission Oil
25000 FC	25000 FC	27-142-02	Right Wing Flap Transmission Universal Oil
25000 FC	25000 FC	27-168-01	Left Wing Flap Transmission No-Back Brake
25000 FC	25000 FC	27-168-02	Right Wing Flap Transmission No-Back Brake
34000 FC	18000 FC	53-646-62	Forward Cargo Door Surround Structure
34000 FC	18000 FC	53-646-63	Forward Cargo Door Surround Structure
34000 FC	18000 FC	53-721-00	Aft Cargo Door Surround Structure
34000 FC	18000 FC	53-721-10	Aft Cargo Door Surround Structure
36000 FC	10000 FC	53-749-10	Bulkhead STA 1016
36000 FC 12 YR	36000 FC 12 YR	20-290-00	Area Forward of Nose Wheel Well
36000 FC 12 YR	36000 FC 12 YR	20-300-00	Area Above Nose Wheel Well And Outbd of Nose Wheel Well



737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

INTERVAL		MPD ITEM NUMBER	TASK TITLE
THRESHOLD	REPEAT		
36000 FC 12 YR	36000 FC 12 YR	20-305-00	External power feeder wiring and connected EWIS
36000 FC 12 YR	36000 FC 12 YR	20-350-00	Area AFT of Forward Cargo Compartment
36000 FC 12 YR	36000 FC 12 YR	20-410-00	Flight Compartment
36000 FC 12 YR	36000 FC 12 YR	20-415-00	Exposed EWIS in Flight Compartment
36000 FC 12 YR	36000 FC 12 YR	20-420-00	Passenger Compartment - Aft of Control Compartment to Fwd Entry Door
36000 FC 12 YR	36000 FC 12 YR	20-430-00	Fwd Passenger Compartment - Fwd Entry Door to STA 663.75
36000 FC 12 YR	36000 FC 12 YR	20-440-00	Aft Passenger Compartment - STA 663.75 to Aft Pressure Bulkhead
36000 FC 12 YR	36000 FC 12 YR	20-450-00	Area Aft of Pressure Bulkhead
36000 FC 12 YR	36000 FC 12 YR	20-560-00	Leading Edge to Front Spar - Outboard of Nacelle Strut - Left Wing
36000 FC 12 YR	36000 FC 12 YR	20-600-00	Leading Edge to Front Spar - Outboard of Nacelle Strut - Right Wing
36000 FC 12 YR	36000 FC 12 YR	20-630-00	Main Deck Cargo Compartment - STA 360 to STA 1016
36000 FC 12 YR	36000 FC 12 YR	27-230-00	Flight Control Cables
36000 FC 12 YR	36000 FC 12 YR	32-460-00	Landing Gear Control System Cables
36000 FC 12 YR	36000 FC 12 YR	53-816-00	Forward Cargo Compartment
36000 FC 12 YR	36000 FC 12 YR	53-824-01	Area Above Center Section Wing Box
36000 FC 12 YR	36000 FC 12 YR	53-834-00	Aft Cargo Compartment



737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

INTERVAL		MPD ITEM NUMBER	TASK TITLE
THRESHOLD	REPEAT		
36000 FC 10 YR	36000 FC 10 YR	53-862-00	Flight Control Compartment
36000 FC 9 YR	36000 FC 8 YR	53-868-00	Passenger Compartment - Aft of Control Compartment to Fwd Entry Door
36000 FC 12 YR	36000 FC 12 YR	53-880-00	Forward Passenger Compartment - Sta 360 to Sta 663.75 Dry Areas
36000 FC 12 YR	36000 FC 12 YR	53-888-00	Aft Passenger Compartment - Sta 663.75 to Aft Pressure Bulkhead Dry Area
36000 FC	36000 FC	55-623-00	Horizontal Stabilizer Elevator Hinge Ribs Trailing Edge Clevis
36000 FC 12 YR	36000 FC 12 YR	55-808-00	Vertical Fin - Leading Edge
36000 FC 10 YR	36000 FC 10 YR	57-800-00	Center Section Wing Box
36000 FC 10 YR	36000 FC 10 YR	57-822-01	Center Fuel Tank - Left Wing
36000 FC 10 YR	36000 FC 10 YR	57-826-01	Main Fuel Tank - Left Wing
36000 FC 10 YR	36000 FC 10 YR	57-830-01	Surge Tank - Left Wing
36000 FC 10 YR	36000 FC 10 YR	57-892-02	Center Fuel Tank - Right Wing
36000 FC 10 YR	36000 FC 10 YR	57-896-02	Main Fuel Tank - Right Wing
36000 FC 10 YR	36000 FC 10 YR	57-900-02	Surge Tank - Right Wing
50000 FC	4000 FC	52-796-00	Electronic Equipment Access Door Aluminum Casting only
50000 FC	4000 FC	53-601-20	Cutout - Crew Cab Windows
50000 FC	4000 FC	53-601-40	Cutout - Crew Cabin Windows
50000 FC	4000 FC	53-601-41	Cutout - Crew Cabin Windows
50000 FC	4000 FC	53-602-20	Crown Skin Panel - STA 259.5 to 360



737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

INTERVAL		MPD ITEM NUMBER	TASK TITLE
THRESHOLD	REPEAT		
50000 FC	4000 FC	53-605-10	Cutout - Electronic Equipment Door
50000 FC	4000 FC	53-630-01	Air Stair Door Cutout
50000 FC	4000 FC	53-633-00	Crown Skin Panel, STA 360 to 540
50000 FC	4000 FC	53-636-00	Fuselage Side Skin Panels
50000 FC	4000 FC	53-644-00	Longitudinal Lap Splice
50000 FC	4000 FC	53-645-01	Window Belt STA 360 to STA 540
50000 FC	4000 FC	53-652-00	Crown Skin Panel - STA 540 to 727
50000 FC	4000 FC	53-682-00	Overwing Emergency Exit Cutout Skin Assembly & Frame Outer Chord
50000 FC	4000 FC	53-682-01	Overwing Emergency Exit Cutout Skin Assembly & Frame Outer Chord
50000 FC	4000 FC	53-682-03	Overwing Emergency Exit Cutout Skin Assembly & Frame Outer Chord
50000 FC	4000 FC	53-684-00	Overwing Emergency Exit Cutout
50000 FC	4000 FC	53-684-01	Overwing Emergency Exit Cutout
50000 FC	4000 FC	53-684-02	Overwing Emergency Exit Cutout
50000 FC	4000 FC	53-687-10	Overwing Emergency Exit Cutout
50000 FC	4000 FC	53-693-00	Overwing Emergency Exit Cutout Structure
50000 FC	4000 FC	53-693-01	Overwing Emergency Exit Cutout Structure
50000 FC	4000 FC	53-698-00	Crown Skin Panel - STA 727 to 887
50000 FC	4000 FC	53-703-00	Fuselage Side Skin Panels
50000 FC	4000 FC	53-711-01	Window Belt STA 727 to 888
50000 FC	4000 FC	53-727-00	Crown Skin Panel - STA 887 to 1016
50000 FC	4000 FC	53-730-00	Cutout, Aft Entry Door Surround Structure
50000 FC	4000 FC	53-731-00	Aft Entry Door Surround Structure
50000 FC	4000 FC	53-734-00	Aft Galley Door Forward Edge Frame Door Stop Backup Structure
50000 FC	4000 FC	53-736-00	Cutout, Aft Galley Door Surround Structure



737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

INTERVAL		MPD ITEM NUMBER	TASK TITLE
THRESHOLD	REPEAT		
50000 FC	4000 FC	53-737-00	Aft Galley Door Surround Structure
50000 FC	4000 FC	53-738-01	Window Belt STA 888 to 927
50000 FC	4000 FC	53-767-00	STA 1042 Bulkhead Lugs, Links and Fittings Link Attach Fittings
50000 FC	4000 FC	53-790-00	Section 48 Longitudinal Lap Splices S-24 Lap Splice, STA 1016 to 1042
50000 FC	4800 FC	53-601-21	Cutout - Crew Cab Windows
50000 FC	6000 FC	53-646-75	Forward Cargo Door Surround Structure
50000 FC	6000 FC	53-685-00	Overwing Emergency Exit Cutout - Door Cutout Corners
50000 FC	6000 FC	53-685-01	Overwing Emergency Exit Cutout - Door Cutout Corners
50000 FC	6000 FC	53-721-20	Aft Cargo Door Surround Structure
50000 FC	6000 FC	53-743-01	Bulkhead STA 1016
50000 FC	6000 FC	53-770-00	APU Inlet Enclosure Installation - Pressure Panels
50000 FC	6000 FC	53-782-00	Side Skin Panel, STA 1016 to 1042 S-9R to S-16R - APU Inlet Cutout
50000 FC	8000 FC	53-636-10	Fuselage Side Skin Panels Under the Wing-to-Body Fairing
50000 FC	8000 FC	53-703-10	Fuselage Side Skin Panels Under the Wing-to-Body Fairing
50000 FC	9000 FC	53-606-70	FWD Entry Door, FWD Edge Frame Stops
50000 FC	9000 FC	53-625-00	Cutout - FWD Galley Door
50000 FC	9000 FC	53-630-00	Air Stair Door Cutout
50000 FC	9000 FC	53-646-00	Forward Cargo Door Surround Structure
50000 FC	9000 FC	53-646-60	Forward Cargo Door Surround Structure
50000 FC	9000 FC	53-646-61	Forward Cargo Door Surround Structure
50000 FC	9000 FC	53-647-00	Forward Cargo Door Fittings and Stops at the Forward and Aft Edge Frames
50000 FC	9000 FC	53-649-00	Wing to Body Upper Drag Angle
50000 FC	9000 FC	53-649-01	Wing to Body Upper Drag Angle
50000 FC	9000 FC	53-651-00	Floor Beam to Frame Joint



737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

INTERVAL		MPD ITEM NUMBER	TASK TITLE
THRESHOLD	REPEAT		
50000 FC	9000 FC	53-670-00	Aft Wheel Well Bulkhead and Pressure Web, STA 727
50000 FC	9000 FC	53-672-00	Side Strut Support Frame STA 706
50000 FC	9000 FC	53-680-00	Overwing Emergency Exit Cutout
50000 FC	9000 FC	53-687-00	Overwing Emergency Exit Cutout
50000 FC	9000 FC	53-695-00	Overwing Emergency Exit Door Stops and Fittings
50000 FC	9000 FC	53-714-00	Aft Cargo Door Surround Structure
50000 FC	9000 FC	53-714-01	Aft Cargo Door Surround Structure
50000 FC	9000 FC	53-720-00	Aft Cargo Door Surround Structure
50000 FC	9000 FC	53-722-00	Aft Cargo Door Fittings and Stops at the Forward and Aft Edge Frames
50000 FC	9000 FC	53-725-00	Longitudinal Lap Splice
50000 FC	9000 FC	53-728-00	Aft Entry Door, Forward Edge Frame Door Stop Backup Structure
50000 FC	9000 FC	53-739-00	Bulkhead STA 1016
50000 FC	9000 FC	53-740-00	Bulkhead STA 1016
50000 FC	9000 FC	53-745-00	Bulkhead STA 1016
50000 FC	9000 FC	53-747-00	Bulkhead STA 1016
50000 FC	9000 FC	53-747-10	Bulkhead STA 1016
50000 FC	10000 FC	53-636-20	Fuselage Skin Under the Upper Wing-to-Body Drag Angle
50000 FC	12000 FC	53-601-01	Cutout - Crew Cab Windows
50000 FC	12000 FC	53-702-01	SATCOM Antenna Installation (All except those covered by PSE 53-60-01-5)
50000 FC	12000 FC	53-734-01	Aft Galley Door Forward Edge Frame Door Stop Backup Structure
50000 FC	12000 FC	53-742-00	Bulkhead STA 1016
50000 FC	14000 FC	53-759-00	Horizontal Stabilizer Pivot Pins
50000 FC	15000 FC	53-646-50	Forward Cargo Door Surround Structure
50000 FC	15000 FC	53-676-10	Main Landing Gear Support Frame STA 716



737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

INTERVAL		MPD ITEM NUMBER	TASK TITLE
THRESHOLD	REPEAT		
50000 FC	15000 FC	53-717-00	Aft Cargo Door Surround Structure
50000 FC	15000 FC	53-765-00	STA 1042 Bulkhead Lugs, Links and Fittings End Beam Lug Attachment at Diagonal Beam
50000 FC	16000 FC	53-667-00	Aft Wheel Well Bulkhead STA 727
50000 FC	17000 FC	53-628-00	Nose Landing Gear Support Fittings
50000 FC	18000 FC	52-795-00	Main Deck Cargo Door
50000 FC	18000 FC	52-795-10	Main Deck Cargo Door
50000 FC	18000 FC	53-601-00	Cutout - Crew Cab Windows
50000 FC	18000 FC	53-601-30	Cutout - Crew Cab Windows
50000 FC	18000 FC	53-619-00	FWD Entry Door, FWD Edge Frame Stops
50000 FC	18000 FC	53-621-00	FWD Entry Door, AFT Edge Frame Stops
50000 FC	18000 FC	53-624-00	Forward Galley Door Surround Structure, Door Stop Backup Structure
50000 FC	18000 FC	53-632-00	Forward Nose Wheel Well Cutout Outer Chord
50000 FC	18000 FC	53-638-00	Longitudinal Lap Splice
50000 FC	18000 FC	53-638-10	Longitudinal Lap Splice
50000 FC	18000 FC	53-642-00	Longitudinal Lap Splice
50000 FC	18000 FC	53-642-10	Longitudinal Lap Splice
50000 FC	18000 FC	53-646-10	Forward Cargo Door Surround, Forward and Aft Edge Frames at STA 440 and 492.4
50000 FC	18000 FC	53-646-20	Forward Cargo Door Surround, Forward and Aft Edge Frames at STA 440 and 492.4
50000 FC	18000 FC	53-646-30	Forward Cargo Door Surround
50000 FC	18000 FC	53-646-40	Forward Cargo Door Surround Structure
50000 FC	18000 FC	53-654-00	Longitudinal Lap Splice
50000 FC	18000 FC	53-654-10	Longitudinal Lap Splice
50000 FC	18000 FC	53-655-00	Longitudinal Skin Splice
50000 FC	18000 FC	53-657-00	Window Belt, STA 540 to 727



737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

INTERVAL		MPD ITEM NUMBER	TASK TITLE
THRESHOLD	REPEAT		
50000 FC	18000 FC	53-658-00	Stringer Splice, STA 663
50000 FC	18000 FC	53-659-00	Keel Beam Chords, Stiffeners and Splice
50000 FC	18000 FC	53-663-00	Frame Splice at STA 540
50000 FC	18000 FC	53-664-00	BS 540 Bulkhead
50000 FC	18000 FC	53-665-00	BS 663 Bulkhead
50000 FC	18000 FC	53-667-10	Aft Wheel Well Bulkhead STA 727
50000 FC	18000 FC	53-674-00	Main Landing Gear Support Frame STA 716
50000 FC	18000 FC	53-692-00	Overwing Emergency Exit Cutout
50000 FC	18000 FC	53-701-00	SATCOM Antenna Installation (Canadian Marconi and Honeywell)
50000 FC	18000 FC	53-705-00	Longitudinal Lap Splice
50000 FC	18000 FC	53-705-10	Longitudinal Lap Splice
50000 FC	18000 FC	53-709-00	Longitudinal Lap Splice
50000 FC	18000 FC	53-709-10	Longitudinal Lap Splice
50000 FC	18000 FC	53-715-00	Aft Cargo Door Surround Structure
50000 FC	18000 FC	53-716-00	Aft Cargo Door Surround Structure
50000 FC	18000 FC	53-718-00	Aft Cargo Door Surround Forward and Aft Edge Frames at BS 794.37 and 847
50000 FC	18000 FC	53-719-00	Aft Cargo Door Surround Forward and Aft Edge Frames at BS 794.37 and 847
50000 FC	18000 FC	53-724-00	Longitudinal Lap Splice
50000 FC	18000 FC	53-729-01	Aft Entry Door, Aft Edge Frame Door Stop Backup Intercostals
50000 FC	18000 FC	53-731-01	Aft Entry Door Surround Structure
50000 FC	18000 FC	53-735-01	Aft Galley Door Aft Edge Frame Door Stop Backup Intercostals
50000 FC	18000 FC	53-737-01	Aft Galley Door Surround Structure
50000 FC	18000 FC	53-760-00	Section 48 Skin Panels, STA 1088 to 1156
50000 FC	18000 FC	53-769-00	APU Inlet Cutout Enclosure Forward Panel



737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

INTERVAL		MPD ITEM NUMBER	TASK TITLE
THRESHOLD	REPEAT		
50000 FC	22000 FC	53-732-00	Aft Entry Door Surround Structure
50000 FC	22000 FC	53-732-01	Aft Entry Door Surround Structure
50000 FC	22000 FC	53-733-00	Aft Galley Door Surround Structure
50000 FC	22000 FC	53-733-01	Aft Galley Door Surround Structure
50000 FC	24000 FC	53-510-10	KU Band Antenna Installation
50000 FC	24000 FC	53-600-41	Longitudinal Lap Splice
50000 FC	24000 FC	53-602-10	Crown Skin Panel - FWD of STA 259.5
50000 FC	24000 FC	53-606-40	Cutout - Forward Entry Door Frame
50000 FC	24000 FC	53-620-00	FWD Entry Door, AFT Edge Frame Stops
50000 FC	24000 FC	53-627-00	Nose Wheel Well Side and Top Panels
50000 FC	24000 FC	53-629-00	Nose Landing Gear Trunnion Support Fittings
50000 FC	24000 FC	53-631-01	Air Stair Door Cutout
50000 FC	24000 FC	53-640-00	Longitudinal Lap Splice
50000 FC	24000 FC	53-640-10	Longitudinal Lap Splice
50000 FC	24000 FC	53-641-00	Longitudinal Lap Splice
50000 FC	24000 FC	53-641-10	Longitudinal Lap Splice
50000 FC	24000 FC	53-645-00	Window Belt STA 360 to 540
50000 FC	24000 FC	53-646-70	Forward Cargo Door Surround Structure
50000 FC	24000 FC	53-646-71	Forward Cargo Door Surround Structure
50000 FC	24000 FC	53-656-00	Window Belt, STA 540 to 727
50000 FC	24000 FC	53-666-00	BS 663 Bulkhead
50000 FC	24000 FC	53-671-00	Aft Wheel Well Bulkhead Frame STA 727
50000 FC	24000 FC	53-673-00	Main Landing Gear Support Frame, STA 695
50000 FC	24000 FC	53-676-00	Main Landing Gear Support Frame STA 716



737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

INTERVAL		MPD ITEM NUMBER	TASK TITLE
THRESHOLD	REPEAT		
50000 FC	24000 FC	53-677-00	Wheel Well Frame, STA 685
50000 FC	24000 FC	53-681-00	Overwing Emergency Exit Cutout
50000 FC	24000 FC	53-681-01	Overwing Emergency Exit Cutout
50000 FC	24000 FC	53-681-02	Overwing Emergency Exit Cutout
50000 FC	24000 FC	53-691-00	Overwing Emergency Exit Cutout
50000 FC	24000 FC	53-707-00	Longitudinal Lap Splice
50000 FC	24000 FC	53-707-10	Longitudinal Lap Splice
50000 FC	24000 FC	53-708-00	Longitudinal Lap Splice
50000 FC	24000 FC	53-708-10	Longitudinal Lap Splice
50000 FC	24000 FC	53-711-00	Window Belt STA 727 to 888
50000 FC	24000 FC	53-713-00	Aft Cargo Door Surround Structure
50000 FC	24000 FC	53-713-01	Aft Cargo Door Surround Structure
50000 FC	24000 FC	53-722-10	Mid Exit Door Surround Structure
50000 FC	24000 FC	53-738-00	Window Belt STA 888 to 927
50000 FC	24000 FC	53-743-00	Bulkhead STA 1016
50000 FC	24000 FC	53-744-00	Bulkhead STA 1016
50000 FC	24000 FC	53-746-00	Bulkhead STA 1016
50000 FC	24000 FC	53-748-00	Bulkhead STA 1016
50000 FC	24000 FC	53-749-00	Bulkhead STA 1016
50000 FC	24000 FC	53-753-00	Jackscrew Fitting Lugs
50000 FC	24000 FC	53-758-00	Horizontal Stabilizer Pivot Fitting
50000 FC	24000 FC	53-761-00	STA 1042 Bulkhead Straps
50000 FC	24000 FC	53-762-00	STA 1042 Bulkhead Intercostals
50000 FC	24000 FC	53-768-00	STA 1042 Bulkhead Chord Splice



737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

INTERVAL		MPD ITEM NUMBER	TASK TITLE
THRESHOLD	REPEAT		
50000 FC	24000 FC	53-774-00	APU Inlet Enclosure Installation - Pressure Panels
50000 FC	24000 FC	53-775-00	APU Enclosure Installation
50000 FC	30000 FC	53-618-00	FWD Entry Door FWD Edge Frame Stops
50000 FC	33000 FC	53-750-00	Vertical Fin Front Spar Fitting Bulkhead Attachment - STA 1016
50000 FC	36000 FC	53-600-00	Longitudinal Lap Splice
50000 FC	36000 FC	53-600-01	Longitudinal Lap Splice
50000 FC	36000 FC	53-600-20	Longitudinal Lap Splice
50000 FC	36000 FC	53-600-30	Longitudinal Lap Splice
50000 FC	36000 FC	53-600-40	Longitudinal Lap Splice
50000 FC	36000 FC	53-600-50	Longitudinal Lap Splice
50000 FC	36000 FC	53-601-50	Cutout - Crew Cabin Windows
50000 FC	36000 FC	53-601-60	Cutout - Crew Cabin Windows
50000 FC	36000 FC	53-603-10	Cutout - Forward Access Door, Forward Edge of Cutout
50000 FC	36000 FC	53-606-50	Cutout - Forward Entry Door Frame
50000 FC	36000 FC	53-622-00	FWD Entry Door Cutout
50000 FC	36000 FC	53-623-00	FWD Galley Door Cutout
50000 FC	36000 FC	53-626-00	Bulkhead, STA 294.5
50000 FC	36000 FC	53-631-00	Air Stair Door Cutout
50000 FC	36000 FC	53-634-00	Crown Skin Panel, STA 360 to 540
50000 FC	36000 FC	53-634-10	Crown Skin Panel, STA 360 to 540
50000 FC	36000 FC	53-635-00	SATCOM AERO - H Antenna Installation
50000 FC	36000 FC	53-637-00	Longitudinal Lap Splice
50000 FC	36000 FC	53-637-10	Longitudinal Lap Splice
50000 FC	36000 FC	53-639-00	Longitudinal Skin Splice



737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

INTERVAL		MPD ITEM NUMBER	TASK TITLE
THRESHOLD	REPEAT		
50000 FC	36000 FC	53-639-10	Longitudinal Skin Splice
50000 FC	36000 FC	53-643-00	Longitudinal Lap Splice
50000 FC	36000 FC	53-646-80	Forward Cargo Door Surround Structure
50000 FC	36000 FC	53-648-00	Wing to Body Lower Drag Angle
50000 FC	36000 FC	53-650-00	Wing to Body Upper Drag Angle
50000 FC	36000 FC	53-653-00	Longitudinal Lap Splice
50000 FC	36000 FC	53-653-10	Longitudinal Lap Splice
50000 FC	36000 FC	53-655-10	Longitudinal Skin Splice
50000 FC	36000 FC	53-660-00	Stiffener Attachment to Floor Beam, STA 727
50000 FC	36000 FC	53-661-00	Stringer 18 Strap Side of Body
50000 FC	36000 FC	53-662-00	Stringer 18A Chord and Links
50000 FC	36000 FC	53-669-00	Wheel Well Aft Bulkhead and Pressure Web STA 727
50000 FC	36000 FC	53-675-00	Main Landing Gear Support Frame STA 716
50000 FC	36000 FC	53-678-00	Wheel Well Frame STA 685
50000 FC	36000 FC	53-679-00	Wheel Well Frame At STA 685
50000 FC	36000 FC	53-683-00	Overwing Emergency Exit Cutout
50000 FC	36000 FC	53-686-00	Overwing Emergency Exit Cutout
50000 FC	36000 FC	53-688-00	Overwing Emergency Exit Cutout
50000 FC	36000 FC	53-689-00	Overwing Emergency Exit Cutout Skin and Frame Assembly Section at STA 616 and Stringer S-13
50000 FC	36000 FC	53-690-00	Overwing Emergency Exit Cutout Skin Assembly and Frame Outer Chord
50000 FC	36000 FC	53-694-00	Overwing Emergency Exit Cutout Structure
50000 FC	36000 FC	53-696-00	Overwing Emergency Exit Door Stops and Fittings
50000 FC	36000 FC	53-697-00	Overwing Exit Door Stops and Fittings
50000 FC	36000 FC	53-697-10	Pressure Deck Attachments to Rear Spar Extension



737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

INTERVAL		MPD ITEM NUMBER	TASK TITLE
THRESHOLD	REPEAT		
50000 FC	36000 FC	53-699-00	Crown Skin Panel STA 727 to 887
50000 FC	36000 FC	53-700-00	SATCOM Antenna Installation (Canadian Marconi and Honeywell)
50000 FC	36000 FC	53-702-00	SATCOM Antenna Installation (All except those covered by PSE 53-60-01-5)
50000 FC	36000 FC	53-704-00	Longitudinal Lap Splice
50000 FC	36000 FC	53-704-10	Longitudinal Lap Splice
50000 FC	36000 FC	53-706-00	Longitudinal Skin Splice
50000 FC	36000 FC	53-706-10	Longitudinal Skin Splice
50000 FC	36000 FC	53-710-00	Longitudinal Lap Splice
50000 FC	36000 FC	53-712-00	Aft Cargo Door Surround Structure
50000 FC	36000 FC	53-722-15	Mid Exit Door Surround Structure
50000 FC	36000 FC	53-723-00	Longitudinal Lap Splice
50000 FC	36000 FC	53-723-10	Longitudinal Lap Splice
50000 FC	36000 FC	53-726-00	Longitudinal Lap Splice
50000 FC	36000 FC	53-729-00	Aft Entry Door, Aft Edge Frame Door Stop Backup Intercostals
50000 FC	36000 FC	53-732-10	Aft Entry Door Surround Structure
50000 FC	36000 FC	53-735-00	Aft Galley Door Aft Edge Frame Door Stop Backup Intercostals
50000 FC	36000 FC	53-737-10	Aft Galley Door Surround Structure
50000 FC	36000 FC	53-741-00	Bulkhead STA 1016
50000 FC	36000 FC	53-750-10	Vertical Fin Front Spar Fitting Bulkhead Attachment - STA 1016
50000 FC	36000 FC	53-751-00	Vertical Fin Front Spar Fitting - STA 1016
50000 FC	36000 FC	53-752-00	Stringer Splice Fittings
50000 FC	36000 FC	53-754-00	Vertical Fin Rear Spar Attachment Fittings
50000 FC	36000 FC	53-755-00	Vertical Fin Rear Spar Attachment Fittings
50000 FC	36000 FC	53-756-00	Bulkhead Station 1156



737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

INTERVAL		MPD ITEM NUMBER	TASK TITLE
THRESHOLD	REPEAT		
50000 FC	36000 FC	53-757-00	Integrated Bulkhead STA 1156
50000 FC	36000 FC	53-763-00	STA 1042 Bulkhead Lugs, Links and Fittings Bulkhead Lugs
50000 FC	36000 FC	53-764-00	STA 1042 Bulkhead Lugs, Links and Fittings End Beam Lugs
50000 FC	36000 FC	53-766-00	STA 1042 Bulkhead Link Fittings
50000 FC	36000 FC	53-771-00	APU Inlet Enclosure Installation Pressure Panels
50000 FC	36000 FC	53-772-00	APU Enclosure Installation Pressure Panels
50000 FC	36000 FC	53-773-00	APU Enclosure Installation Pressure Panels
50000 FC	36000 FC	53-776-00	Section 48 Longitudinal Lap Splices S-4 Lap Splice, STA 1016 to 1042
50000 FC	36000 FC	53-777-00	Section 48 Longitudinal Lap Splices S-4 Lap Splice, STA 1016 to 1042
50000 FC	36000 FC	53-778-00	Section 48 Longitudinal Lap Splices S-24 Lap Splice, STA 1016 to 1042
50000 FC	36000 FC	53-779-00	Section 48 Butt Splice at S-9R and S-9L BS 1016 - BS 1042
50000 FC	36000 FC	53-780-00	Section 48 Butt Splice at S-9R and 9L BS 1016 - BS 1042
50000 FC	36000 FC	53-781-00	Section 48 Butt Splice at S-9R and S-9L BS 1016 - BS 1042
50000 FC	36000 FC	53-791-00	Crown Skin Panel - STA 540 to 727
50000 FC	40000 FC	53-600-21	Longitudinal Lap Splice
56000 FC	1600 FC	55-606-00	Horizontal Stabilizer Center Section Thrust Link Fittings
56000 FC	2000 FC	55-611-20	Horizontal Stabilizer Rear Spar Upper Chord at Side-of-Body
56000 FC	2000 FC	55-611-26	Horizontal Stabilizer Rear Spar Upper Chord
56000 FC	2000 FC	55-615-00	Horizontal Stabilizer Front Spar Upper Chord
56000 FC	2000 FC	55-616-00	Horizontal Stabilizer Front Spar Upper Chord, Aft Flange
56000 FC	2000 FC	55-616-11	Horizontal Stabilizer Front Spar Upper Chord, Forward Flange
56000 FC	3000 FC	55-605-00	Horizontal Stabilizer Center Section Pivot Fitting
56000 FC	3500 FC	55-611-27	Horizontal Stabilizer Rear Spar Upper Chord
56000 FC	3550 FC	55-611-22	Horizontal Stabilizer Rear Spar Upper Chord at Side-of-Body



737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

INTERVAL		MPD ITEM NUMBER	TASK TITLE
THRESHOLD	REPEAT		
56000 FC	3550 FC	55-611-23	Horizontal Stabilizer Rear Spar Upper Chord at Side-of-Body
56000 FC	3550 FC	55-613-00	Horizontal Stabilizer Rear Spar Upper Chord Terminal Fitting
56000 FC	3550 FC	55-613-01	Horizontal Stabilizer Rear Spar Upper Chord Terminal Fitting
56000 FC	4000 FC	55-600-00	Horizontal Stabilizer Center Section Rear Spar Upper Chord
56000 FC	4000 FC	55-601-00	Horizontal Stabilizer Center Section Rear Spar Upper Chord
56000 FC	4000 FC	55-616-26	Horizontal Stabilizer Front Spar Lower Chord, Aft Flange
56000 FC	4000 FC	55-636-00	Horizontal Stabilizer Center Section Rear Spar Upper Chord
56000 FC	4000 FC	57-660-00	Track #1 & #8 - Outboard Main Flap Outboard Track
56000 FC	4000 FC	57-661-00	Support, Forward Fitting Assy Flap Tracks 1, 2, 3, (6, 7, & 8)
56000 FC	4000 FC	57-662-00	Track #2 & #7 - Outboard Main Flap, Inboard Track
56000 FC	4000 FC	57-664-00	Track #3 & #6 - Inboard Main Flap, Outboard Track
56000 FC	4000 FC	57-667-00	Track #4 & #5 - Inboard Flap Support, Inboard Track
56000 FC	5000 FC	57-654-00	Strut to Wing Attachments
56000 FC	6000 FC	54-600-00	Strut to Wing Attachments
56000 FC	6000 FC	54-635-00	Thrust Link Assembly
56000 FC	6000 FC	54-636-00	Thrust Link Pin
56000 FC	6000 FC	54-638-00	Evener Bar Assembly - Outboard Lugs
56000 FC	6000 FC	54-640-00	Strut Attach Bolts (Forward and Aft Mounts)
56000 FC	6000 FC	55-607-00	Horizontal Stabilizer Center Section Jackscrew Fitting
56000 FC	6000 FC	55-616-05	Horizontal Stabilizer Front Spar Upper Chord - Web Flange
56000 FC	6000 FC	55-616-06	Horizontal Stabilizer Front Spar Upper Chord - Web Flange
56000 FC	6000 FC	55-616-09	Horizontal Stabilizer Front Spar Upper Chord - Web Flange
56000 FC	6000 FC	55-616-10	Horizontal Stabilizer Front Spar Upper Chord, Forward Flange
56000 FC	6000 FC	55-616-12	Horizontal Stabilizer Front Spar Upper Chord - Web Flange



737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

INTERVAL		MPD ITEM NUMBER	TASK TITLE
THRESHOLD	REPEAT		
56000 FC	8000 FC	55-646-00	Horizontal Stabilizer Center Section Primary Beam Chord to Web Attachment
56000 FC	9000 FC	54-615-00	Lower Spar Chord, Web Only
56000 FC	9000 FC	54-619-00	Lower Spar Chord - Typical Frame Detail, Vertical Leg (Direction 1)
56000 FC	9000 FC	54-619-01	Lower Spar Chord - Typical Frame Detail, Vertical Leg (Direction 2)
56000 FC	9000 FC	54-626-00	Upper Spar Chord
56000 FC	9000 FC	54-627-00	Upper Spar Chord near Cutouts (Direction 1)
56000 FC	9000 FC	54-627-01	Upper Spar Chord near Cutouts (Direction 2)
56000 FC	9000 FC	54-630-00	Upper and Lower Spar Chords
56000 FC	9000 FC	54-630-01	Upper and Lower Spar Chords
56000 FC	9000 FC	54-633-00	R3/R4 First Fastener Row - Vertical Leg
56000 FC	9000 FC	55-613-10	Horizontal Stabilizer Rear Spar Upper Chord Terminal Fitting
56000 FC	9000 FC	55-614-00	Horizontal Stabilizer Rear Spar Terminal Fitting
56000 FC	9000 FC	55-633-00	Horizontal Stabilizer Lower Inspar Skin
56000 FC	9000 FC	55-638-00	Horizontal Stabilizer Center Section Primary and Thrust Beams
56000 FC	9000 FC	55-639-00	Horizontal Stabilizer Center Section Primary and Thrust Beams
56000 FC	9000 FC	55-640-00	Horizontal Stabilizer Center Section Primary and Thrust Beams
56000 FC	9000 FC	55-664-00	Rudder Hinge Fittings
56000 FC	9000 FC	57-670-00	Rear Spar Chord at Inbd and Outbd Cutout
56000 FC	9000 FC	57-670-10	Rear Spar Chord at Inbd and Outbd Pushrod Cutout
56000 FC	9000 FC	57-670-11	Rear Spar Chord at Inbd and Outbd Pushrod Cutout
56000 FC	9000 FC	57-670-20	Rear Spar Upper Chord
56000 FC	9000 FC	57-671-00	Inboard Main Flap - In-Spar Upper Skin Panels
56000 FC	9000 FC	57-676-20	Inboard Main Flap
56000 FC	9000 FC	57-679-00	Front Spar Assembly - Outbd Main Flap



737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

INTERVAL		MPD ITEM NUMBER	TASK TITLE
THRESHOLD	REPEAT		
56000 FC	9000 FC	57-686-00	Rear Spar Spigot Fitting - Outbd Main Flap
56000 FC	10000 FC	55-604-00	Horizontal Stabilizer Center Section Pivot Fitting
56000 FC	11000 FC	57-609-10	Wing Center Section Floor Beam Upper Chord
56000 FC	11600 FC	57-642-10	Lower Skin Panel at Main Landing Gear Outboard Support Fittings
56000 FC	12000 FC	55-611-24	Horizontal Stabilizer Rear Spar Upper Chord at Side-of-Body
56000 FC	12000 FC	55-611-25	Horizontal Stabilizer Rear Spar Upper Chord at Side-of-Body
56000 FC	12000 FC	55-616-32	Horizontal Stabilizer Front Spar Web
56000 FC	12000 FC	55-618-00	Horizontal Stabilizer Front Spar Terminal Fitting
56000 FC	12000 FC	55-627-00	Horizontal Stabilizer Trailing Edge Elevator Hinge Rib
56000 FC	13000 FC	55-645-00	Horizontal Stabilizer Center Section Thrust Beams
56000 FC	14000 FC	55-643-00	Horizontal Stabilizer Center Section Thrust Beams
56000 FC	14000 FC	57-601-20	Double Plus Chord Upper Vertical Flange at Body Stringer 18A Interface
56000 FC	15000 FC	55-611-14	Horizontal Stabilizer Rear Spar Lower Chord
56000 FC	15000 FC	55-611-28	Horizontal Stabilizer Rear Spar Upper Chord
56000 FC	15000 FC	55-611-34	Horizontal Stabilizer Rear Spar Upper Chord
56000 FC	15000 FC	55-611-50	Horizontal Stabilizer Rear Spar Web
56000 FC	15000 FC	55-611-52	Horizontal Stabilizer Rear Spar Web
56000 FC	15000 FC	55-616-07	Horizontal Stabilizer Front Spar Upper Chord - Web Flange
56000 FC	15000 FC	55-616-08	Horizontal Stabilizer Front Spar Upper Chord - Web Flange
56000 FC	15000 FC	55-616-30	Horizontal Stabilizer Front Spar Web
56000 FC	18000 FC	54-610-00	Lower Spar Chord - Typical Exposed Detail
56000 FC	18000 FC	54-611-00	Lower Spar Chord at Fire Seal Depressor Bracket
56000 FC	18000 FC	54-611-01	Lower Spar Chord at Fire Seal Depressor Bracket
56000 FC	18000 FC	54-612-00	Lower Spar Chord - Bracket



737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

INTERVAL		MPD ITEM NUMBER	TASK TITLE
THRESHOLD	REPEAT		
56000 FC	18000 FC	54-613-00	Lower Spar Chord at Frames with Brackets
56000 FC	18000 FC	54-614-00	Lower Spar Chord (Direction 1)
56000 FC	18000 FC	54-614-01	Lower Spar Chord (Direction 2)
56000 FC	18000 FC	54-616-00	Lower Spar Chord, Chord Only
56000 FC	18000 FC	54-617-00	Lower Spar Chord - Compression Pad Bracket, Horizontal Leg
56000 FC	18000 FC	54-617-01	Lower Spar Chord - Compression Pad Bracket, Horizontal Leg
56000 FC	18000 FC	54-618-00	Lower Spar Chord - Compression Pad Bracket, Vertical Leg
56000 FC	18000 FC	54-620-00	Lower Spar Chord - Typical Frame Detail, Horizontal Leg
56000 FC	18000 FC	54-621-00	Lower Spar Chord
56000 FC	18000 FC	54-623-00	Mid Strut Bulkhead
56000 FC	18000 FC	54-624-00	Side Skin Cutouts
56000 FC	18000 FC	54-628-00	Upper Spar, R1 - Fitting and Upper Spar Web Joints, Chord Only (Direction 1)
56000 FC	18000 FC	54-628-01	Upper Spar, R1 - Fitting and Upper Spar Web Joints, Chord Only (Direction 2)
56000 FC	18000 FC	54-629-00	Upper Spar, R1 - Fitting and Upper Spar Joints, Web Only
56000 FC	18000 FC	54-631-00	Upper Spar Chord
56000 FC	18000 FC	54-632-00	Upper Spar Chord
56000 FC	18000 FC	54-632-01	Upper Spar Chord
56000 FC	18000 FC	54-634-00	Forward Engine Mount Hanger
56000 FC	18000 FC	54-637-00	Aft Engine Mount Assembly
56000 FC	18000 FC	55-603-00	Horizontal Stabilizer Center Section Rear Spar Upper Chord
56000 FC	18000 FC	55-611-30	Horizontal Stabilizer Rear Spar Upper Chord
56000 FC	18000 FC	55-611-38	Horizontal Stabilizer Rear Spar Upper Chord
56000 FC	18000 FC	55-611-44	Horizontal Stabilizer Rear Spar Web
56000 FC	18000 FC	55-611-46	Horizontal Stabilizer Rear Spar Web



737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

INTERVAL		MPD ITEM NUMBER	TASK TITLE
THRESHOLD	REPEAT		
56000 FC	18000 FC	55-612-00	Horizontal Stabilizer Rear Spar Upper and Failsafe Chord Lugs
56000 FC	18000 FC	55-616-28	Horizontal Stabilizer Front Spar Web
56000 FC	18000 FC	55-616-34	Horizontal Stabilizer Front Spar Web
56000 FC	18000 FC	55-616-36	Horizontal Stabilizer Front Spar Web
56000 FC	18000 FC	55-617-00	Horizontal Stabilizer Front Spar Upper Chord
56000 FC	18000 FC	55-625-00	Horizontal Stabilizer Elevator Hinge Ribs
56000 FC	18000 FC	55-626-00	Horizontal Stabilizer Elevator Hinge Ribs
56000 FC	18000 FC	55-631-00	Horizontal Stabilizer Elevator Hinge Ribs
56000 FC	18000 FC	55-631-10	Horizontal Stabilizer Upper Inspar Skin
56000 FC	18000 FC	55-634-00	Horizontal Stabilizer Center Section Front Spar Upper Chord
56000 FC	18000 FC	55-647-00	Elevator Hinge Fittings
56000 FC	18000 FC	55-649-00	Elevator Horn Balance Weight Support Structure
56000 FC	18000 FC	55-651-00	183A8700 Hinge/Mast Arm Fitting Upper Flange
56000 FC	18000 FC	55-652-00	183A8700 Hinge/Mast Arm Fitting Upper Flange
56000 FC	18000 FC	55-665-00	Rudder Actuator Fittings
56000 FC	18000 FC	55-666-00	737NG Rudder Balance Arm
56000 FC	18000 FC	57-601-00	Double Plus Chord at Stringer 18A Interface
56000 FC	18000 FC	57-601-10	Double Plus Chord Vertical Flange at Body Stringer 18A Interface
56000 FC	18000 FC	57-601-27	Double Plus Chord Upper Vertical Flange
56000 FC	18000 FC	57-601-28	Double Plus Chord Upper Vertical Flange
56000 FC	18000 FC	57-610-01	Wing Center Section Floor Beam Lower Chord Over Pressure Deck
56000 FC	18000 FC	57-611-10	Wing Center Section Floor Beams Lower Chord - Overwing
56000 FC	18000 FC	57-648-00	Wing Upper Skin Tab at R1 Nacelle Fitting
56000 FC	18000 FC	57-658-00	Inboard Actuator Support Fittings



737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

INTERVAL		MPD ITEM NUMBER	TASK TITLE
THRESHOLD	REPEAT		
56000 FC	18000 FC	57-659-00	Gear Beam Inboard Support Fitting
56000 FC	18000 FC	57-660-10	Track #1 & #8 - Outboard Main Flap, Outboard Track
56000 FC	18000 FC	57-663-00	Track #2 & #7 - Outboard Main Flap, Inboard Track
56000 FC	18000 FC	57-665-00	Track #3 & #6 - Inboard Flap Support, Outboard Track
56000 FC	18000 FC	57-667-10	Track #4 & #5 - Inboard Flap Support, Inboard Track
56000 FC	18000 FC	57-668-00	Inboard Main Flap Fitting Assembly Fwd, Inboard Track
56000 FC	18000 FC	57-669-00	Front Spar Upper Chord
56000 FC	18000 FC	57-669-20	Front Spar Cutout/Front Spar Fitting
56000 FC	18000 FC	57-672-00	Inbd Main Flap, Inbd Torque Tube Rib
56000 FC	18000 FC	57-673-00	Inbd Main Flap - Torque Tube
56000 FC	18000 FC	57-676-00	Inbd Flap - No. 4 & No.5 Carriage Assy
56000 FC	18000 FC	57-677-00	No. 1 & No. 8 Carriage Assembly
56000 FC	18000 FC	57-677-10	No. 1 & No. 8 Carriage Assembly
56000 FC	18000 FC	57-678-00	No. 2 & No. 7 Carriage Assembly
56000 FC	18000 FC	57-678-10	No. 2 & No. 7 Carriage Assembly
56000 FC	18000 FC	57-682-00	Rear Spar - Outbd Main Flap
56000 FC	18000 FC	57-685-00	Front Spar Spigot Fitting - Outbd Main Flap
56000 FC	18000 FC	57-688-00	Hinge / Actuator Fittings, Inboard Spoiler #6 and #7
56000 FC	21000 FC	55-611-36	Horizontal Stabilizer Rear Spar Upper Chord
56000 FC	21000 FC	55-614-10	Horizontal Stabilizer Rear Spar Upper Chord Terminal Fitting
56000 FC	21000 FC	55-641-00	Horizontal Stabilizer Center Section Thrust Beams
56000 FC	22600 FC	57-607-30	Wing Center Section Rear Spar Keel Beam Stiffeners
56000 FC	24000 FC	55-611-10	Horizontal Stabilizer Rear Spar Lower Chord
56000 FC	24000 FC	55-611-12	Horizontal Stabilizer Rear Spar Lower Chord



737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

INTERVAL		MPD ITEM NUMBER	TASK TITLE
THRESHOLD	REPEAT		
56000 FC	24000 FC	55-611-16	Horizontal Stabilizer Rear Spar Lower Chord
56000 FC	24000 FC	55-611-32	Horizontal Stabilizer Rear Spar Upper Chord
56000 FC	24000 FC	55-611-40	Horizontal Stabilizer Rear Spar Upper Chord
56000 FC	24000 FC	55-611-48	Horizontal Stabilizer Rear Spar Web
56000 FC	24000 FC	55-616-14	Horizontal Stabilizer Front Spar Upper Chord, Web Flange
56000 FC	24000 FC	55-616-16	Horizontal Stabilizer Front Spar Lower Chord - Forward Flange
56000 FC	24000 FC	55-616-20	Horizontal Stabilizer Front Spar Lower Chord, Forward Flange
56000 FC	24000 FC	55-616-24	Horizontal Stabilizer Front Spar Lower Chord, Forward Flange
56000 FC	24000 FC	55-628-00	Horizontal Stabilizer, Trailing Edge Hinge Rib to Rear Spar Attachment
56000 FC	24000 FC	55-630-00	Horizontal Stabilizer Elevator Hinge Ribs
56000 FC	24000 FC	55-648-00	Elevator Mast Arm Assembly (Elevator Actuator Fitting)
56000 FC	24000 FC	55-654-00	183A8300 Bridge Fitting Upper/Lower Flange
56000 FC	24000 FC	55-658-00	Vertical Fin - Rear Spar
56000 FC	24000 FC	55-662-00	Rudder Hinge Ribs
56000 FC	24000 FC	57-610-00	Wing Center Section Floor Beam Upper Chord
56000 FC	27000 FC	55-644-00	Horizontal Stabilizer Center Section Thrust Beam Intersection
56000 FC	28000 FC	57-642-00	Lower Skin Panel at Main Landing Gear Outboard Support Fittings
56000 FC	30000 FC	55-629-00	Horizontal Stabilizer Elevator Hinge Ribs
56000 FC	34000 FC	55-642-00	Horizontal Stabilizer Center Section Thrust Beams
56000 FC	36000 FC	54-622-00	Forward Engine Mount Bulkhead
56000 FC	36000 FC	54-625-00	Strut Side Skin
56000 FC	36000 FC	55-602-00	Horizontal Stabilizer Center Section Rear Spar Upper Chord
56000 FC	36000 FC	55-608-00	Horizontal Stabilizer Rear Spar Lower Chord
56000 FC	36000 FC	55-609-00	Horizontal Stabilizer Rear Spar Lower Chord



737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

INTERVAL		MPD ITEM NUMBER	TASK TITLE
THRESHOLD	REPEAT		
56000 FC	36000 FC	55-610-00	Horizontal Stabilizer Rear Spar Lower Chord
56000 FC	36000 FC	55-611-00	Horizontal Stabilizer Rear Spar Lower Chord
56000 FC	36000 FC	55-611-18	Horizontal Stabilizer Rear Spar Lower Chord
56000 FC	36000 FC	55-611-42	Horizontal Stabilizer Rear Spar Upper Chord
56000 FC	36000 FC	55-614-12	Horizontal Stabilizer Rear Spar Lower Chord
56000 FC	36000 FC	55-616-18	Horizontal Stabilizer Front Spar Lower Chord, Aft Flange
56000 FC	36000 FC	55-616-22	Horizontal Stabilizer Front Spar Lower Chord, Aft Flange
56000 FC	36000 FC	55-618-10	Horizontal Stabilizer Front Spar Lower Chord
56000 FC	36000 FC	55-619-00	Horizontal Stabilizer Elevator Hinge Ribs
56000 FC	36000 FC	55-620-00	Horizontal Stabilizer Elevator Hinge Ribs
56000 FC	36000 FC	55-621-00	Horizontal Stabilizer Trailing Edge Hinge Plate Lower Forward Lug
56000 FC	36000 FC	55-622-00	Horizontal Stabilizer Elevator Hinge Ribs
56000 FC	36000 FC	55-623-01	Horizontal Stabilizer Elevator Hinge Ribs Trailing Edge Clevis
56000 FC	36000 FC	55-624-00	Horizontal Stabilizer Elevator Hinge Ribs
56000 FC	36000 FC	55-635-00	Horizontal Stabilizer Center Section Rear Spar Lugs
56000 FC	36000 FC	55-637-00	Horizontal Stabilizer Center Section Front Spar Upper Chord
56000 FC	36000 FC	55-655-00	183A8300 Bridge Fitting Upper/Lower Flange
56000 FC	36000 FC	55-656-00	183A1400 - Bracket Assy - Tab Control Mechanism, Elevator
56000 FC	36000 FC	55-657-00	183A1400 - Bracket Assy - Tab Control Mechanism, Elevator
56000 FC	36000 FC	55-659-00	Vertical Fin - Rear Spar
56000 FC	36000 FC	55-660-00	Vertical Fin - Closure Rib
56000 FC	36000 FC	55-661-00	Vertical Fin - Closure Rib
56000 FC	36000 FC	55-663-00	Rudder Hinge Ribs
56000 FC	36000 FC	57-600-00	Upper Side of Body Splice



737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

INTERVAL		MPD ITEM NUMBER	TASK TITLE
THRESHOLD	REPEAT		
56000 FC	36000 FC	57-611-00	Wing Center Section Floor Beams Lower Chord - Overwing
56000 FC	36000 FC	57-666-00	No. 4 and No. 5 Support, Aft Link Pins
56000 FC	36000 FC	57-669-10	Front Spar, Inboard Main Flap
56000 FC	36000 FC	57-670-30	Rear Spar Upper Chord
56000 FC	36000 FC	57-674-00	Inbd Main Flap, Rear Spar
56000 FC	36000 FC	57-675-00	Carriage Assembly No. 3 & No. 6 - Inboard Main Flap, Outboard Carriage.
56000 FC	36000 FC	57-680-00	Front Spar Assembly - Outbd Main Flap
56000 FC	36000 FC	57-681-00	Rear Spar - Outbd Main Flap
56000 FC	36000 FC	57-683-00	Rear Spar - Outbd Main Flap
56000 FC	36000 FC	57-684-00	Lower Skin - Outbd Main Flap, Front Spar and Rear Spar LWR Chord - LWR Skin Interface
56000 FC	75000 FC	54-639-00	Aft Engine Mount Evener Bar - Mid Span
56000 FC	75000 FC	54-640-01	Strut Attach Bolts (Forward and Aft Mounts)
75000 FC	75000 FC	32-050-01	Left Main Landing Gear Discard
75000 FC	75000 FC	32-050-02	Right Main Landing Gear Discard
75000 FC	75000 FC	32-100-00	Discard Nose Gear
150 FH	150 FH	73-020-01	FMC CDU for Left Engine Faults
150 FH	150 FH	73-020-02	FMC CDU for Right Engine Faults
300 FH	300 FH	23-040-00	Voice Recorder
300 FH	300 FH	73-030-01	Remove the Left Engine Hydro Mechanical Unit for Inspection
300 FH	300 FH	73-030-02	Remove the Right Engine Hydro Mechanical Unit for Inspection
500 FH	500 FH	72-320-01	Left Engine Fwd Sump, Aft Sump, AGB/TGB MCD or DMS detectors and scavenge screens
500 FH	500 FH	72-320-02	Right Engine Fwd Sump, Aft Sump, AGB/TGB MCD or DMS detectors and scavenge screens
600 FH	600 FH	29-030-01	EMDP Case Drain Filter
600 FH	600 FH	29-030-02	EMDP Case Drain Filter



737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

INTERVAL		MPD ITEM NUMBER	TASK TITLE
THRESHOLD	REPEAT		
600 FH	600 FH	29-090-00	A & B System Return Filter Module
600 FH	600 FH	33-010-00	Emergency Lights
750 FH	750 FH	27-162-00	Flap Skew and Asymmetry System
800 FH	800 FH	24-020-01	Left IDG Delta P Indicator (DPI)
800 FH	800 FH	24-020-02	Right IDG Delta P Indicator (DPI)
800 FH	800 FH	24-030-01	Left IDG Oil Level
800 FH	800 FH	24-030-02	Right IDG Oil Level
1000 FH	1000 FH	24-120-00	Restore the Main and Auxiliary Batteries
1200 FH	1200 FH	21-150-00	Cabin Temperature Sensor Filters
1200 FH 180 DY	1200 FH 180 DY	29-230-00	Standby Rudder System
1200 FH	1200 FH	32-300-00	Brake Accumulator Precharge Pressure
1250 FH	1250 FH	27-224-00	Standby Hydraulic System Leading Edge Uncommanded Motion
1600 FH 1 YR	1600 FH 1 YR	27-102-00	Stabilizer Trim Actuator Lubrication
1800 FH	1800 FH	24-010-01	IDG Oil - Left IDG
1800 FH	1800 FH	24-010-02	IDG Oil - Right IDG
1800 FH	1800 FH	24-040-01	Left IDG Charge and Scavenge Filters
1800 FH	1800 FH	24-040-02	Right IDG Charge and Scavenge Filters
2000 FH	2000 FH	52-170-00	Airstair System Inspection
2400 FH	2400 FH	29-050-01	EDP Case Drain Filter
2400 FH	2400 FH	29-050-02	EDP Case Drain Filter
2400 FH	2400 FH	35-050-00	Flight Crew Oxygen Cylinder
2400 FH	2400 FH	35-052-00	Flight Crew Oxygen Cylinder
2500 FH	2500 FH	21-140-01	Water Separator Indication Disk



737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

INTERVAL		MPD ITEM NUMBER	TASK TITLE
THRESHOLD	REPEAT		
2500 FH	2500 FH	21-140-02	Water Separator Indication Disk
2500 FH	2500 FH	38-030-00	Restore Vacuum Blower Filter
2500 FH	2500 FH	38-090-00	Waste Tank Water Separator
2500 FH	2500 FH	71-010-01	Inlet Cowl - Inner Surface
2500 FH	2500 FH	71-010-02	Inlet Cowl - Inner Surface
2500 FH	2500 FH	72-020-01	Left Engine Inlet and Fan Blades
2500 FH	2500 FH	72-020-02	Right Engine Inlet and Fan Blades
3000 FH	3000 FH	25-090-00	Inspect Attendant Seat Harness
3000 FH	3000 FH	25-100-00	Check Attendant Seat Harness
3000 FH	3000 FH	26-410-00	Cargo Fire Protection Operation Check
3000 FH	3000 FH	27-216-00	Autoslat System
3000 FH	3000 FH	31-160-02	First Officer's Display Units Ventilation Hole Cleaning
3000 FH	3000 FH	38-100-00	Waste Tank Water Separator
3600 FH	3600 FH	24-050-01	Left QAD
3600 FH	3600 FH	24-050-02	Right QAD
3600 FH	3600 FH	26-050-00	Engine Fire Bottle Pressure Gauges
3600 FH	3600 FH	78-120-01	Left Engine Bite Check the EAU
3600 FH	3600 FH	78-120-02	Right Engine Bite Check the EAU
4000 FH	4000 FH	23-056-00	RIPS Maintenance Port
4000 FH	4000 FH	25-040-00	Inspect Passenger Seat Belts
4000 FH	4000 FH	25-130-00	Lavatory Waste Compartment Flapper Door and Spring and Access Door
4000 FH	4000 FH	27-026-01	Left Wing Aileron Lubrication
4000 FH	4000 FH	27-026-02	Right Wing Aileron Lubrication



737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

INTERVAL		MPD ITEM NUMBER	TASK TITLE
THRESHOLD	REPEAT		
4000 FH 24 MO	4000 FH 24 MO	27-136-01	Left Wing Flap Skew Sensor Mechanism Lubrication
4000 FH 24 MO	4000 FH 24 MO	27-136-02	Right Wing Flap Skew Sensor Mechanism Lubrication
4000 FH	4000 FH	27-182-00	Lubricate the Spoiler Mechanical Control Path (Spoiler Mixer)
4000 FH	4000 FH	27-182-01	Left Wing Spoiler Mechanical Control Path Lubrication
4000 FH	4000 FH	27-182-02	Right Wing Spoiler Mechanical Control Path Lubrication
4000 FH	4000 FH	29-070-00	Reservoir Pressurization Module Filter
4000 FH	4000 FH	52-340-00	Main Deck Cargo Door Unlock Switch
4000 FH 1600 FC	4000 FH 1600 FC	72-025-01	Lubricate Left Engine Fan Blades Dovetail.
4000 FH 1600 FC	4000 FH 1600 FC	72-025-02	Lubricate Right Engine Fan Blades Dovetail.
5000 FH	5000 FH	26-420-00	Main Deck Cargo Compartment Ceiling Grill Cleaning
5000 FH	5000 FH	26-430-00	Operationally Check the Forward Galley Smoke Detector
5000 FH	5000 FH	26-440-00	Forward Galley Smoke Detector Grill Cleaning
5000 FH	5000 FH	27-056-00	Standby Rudder Power Control Unit
5000 FH	5000 FH	27-154-00	Flap Load Relief System
5000 FH	5000 FH	27-191-00	Speedbrake Autostow System Functional Check
5000 FH	5000 FH	27-215-03	Spoiler Mechanical Control Path
5000 FH	5000 FH	27-218-00	Leading Edge Uncommanded Motion Protection
5000 FH	5000 FH	29-080-00	EMDP Ground Fault Protection System
5000 FH	5000 FH	52-100-00	Forward and Aft Cargo Door Seal
5000 FH	5000 FH	52-200-00	Door Sensor Check
5000 FH	5000 FH	78-110-01	Left Engine T/R Sync Lock
5000 FH	5000 FH	78-110-02	Right Engine T/R Sync Lock



737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

INTERVAL		MPD ITEM NUMBER	TASK TITLE
THRESHOLD	REPEAT		
6000 FH	6000 FH	20-110-01	Engine Harness (Cowl Open) - Left Engine
6000 FH	6000 FH	20-110-02	Engine Harness (Cowl Open) - Right Engine
6000 FH	6000 FH	21-015-00	Recirculation Fan Check Valve(s)
6000 FH	6000 FH	21-180-00	Pack Supply Air Cleaner System
6000 FH	6000 FH	23-080-00	Oxygen Mask Microphone
6000 FH	6000 FH	25-070-00	Inspect Passenger Seat Back Recline Mechanisms
6000 FH	6000 FH	26-411-00	Cargo Fire Protection Air supply Shutoff Valves Operational Check
6000 FH	6000 FH	26-412-00	Cargo Fire Protection Mix Manifold Exhaust Shutoff Valves Operational Check
6000 FH 2 YR	6000 FH 2 YR	27-040-00	Feel and Centering Spring Lubrication
6000 FH	6000 FH	27-046-00	Rudder PCU and Hinge Lubrication
6000 FH	6000 FH	27-070-00	Elevator Lubrication
6000 FH	6000 FH	27-086-00	Elevator Tab Control
6000 FH	6000 FH	27-114-00	Control Column Switching Module
6000 FH	6000 FH	27-186-00	Speedbrake Lever No-Back Brake
6000 FH	6000 FH	27-187-00	Operationally Check the Speedbrake Handle Stop
6000 FH	6000 FH	27-215-01	Left Wing Spoiler Actuators
6000 FH	6000 FH	27-215-02	Right Wing Spoiler Actuators
6000 FH	6000 FH	27-225-01	Left Wing Leading Edge Flap and Slat Actuators and Actuation Mechanism
6000 FH	6000 FH	27-225-02	Right Wing Leading Edge Flap and Slat Actuators and Actuation Mechanism
6000 FH	6000 FH	31-020-00	Cabin Pressure Switch
6000 FH	6000 FH	31-040-00	Landing Gear Logic Module to the AWM Systems 1 and 2
6000 FH	6000 FH	31-050-00	Takeoff Warning for the Aural Warning System
6000 FH	6000 FH	31-160-01	Captain's Display Units Ventilation Hole Cleaning



737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

INTERVAL		MPD ITEM NUMBER	TASK TITLE
THRESHOLD	REPEAT		
6000 FH	6000 FH	35-010-00	Flight Crew Oxygen Mask/Regulator
6000 FH	6000 FH	35-011-00	Gaseous Oxygen Mask/Regulator Operational Check
6000 FH	6000 FH	35-012-00	Operational Check Each Cylinder Oxygen Mask/Regulator
6000 FH	6000 FH	35-167-00	Check Valve Operational Check
6000 FH	6000 FH	52-050-00	Service and Entry Door Seals
6000 FH	6000 FH	52-390-00	Flight Deck Door Seals for Condition and Security
6000 FH	6000 FH	73-010-01	Replace the Left Engine Fuel Filter
6000 FH	6000 FH	73-010-02	Replace the Right Engine Fuel Filter
6400 FH 2 YR	6400 FH 2 YR	27-110-00	Stabilizer Trim Jackscrew Inspection
6500 FH	6500 FH	38-060-00	Replace Bleed Air In-Line Filter
6500 FH	6500 FH	47-200-00	NGS Drain - Fluid Accumulation
6500 FH	6500 FH	47-220-00	NEA distribution lines inspection
7000 FH	7000 FH	25-020-00	Flight Compartment Crew Seat Harnesses, Straps, and Belts
7000 FH	7000 FH	25-030-00	Check Captain, First Officer, & First Observer Seat Harness Inertia Reels
7000 FH	7000 FH	27-196-00	Functionally Check the Spoiler Electrical Control System Relays for Continuity
7500 FH	7500 FH	21-010-00	Recirculation Fan Hepa Filter(s)
7500 FH	7500 FH	21-040-00	E/E Cooling Supply Fan Filter
7500 FH	7500 FH	25-010-01	Captains Seat Tracks and Locking Mechanism
7500 FH	7500 FH	25-010-02	First Officer seat tracks and locking mechanism
7500 FH	7500 FH	26-010-00	Lavatory Smoke Detector
7500 FH	7500 FH	26-020-00	Lavatory Smoke Detector Grill Cleaning
7500 FH	7500 FH	26-300-00	Lavatory Fire Bottle Fusible Tips and Discharge
7500 FH	7500 FH	26-310-00	Lavatory Heat Sensitive Tape



737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

INTERVAL		MPD ITEM NUMBER	TASK TITLE
THRESHOLD	REPEAT		
7500 FH	7500 FH	26-370-00	Cargo Fire Extinguishing Arm/Discharge Switches
7500 FH	7500 FH	26-400-00	Cargo Fire Extinguishing 60-Minute Timer
7500 FH	7500 FH	27-107-00	Stabilizer Trim Brake Servicing
7500 FH	7500 FH	27-178-00	Alternate Flap Drive Gearbox Servicing
7500 FH	7500 FH	27-214-00	Leading Edge Standby Actuation
7500 FH	7500 FH	28-050-00	ENGINE FUEL SUCTION FEED
7500 FH	7500 FH	28-054-00	GFI Relay Check
7500 FH	7500 FH	29-100-00	A & B System Engine Pump (EDP) Shutoff Valves
7500 FH	7500 FH	29-240-00	Leading Edge Standby Actuation
7500 FH	7500 FH	31-120-00	Download FDR Data Req'd Parameters to Check Interfacing Systems
7500 FH	7500 FH	34-070-01	Pitot Probes
7500 FH	7500 FH	78-100-01	Left Engine T/R Fire Seal
7500 FH	7500 FH	78-100-02	Right Engine T/R Fire Seal
7500 FH	7500 FH	79-010-01	Oil Supply Filter Element - Left Engine
7500 FH	7500 FH	79-010-02	Oil Supply Filter Element - Right Engine
7500 FH	7500 FH	79-040-01	Oil Scavenge Filter Element - Left Engine
7500 FH	7500 FH	79-040-02	Oil Scavenge Filter Element - Right Engine
7560 FH	7560 FH	24-060-01	Left Engine IDG Surface Air Cooled Oil Cooler
7560 FH	7560 FH	24-060-02	Right Engine IDG Surface Air Cooled Oil Cooler
7560 FH	7560 FH	26-018-00	Wing and Lower Aft Body Overheat Detection
8000 FH	8000 FH	21-020-00	Alternate E/E Cooling Supply Fan
8000 FH	8000 FH	21-030-00	Alternate E/E Cooling Exhaust Fan
8000 FH	8000 FH	27-011-00	Aileron Mechanical Components
8000 FH	8000 FH	27-013-01	Left Wing Aileron Mechanical Components



737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

INTERVAL		MPD ITEM NUMBER	TASK TITLE
THRESHOLD	REPEAT		
8000 FH	8000 FH	27-013-02	Right Wing Aileron Mechanical Components
8000 FH	8000 FH	27-033-00	Wing Aileron Tab Freeplay Inspection
8000 FH 3 YR	8000 FH 3 YR	27-034-01	Left Wing Aileron Balance Bay Seals
8000 FH 3 YR	8000 FH 3 YR	27-034-02	Right Wing Aileron Balance Bay Seals
8000 FH	8000 FH	27-050-00	Rudder PCU Pressure Reducing Valve
8000 FH	8000 FH	27-098-01	Elevator Surface Freeplay Check
8000 FH	8000 FH	28-010-00	Inspect Fuel Tanks Lower Surface - External
8000 FH	8000 FH	32-240-00	Landing Gear Transfer Valve
8000 FH	8000 FH	35-100-00	Portable Oxygen Cylinders
8000 FH	8000 FH	52-130-00	E/E Access Door Seal
8000 FH	8000 FH	52-180-00	Airstair Door Pressure Seal Inspection
9000 FH	9000 FH	21-050-00	Overboard Exhaust Valve Check
9000 FH	9000 FH	34-140-00	Integrated Standby Flight Display
10000 FH	10000 FH	27-041-00	Operational Check of the Main Rudder PCU Force Fight Monitor
10000 FH	10000 FH	27-047-00	Rudder PCU Internal Leakage Check
10000 FH	10000 FH	27-048-00	RUDDER AUTHORITY LIMITER
10000 FH	10000 FH	29-250-00	Power Transfer Unit Control System
10000 FH	10000 FH	34-070-00	Pitot Probes
11000 FH	11000 FH	27-190-00	Speedbrake Extended Light
11000 FH	11000 FH	30-010-00	Automatic Air Data Sensor Heat
11000 FH	11000 FH	52-410-00	Deny Time Delay and Deny Function
12000 FH	12000 FH	20-030-01	DET of L/HIRF protection components Outside the Pressure Vessel - Left
12000 FH	12000 FH	20-030-02	DET of L/HIRF protection components Outside the Pressure Vessel- Right



737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

INTERVAL		MPD ITEM NUMBER	TASK TITLE
THRESHOLD	REPEAT		
12000 FH	12000 FH	21-060-00	Outflow Valve Motor, Selector Panel, Indicator, Feed Back Module
12000 FH	12000 FH	21-160-00	Ozone Converters
12000 FH	12000 FH	25-045-00	Passenger Compartment Seats
12000 FH	12000 FH	25-050-00	Check Passenger Seat Break-Over Feature
12000 FH	12000 FH	26-030-00	APU Remote Fire Detection System
12000 FH	12000 FH	26-340-00	Cargo Fire Extinguishing Tubing
12000 FH	12000 FH	26-414-00	Pressurization Control Panel Outflow Valve Operational Check
12000 FH	12000 FH	27-016-00	Aileron Spring Cartridge and Transfer Mechanism
12000 FH	12000 FH	27-036-00	Rudder Aft Components
12000 FH	12000 FH	27-076-00	Elevator Power Control Unit Inspection
12000 FH	12000 FH	27-116-00	Control Column Cutout Switches
12000 FH	12000 FH	27-171-01	Left Wing Flap Drive System
12000 FH	12000 FH	27-171-02	Right Wing Flap Drive System
12000 FH	12000 FH	28-056-00	Center Tank Fuel Pump Power Failed On Protection System
12000 FH	12000 FH	28-060-01	Restore (Clean) Left Main Fuel Tank Scavenger Jet Pump
12000 FH	12000 FH	28-060-02	Restore (Clean) Right Main Fuel Tank Scavenger Jet Pump
12000 FH	12000 FH	28-060-03	Restore (Clean) the Center Fuel Tank Left and Right Water Scavenger Jet Pump
12000 FH	12000 FH	28-070-00	Functionally (Pressure Decay) Check the APU Fuel Line Shroud
12000 FH	12000 FH	29-210-00	Standby Hydraulic Pressure Filter
12000 FH	12000 FH	29-220-00	Standby Hydraulic System Case Drain Filter
12000 FH	12000 FH	29-270-00	Power Transfer Unit Pressure Filter
12000 FH	12000 FH	35-090-00	Passenger Oxygen Masks
12000 FH	12000 FH	47-300-00	Ozone Converter
12000 FH	12000 FH	47-310-00	Nitrogen generation system heat exchanger



737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

INTERVAL		MPD ITEM NUMBER	TASK TITLE
THRESHOLD	REPEAT		
12000 FH	12000 FH	78-060-01	Left Engine Drag Link's Spherical Bearing
12000 FH	12000 FH	78-060-02	Right Engine Drag Link's Spherical Bearing
12000 FH	12000 FH	78-070-01	Left Engine Blocker Doors
12000 FH	12000 FH	78-070-02	Right Engine Blocker Doors
12500 FH	12500 FH	27-043-00	Operational Check of Rudder PCU Overrides
12500 FH	12500 FH	27-044-00	Rudder PCU Internal Leakage Check
13000 FH	13000 FH	47-210-00	Center Tank Cross Vent Check Valve
14000 FH	14000 FH	27-080-00	Elevator Pitot Static Tube
15000 FH	15000 FH	20-010-01	GVI of HIRF/L Sensitive Wire Runs Outside Pressure Vessel - Left
15000 FH	15000 FH	20-010-02	GVI of HIRF/L Sensitive Wire Runs Outside Pressure Vessel - Right
15000 FH	15000 FH	20-040-01	H/L Sensitive Connectors Outside the Pressure Vessel - Left
15000 FH	15000 FH	20-040-02	HIRF/L Sensitive Connectors Outside the Pressure Vessel - Right
15000 FH	15000 FH	20-040-04	L/HIRF Protection Components Outside the Pressure Vessel - Vertical Stabilizer
15000 FH	15000 FH	20-100-00	GVI of HIRF/L Sensitive Bonding Straps (Flight Controls, Door)
15000 FH	15000 FH	20-120-01	Connector Tightness - Left Engine
15000 FH	15000 FH	20-120-02	Connector Tightness - Right Engine
15000 FH	15000 FH	20-130-01	Bonding Straps GVI - Left Engine
15000 FH	15000 FH	20-130-02	Bonding Straps GVI - Right Engine
15000 FH	15000 FH	20-140-00	HIRF/L Sensitive Connectors Inside the Empennage
15000 FH	15000 FH	21-110-01	Compressor Discharge and Turbine Inlet Overheat Switches
15000 FH	15000 FH	21-110-02	Compressor Discharge and Turbine Inlet Overheat Switches
15000 FH	15000 FH	21-120-00	Pack Overheat Switch
15000 FH	15000 FH	21-130-00	Trim Air Pressure Regulator and Shutoff Valve
15000 FH	15000 FH	26-080-00	Engine Fire Extinguishing System Squib Circuit



737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

INTERVAL		MPD ITEM NUMBER	TASK TITLE
THRESHOLD	REPEAT		
15000 FH	15000 FH	26-110-00	Engine Fire Handle for Engine Shutdown and Isolation
15000 FH	15000 FH	26-150-00	Engine Fire Extinguisher Distribution System
15000 FH	15000 FH	26-170-00	Engine Fire Extinguisher Distribution System
15000 FH	15000 FH	26-220-00	APU Fire Extinguishing System Squib Circuit
15000 FH	15000 FH	26-230-00	APU Fire Handle for APU Shutdown and Isolation
15000 FH	15000 FH	26-250-00	APU Remote Control Panel
15000 FH	15000 FH	26-280-00	APU Fire Extinguisher Distribution System
15000 FH	15000 FH	27-012-00	Aileron Transfer Mechanism
15000 FH	15000 FH	27-028-00	Aileron Feel and Centering Springs
15000 FH	15000 FH	27-030-00	Full Range Aileron Travel
15000 FH	15000 FH	27-038-00	Forward Rudder Mechanical Control Path
15000 FH	15000 FH	27-058-00	Standby Rudder PCU Attachment Points
15000 FH	15000 FH	27-060-00	Wheel to Rudder Interconnect
15000 FH	15000 FH	27-062-00	Rudder Trim Travel
15000 FH	15000 FH	27-068-00	Elevator Feel Shift Function
15000 FH	15000 FH	27-073-00	Elevator Mechanical Control Path
15000 FH	15000 FH	27-074-00	Elevator Range of Travel
15000 FH	15000 FH	27-075-01	Left Elevator Balance Weight and Tab Control Mechanism
15000 FH	15000 FH	27-075-02	Right Elevator Balance Weight and Tab Control Mechanism
15000 FH	15000 FH	27-088-00	Stall Warning System
15000 FH	15000 FH	27-094-00	Elevator Autopilot Servo Pressure Regulator
15000 FH	15000 FH	27-106-00	Secondary Stabilizer Trim Brake
15000 FH	15000 FH	27-112-00	Stabilizer Trim Limit Switches
15000 FH	15000 FH	27-118-00	Stabilizer Trim Override Switch



737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

INTERVAL		MPD ITEM NUMBER	TASK TITLE
THRESHOLD	REPEAT		
15000 FH	15000 FH	27-120-00	Stabilizer Trim Forward Mechanism
15000 FH	15000 FH	27-121-00	Forward Stabilizer Trim Mechanism and the Speedbrake Lever Assembly
15000 FH	15000 FH	27-122-00	Stabilizer Trim Switches
15000 FH	15000 FH	27-158-00	Alternate Flap Drive System
15000 FH	15000 FH	27-164-00	Flap Uncommanded Motion Protection
15000 FH	15000 FH	27-188-00	Speedbrake RTO System
15000 FH	15000 FH	28-080-00	Operationally (Bite) Check the Fuel Quantity Indicating System
15000 FH	15000 FH	28-125-00	Engine Fuel Spar and APU Shutoff Valve Battery
15000 FH	15000 FH	29-005-00	A & B Engine Driven Pump Depressurization Solenoid Valve
15000 FH	15000 FH	29-200-00	Standby Hydraulic Electric Motor Driven Pump
15000 FH	15000 FH	31-010-00	Aural Warning System
15000 FH	15000 FH	31-030-00	Mach/Airspeed System 1 and 2 Discrete Outputs
15000 FH	15000 FH	34-080-00	Static Ports
15000 FH	15000 FH	34-090-00	Pitot Systems
15000 FH	15000 FH	34-100-00	Static Systems
15000 FH	15000 FH	35-080-00	Passenger Oxygen System
15000 FH	15000 FH	35-085-00	Passenger Oxygen System Manual Actuation
15000 FH	15000 FH	47-330-00	Nitrogen Generation System Filter Element
15000 FH	15000 FH	52-140-00	Forward Access Door Seal
15000 FH	15000 FH	72-070-01	Left Engine AGB/TGB Mount Flanges and Fan Case/Frame Mounts
15000 FH	15000 FH	72-070-02	Right Engine AGB/TGB Mount Flanges and Fan Case/Frame Mounts
15000 FH	15000 FH	72-110-01	Left Engine Thrust Mount Fittings
15000 FH	15000 FH	72-110-02	Right Engine Thrust Mount Fittings
15000 FH	15000 FH	72-300-01	Left Engine Stage Aft Mounts Clevis



737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

INTERVAL		MPD ITEM NUMBER	TASK TITLE
THRESHOLD	REPEAT		
15000 FH	15000 FH	72-300-02	Right Engine Stage Aft Mounts Clevis
15000 FH	15000 FH	78-050-01	Left Engine T/R Fan Duct Walls
15000 FH	15000 FH	78-050-02	Right Engine T/R Fan Duct Walls
15000 FH	15000 FH	78-080-01	Left Engine Bullnose Seal and Retainer
15000 FH	15000 FH	78-080-02	Right Engine Bullnose Seal and Retainer
15000 FH	15000 FH	78-130-01	Left Engine "Reverser" Light Indication System
15000 FH	15000 FH	78-130-02	Right Engine "Reverser" Light Indication System
16000 FH	16000 FH	27-035-00	Wing Aileron Surface Freeplay Inspection
16000 FH	16000 FH	27-064-00	Rudder Surface Freeplay
16000 FH	16000 FH	29-020-00	Hydraulic System "A" and "B" Pressure Filter Elements (EMDP Pumps)
16000 FH	16000 FH	29-180-00	Reservoir Fill Filter
16000 FH	16000 FH	35-020-00	Flight Crew Oxygen Mask/Regulator
16000 FH	16000 FH	35-021-00	Gaseous Oxygen Mask/Regulator Functional Check
16000 FH	16000 FH	36-020-01	Precooler Control Valve and Wing TAI Solenoid - Left
16000 FH	16000 FH	36-020-02	Precooler Control Valve and Wing TAI Solenoid - Right
16000 FH	16000 FH	36-030-01	Precooler Control Valve Sensor - Left
16000 FH	16000 FH	36-030-02	Precooler Control Valve Sensor - Right
16000 FH	16000 FH	49-240-00	APU Vortex Generator Hinge Pin
17000 FH	17000 FH	21-070-00	Positive Pressure Relief Valves
18000 FH	18000 FH	20-142-01	Lightning/HIRF Protection Components Aft of E/E rack in the FWD Cargo Compartment
18000 FH	18000 FH	47-320-00	Nitrogen generation system oxygen sensor
20000 FH	20000 FH	20-050-00	DVI of HIRF/L Sensitive Connectors Inside Pressure Vessel
20000 FH	20000 FH	21-080-00	Positive Pressure Relief Valves Filters
20000 FH	20000 FH	27-194-00	Spoiler Mixer Centering Mechanism



737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

INTERVAL		MPD ITEM NUMBER	TASK TITLE
THRESHOLD	REPEAT		
22400 FH	22400 FH	27-184-00	Spoiler Ratio Changer No-Back Assembly
22500 FH	22500 FH	47-400-00	Thermal switch
24000 FH	24000 FH	28-040-00	Operationally Check Center Tank Fuel Scavenge System
24000 FH	24000 FH	29-010-00	Internal Hydraulic System Leakage
25000 FH	25000 FH	20-142-02	Lightning/HIRF Protection Components Aft of E/E rack in the FWD Cargo Compartment
25000 FH	25000 FH	27-018-00	Aileron Spring Cartridge and Transfer Mechanism
25000 FH	25000 FH	27-022-00	Aileron Power Control Units
25000 FH	25000 FH	27-024-00	Aileron PCU Internal Leakage Test
25000 FH	25000 FH	27-032-00	Aileron Wheel Forces
25000 FH	25000 FH	27-054-00	Standby Rudder PCU Internal Leakage Test
25000 FH	25000 FH	27-078-00	Elevator PCU Internal Leakage Test
25000 FH	25000 FH	27-084-00	Elevator Control Column Override
25000 FH	25000 FH	27-092-00	Elevator Input Rod Pogo's
25000 FH	25000 FH	27-104-00	Forward Stabilizer Trim Drive Train
25000 FH	25000 FH	27-108-00	Stabilizer Trim Restoration
25000 FH	25000 FH	27-156-00	Flap Load Relief System
25000 FH	25000 FH	27-166-00	Flap Lever Sensor
25000 FH	25000 FH	27-192-01	Left Wing Spoiler Actuator Override Quadrants
25000 FH	25000 FH	27-192-02	Right Wing Spoiler Actuator Override Quadrants
25000 FH	25000 FH	27-210-00	Leading Edge Slat Actuators Internal Leakage Test
25000 FH	25000 FH	27-212-00	Leading Edge Flap Actuators Internal Leakage Test
25000 FH	25000 FH	29-110-00	Nose Landing Gear (NLG) Down Line Fuse
25000 FH	25000 FH	29-120-00	Nose Landing Gear (NLG) up Line Fuse
25000 FH	25000 FH	29-130-00	Thrust Reverser A System EMDP Fuse



737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

INTERVAL		MPD ITEM NUMBER	TASK TITLE
THRESHOLD	REPEAT		
25000 FH	25000 FH	29-140-00	Leading Edge B System Fuses
25000 FH	25000 FH	29-150-00	B System Brake Fuses
25000 FH	25000 FH	29-160-00	A System Brake Fuses
25000 FH	25000 FH	29-170-00	B System Rudder Fuse
25000 FH	25000 FH	29-260-00	Power Transfer Unit
25000 FH	25000 FH	29-290-00	Leading Edge Standby Fuse
25000 FH	25000 FH	29-300-00	Thrust Reverser Standby Fuse
25000 FH	25000 FH	29-310-00	Case Drain Warning Switches
25000 FH	25000 FH	32-230-00	Main Gear Wheel Well Protection Retract Pressure Fuse
25000 FH	25000 FH	32-420-00	PSEU Operational Check
25000 FH	25000 FH	49-220-00	APU Eductor Inlet Duct
30000 FH	30000 FH	20-020-00	GVI of HIRF/L Sensitive Wire Runs Inside the Pressure Vessel
30000 FH	30000 FH	20-060-00	H/L Sensitive Connectors Inside Pressure Vessel
30000 FH	30000 FH	20-070-00	DVI of HIRF/L Sensitive Pig Tails Inside the Pressure Vessel
30000 FH	30000 FH	21-170-00	Pack Supply Air Cleaner System
30000 FH	30000 FH	52-360-00	Flight Deck Door Decompression Panel Latches/Pressure Switches
30000 FH	30000 FH	52-370-00	Flight Deck Door Decompression Panel Hinges
30000 FH	30000 FH	52-380-00	Flight Deck Door Decompression Panel Hinges
30000 FH	30000 FH	52-400-00	Flight Deck Door Decompression Panel Seals
40000 FH	40000 FH	20-142-03	Lightning/HIRF Protection Components Aft of E/E rack in the FWD Cargo Compartment
48000 FH	48000 FH	20-141-00	Lightning/HIRF Protection Components - Tail Cone (L/HIRF)
48 HR	48 HR	32-350-00	Tire Inflation Check
48 HR	48 HR	32-360-00	Nose and Main Gear Tires and Wheels
LIF LIM	LIF LIM	26-330-00	Cargo Fire Bottle Squib



737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

INTERVAL		MPD ITEM NUMBER	TASK TITLE
THRESHOLD	REPEAT		
LIF LIM	LIF LIM	35-075-00	Lavatory Oxygen CDS system cylinder
LIF LIM	LIF LIM	49-052-00	Engine Compressor Impeller
LIF LIM	LIF LIM	49-062-00	First Stage Turbine Disk
LIF LIM	LIF LIM	49-072-00	Second Stage Turbine Rotor
LIF LIM	LIF LIM	49-082-00	Turbine Shaft
LIF LIM	LIF LIM	72-030-01	Left Fan Disk
LIF LIM	LIF LIM	72-030-02	Right Fan Disk
LIF LIM	LIF LIM	72-040-01	Left Engine Booster Spool
LIF LIM	LIF LIM	72-040-02	Right Engine Booster Spool
LIF LIM	LIF LIM	72-050-01	Left Engine Fan Shaft
LIF LIM	LIF LIM	72-050-02	Right Engine Fan Shaft
LIF LIM	LIF LIM	72-130-01	Left Engine Stage 1 and 2 Spool
LIF LIM	LIF LIM	72-130-02	Right Engine Stage 1 and 2 Spool
LIF LIM	LIF LIM	72-140-01	Left Engine Stage 3 Disk
LIF LIM	LIF LIM	72-140-02	Right Engine Stage 3 Disk
LIF LIM	LIF LIM	72-150-01	Left Engine Stages 4 - 9 Spool
LIF LIM	LIF LIM	72-150-02	Right Engine Stages 4 - 9 Spool
LIF LIM	LIF LIM	72-160-01	Left Engine Front Shaft
LIF LIM	LIF LIM	72-160-02	Right Engine Front Shaft
LIF LIM	LIF LIM	72-170-01	Left Engine Rear Rotating (CDP) Seal
LIF LIM	LIF LIM	72-170-02	Right Engine Rear Rotating (CDP) Seal
LIF LIM	LIF LIM	72-220-01	Left Engine HPT Front Shaft
LIF LIM	LIF LIM	72-220-02	Right Engine HPT Front Shaft
LIF LIM	LIF LIM	72-230-01	Left HPT Front Rotating Air Seal



737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

INTERVAL		MPD ITEM NUMBER	TASK TITLE
THRESHOLD	REPEAT		
LIF LIM	LIF LIM	72-230-02	Right HPT Front Rotating Air Seal
LIF LIM	LIF LIM	72-240-01	Left Engine HPT Disk
LIF LIM	LIF LIM	72-240-02	Right Engine HPT Disk
LIF LIM	LIF LIM	72-250-01	Left Engine HPT Rear Shaft
LIF LIM	LIF LIM	72-250-02	Right Engine HPT Rear Shaft
LIF LIM	LIF LIM	72-270-01	Left Engine LPT Rotor Support
LIF LIM	LIF LIM	72-270-02	Right Engine LPT Rotor Support
LIF LIM	LIF LIM	72-280-01	Left Engine LPT Shaft
LIF LIM	LIF LIM	72-280-02	Right Engine LPT Shaft
LIF LIM	LIF LIM	72-290-01	Left Engine Stage 1, 2, 3, 4 LPT Disks
LIF LIM	LIF LIM	72-290-02	Right Engine Stage 1, 2, 3, 4 LPT Disks
6 MO	6 MO	33-090-00	Winglet Leading Edge Lens
12 MO	12 MO	25-165-00	Inspect Main Deck Cargo Compartment Panels/Liners
15 MO	15 MO	25-440-00	Emergency Alert Panels
18 MO	18 MO	52-280-00	Crew Door Seals
18 MO	18 MO	52-300-00	Main Deck Cargo Door Lubrication
18 MO	18 MO	52-305-00	Lift Linkages, Latch Cams and Lock Torque Tube Lubrications
24 MO	24 MO	25-400-00	Smoke Hoods
24 MO	24 MO	33-090-01	Winglet Leading Edge Lens
24 MO	24 MO	34-030-00	Pitot Static System Leak Check
24 MO	24 MO	34-060-00	Pitot Static System Leak Check
24 MO	24 MO	34-110-01	ATC System Functional Check
24 MO 4000 FC	24 MO 4000 FC	52-762-00	Mid Emergency Exit Door



737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

INTERVAL		MPD ITEM NUMBER	TASK TITLE
THRESHOLD	REPEAT		
24 MO 4000 FC	24 MO 4000 FC	52-764-00	Mid Emergency Exit Door
24 MO 4000 FC	24 MO 4000 FC	52-770-00	Main Deck Cargo Door
24 MO 4000 FC	24 MO 4000 FC	53-415-00	Mid Exit Structural Plug Surround
24 MO 4000 FC	24 MO 4000 FC	53-417-00	Mid Exit Structural Plug
24 MO 4000 FC	24 MO 4000 FC	53-418-00	Mid Exit Structural Plug
24 MO 4000 FC	24 MO 4000 FC	53-419-00	Mid Exit Structural Plug
24 MO 4000 FC	24 MO 4000 FC	53-490-00	Main Deck Cargo Door Cutout Frames, Fittings, Pins, and Hinges
24 MO 4000 FC	24 MO 4000 FC	53-495-00	Main Deck Cargo Door Cutout Frames, Fittings, Pins, and Hinges
36 MO	36 MO	32-085-00	Nose Landing Gear Axle inspection
36 MO	36 MO	32-200-00	Nose Gear Manual Extension
36 MO	36 MO	32-220-00	Manual Extension System
36 MO 6600 FC	36 MO 6600 FC	52-510-00	Forward Access Door Stop Fittings and Pins
36 MO 4000 FC	36 MO 4000 FC	52-540-00	E/E Equipment Compartment Access Door Stop Fittings and Pins
36 MO 4000 FC	36 MO 4000 FC	52-610-00	Entry and Galley Service Doors
36 MO 6600 FC	36 MO 6600 FC	52-670-00	Cargo Doors
36 MO 4000 FC	36 MO 4000 FC	52-730-00	Automatic Overwing Exit Doors
36 MO 4000 FC	36 MO 4000 FC	53-010-00	Fuselage Lower Lobe



737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

INTERVAL		MPD ITEM NUMBER	TASK TITLE
THRESHOLD	REPEAT		
36 MO 6600 FC	36 MO 6600 FC	53-030-00	Cargo Door Surround Structure, Fittings and Stops
36 MO 6600 FC	36 MO 6600 FC	53-310-00	Fuselage Upper Lobe Door Frames, Stops, Latches and Hinges
36 MO	36 MO	57-950-01	Winglet - Left Wing
36 MO	36 MO	57-960-02	Winglet - Right Wing
48 MO 6600 FC	48 MO 6600 FC	52-580-00	Forward Airstairs Door Stop Fittings and Pins
48 MO 6600 FC	48 MO 6600 FC	52-590-00	Forward Airstairs Door
48 MO 9000 FC	48 MO 9000 FC	54-040-01	Left Strut to Wing Attachments
48 MO 9000 FC	48 MO 9000 FC	54-040-02	Right Strut to Wing Attachments
48 MO 9000 FC	48 MO 9000 FC	54-050-01	Left Strut to Wing Attachments - Pins and Fuse Pins
48 MO 9000 FC	48 MO 9000 FC	54-050-02	Right Strut to Wing Attachments - Pins and Fuse Pins
48 MO 9000 FC	48 MO 9000 FC	57-100-01	Left Nacelle Support Fittings
48 MO 9000 FC	48 MO 9000 FC	57-100-02	Right Nacelle Support Fittings
48 MO 9000 FC	48 MO 9000 FC	57-110-01	Left Outboard Wing Lower Surface
48 MO 9000 FC	48 MO 9000 FC	57-110-02	Right Outboard Wing Lower Surface
60 MO	60 MO	38-040-00	Restore Waste Drain Ball-Valve
NOTE	NOTE	20-435-00	Restore Passenger Compartment, Sta. 360 to 663.75
NOTE	NOTE	20-445-00	Restore Passenger Compartment STA 663.75 to Aft Pressure Bulkhead
NOTE	NOTE	20-640-00	Restore Main Deck Cargo Compartment, Sta. 360 to 1016



737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

INTERVAL		MPD ITEM NUMBER	TASK TITLE
THRESHOLD	REPEAT		
NOTE	NOTE	23-060-00	ULB (Underwater Locator Beacon) for Voice Recorder
NOTE	NOTE	23-100-00	Emergency Locator Transmitter (Automatic / Fixed Type)
NOTE	NOTE	23-110-00	Emergency Locator Transmitter (Automatic / Fixed Type)
NOTE	NOTE	24-090-00	Restore the Main Battery
NOTE	NOTE	25-220-00	Emergency Escape System Operational Check
NOTE	NOTE	25-225-00	Mid-Exit Door Emergency Escape System Operational Check
NOTE	NOTE	25-240-00	Emergency Escape Slides
NOTE	NOTE	25-380-00	Emergency Flashlights
NOTE	NOTE	26-070-00	Engine Fire Bottle Squib
NOTE	NOTE	26-090-00	Engine Fire Extinguishing System Check Valve
NOTE	NOTE	26-100-00	Engine Fire Bottle Pressure Switch
NOTE	NOTE	26-120-00	Engine Fire Bottle Pressure Gauge
NOTE	NOTE	26-130-00	Engine Fire Bottle Pressure Relief Disc.
NOTE	NOTE	26-140-00	Engine Fire Bottle Weight Check
NOTE	NOTE	26-210-00	APU Fire Bottle Squib
NOTE	NOTE	26-260-00	APU Fire Bottle Pressure Switch
NOTE	NOTE	26-265-00	APU Fire Bottle Pressure Gauge
NOTE	NOTE	26-270-00	APU Fire Bottle Over Pressure Relief Disc
NOTE	NOTE	26-275-00	APU Fire Bottle Weight Check
NOTE	NOTE	26-290-00	Lavatory Fire Bottle Weight Check
NOTE	NOTE	26-360-00	Cargo Fire Bottle Pressure Switch
NOTE	NOTE	26-365-00	Cargo Fire Bottle(s) Weight Check
NOTE	NOTE	26-390-00	Cargo Fire Extinguishing System
NOTE	NOTE	26-450-00	Portable Halon Fire Extinguishers Inspection



737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

INTERVAL		MPD ITEM NUMBER	TASK TITLE
THRESHOLD	REPEAT		
NOTE	NOTE	28-100-00	Visual Inspection of Fuel Pumps
NOTE	NOTE	28-110-00	Insulation Resistance Test of Fuel Pumps
NOTE	NOTE	31-140-00	DFDR ULB OPS Check
NOTE	NOTE	31-150-00	DFDR ULB Battery Replacement
NOTE	NOTE	32-380-00	Nose Wheel Assemblies
NOTE	NOTE	32-380-01	Left Main Gear Wheel Assemblies
NOTE	NOTE	32-380-02	Right Main Gear Wheel Assemblies
NOTE	NOTE	35-070-00	Chemical Oxygen Generators
NOTE	NOTE	35-120-00	Portable Oxygen Cylinders
NOTE	NOTE	35-163-00	GASEOUS PASSENGER OXYGEN SYSTEM
NOTE	NOTE	52-160-00	Airstair System Lubrication
NOTE	NOTE	53-110-00	Passenger Compartment Floor Structure - Wet Area
NOTE	NOTE	53-360-00	Passenger Compartment Door Cutouts
NOTE	NOTE	53-380-00	Passenger Compartment Floor Structure - Wet Area
NOTE	NOTE	53-668-00	Wheel Well Aft Bulkhead
NOTE	NOTE	53-668-10	Wheel Well Aft Bulkhead
NOTE	NOTE	53-878-00	Forward Passenger Compartment - Sta 360 to Sta 663.75 Wet Areas
NOTE	NOTE	53-886-00	Aft Passenger Compartment - Sta 663.75 to Aft Pressure Bulkhead Wet Area
NOTE	NOTE	57-601-22	Double Plus Chord Upper Horizontal Flange
NOTE	NOTE	57-601-25	Double Plus Chord Upper Horizontal Flange at Stub Beams
NOTE	NOTE	57-601-30	Wing Center Section Upper Skin at Floor Beams and Shear Ties
NOTE	NOTE	57-602-00	Wing Center Section Lower Panel Typical Stringers
NOTE	NOTE	57-602-10	Wing Center Section Lower Panel Skin
NOTE	NOTE	57-603-00	Wing Center Section Lower Panel



737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

INTERVAL		MPD ITEM NUMBER	TASK TITLE
THRESHOLD	REPEAT		
NOTE	NOTE	57-603-10	Wing Center Section Lower Panel
NOTE	NOTE	57-604-00	Wing Center Section Lower Panel
NOTE	NOTE	57-605-00	Side of Body Splice, Lower Surface
NOTE	NOTE	57-605-01	Side of Body Splice, Lower Surface
NOTE	NOTE	57-605-10	Side of Body Splice, Lower Surface Skin
NOTE	NOTE	57-605-20	Side of Body Splice, Lower Surface Skin
NOTE	NOTE	57-606-00	Wing Center Section Lower Panel
NOTE	NOTE	57-606-01	Wing Center Section Lower Panel
NOTE	NOTE	57-607-00	Wing Center Section Lower Panel
NOTE	NOTE	57-607-10	Wing Center Section Rear Spar Typical Web (Crack initially hidden)
NOTE	NOTE	57-607-11	Wing Center Section Rear Spar Typical Web (Crack initially hidden)
NOTE	NOTE	57-607-20	Wing Center Section Rear Spar Typical Web (Non-Hidden Locations)
NOTE	NOTE	57-607-21	Wing Center Section Rear Spar Typical Web (Non-Hidden Locations)
NOTE	NOTE	57-608-00	Side of Body Splice Upper and Lower Rear Spar
NOTE	NOTE	57-609-00	Side of Body Splice Upper and Lower Front Spar
NOTE	NOTE	57-611-20	Side of Body Rib (Direction 1)
NOTE	NOTE	57-611-21	Side of Body Rib (Direction 2)
NOTE	NOTE	57-612-00	Lower Wing Panel, Typical Stringers
NOTE	NOTE	57-612-01	Lower Wing Panel, Typical Stringers
NOTE	NOTE	57-613-00	Lower Wing Panel, Typical Stringers
NOTE	NOTE	57-614-00	Lower Wing Panel Skin; Under the Flap Track Fairings and Nacelle Fairings
NOTE	NOTE	57-614-10	Lower Wing Panel Skin
NOTE	NOTE	57-614-20	Lower Wing Panel Skin
NOTE	NOTE	57-614-30	Lower Wing Panel Skin



737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

INTERVAL		MPD ITEM NUMBER	TASK TITLE
THRESHOLD	REPEAT		
NOTE	NOTE	57-614-40	Lower Wing Panel, Rail Stringers
NOTE	NOTE	57-615-00	Lower Wing Panel, Rail Stringers
NOTE	NOTE	57-615-01	Lower Wing Panel, Rail Stringers
NOTE	NOTE	57-616-00	Lower Wing Panel, Rail Stringer
NOTE	NOTE	57-616-10	Lower Wing Panel, Rail Stringer
NOTE	NOTE	57-617-00	Lower Wing Panel, Splice Stringers
NOTE	NOTE	57-617-01	Lower Wing Panel, Splice Stringers
NOTE	NOTE	57-618-00	Lower Wing Panel, Splice Stringers (Direction 3)
NOTE	NOTE	57-618-01	Lower Wing Panel, Splice Stringers (Direction 4)
NOTE	NOTE	57-619-00	Lower Wing Panel, Splice Stringers
NOTE	NOTE	57-619-01	Lower Wing Panel, Splice Stringers
NOTE	NOTE	57-620-00	Wing Lower Panel, Splice Stringers
NOTE	NOTE	57-620-01	Wing Lower Panel, Splice Stringer
NOTE	NOTE	57-621-00	Wing Lower Panel, Splice Stringers
NOTE	NOTE	57-621-01	Wing Lower Panel, Splice Stringer (Direction 3)
NOTE	NOTE	57-621-02	Wing Lower Panel, Splice Stringer (Direction 4)
NOTE	NOTE	57-621-10	Lower Wing Panel, Splice Stringers (Direction 3)
NOTE	NOTE	57-621-11	Lower Wing Panel, Splice Stringers (Direction 4)
NOTE	NOTE	57-621-20	Splice Stringers at Chordwise Skin Splices (Upper and Lower Panel)
NOTE	NOTE	57-622-00	Front Spar Lower Chord (Skin Flange Inspections)
NOTE	NOTE	57-623-00	Front Spar Lower Chord (Skin Flange Inspections)
NOTE	NOTE	57-624-00	Front Spar Lower Chord (Web Flange Inspections)
NOTE	NOTE	57-625-00	Front Spar Lower Chord (Skin Flange Inspections)
NOTE	NOTE	57-626-00	Front Spar Lower Chord (Web Flange Inspections)



737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

INTERVAL		MPD ITEM NUMBER	TASK TITLE
THRESHOLD	REPEAT		
NOTE	NOTE	57-627-00	Front Spar Lower Chord (Web Flange Inspections)
NOTE	NOTE	57-627-01	Front Spar Lower Chord (Web Flange Inspections)
NOTE	NOTE	57-628-00	Front Spar Lower Chord (Web Flange Inspections)
NOTE	NOTE	57-628-01	Front Spar Lower Chord (Web Flange Inspections)
NOTE	NOTE	57-628-10	Front Spar Lower Chord (Web Flange Inspections)
NOTE	NOTE	57-629-00	Front Spar Lower Chord (Direction 1)
NOTE	NOTE	57-630-00	Front Spar Lower Chord (Direction 2)
NOTE	NOTE	57-631-00	Front Spar Lower Chord (Direction 3)
NOTE	NOTE	57-632-00	Front Spar Lower Chord (Direction 4)
NOTE	NOTE	57-632-10	Front Spar Lower Chord (Skin and Web Flange Inspections)
NOTE	NOTE	57-633-00	Spar Chords at Chordwise Skin Splices (Upper and Lower Panel)
NOTE	NOTE	57-633-01	Spar Chords at Chordwise Skin Splices (Upper and Lower Panel)
NOTE	NOTE	57-634-00	Rear Spar Lower Chord (Skin Flange Inspections)
NOTE	NOTE	57-635-00	Rear Spar Lower Chord (Web Flange Inspections)
NOTE	NOTE	57-636-00	Rear Spar Lower Chord (Web Flange Inspections)
NOTE	NOTE	57-637-00	Rear Spar Lower Chord (Skin Flange Inspections)
NOTE	NOTE	57-638-00	Rear Spar Lower Chord (Skin Flange Inspections)
NOTE	NOTE	57-639-00	Rear Spar Lower Chord (Skin Flange Inspections)
NOTE	NOTE	57-640-00	Rear Spar Lower Chord (Web Flange Inspections)
NOTE	NOTE	57-641-00	Rear Spar Lower Chord (Skin and Web Flange Inspections)
NOTE	NOTE	57-641-10	Rear Spar Lower Chord (Skin Flange and Web Flange Inspections)
NOTE	NOTE	57-643-00	Skin at Nacelle Support Fitting Attachments
NOTE	NOTE	57-643-01	Skin at Nacelle Support Fitting Attachments
NOTE	NOTE	57-643-10	Lower Wing Panel Skin at Shear Tied Rib Attachments



737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

INTERVAL		MPD ITEM NUMBER	TASK TITLE
THRESHOLD	REPEAT		
NOTE	NOTE	57-644-00	Lower Wing Panel Under Flap Track Fittings (Direction 1)
NOTE	NOTE	57-644-01	Lower Wing Panel Under Flap Track Fittings (Direction 1)
NOTE	NOTE	57-644-02	Lower Wing Panel Under Flap Track Fittings (Direction 2)
NOTE	NOTE	57-645-00	Upper Wing Panel Typical Stringers
NOTE	NOTE	57-645-05	Upper Wing Panel At Side-of-Body Double Plus Chord
NOTE	NOTE	57-645-10	Upper Wing Panel At Side-of-Body Double Plus Chord (Direction 2)
NOTE	NOTE	57-645-11	Upper Wing Panel At Side-of-Body Double Plus Chord (Direction 2)
NOTE	NOTE	57-645-12	Upper Wing Panel At Side-of-Body Double Plus Chord (Direction 3)
NOTE	NOTE	57-645-13	Upper Wing Panel At Side-of-Body Double Plus Chord (Direction 3)
NOTE	NOTE	57-645-15	Upper Wing Panel Splice Stringer
NOTE	NOTE	57-646-00	Rear Spar Upper Chord Skin Flange Inspections
NOTE	NOTE	57-647-00	Rear Spar Upper Chord (Skin Flange Inspections)
NOTE	NOTE	57-647-10	Rear Spar Upper Chord (Web Flange Inspections)
NOTE	NOTE	57-647-20	Rear Spar Upper Chord (Web Flange Inspections)
NOTE	NOTE	57-647-30	Rear Spar Upper Chord (Skin Flange and Web Flange Inspections)
NOTE	NOTE	57-649-00	Front Spar Web Crack - Typical Details
NOTE	NOTE	57-650-00	Outboard Wing Rear Spar Web Typical Details
NOTE	NOTE	57-650-10	Outboard Wing Rear Spar Web Typical Details
NOTE	NOTE	57-651-00	Rear Spar Web at Trunnion Attachment, MLG and T.E Fittings
NOTE	NOTE	57-651-10	Rib 25 Upper and Lower Horizontal Flange
NOTE	NOTE	57-652-00	RIB 27, Upper and Lower Rib Flange to Skin Attachment
NOTE	NOTE	57-653-00	Rib 27, Front and Rear Spar Tension Fittings
NOTE	NOTE	57-655-00	In-Spar Rib, Station 0, Winglet
NOTE	NOTE	57-656-00	In-Spar Rib, Sta 0 Bolt Holes



737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

INTERVAL		MPD ITEM NUMBER	TASK TITLE
THRESHOLD	REPEAT		
NOTE	NOTE	57-676-10	Inbd Flap - No. 4 & No. 5 Carriage Assy
VEN REC	VEN REC	23-052-00	RIPS System Battery
VEN REC	VEN REC	23-070-00	ULB (Underwater Locator Beacon) for Voice Recorder
VEN REC	VEN REC	25-041-00	Inflatable Seat Restraint System Operational Check
VEN REC	VEN REC	25-042-00	Inflatable Seat Restraint System Detailed Inspection
VEN REC	VEN REC	25-043-00	Inflatable Seat Restraint System Inflator
VEN REC	VEN REC	25-044-00	Inflatable Seat Restraint System Electronics Module Assembly
VEN REC	VEN REC	25-245-00	Mid-Exit Doors Emergency Escape Slides
VEN REC	VEN REC	25-290-00	Restore Life Jackets
VEN REC	VEN REC	25-300-00	Restore Life Rafts
VEN REC	VEN REC	25-305-00	Restore Flight Deck Life Raft
VEN REC	VEN REC	25-340-00	Power Megaphones Batteries
VEN REC	VEN REC	25-350-00	Emergency Locator Transmitter (Survival / Portable Type)
VEN REC	VEN REC	25-360-00	Emergency Locator Transmitter (Survival / Portable Type) - Batteries
VEN REC	VEN REC	25-390-00	Emergency Flashlights Batteries
VEN REC	VEN REC	25-395-00	Restore Emergency Flashlight Batteries
VEN REC	VEN REC	25-410-00	Smoke Hoods
VEN REC	VEN REC	25-420-00	First Aid Kits
VEN REC	VEN REC	25-430-00	Medical Kits
VEN REC	VEN REC	35-040-00	Flight Crew Oxygen Cylinder
VEN REC	VEN REC	35-041-00	Flight Crew Oxygen Cylinder
1 YR	1 YR	26-470-00	Portable Water Fire Extinguisher Inspection
1 YR	1 YR	26-490-00	Inspect Portable Carbon Dioxide Fire Extinguishers
1 YR	1 YR	26-510-00	Inspect Portable Chemical Fire Extinguishers



737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

INTERVAL		MPD ITEM NUMBER	TASK TITLE
THRESHOLD	REPEAT		
1 YR	1 YR	28-115-00	Center Tank Boost Pump Auto Shutoff Test
1 YR	1 YR	33-055-00	Emergency Battery Pack Capacity Functional Check
1 YR	1 YR	52-020-00	Service and Entry Door Lubrication
1 YR	1 YR	52-090-00	Forward and Aft Cargo Compartment Door Lubrication
1 YR	1 YR	52-150-00	Airstair Door System Lubrication
2 YR	2 YR	20-040-05	Lightning/HIRF Protection Components - Wing to Body Fairing
2 YR	2 YR	23-054-00	RIPS Capacity
2 YR	2 YR	25-330-00	Power Megaphones
2 YR	2 YR	25-370-00	Detachable Emergency Equipment
2 YR	2 YR	25-460-00	Main Deck Cargo Barrier Net Receptacle Fittings
2 YR	2 YR	25-470-00	Main Deck Cargo Barrier Net and Fittings
2 YR	2 YR	25-480-00	Main Deck Cargo Barrier Net Test Strap
2 YR	2 YR	33-060-00	Emergency Lighting - Battery Pack Restoration
2 YR	2 YR	52-010-00	Service and Entry Door Lubrication
2 YR	2 YR	52-120-00	E/E Access Door Lubrication
2 YR	2 YR	52-202-00	MID EXIT DOOR LATCH AND LOCK SWITCHES
2 YR	2 YR	52-222-00	MID EXIT DOOR OPERATIONAL CHECK
2 YR	2 YR	52-232-00	MID EXIT DOOR INSPECTION
2 YR	2 YR	52-242-00	MID EXIT DOOR FLIGHT LOCK OPERATIONAL CHECK
2 YR	2 YR	52-262-00	MID EXIT DOOR PRESSURE SEAL INSPECTION
2 YR	2 YR	52-263-00	MID EXIT DOOR VENT DOOR SEAL INSPECTION
2 YR 4000 FC	2 YR 4000 FC	52-290-00	Main Deck Cargo Door
2 YR	2 YR	56-010-00	Control Cabin Sliding Windows



737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

INTERVAL		MPD ITEM NUMBER	TASK TITLE
THRESHOLD	REPEAT		
2 YR	2 YR	56-020-00	Control Cabin Sliding Windows
2 YR	2 YR	56-040-00	Control Cabin Sliding Windows
2 YR	2 YR	56-060-00	Control Cabin Sliding Windows
3 YR	3 YR	23-120-00	Functionally check the underwater locator device
3 YR	3 YR	28-020-01	Operationally Check Left Surge Tank Pressure Relief Valves
3 YR	3 YR	28-020-02	Operationally Check Right Surge Tank Pressure Relief Valves
3 YR	3 YR	28-030-01	Inspect (Detailed) the Left Surge Tank Vent Flame Arrestor
3 YR	3 YR	28-030-02	Inspect (Detailed) the Right Surge Tank Vent Flame Arrestor
3 YR	3 YR	33-065-00	Self Illuminating Exit Signs
3 YR 12000 FH	3 YR 12000 FH	33-070-00	Photoluminescent Floor Proximity Lighting
3 YR	3 YR	34-060-10	Air Data System - Altimetry System
3 YR	3 YR	34-130-00	Integrated Standby Flight Display
3 YR	3 YR	35-150-00	Manual Shutoff Valve Sensor
3 YR	3 YR	35-164-00	Gaseous passenger oxygen flow control units.
3 YR	3 YR	52-030-00	Forward Entry Door Inspection
3 YR	3 YR	52-040-00	Service and Entry Door Centering Guide Bearing
3 YR	3 YR	52-350-00	Main Deck Cargo Door Control Panel Operational Check
3 YR	3 YR	57-952-01	Winglet - Left Wing
3 YR	3 YR	57-962-02	Winglet - Right Wing
4 YR	4 YR	23-030-00	Resistance of Static Discharges
4 YR	4 YR	23-050-00	Voice Recorder for Audio Fidelity
4 YR	4 YR	56-030-00	Control Cabin Sliding Windows
4 YR	4 YR	56-050-00	Control Cabin Sliding Windows



737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

INTERVAL		MPD ITEM NUMBER	TASK TITLE
THRESHOLD	REPEAT		
5 YR	5 YR	28-180-00	Functional Check of the Equipment Fault Current Ground Strap for HSP (SFAR 88)
5 YR	5 YR	49-010-00	APU Mounts
6 YR	6 YR	21-190-00	APU Boot Pressure Seal
6 YR	6 YR	23-130-00	Discard the underwater locator device battery
6 YR	6 YR	27-100-00	Elevator Pushrods
6 YR	6 YR	27-101-00	Feel and Centering Single Element Dual Load Path Components
6 YR	6 YR	28-150-00	FUNCTIONAL CHECK OF THE FUEL PUMP BONDING TO STRUCTURE - LEFT AND RIGHT WING (SFAR 88)
6 YR	6 YR	28-160-00	FUNCTIONAL CHECK OF BONDING RESISTANCE OF APU DC FUEL PUMP (SFAR 88)
6 YR	6 YR	28-199-00	Motor Operated Valve (MOV) Actuator
6 YR	6 YR	34-105-00	Source Select Panel Inertial Reference System Transfer Switch
6 YR	6 YR	35-060-00	Chemical Oxygen Generator Temperature Sensitive Tape
6 YR	6 YR	35-065-00	Lavatory Oxygen Constant Dispensing System (CDS).
6 YR	6 YR	35-166-00	Passenger gaseous oxygen system pressure regulators.
6 YR	6 YR	52-230-00	Inspection of Automatic Emergency Exit Door Components
6 YR	6 YR	52-240-00	Automatic Emergency Exit Door Flight Lock Operational Check
6 YR	6 YR	52-250-00	Automatic Emergency Door Flight Lock Inspection
6 YR	6 YR	52-310-00	Main Deck Cargo Door Lift Actuator Linkage
6 YR	6 YR	52-320-00	Main Deck Cargo Door Manual Pump
6 YR	6 YR	52-325-00	Operationally check the manual operation of PULL-IN/LATCH ACTUATOR and LOCK ACTUATOR
6 YR 18000 FC	6 YR 18000 FC	53-220-00	Keel Beam In Wheel Well
6 YR 18000 FC NOTE	6 YR 18000 FC NOTE	53-914-00	Main Deck Cargo Compartment - Sta 360 to Sta 1016 Wet Areas



737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

INTERVAL		MPD ITEM NUMBER	TASK TITLE
THRESHOLD	REPEAT		
6 YR 18000 FC	6 YR 18000 FC	54-010-01	Left Forward Engine Mount Assembly
6 YR 18000 FC	6 YR 18000 FC	54-010-02	Right Forward Engine Mount Assembly
6 YR 18000 FC	6 YR 18000 FC	54-030-01	Left Strut Aft Engine Mount Assembly
6 YR 18000 FC	6 YR 18000 FC	54-030-02	Right Strut Aft Engine Mount Assembly
6 YR 16000 FC	6 YR 16000 FC	54-090-01	Functional Check Left Engine Forward Strut and Aft Strut Fairing Drains
6 YR 16000 FC	6 YR 16000 FC	54-090-02	Functional Check Right Engine Forward Strut and Aft Strut Fairing Drains
6 YR 18000 FC	6 YR 18000 FC	57-040-00	Wing Center Section
6 YR 18000 FC	6 YR 18000 FC	57-050-00	Wing Center Section
6 YR 18000 FC	6 YR 18000 FC	57-060-01	Left Outboard Wing
6 YR 18000 FC	6 YR 18000 FC	57-060-02	Right Outboard Wing
6 YR 18000 FC	6 YR 18000 FC	57-120-01	Left Outboard Wing Front Spar
6 YR 18000 FC	6 YR 18000 FC	57-120-02	Right Outboard Wing Front Spar
6 YR	6 YR	57-140-01	Left Wing Slat Tracks
6 YR	6 YR	57-140-02	Right Wing Slat Tracks
6 YR 18000 FC	6 YR 18000 FC	57-160-01	Left Outboard Wing Access Holes
6 YR 18000 FC	6 YR 18000 FC	57-160-02	Right Outboard Wing Access Holes
6 YR 18000 FC	6 YR 18000 FC	57-200-01	Left Flap Support No. 4



737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

INTERVAL		MPD ITEM NUMBER	TASK TITLE
THRESHOLD	REPEAT		
6 YR 18000 FC	6 YR 18000 FC	57-200-02	Right Flap Support No. 5
6 YR 18000 FC	6 YR 18000 FC	57-210-01	Left Flap Support No. 3
6 YR 18000 FC	6 YR 18000 FC	57-210-02	Right Flap Support No. 6
6 YR 18000 FC	6 YR 18000 FC	57-220-01	Left Outboard Wing Lower Surface
6 YR 18000 FC	6 YR 18000 FC	57-220-02	Right Outboard Wing Lower Surface
6 YR 18000 FC	6 YR 18000 FC	57-230-01	Flap Supports No. 1 & 2
6 YR 18000 FC	6 YR 18000 FC	57-230-02	Flap Supports No.7 & 8
6 YR 18000 FC	6 YR 18000 FC	57-240-01	Left Outboard Wing Lower Surface
6 YR 18000 FC	6 YR 18000 FC	57-240-02	Right Outboard Wing Lower Surface
6 YR 18000 FC	6 YR 18000 FC	57-250-01	Left Main Landing Gear Support Structure
6 YR 18000 FC	6 YR 18000 FC	57-250-02	Right Main Landing Gear Support Structure
6 YR 18000 FC	6 YR 18000 FC	57-260-01	Left Wing Outboard Rear Spar
6 YR 18000 FC	6 YR 18000 FC	57-260-02	Right Wing Outboard Rear Spar
6 YR 18000 FC	6 YR 18000 FC	57-310-01	Left Outboard Wing Rear Spar
6 YR 18000 FC	6 YR 18000 FC	57-310-02	Right Outboard Wing Rear Spar
6 YR	6 YR	57-340-01	Left Winglet
6 YR	6 YR	57-340-02	Right Winglet



737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

INTERVAL		MPD ITEM NUMBER	TASK TITLE
THRESHOLD	REPEAT		
6 YR	6 YR	57-351-01	Left Winglet
6 YR	6 YR	57-351-02	Right Winglet
6 YR	6 YR	71-040-01	Check Left Engine Drain Lines
6 YR	6 YR	71-040-02	Check Right Engine Drain Lines
7 YR	7 YR	28-130-00	Engine Spar and APU Fuel Shut-Off Valve Battery Restoration
8 YR 24000 FC	6 YR 18000 FC	53-140-00	Forward and Aft Cargo Compartment - Floor Structure
8 YR 24000 FC	6 YR 18000 FC	53-160-00	Forward Bilge
8 YR 24000 FC	6 YR 18000 FC	53-240-00	Aft Cargo Door Cutout
8 YR 24000 FC	6 YR 18000 FC	53-250-00	Aft Bilge
8 YR 24000 FC	6 YR 18000 FC	53-500-00	Main Deck Cargo Door Cutout and Surround Structure
8 YR 24000 FC	6 YR 18000 FC	53-505-00	Main Deck Cargo Door Cutout and Surround Structure
8 YR 24000 FC	6 YR 18000 FC	53-530-00	Crown Skin Panel, Sta 360 to 500H
8 YR	8 YR	35-165-00	Passenger gaseous oxygen low pressure distribution system
8 YR	8 YR	49-020-00	APU Mounts
8 YR	8 YR	52-264-00	MID EXIT DOOR PRESSURE SEAL INSPECTION
8 YR	8 YR	52-265-00	MID EXIT DOOR VENT DOOR SEAL INSPECTION
8 YR 18000 FC	8 YR 18000 FC	52-550-00	E/E Equipment Compartment Access Door
8 YR 18000 FC	8 YR 18000 FC	52-600-00	Forward Airstairs Door
8 YR 18000 FC	8 YR 18000 FC	52-766-00	Mid Emergency Exit Door



737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

INTERVAL		MPD ITEM NUMBER	TASK TITLE
THRESHOLD	REPEAT		
8 YR 18000 FC	8 YR 18000 FC	52-768-00	Mid Emergency Exit Door
8 YR 18000 FC	8 YR 18000 FC	52-780-00	Main Deck Cargo Door
8 YR 18000 FC	8 YR 18000 FC	52-790-00	Main Deck Cargo Door
8 YR 24000 FC	8 YR 24000 FC	53-414-00	Mid Emergency Exit Door Surround Structure
8 YR 18000 FC	8 YR 18000 FC	55-135-01	Left Elevator Hinge, Actuator, and Tab Mast Arm Ftgs and Balance Wt Suppt Struct.
8 YR 18000 FC	8 YR 18000 FC	55-135-02	Right Elevator Hinge, Actuator, and Tab Mast Arm Ftgs and Balance Wt Suppt Struct.
9 YR	3 YR	53-050-00	Main Landing Gear Wheel Well
9 YR	3 YR	57-030-00	Wing Center Section
9 YR 24000 FC	6 YR 18000 FC	53-150-00	Forward Cargo Door Cutout
9 YR	6 YR	53-390-00	Passenger Compartment Floor Structure - Wet Area
9 YR	6 YR	55-120-01	Left Horizontal Stabilizer Trailing Edge
9 YR	6 YR	55-120-02	Right Horizontal Stabilizer Trailing Edge
9 YR 18000 FC	8 YR 18000 FC	52-530-00	Forward Access Door
9 YR 18000 FC	8 YR 18000 FC	52-570-00	E/E Equipment Compartment Access Door
9 YR 18000 FC	8 YR 18000 FC	52-620-00	Entry and Galley Service Doors
9 YR 18000 FC	8 YR 18000 FC	52-650-00	Entry and Galley Service Doors
9 YR 18000 FC	8 YR 18000 FC	52-680-00	Cargo Doors
9 YR 18000 FC	8 YR 18000 FC	52-710-00	Cargo Doors



737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

INTERVAL		MPD ITEM NUMBER	TASK TITLE
THRESHOLD	REPEAT		
9 YR 18000 FC	8 YR 18000 FC	52-740-00	Automatic Overwing Exit Doors
9 YR 18000 FC	8 YR 18000 FC	52-760-00	Automatic Overwing Exit Doors
9 YR 24000 FC	8 YR 24000 FC	53-290-00	Overwing Emergency Exit Cutout
9 YR 24000 FC	8 YR 24000 FC	53-450-00	Fuselage Skin Under Dorsal Fin
9 YR	9 YR	52-220-00	Automatic Emergency Door Operational Check
9 YR	9 YR	52-450-00	Flight Deck Security Door Panel Assembly
9 YR	9 YR	52-460-00	Flight Deck Security Door Surround Assembly
9 YR	9 YR	52-470-00	Flight Deck Security Door Surround Assembly
9 YR	9 YR	52-490-00	Flight Deck Door Latch and Hinge Support Assemblies
9 YR 24000 FC	9 YR 24000 FC	53-510-00	Crown Skin Panel
9 YR 24000 FC	9 YR 24000 FC	53-520-00	Seat Track to Frame Attachment, Sta 540 to 727
9 YR 18000 FC	9 YR 18000 FC	54-015-01	Left Strut Attach Bolts at Forward Engine Mount
9 YR 18000 FC	9 YR 18000 FC	54-015-02	Right Strut Attach Bolts at Forward Engine Mounts
9 YR 18000 FC	9 YR 18000 FC	54-070-01	Left Strut Box
9 YR 18000 FC	9 YR 18000 FC	54-070-02	Right Strut Box
9 YR 18000 FC	9 YR 18000 FC	54-080-01	Left Strut Box
9 YR 18000 FC	9 YR 18000 FC	54-080-02	Right Strut Box
9 YR	9 YR	55-080-01	Left Horizontal Stabilizer Leading Edge



737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

INTERVAL		MPD ITEM NUMBER	TASK TITLE
THRESHOLD	REPEAT		
9 YR	9 YR	55-080-02	Right Horizontal Stabilizer Leading Edge
9 YR 18000 FC	9 YR 18000 FC	57-070-01	Left Outboard Wing
9 YR 18000 FC	9 YR 18000 FC	57-070-02	Right Outboard Wing
9 YR 18000 FC	9 YR 18000 FC	57-280-01	Left Inboard Ground Spoiler
9 YR 18000 FC	9 YR 18000 FC	57-280-02	Right Inboard Ground Spoiler
10 YR	5 YR	57-270-01	Left Wing Outboard Trailing Edge Structure
10 YR	5 YR	57-270-02	Right Wing Outboard Trailing Edge Structure
10 YR	10 YR	21-090-00	Negative Pressure Relief Door
10 YR	10 YR	25-190-01	Left Emergency Exit Hatch Escape Straps
10 YR	10 YR	25-190-02	Right Emergency Exit Hatch Escape Straps
10 YR	10 YR	25-210-00	Inspect Flight Compartment Escape Lanyards
10 YR	10 YR	28-090-00	Detailed inspection of the out of tank wire bundles
10 YR	10 YR	28-140-00	Inspect (Detailed) the Tubing, Static Ground Straps and Clamps, No. 1, 2 and Center Tank (SFAR 88)
10 YR	10 YR	28-170-00	DETAILED INSPECTION IN-TANK FQIS (SFAR 88) (EZAP)
10 YR	10 YR	28-171-00	Detailed Inspection of FQIS components (SFAR 88)
10 YR	10 YR	28-181-00	Inspect (detailed) the equipment current ground straps for the Densitometer Hot Short Protector (SFAR 88)
10 YR	10 YR	28-200-00	Wire Bundles Routed on Main Deck over Center Fuel Tank
10 YR	10 YR	32-720-01	Left Main Landing Gear Assembly
10 YR	10 YR	32-720-02	Right Main Landing Gear Assembly
10 YR	10 YR	32-750-00	Nose Landing Gear Assembly
10 YR	10 YR	33-020-00	Emergency Lighting Switch Operational Test



737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

INTERVAL		MPD ITEM NUMBER	TASK TITLE
THRESHOLD	REPEAT		
10 YR	10 YR	33-080-00	Replace Photoluminescent Floor Proximity Lighting
10 YR	10 YR	53-080-00	Flight Compartment Floor Structure
10 YR	10 YR	53-340-00	Flight Compartment Floor Structure
10 YR 36000 FC	10 YR 36000 FC	54-060-01	Left Strut to Wing Attachments
10 YR 36000 FC	10 YR 36000 FC	54-060-02	Right Strut to Wing Attachments
10 YR 36000 FC	10 YR 36000 FC	57-010-00	Wing Center Section
10 YR 36000 FC	10 YR 36000 FC	57-020-00	Wing Center Section
10 YR 36000 FC	10 YR 36000 FC	57-090-00	Wing Center Section
10 YR	10 YR	57-130-01	Left Outboard Wing Leading Edge Structure
10 YR	10 YR	57-130-02	Right Outboard Wing Leading Edge Structure
10 YR 36000 FC	10 YR 36000 FC	57-170-01	Left Outboard Wing
10 YR 36000 FC	10 YR 36000 FC	57-170-02	Right Outboard Wing
10 YR 36000 FC	10 YR 36000 FC	57-180-01	Left Outboard Wing
10 YR 36000 FC	10 YR 36000 FC	57-180-02	Right Outboard Wing
10 YR 36000 FC	10 YR 36000 FC	57-190-01	Left Outboard Wing
10 YR 36000 FC	10 YR 36000 FC	57-190-02	Right Outboard Wing
10 YR 36000 FC	10 YR 36000 FC	57-300-01	Left Inboard Flap
10 YR 36000 FC	10 YR 36000 FC	57-300-02	Right Inboard Flap



737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

INTERVAL		MPD ITEM NUMBER	TASK TITLE
THRESHOLD	REPEAT		
10 YR 36000 FC	10 YR 36000 FC	57-330-01	Left Outboard Flap
10 YR 36000 FC	10 YR 36000 FC	57-330-02	Right Outboard Flap
10 YR	10 YR	57-866-01	Fixed Trailing Edge - Left Wing
10 YR	10 YR	57-936-02	Fixed Trailing Edge - Right Wing
12 YR	6 YR	53-020-00	Nose Wheel Well
12 YR 36000 FC	8 YR 24000 FC	53-060-00	Forward Pressure Bulkhead
12 YR 36000 FC	8 YR 24000 FC	53-070-00	Area Forward of Nose Wheel Well
12 YR 36000 FC	8 YR 24000 FC	53-090-00	Area Above and Outboard of Nose Wheel Well
12 YR 36000 FC	8 YR 24000 FC	53-120-00	Electrical and Electronics Compartment
12 YR 36000 FC	8 YR 24000 FC	53-130-00	Forward Cargo Compartment
12 YR 36000 FC	8 YR 24000 FC	53-180-00	Area Under Lower Wing-To-Body Fairing (forward of wing box)
12 YR 36000 FC	8 YR 24000 FC	53-210-00	Keel Beam Under Wing-To-Body Fairing (under wing box)
12 YR 36000 FC	8 YR 24000 FC	53-230-00	Aft Cargo Compartment
12 YR 36000 FC	8 YR 24000 FC	53-235-00	Mid Emergency Exit Door Cutout
12 YR 36000 FC	8 YR 24000 FC	53-260-00	Area Aft of Cargo Compartment
12 YR 36000 FC	8 YR 24000 FC	53-262-00	Area Aft of Cargo Compartment
12 YR 36000 FC	8 YR 24000 FC	53-270-00	Area Under Lower Wing-To-Body Fairing (aft of Wheel Well)



737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

INTERVAL		MPD ITEM NUMBER	TASK TITLE
THRESHOLD	REPEAT		
12 YR 36000 FC	8 YR 24000 FC	53-280-00	Area Under Wing-To-Body Fairing (above wing)
12 YR 36000 FC	8 YR 24000 FC	53-330-00	Flight Compartment from Sta 178 to 270
12 YR 36000 FC	8 YR 24000 FC	53-350-00	Passenger Compartment from Sta 270 to 360
12 YR 36000 FC	8 YR 24000 FC	53-400-00	Forward Passenger Compartment, Sta 360 to 663.75
12 YR 36000 FC	8 YR 24000 FC	53-410-00	Aft Passenger Compartment, STA 663.75 to 1016
12 YR 36000 FC	8 YR 24000 FC	53-412-00	Aft Passenger Compartment, STA 663.75 to 1042
12 YR 36000 FC	8 YR 24000 FC	53-416-00	Mid Emergency Exit Door
12 YR 36000 FC	8 YR 24000 FC	53-420-00	Area Aft of STA 1016 Bulkhead
12 YR 36000 FC	8 YR 24000 FC	53-422-00	Area Aft of STA 1042 Bulkhead
12 YR 36000 FC	8 YR 24000 FC	53-430-00	Stabilizer Torsion Box Compartment and APU Compartment
12 YR 36000 FC	8 YR 24000 FC	53-440-00	STA 1156 Bulkhead
12 YR 36000 FC	8 YR 24000 FC	53-460-00	Vertical Fin Front Spar Fitting
12 YR 36000 FC	8 YR 24000 FC	53-480-00	Vertical Fin Rear Spar Fitting
12 YR 36000 FC	8 YR 24000 FC	55-010-00	Horizontal Stabilizer Center Section
12 YR 36000 FC	8 YR 24000 FC	55-020-00	Stabilizer Torsion Box Compartment
12 YR 36000 FC	8 YR 24000 FC	55-030-00	Vertical Fin Leading Edge



737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

INTERVAL		MPD ITEM NUMBER	TASK TITLE
THRESHOLD	REPEAT		
12 YR 36000 FC	8 YR 24000 FC	55-050-00	Vertical Fin
12 YR 36000 FC	8 YR 24000 FC	55-060-00	Vertical Fin Trailing Edge
12 YR 36000 FC	8 YR 24000 FC	55-070-01	Left Horizontal Stabilizer Leading Edge
12 YR 36000 FC	8 YR 24000 FC	55-070-02	Right Horizontal Stabilizer Leading Edge
12 YR 36000 FC	8 YR 24000 FC	55-100-01	Left Horizontal Stabilizer
12 YR 36000 FC	8 YR 24000 FC	55-100-02	Right Horizontal Stabilizer
12 YR 36000 FC	8 YR 24000 FC	55-110-01	Left Horizontal Stabilizer Trailing Edge and Elevator Tab Leading Edge
12 YR 36000 FC	8 YR 24000 FC	55-110-02	Right Horizontal Stabilizer Trailing Edge and Elevator Tab Leading Edge
12 YR 36000 FC	8 YR 24000 FC	55-115-01	Left Elevator Tab Supt Ftgs on Front Spar and Tab Spar at Leading Edge
12 YR 36000 FC	8 YR 24000 FC	55-115-02	Right Elevator Tab Supt Ftgs on Front Spar and Tab Spar at Leading Edge
12 YR 36000 FC	10 YR 36000 FC	53-170-00	Area Aft of Forward Cargo Compartment
12 YR 36000 FC	10 YR 36000 FC	53-190-00	Area Above Wing Box Center Section
12 YR 36000 FC	10 YR 36000 FC	53-200-00	Area Above Main Landing Gear Wheel Well
12 YR 36000 FC	10 YR 30000 FC	55-130-00	Rudder, Elevator and Elevator Tab Attach Fittings
12 YR	12 YR	28-173-00	Functional Check of FQIS wire bundle lightning shield to ground termination (SFAR 88)
12 YR	12 YR	28-201-00	Functional check of bonding resistance between the hydraulic line fitting and structure (SFAR 88)
12 YR	12 YR	28-204-00	Functional Check of the Bonding of Air Vent to the Door Structure (SFAR 88)



737-600/700/800/900/900ER MAINTENANCE PLANNING DOCUMENT

INTERVAL		MPD ITEM NUMBER	TASK TITLE
THRESHOLD	REPEAT		
12 YR	12 YR	28-205-00	Functional Check the Bonding of Pressure Relief Valve to the Structure (SFAR 88)
12 YR	12 YR	28-207-00	Functional Check of Shutoff Valves Actuator to structure (SFAR 88)
12 YR	12 YR	28-208-00	Functional Check of the Bonding of the Fueling Receptacle to Structure (SFAR 88)
12 YR	12 YR	28-211-00	Functional Check of the Bonding of MOV actuator to the Structure (SFAR 88)
12 YR	12 YR	28-213-00	Functional check of the Bonding of APU Shutoff valve to Structure (SFAR 88)
12 YR	12 YR	52-330-00	Main Deck Cargo Door Lift Actuator Attachment Points
12 YR	12 YR	53-100-00	Passenger Compartment Floor Structure - Dry Area
12 YR	12 YR	53-370-00	Passenger Compartment Floor Structure - Dry Area
16 YR	16 YR	20-040-06	Lightning/HIRF Protection Components - Wing to Body Fairing
20 YR 50000 FC	8 YR 24000 FC	53-335-00	Flight Compartment from Sta 178 to 270
20 YR	8 YR	53-470-00	Vertical Fin Front Spar Fitting

