

Hubitat Node.js Server Package Installation - Android or Fire Tablet

I have in the past installed node.js into an Android and Fire environment, using the Android applet "Servers Ultimate Pro" (\$8.49 via Google Play or Amazon) and "Servers Ultimate Pack F" (free add-on). You can test this capability using Servers Ultimate and Pack F for free; however, you will eventually have to upgrade. The instructions below are what I did on my Amazon Fire Tablet.

BASIC INSTALLATION STEPS - Index

- A. Download and install "Servers Ultimate Pro" and "Servers Ultimate Pack F" from Google Play or Amazon Fire App Store.
- B. Install the "TP-LinkHub_v3" node.js applet.
- C. Load and start the package into Servers Ultimate Pro.

A. NODE.JS UTILITY INSTALLATION

- a. Go to Google play and download "Servers Ultimate Pro" (\$8.49) or the "Servers Ultimate" seven-day trial package.
- b. After installing "Servers Ultimate Pro", download and install "Servers Ultimate Pack F".

B. INSTALL THE TP-LinkHub_V3.JS APPLLET

- a. Copy the files "TP-LinkHub_v3.js" to a convenient location on your device. To do this, I connect the device to my pc and use Windows file server to create the file and move to the directory (I created "This PC\Fire\Internal storage\NodeJs").
- b. Disconnect from your PC (causes problems otherwise).

C. START SERVERS ULTIMATE PRO AND SERVER

- a. Start Servers Ultimate Pro.
- b. In "General", select: "Start the app on boot".
- c. Select "Servers" and "+ADD" (upper right corner).
- d. Select "Node.js", then "General" tab.
 - 1) Server Name: Enter your name for the server
 - 2) More: "Start on boot"
 - 3) More: "Start directly when app starts"
- e. Select the "Specific" tab.
 - 1) Script Location: Select Brows

Hubitat Node.js Server Package Installation - Android or Fire Tablet

- 2) At the name, type "TP-LinkHub_V3.js"
- 3) Browse to the location you your TP link file.
- 4) Select Save.

- f. Start the server by pressing the > symbol (left of line).
- g. Go to logging and check for no errors (in red).
- h. If you have devices installed in Hubitat, test a device.
- i. Restart your device to assure the server auto-starts.