

Note: States marked as STs only active when you have connected to STs.	
Source Keys	WS: Websocket LAN: Local LAN interface ST: SmartThings Colud.
Samsung TV Remote Current States	
artModeStatus	WS Status of art Mode for frameTV's
inputSource	ST: The current input source
pictureMode	ST: TV picture mode
soundMode	ST: TV sound mode
switch	LAN: on/off
tvChannel	ST: TV Channel number
tvChannelName	ST: TV Channel name
Volume	ST: Volume
Samsung TV Remote State Variables	
Note: State Variables do not update on Devices Edit page until a page refresh is completed.	
currentFunction:	WS: last function sent to the WS Interface
wsDeviceStatus	WS: open/closed
supportedInputs	ST: available inputs for your device. If you add an input, run Save Preferences to update.
soundModes	ST: available sound modes for your device.
pictureMode	ST: support picture modes for your device
token	WS: token from TV allowing WS remote control.
Samsung TV Remote State Preferences	
Samsung TV IP	The IP of the TV. You should set this up as a static IP within your router.
Power Polling Interval	LAN: Frequency to poll the LAN interface using a canned message. A valid return causes the power (switch) to set to on and on first encounter initiates some power-on processing. An invalid return sets switch to off.
Device Refresh Interval	Runs refresh processing. If switch is off, the processing will stop. If on, it will update LAN and ST settings.
TV Startup Display	When turned on via this driver, the startup display to initiate. Only works if the device is turned on via the Hubitat Device instance.
DebugLog/ Info Log	
Use Alternate WOL MAC	If the power on function doesn't work on initiation, setting this will set an alternate WOL MAC (w/o colons).
Connect to SmartThings	Enables the preference SmartThings API Key to allow you to enter that key.
SmartThings API Key	Allows entry of ST API Key. If valid, enables preference SmartThings Device ID.
SmartThings Device ID	Allows entry of the device ID.