

## Button Interface

The driver has a method "push()" at the bottom. This is for the button interface. This function has been added to allow control via dashboards without creating driver-external buttons.

**Adding to interface.** The user can add to this interface to meet their individual needs. Example: you want to create a button that takes the device to pictureMode "Dynamic".

a. Add another case statement on a new line: case 44:

setPictureMode("Dynamic"); break

b. Save the code and test using the push button with a value of 44.