

# **COMMAND REFERENCE**

**Manual Rev. 1.0c**

**By Galil Motion Control, Inc.**

*Galil Motion Control, Inc.  
3750 Atherton Road  
Rocklin, California 95765  
Phone: (916) 626-0101  
Fax: (916) 626-0102  
Internet Address: [support@galilmc.com](mailto:support@galilmc.com)  
URL: [www.galilmc.com](http://www.galilmc.com)*

*Rev 07/02*

---



# Overview

---

## Controller Notation

This command reference is a supplement to the Galil Motion Control User Manual. For proper controller operation, consult the Users Manual. This manual describes commands to be used with the Galil Econo Series Motion Controllers: DMC-1812, DMC-1822, DMC-1832, and DMC-1842. Commands are listed in alphabetical order.

---

## Servo and Stepper Motor Notation:

Your motion controller has been designed to work with both servo and stepper type motors. Installation and system setup will vary depending upon whether the controller will be used with stepper motors, or servo motors. To make finding the appropriate instructions faster and easier, icons are next to any information that applies exclusively to one type of system. Otherwise, assume that the instructions apply to all types of systems. The icon legend is shown below.



Attention!: Pertains to servo motor use.



Attention!: Pertains to stepper motor use.

---

## Command Descriptions

Each executable instruction is listed in the following section in alphabetical order. Below is a description of the information which is provided for each command.

The two-letter Opcode for each instruction is placed in the upper right corner. Some commands have a binary equivalent and the binary value is listed next to the ASCII command in parenthesis. For binary command mode, see discussion below. Below the Opcode is a description of the command and required arguments.

## Axes Arguments

Some commands require the user to identify the specific axes to be affected. These commands are followed by uppercase X,Y,Z, or W. No commas are needed and the order of axes is not important. Do not insert any spaces prior to a command. For example, STX; AMX is invalid because there is a space after the semicolon. When an argument is not required and is not given, the command is executed for all axes.

### Valid syntax

SH X	Servo Here, X only
SH XYW	Servo Here, X,Y, and W axes
SH XZW	Servo Here, X, Z, and W axes
SH ZXW	Servo Here, Z, X, and W axes (the axes order does not matter)
SH XYZW	Servo Here, X,Y,Z, and W axes
SH	Servo Here, all axes

## Parameter Arguments

Some commands require numerical arguments to be specified following the instruction. In the argument description, these commands are followed by lower case n,n,n,n where the letter, n, represents the value. Values may be specified for any axis separately or any combination of axes. The argument for each axis is separated by commas. Examples of valid syntax are listed below.

### Valid syntax

AC n	Specify argument for x axis only
AC n,n	Specify x and y only
AC n,,n	Specify x and z only
AC n,n,n,n	Specify x,y,z,w

Where n is replaced by actual values.

## Direct Command Arguments

An alternative method for specifying data is to set data for individual axes using an axis designator followed by an equals sign. The \* symbol can be used in place of the axis designator. The \* defines data for all axes to be the same. For example:

PRY=1000	Sets Y axis data to 1000
PR*=1000	Sets all axes to 1000

## Interrogation

Most commands accept a question mark (?) as an argument. This argument causes the controller to return parameter information listed in the command description. Type the command followed by a ? for each axis requested. The syntax format is the same as the parameter arguments described above except '?' replaces the values.

PR ?	The controller will return the PR value for the X axis
PR ?,?,?	The controller will return the PR value for the X, Y, and Z axes
PR ,,,?	The controller will return the PR value for the W axis

## Operand Usage

Most commands have a corresponding operand that can be used for interrogation. The Operand Usage description provides proper syntax and the value returned by the operand. Operands must be used inside of valid DMC expressions. For example, to display the value of an operand, the user could use the command:

MG 'operand'

All of the command operands begin with the underscore character (\_). For example, the value of the current position on the X axis can be assigned to the variable 'V' with the command:

V=\_TPX

## Usage Description

The Usage description specifies the restrictions on proper command usage. The following provides an explanation of the command information provided:

"While Moving":

Describes whether the command is valid while the controller is performing a motion.

"In a program":

Describes whether the command may be used as part of a user-defined program.

"Command Line":

Describes whether the command may be used as a direct command.

## Default Description

In the command description, the DEFAULT section provides the default values for controller setup parameters. These parameters can be changed and the new values can be saved in the controller's non-volatile memory by using the command, BN. If the setup parameters are not saved in non-volatile memory, the default values will automatically reset when the system is reset. A reset occurs when the power is turned off and on, when the reset button is pushed, or the command, RS, is given.

## Resetting the Controller to Factory Default

When a master reset occurs, the controller will always reset all setup parameters to their default values and the non-volatile memory is cleared to the factory state. A master reset is executed by the command, <ctrl R> <ctrl S> <Return> OR by powering up or resetting the controller with the MRST jumper on.

For example, the command KD is used to set the Derivative Constant for each axis. The default value for the derivative constant is 64. If this parameter is not set by using the command, KD, the controller will automatically set this value to 64 for each axis. If the Derivative Constant is changed but not saved in non-volatile memory, the default value of 64 will be used if the controller is reset or upon power up of the controller. If this value is set and saved in non-volatile memory, it will be restored upon reset until a master reset is given to the controller.

The default format describes the format for numerical values which are returned when the command is interrogated. The format value represents the number of digits before and after the decimal point.

---

## Binary Commands

Some commands have an equivalent binary value for the controllers. These values are listed next to the command in parentheses in hexadecimal format \*. Binary communication mode can be executed much faster than ASCII commands. Binary format can only be used when commands are sent from the PC and cannot be embedded in an application program.

\* hexadecimal format represents a byte as two 4 bit values. Each 4 bit value is represented as a single character with a decimal equivalent between 0 and 15. The characters used for representing 10-15 is A,B,C,D,E and F. For example, the hexadecimal value **6D** represent the binary value 01101101. Negative values are represented in 2's complement.

### Binary Command Format

All binary commands have a 4 byte header followed by data fields. The 4 bytes are specified in hexadecimal format.

#### *Header Format:*

**Byte 1** specifies the command number between 80 to FF. The complete binary command number table is listed below.

**Byte 2** specifies the # of bytes in each field as 0, 1, 2, 4 or 6 as follows:

00	No datafields (i.e. SH or BG)
01	One byte per field
02	One word (2 bytes per field)
04	One long word (4 bytes) per field
06	Galil real format (4 bytes integer and 2 bytes fraction)

**Byte 3** specifies whether the command applies to a coordinated move as follows:

00	No coordinated motion movement
01	Coordinated motion movement

For example, the command STS designates motion to stop on a vector motion. The third byte for the equivalent binary command would be 01.

**Byte 4** specifies the axis # or data field as follows

Bit 7 = 8 <sup>th</sup> data field
Bit 6 = 7 <sup>th</sup> data field
Bit 5 = 6 <sup>th</sup> data field
Bit 4 = 5 <sup>th</sup> data field
Bit 3 = W axis or 4 <sup>th</sup> data field
Bit 2 = Z axis or 3 <sup>rd</sup> data field
Bit 1 = Y axis or 2 <sup>nd</sup> data field
Bit 0 = X axis or 1 <sup>st</sup> data field

### ***Datafields Format***

Datafields must be consistent with the format byte and the axes byte. For example, the command PR 1000,, -500 would be

A7 02 00 05 03 E8 FE 0C

where A7 is the command number for PR

02 specifies 2 bytes for each data field

00 S is not active for PR

05 specifies bit 0 is active for A axis and bit 2 is active for C axis ( $2^0 + 2^2 = 5$ )

03 E8 represents 1000

FE 0C represents -500

### ***Example***

The command ST XYZS would be

A1 00 01 07

where A1 is the command number for ST

00 specifies 0 data fields

01 specifies stop the coordinated axes S

07 specifies stop X (bit 0), Y (bit 1) and Z (bit 2)  $2^0 + 2^1 + 2^2 = 7$

### **Binary command table**

COMMAND	NO.	COMMAND	NO.	COMMAND	NO.
reserved	80	reserved	ab	reserved	d6
KP	81	reserved	ac	reserved	d7
KI	82	reserved	ad	RP	d8
KD	83	reserved	ae	TP	d9
DV	84	reserved	af	TE	da
AF	85	LM	b0	TD	db
KS	86	LI	b1	TV	dc
PL	87	VP	b2	RL	dd
ER	88	CR	a3	TT	de
IL	89	TN	b4	TS	df
TL	8a	LE, VE	b5	TI	e0
MT	8b	VT	b6	SC	e1
CE	8c	VA	b7	reserved	e2
OE	8d	VD	b8	reserved	e3
FL	8e	VS	b9	reserved	e4
BL	8f	VR	ba	TM	e5
AC	90	reserved	bb	CN	e6
DC	91	reserved	bc	LZ	e7
SP	92	CM	bd	OP	e8
IT	93	CD	be	OB	e9
FA	94	DT	bf	SB	ea

FV	95	ET	c0	CB	eb
GR	96	EM	c1	II	ec
DP	97	EP	c2	EI	ed
DE	98	EG	c3	AL	ee
OF	99	EB	c4	reserved	ef
GM	9a	EQ	c5	reserved	f0
reserved	9b	EC	c6	reserved	f1
reserved	9c	reserved	c7	reserved	f2
reserved	9d	AM	c8	reserved	f3
reserved	9e	MC	c9	reserved	f4
reserved	9f	TW	ca	reserved	f5
BG	a0	MF	cb	reserved	f6
ST	a1	MR	cc	reserved	f7
AB	a2	AD	cd	reserved	f8
HM	a3	AP	ce	reserved	f9
FE	a4	AR	cf	reserved	fa
FI	a5	AS	d0	reserved	fb
PA	a6	AI	d1	reserved	fc
PR	a7	AT	d2	reserved	fd
JG	a8	WT	d3	reserved	fe
MO	a9	WC	d4	reserved	ff
SH	aa	reserved	d5		

## Fast Firmware Operation

The motion controllers can operate in a mode which allows for very fast servo update rates. This mode is known as 'fast mode' and allows the following update rates:

DMC-1812     125 usec

DMC-1822     125 usec

DMC-1832     250 usec

DMC-1842     250 usec

**Note:** To set the desired update rates use the command, TM.

In order to run the motion controller in fast mode, the fast firmware must be uploaded. This can be done through the Galil terminal software such as DMCTERM and WSDK. Use the menu option, "Update Flash EEPROM" to change the controller firmware. The fast firmware is included with the controller utilities.

When operating in fast mode, there are functions which are disabled and/or altered.

### *Commands which are not Allowed when Operating in Fast Mode:*

Command
Gearing Mode
Ecam Mode
Pole (PL)
Stepper Motor Operation (MT 2, -2, 2.5, -2.5)
Trippoints allowed only in thread 0
Tell Velocity Interrogation Command (TV)



***Commands which are Altered when Operating in Fast Mode:***

Command	Modification
MT	Command argument 2, 2.5, -2, -2.5 not valid
AD, AI, AM, AP, AR, AS, AT, AV, MC, MF, MR, WC	Commands not allowed in threads 1-7

---

## Trippoints

The DMC-18x2 series controllers provide several commands that can be used to make logical decisions, or “trippoints,” based on events during a running program. Such events include: the completion of a specific motion, waiting for a certain position to be reached, or simply waiting for a certain amount of time to elapse.

When a program is executing on the controller, each program line is executed sequentially. However, when a trippoint command is executed, the program halts execution of the next line of code until the status of the trippoint is cleared. Note that the trippoint only halts execution of the thread from which it is commanded while all other independent threads are unaffected. Additionally, if the trippoint is commanded from a subroutine, execution of the subroutine, as well as the main thread, is halted.

Since trippoint commands are used as program flow instructions during a running program, they should not be implemented directly from the command line of the terminal. Sending a trippoint command directly from the command line might cause an interruption in communications between the host PC and the controller until the trippoint is cleared.

As a brief introduction, the following table lists the available commands and their basic usages:

AD	after distance
AI	after input
AM	after move
AP	after absolute position
AR	after relative position
AS	at speed
AT	at time relative to a reference time
AV	after vector distance
MC	motion complete and “in position”
MF	after motion reverse
MR	after motion reverse
WC	wait for contour data to complete
WT	wait for time

---

# Instruction Set

## *Brushless Motor Commands*

BA	Brushless axis
BB	Brushless phase
BC	Brushless calibration
BD	Brushless degrees
BI	Brushless inputs
BM	Brushless modulo
BO	Brushless offset
BS	Brushless setup
BZ	Brushless zero

## *Contour Mode Commands*

CD	Contour data
CM	Contour mode
DT	Contour time interval
WC	Wait for contour data

## *ECAM/Gearing*

EA	Ecam master
EB	Enable ECAM
EC	ECAM table index
EG	ECAM go
EM	ECAM cycle
EP	ECAM interval
EQ	Disengage ECAM
ET	ECAM table entry
GA	Master axis for gearing
GM	Gantry mode
GR	Gear ratio for gearing

## *Error Control Commands*

BL	Backward software limit
ER	Error limit
FL	Forward software limit
OE	Off-on-error function
TL	Torque limit
TW	Timeout for in-position

## *I/O Commands*

AL	Arm latch
CB	Clear bit
CI	Communication interrupt
CO	Configure I/O points
EI	Enable interrupts
II	Input interrupt
OB	Define output bit
OC	Output compare function
OP	Output port
SB	Set bit
UI	User interrupts

### ***Independent Motion Commands***

AB	Abort motion
AC	Acceleration
BG	Begin motion
DC	Deceleration
FE	Find edge
FI	Find index
HM	Home
HX	Halt execution
IP	Increment position
IT	Smoothing time constant
JG	Jog mode
PA	Position absolute
PR	Position relative
SP	Speed
ST	Stop

### ***Interrogation Commands***

LA	List arrays
_LF	Forward limit switch operand
LL	List labels
_LR	Reverse limit switch operand
LS	List program
LV	List variables
MG	Message command
QR	Data record
QZ	Return DMA information
RP	Report command position
RL	Report latch
^R^V	Firmware revision information
SC	Stop code
TB	Tell status
TC	Tell error code
TD	Tell dual encoder
TE	Tell error
TI	Tell input
TIME	Time operand, internal clock
TP	Tell position
TR	Trace program
TS	Tell switches
TT	Tell torque
TV	Tell velocity

### ***Math/Special Functions***

@SIN[x]	Sine of x
@COS[x]	Cosine of x
@COM[x]	1's compliment of x
@ASIN[x]	Arc sine of x
@ACOS[x]	Arc cosine of x
@ATAN[x]	Arc tangent of x
@ABS[x]	Absolute value of x

@FRAC[x]	Fraction portion of x
@INT[x]	Integer portion of x
@RND[x]	Round of x
@SQR[x]	Square root of x
@IN[x]	State of digital input x
@OUT[x]	State of digital output x
@AN[x]	Value of analog input x

### ***Programming Commands***

DA	Deallocate variables/arrays
DL	Download program
DM	Dimension arrays
ED	Edit program
ELSE	Conditional statement
ENDIF	End of conditional statement
EN	End program
IF	If statement
IN	Input variable
JP	Jump
JS	Jump to subroutine
NO	No-operation — for remarks
RA	Record array, automatic data capture
RC	Record interval for RA
RD	Record data for RA
RE	Return from error routine
REM	Remark program
RI	Return from interrupt routine
UI	User Interrupt
UL	Upload program
XQ	Execute program
ZS	Zero stack

### ***Servo Motor Commands***

FA	Acceleration feedforward
FV	Velocity feedforward
IL	Integrator limit
KD	Derivative constant
KI	Integrator constant
KP	Proportional constant
NB	Notch bandwidth
NF	Notch frequency
NZ	Notch zero
OF	Offset
PL	Pole
SH	Servo here
TL	Torque limit
TM	Sample time
ZR	Zero

### ***Stepper Motor Commands***

DE	Define encoder position
DP	Define reference position
KS	Stepper motor smoothing

MT	Motor type
RP	Report commanded position
TD	Step counts output
TP	Tell position of encoder

### ***System Configuration***

BN	Burn parameters
BP	Burn program
BV	Burn variables and arrays
CC	Configure auxiliary port
CE	Configure encoder type
CF	Configure default port
CN	Configure switches
CW	Data adjustment bit
DE	Define dual encoder position
DP	Define position
EI	Enable interrupts
EO	Echo off
IT	Independent smoothing
LZ	Leading zeros format
MO	Motor off
MT	Motor Type
PF	Position format
QD	Download array
QU	Upload array
RS	Reset
^R^S	Master reset
^R^V	Revision information
VF	Variable format

### ***Trippoint Commands***

AD	After distance
AI	After input
AM	After motion profiler
AP	After absolute position
AR	After relative distance
AS	At speed
AT	At time
AV	After vector distance
MC	Motion complete
MF	After motion—forward
MR	After motion—reverse
WC	Wait for contour data
WT	Wait for time

### ***Vector/Linear Interpolation***

CA	Define vector plane
CR	Circular interpolation move
CS	Clear motion sequence
ES	Ellipse scaling
LE	Linear interpolation end
LI	Linear interpolation segment

LM	Linear interpolation mode
ST	Stop motion
TN	Tangent
VA	Vector acceleration
VD	Vector deceleration
VE	Vector sequence end
VM	Coordinated motion mode
VP	Vector position
VR	Vector speed ratio
VS	Vector speed
VT	Smoothing time constant—vector

## AB (Binary A2)

**FUNCTION:** Abort

**DESCRIPTION:**

AB (Abort) stops a motion instantly without a controlled deceleration. If there is a program operating, AB also aborts the program unless a 1 argument is specified. The command, AB, will shut off the motors for any axis in which the off-on-error function is enabled (see command "OE" ).

AB aborts motion on all axes in motion and cannot stop individual axes.

**ARGUMENTS:** AB n                      where

n = 0              The controller aborts motion and program

n = 1              The controller aborts motion only

No argument will cause the controller to abort the motion and program

**USAGE:**

**DEFAULTS:**

While Moving	Yes	Default Value	---
In a Program	Yes	Default Format	---
Command Line	Yes		

**OPERAND USAGE:**

\_AB gives state of Abort Input, 1 inactive and 0 active.

**RELATED COMMANDS:**

"SH (Binary AA)" on page 141      Re-enables motor.

"OE (Binary 8D)" on page 118      Specifies Off-On-Error.

**EXAMPLES:**

AB	Stops motion
OE 1,1,1,1	Enable off-on-error
AB	Shuts off motor command and stops motion
#A	Label - Start of program
JG 20000	Specify jog speed on X-axis
BGX	Begin jog on X-axis
WT 5000	Wait 5000 msec
AB1	Stop motion without aborting program
WT 5000	Wait 5000 milliseconds
SH	Servo Here
JP #A	Jump to Label A
EN	End of the routine

**Hint:** Remember to use the parameter 1 following AB if you only want the motion to be aborted. Otherwise, your application program will also be aborted.

## AC (Binary 90)

**FUNCTION:** Acceleration

**DESCRIPTION:**

The Acceleration (AC) command sets the linear acceleration rate of the motors for independent moves, such as PR, PA and JG moves. The parameters input will be rounded DOWN to the nearest factor of 1024. The units of the parameters are counts per second squared. The acceleration rate may be changed during motion. The DC command is used to specify the deceleration rate.

**ARGUMENTS:** AC n,n,n,n or ACX=n where

n is an unsigned numbers in the range in the range 1024 to 67107840

n = ? Returns the acceleration value for the specified axes.

**USAGE:**

**DEFAULTS:**

While Moving	Yes	Default Value	25600
In a Program	Yes	Default Format	8.0
Command Line	Yes		

**OPERAND USAGE:**

\_ACx contains the value of acceleration for the specified axis.

**RELATED COMMANDS:**

"DC" on page 49	Specifies deceleration rate.
"FA" on page 72	Feedforward Acceleration
"IT" on page 87	Smoothing constant - S-curve

**EXAMPLES:**

AC 150000,200000,300000,400000	Set X-axis acceleration to 150000, Y-axis to 200000 counts/sec <sup>2</sup> , the Z-axis to 300000 counts/sec <sup>2</sup> , and the W-axis to 400000 count/sec <sup>2</sup> .
AC ?,?,?,?	Request the Acceleration
0149504,0199680,0299008,0399360	Return Acceleration (resolution = 1024)
V=_ACY	Assigns the Y acceleration to the variable V

**Hint:** Specify realistic acceleration rates based on your physical system such as motor torque rating, loads, and amplifier current rating. Specifying an excessive acceleration will cause large following error during acceleration and the motor will not follow the commanded profile. The acceleration feedforward command FA will help minimize the error.



## AD (Binary CD)

**FUNCTION:** After Distance

**DESCRIPTION:**

The After Distance (AD) command is a trippoint used to control the timing of events. This command will hold up the execution of the following command until one of the following conditions have been met:

1. The commanded motor position crosses the specified relative distance from the start of the move.
2. The motion profiling on the axis is complete.
3. The commanded motion is in the direction which moves away from the specified position.

The units of the command are quadrature counts. Only one axis may be specified at a time. The motion profiler must be on or the trippoint will automatically be satisfied.

Note: AD will be affected when the motion smoothing time constant, IT, is not 1. See IT command for further information.

**ARGUMENTS:** AD n,n,n,n or ADX=n where

n is an unsigned integers in the range 0 to 2147483647 decimal.

**USAGE:**

**DEFAULTS:**

While Moving	Yes	Default Value	-
In a Program	Yes	Default Format	-
Command Line	Yes		

**RELATED COMMANDS:**

"AV" on page 23                      After distance for vector moves

**EXAMPLES:**

#A;DP0,0,0,0	Begin Program, Define position to 0 on all axes
PR 10000,20000,30000,40000	Specify positions
BG	Begin motion
AD 5000	After X reaches 5000
MG "Halfway to X";TPX	Send message
AD ,10000	After Y reaches 10000
MG "Halfway to Y";TPY	Send message
AD ,,15000	After Z reaches 15000
MG "Halfway to Z";TPZ	Send message
AD ,,20000	After W reaches 20000
MG "Halfway to W";TPW	Send message
EN	End Program

**Hint:** The AD command is accurate to the number of counts that occur in 2 servo samples. Multiply your speed by 2 servo samples to obtain the maximum position error in counts. Remember AD measures incremental distance from start of move on one axis.

## AI (Binary D1)

**FUNCTION:** After Input

**DESCRIPTION:**

The AI command is used in motion programs to wait until after the specified input has occurred.

If n is positive, it waits for the input to go high. If n is negative, it waits for n to go low.

**ARGUMENTS:** AI +/-n                      where

n is 1-96

**USAGE:**

While Moving

Yes

Default Value

-

In a Program

Yes

Default Format

-

Command Line

Yes

**DEFAULTS:**

**RELATED COMMANDS:**

@IN[n]

Function to read input 1 through 8

"II" on page 82

Input interrupt

#ININT

Label for input interrupt

**EXAMPLES:**

#A

Begin Program

AI 8

Wait until input 8 is high

SP 10000

Speed is 10000 counts/sec

AC 20000

Acceleration is 20000 counts/sec<sup>2</sup>

PR 400

Specify position

BG X

Begin motion

EN

End Program

**Hint:** The AI command actually halts execution until specified input is at desired logic level. Use the conditional Jump command (JP) or input interrupt (II) if you do not want the program sequence to halt.

## AL (Binary EE)

**FUNCTION:** Arm Latch

**DESCRIPTION:**

The AL command enables the latching function (high speed main or auxiliary position capture) of the controller. When the position latch is armed, the main or auxiliary encoder position will be captured upon a low going signal. Each axis has a position latch and can be activated through the general inputs: Input 1 (X or A axis), Input 2 (Y or B axis), Input 3 (Z or C axis), and Input 4 (W or D axis). The command RL returns the captured position for the specified axes. When interrogated the AL command will return a 1 if the latch for that axis is armed or a zero after the latch has occurred. The CN command will change the polarity of the latch.

**ARGUMENTS:** AL xxxx or AL x,x,x,x where

x can be X,Y,Z, or W. The value of x is used to specify main encoder for the specified axis to be latched

x can be SX,SY,SZ, or SW. The value of x is used to specify the auxiliary encoder for the specified axis to be latched

**USAGE:**

**DEFAULTS:**

While Moving	Yes	Default Value	0
In a Program	Yes	Default Format	1.0
Command Line	Yes		

**OPERAND USAGE:**

\_ALx contains the state of the specified latch. 0 = not armed, 1 = armed.

**RELATED COMMANDS:**

"RL (Binary DD)" on page 134 Report Latch

**EXAMPLES:**

#START	Start program
ALY	Arm Y-axis latch
JG,50000	Set up jog at 50000 counts/sec
BGY	Begin the move
#LOOP	Loop until latch has occurred
JP #LOOP,_ALY=1	
RLY	Transmit the latched position
EN	End of program

## AM (Binary C8)

**FUNCTION:** After Move

**DESCRIPTION:**

The AM command is a trippoint used to control the timing of events. This command will hold up execution of the following commands until the current move on the specified axis or axes is completed. Any combination of axes or a motion sequence may be specified with the AM command. For example, AM XY waits for motion on both the X and Y axis to be complete. AM with no parameter specifies that motion on all axes is complete.

**ARGUMENTS:** AM xxxx                      where

x is X,Y,Z,W,S, or T or any combination to specify the axis or sequence

No argument specifies to wait for after motion on all axes and / or sequences

**USAGE:**

**DEFAULTS:**

While Moving	Yes	Default Value	0
In a Program	Yes	Default Format	1.0
Command Line	Yes		

**RELATED COMMANDS:**

"BG" on page 28                      \_BGx contains a 0 if motion complete

**EXAMPLES:**

#MOVE	Program MOVE
PR 5000,5000,5000,5000	Position relative moves
BG X	Start the X-axis
AM X	After the move is complete on X
BG Y	Start the Y-axis
AM Y	After the move is complete on Y
BG Z	Start the Z-axis
AM Z	After the move is complete on Z
BG W	Start the W-axis
AM W	After the move is complete on W
EN	End of Program

**Hint:** AM is a very important command for controlling the timing between multiple move sequences. For example, if the X-axis is in the middle of a position relative move (PR) you cannot make a position absolute move (PAX, BGX) until the first move is complete. Use AMX to halt the program sequences until the first motion is complete. AM tests for profile completion. The actual motor may still be moving. Another method for testing motion complete is to check for the internal variable, \_BG, being equal to zero.

## AP (Binary CE)

**FUNCTION:** After Absolute Position

**DESCRIPTION:**

The After Position (AP) command is a trippoint used to control the timing of events. This command will hold up the execution of the following command until one of the following conditions have been met:

1. The actual motor position crosses the specified absolute position.
2. The motion profiling on the axis is complete.
3. The commanded motion is in the direction which moves away from the specified position.

The units of the command are quadrature counts. Only one axis may be specified at a time. The motion profiler must be on or the trippoint will automatically be satisfied

**ARGUMENTS:** AP n,n,n,n or APX=n where

n is a signed integer in the range -2147483648 to 2147483647 decimal

**USAGE:**

**DEFAULTS:**

While Moving	Yes	Default Value	---
In a Program	Yes	Default Format	---
Command Line	Yes		

**RELATED COMMANDS:**

"AD" on page 15                      Trippoint for relative distances  
"MF (Binary CB)" on page 107      Trippoint for forward motion

**EXAMPLES:**

#TEST	Program B
DP0	Define zero
JG 1000	Jog mode (speed of 1000 counts/sec)
BG X	Begin move
AP 2000	After passing the position 2000
V1=_TPX	Assign V1 X position
MG "Position is", V1=	Print Message
ST	Stop
EN	End of Program

**Hint:** The accuracy of the AP command is the number of counts that occur in 2 msec. Multiply the speed by 2 msec to obtain the maximum error. AP tests for absolute position. Use the AD command to measure incremental distances.

## AR (Binary CF)

**FUNCTION:** After Relative Distance

**DESCRIPTION:**

The After Relative (AR) command is a trippoint used to control the timing of events. This command will hold up the execution of the following command until one of the following conditions have been met:

1. The actual motor position crosses the specified relative distance from either the start of the move or the last AR or AD command.
2. The motion profiling on the axis is complete.
3. The commanded motion is in the direction which moves away from the specified position.

The units of the command are quadrature counts. Only one axis may be specified at a time. The motion profiler must be on or the trippoint will automatically be satisfied.

Note: AR will be affected when the motion smoothing time constant, IT, is not 1. See IT command for further information.

**ARGUMENTS:** AR n,n,n,n or ARX=n where  
n is an unsigned integer in the range 0 to 2147483647 decimal.

**USAGE:**

**DEFAULTS:**

While Moving	Yes	Default Value	-
In a Program	Yes	Default Format	-
Command Line	Yes		

**RELATED COMMANDS:**

"AV" on page 23	Trippoint for after vector position for coordinated moves
"AP (Binary CE)" on page 19	Trippoint for after absolute position

**EXAMPLES:**

#A;DP 0,0,0,0	Begin Program
JG 50000,,,7000	Specify speeds
BG XW	Begin motion
#B	Label
AR 25000	After passing 25000 counts of relative distance on X-axis
MG "Passed _X";TPX	Send message on X-axis
JP #B	Jump to Label #B
EN	End Program

**Hint:** AR is used to specify incremental distance from last AR or AD command. Use AR if multiple position trippoints are needed in a single motion sequence.

# AS (Binary DO)

**FUNCTION:** At Speed

**DESCRIPTION:**

The AS command is a trippoint that occurs when the generated motion profile has reached the specified speed. This command will hold up execution of the following command until the commanded speed has been reached. The AS command will operate after either accelerating or decelerating. If the speed is not reached, the trippoint will be triggered after the motion is stopped (after deceleration).

**ARGUMENTS:** AS xxxx                      where  
x is X,Y,Z,W,S or T or any combination to specify the axis or sequence

USAGE:	DEFAULTS:		
While Moving	Yes	Default Value	-
In a Program	Yes	Default Format	-
Command Line	Yes		

EXAMPLES:	
#SPEED	Program A
PR 100000	Specify position
SP 10000	Specify speed
BG X	Begin X
ASX	After speed is reached
MG "At Speed"	Print Message
EN	End of Program

**WARNING:**

The AS command applies to a trapezoidal velocity profile only with linear acceleration. AS used with Smoothing profiling will be inaccurate.

## AT (Binary D2)

**FUNCTION:** At Time

**DESCRIPTION:**

The AT command is a trippoint which is used to hold up execution of the next command until after the specified time has elapsed. The time is measured with respect to a defined reference time. AT 0 establishes the initial reference. AT n specifies n msec from the reference. AT -n specifies n msec from the reference and establishes a new reference after the elapsed time period.

**ARGUMENTS:** AT n      where

n is a signed integer in the range 0 to 2 Billion

n = 0 defines a reference time at current time

positive n waits n msec from reference

negative n waits n msec from reference and sets new reference after elapsed time period

(AT -n is equivalent to AT n; AT <old reference +n>

**USAGE:**

While Moving  
In a Program  
Command Line

**DEFAULTS:**

Yes	Default Value	0
Yes	Default Format	-
Yes		

**EXAMPLES:**

The following commands are sent sequentially

AT 0	Establishes reference time 0 as current time
AT 50	Waits 50 msec from reference 0
AT 100	Waits 100 msec from reference 0
AT -150	Waits 150 msec from reference 0 and sets new reference at 150
AT 80	Waits 80 msec from new reference (total elapsed time is 230 msec)



# AV

**FUNCTION:** After Vector Distance

**DESCRIPTION:**

The AV command is a trippoint which is used to hold up execution of the next command during coordinated moves such as VP,CR or LI. This trippoint occurs when the path distance of a sequence reaches the specified value. The distance is measured from the start of a coordinated move sequence or from the last AV command. The units of the command are quadrature counts.

**ARGUMENTS:** AV s,t      where

s and t are unsigned integers in the range 0 to 2147483647 decimal. 's' represents the vector distance to be executed in the S coordinate system and 't' represents the vector distance to be executed in the T coordinate system.

**USAGE:**

**DEFAULTS:**

While Moving	Yes	Default Value	0
In a Program	Yes	Default Format	-
Command Line	Yes		

**OPERAND USAGE:**

\_AVS contains the vector distance from the start of the sequence in the S coordinate system and  
\_AVT contains the vector distance from the start of the sequence in the T coordinate system.

**EXAMPLES:**

#MOVE;DP 0,0	Label
CAT	Specify the T coordinate system
LMXY	Linear move for X,Y
LI 1000,2000	Specify distance
LI 2000,3000	Specify distance
LE	
BGT	Begin motion in the T coordinate system
AV ,500	After path distance = 500,
MG "Path>500";TPXY	Print Message
EN	End Program

**Hint:** Vector Distance is calculated as the square root of the sum of the squared distance for each axis in the linear or vector mode.

## BA

**FUNCTION:** Brushless Axis

**DESCRIPTION:**

The BA command sets all axes that require sinusoidal commutation and reconfigures the controller to reflect the actual number of motors to be controlled. Each sinusoidal commutation axis requires an additional DAC which will always be associated with the highest axes on the controller. For example a 3 axis controller with X using sinusoidal commutation will require 4 DACs (DMC-1842), where the second DAC for the X will be the W axis motor command signal.

**ARGUMENTS:** BA xx                      where

x is X,Y,Z or any combination to specify the axis (axes) for sinusoidal commutation brushless axes.

No argument clears all axes configured for sinusoidal commutation.

**USAGE:**

**DEFAULTS:**

While Moving	No	Default Value	0
In a Program	Yes	Default Format	0
Command Line	Yes		

**OPERAND USAGE:**

\_BAx indicates the axis number of the auxiliary DAC used for the second phase of the selected sinusoidal axis. The axis numbers start with zero for the X axis DAC. If the motor is not configured as brush-type or stepper motor, \_BAx contains 0.

**RELATED COMMANDS:**

"BB (Binary 9E)" on page 25	Brushless Phase Begins
"BC" on page 26	Brushless Commutation
"BD (Binary 9D)" on page 27	Brushless Degrees
"BI" on page 29	Brushless Inputs
"BM (Binary 9B)" on page 31	Brushless Modulo
"BO (Binary 9F)" on page 33	Brushless Offset
"BS" on page 35	Brushless Setup
"BZ" on page 38	Brushless Zero

# BB (Binary 9E)

**FUNCTION:** Brushless Phase Begins

**DESCRIPTION:**

The BB function describes the position offset between the Hall transition point and  $\theta = 0$ , for sinusoidally commutated motor. This command must be saved in non-volatile memory to be effective upon reset.

**ARGUMENTS:** BB n,n,n,n or BAX=n where

n is a signed integer which represent the phase offset of the selected axes, expressed in multiples of 30°.

n = ? returns the hall offset for the specified axis.

**USAGE:**

While Moving  
In a Program  
Command Line

**DEFAULTS:**

No	Default Value	0
Yes	Default Format	0
Yes		

**EXAMPLES:**

BB,30,,60 The offsets for the Y and W axes are 30° and 60° respectively

**OPERAND USAGE:**

\_BBx contains the position offset between the Hall transition and  $\theta = 0$  for the specified axis.

**RELATED COMMANDS:**

"BA" on page 24	Brushless Axis
"BC" on page 26	Brushless Commutation
"BD (Binary 9D)" on page 27	Brushless Degrees
"BI" on page 29	Brushless Inputs
"BM (Binary 9B)" on page 31	Brushless Modulo
"BO (Binary 9F)" on page 33	Brushless Offset
"BS" on page 35	Brushless Setup
"BZ" on page 38	Brushless Zero

*Note: BB is only effective as part of the BC command or upon reset.*

## BC

**FUNCTION:** Brushless Calibration

**DESCRIPTION:**

The function BC monitors the status of the Hall sensors of a sinusoidally commutated motor, and upon transition, replaces the estimated value of a commutated phase by an exact value.

**ARGUMENTS:** BC xxxx                      where

x is X,Y,Z,W or any combination to specify the axis

**USAGE:**

**DEFAULTS:**

While Moving	Yes	Default Value	0
In a Program	Yes	Default Format	0
Command Line	Yes		

**OPERAND USAGE:**

\_BCx contains the state of the Hall sensor inputs. This value should be between 1 and 6.

**RELATED COMMANDS:**

"BA" on page 24	Brushless Axis
"BB (Binary 9E)" on page 25	Brushless Phase Begins
"BD (Binary 9D)" on page 27	Brushless Degrees
"BI" on page 29	Brushless Inputs
"BM (Binary 9B)" on page 31	Brushless Modulo
"BO (Binary 9F)" on page 33	Brushless Offset
"BS" on page 35	Brushless Setup
"BZ" on page 38	Brushless Zero

# BD (Binary 9D)

**FUNCTION:** Brushless Degrees

**DESCRIPTION:**

This command sets the commutation phase of a sinusoidally commutated motor. When using hall effect sensors, a more accurate value for this parameter can be set by using the command. BC. This command should not be used except when the user is creating a specialized phase initialization procedure.

**ARGUMENTS:** BD n,n,n,n or BDX=n where

n is an integer between 0 - 360°.

n = ? Returns the current brushless motor angle (between 0-360°)

**USAGE:**

**DEFAULTS:**

While Moving	No	Default Value	0
In a Program	Yes	Default Format	0
Command Line	Yes		

**OPERAND USAGE:**

\_BDx contains the commutation phase of the specified axis.

**RELATED COMMANDS:**

"BA" on page 24	Brushless Axis
"BB (Binary 9E)" on page 25	Brushless Phase Begins
"BC" on page 26	Brushless Commutation
"BI" on page 29	Brushless Inputs
"BM (Binary 9B)" on page 31	Brushless Modulo
"BO (Binary 9F)" on page 33	Brushless Offset
"BS" on page 35	Brushless Setup
"BZ" on page 38	Brushless Zero

## BG (Binary AO)

**FUNCTION:** Begin

**DESCRIPTION:**

The BG command starts a motion on the specified axis or sequence.

**ARGUMENTS:** BG xxxx                      where

x is X,Y,Z,W,S or T or any combination to specify the axis or sequence

**USAGE:**

**DEFAULTS:**

While Moving	Yes	Default Value	0
In a Program	Yes	Default Format	-
Command Line	Yes		

**OPERAND USAGE:**

\_BGx contains a '0' if motion complete on the specified axis or coordinate system, otherwise contains a '1'.

**RELATED COMMANDS:**

"AM (Binary C8)" on page 18	After motion complete
"ST (Binary A1)" on page 143	Stop motion

**EXAMPLES:**

PR 2000,3000,,5000	Set up for a relative move
BG XYW	Start the X,Y and W motors moving
HM	Set up for the homing
BGX	Start only the X-axis moving
JG 1000,4000	Set up for jog
BGY	Start only the Y-axis moving
YSTATE=_BGY	Assign a 1 to YSTATE if the Y-axis is performing a move
VMXY	Vector Mode
VP 1000,2000	Specify vector position
VS 20000	Specify vector velocity
BGS	Begin coordinated sequence
VP 4000,-1000	Specify vector position
VE	Vector End
PR ,,8000,5000	Specify Z and W position
BGSZW	Begin sequence and Z,W motion
MG _BGS	Displays a 1 if motion occurring on coordinated system "S"

**Hint:** You cannot give another BG command until current BG motion has been completed. Use the AM trippoint to wait for motion complete between moves. Another method for checking motion complete is to test for \_BG being equal to 0.

# BI

**FUNCTION:** Brushless Inputs

**DESCRIPTION:**

The command BI indicates the starting number for the input lines to which the Hall sensors have been wired for sinusoidally commutated motors. These inputs will be the general use inputs (bits 1-8). The Hall sensors of each axis must be connected with consecutive numbers of input lines.

The brushless setup command, BS, can be used to determine the proper wiring of the hall sensors.

**ARGUMENTS:** BI n,n,n or BIX=n where

n is an unsigned integer which represent the first digital input to be used for hall sensor input

n = 0 Clear the hall sensor configuration for the axis.

n = ? Returns the starting input used for Hall sensors for the specified axis.

**USAGE:**

**DEFAULTS:**

While Moving	Yes	Default Value	0
In a Program	Yes	Default Format	0
Command Line	Yes		

**OPERAND USAGE:**

\_BIx contains the starting input used for Hall sensors for the specified axis.

**EXAMPLE:**

BI, 5 The Hall sensor of the Y axis are on inputs 5, 6 and 7.

**RELATED COMMANDS:**

"BA" on page 24	Brushless Axis
"BB (Binary 9E)" on page 25	Brushless Phase Begins
"BC" on page 26	Brushless Commutation
"BD (Binary 9D)" on page 27	Brushless Degrees
"BM (Binary 9B)" on page 31	Brushless Modulo
"BO (Binary 9F)" on page 33	Brushless Offset
"BS" on page 35	Brushless Setup
"BZ" on page 38	Brushless Zero

## BL (Binary 8F)

**FUNCTION:** Reverse Software Limit

**DESCRIPTION:**

The BL command sets the reverse software limit. If this limit is exceeded during motion, motion on that axis will decelerate to a stop. Reverse motion beyond this limit is not permitted. The reverse limit is activated at X-1, Y-1, Z-1, W-1. To disable the reverse limit, set X,Y,Z,W to -2147483648. The units are in quadrature counts.

When the reverse software limit is activated, the automatic subroutine #LIMSWI will be executed if it is included in the program and a program is executing. See User's Manual, Automatic Subroutine.

**ARGUMENTS:** BL n,n,n,n or BLX=n where

n is a signed integer in the range -2147483648 to 2147483647.

n = -214783648 Turns off the reverse limit.

n = ? Returns the reverse software limit for the specified axes.

**USAGE:**

**DEFAULTS:**

While Moving	Yes	Default Value	-214783648
In a Program	Yes	Default Format	Position format
Command Line	Yes		

**OPERAND USAGE:**

\_BLx contains the value of the reverse software limit for the specified axis.

**RELATED COMMANDS:**

"FL" on page 75	Forward Limit
"PF" on page 122	Position Formatting

**EXAMPLES:**

#TEST	Test Program
AC 1000000	Acceleration Rate
DC 1000000	Deceleration Rate
BL -15000	Set Reverse Limit
JG -5000	Jog Reverse
BGX	Begin Motion
AMX	After Motion (limit occurred)
TPX	Tell Position
EN	End Program

**Hint:** Galil Controllers also provide hardware limits.



# BM (Binary 9B)

**FUNCTION:** Brushless Modulo

**DESCRIPTION:**

The BM command defines the length of the magnetic cycle in encoder counts.

**ARGUMENTS:** BM n,n,n,n or BMX=n where

n is a decimal value between 1 and 1000000 with a resolution of 1/10. This value can also be specified as a fraction with a resolution of 1/16.

n = ? Returns the brushless module for the specified axis.

**USAGE:**

**DEFAULTS:**

While Moving	No	Default Value	0
In a Program	Yes	Default Format	0
Command Line	Yes		

**OPERAND USAGE:**

\_BMx indicates the cycle length in counts for the specified axis.

**RELATED COMMANDS:**

"BA" on page 24	Brushless Axis
"BB (Binary 9E)" on page 25	Brushless Phase Begins
"BC" on page 26	Brushless Commutation
"BD (Binary 9D)" on page 27	Brushless Degrees
"BI" on page 29	Brushless Inputs
"BO (Binary 9F)" on page 33	Brushless Offset
"BS" on page 35	Brushless Setup
"BZ" on page 38	Brushless Zero

**EXAMPLES:**

BM ,60000	Set brushless modulo for Y axis to be 60000
BMZ=100000/6	Set brushless modulo for Z axis to be 100000/3 (33333.333)
BM ,,?	Interrogate the Brushless Module for the W axis

*Note:* Changing the BM parameter causes an instant change in the commutation phase.

## BN

**FUNCTION:** Burn

**DESCRIPTION:**

The BN command saves controller parameters, variables, arrays and applications programs shown below in Flash EEPROM memory. This command typically takes 1 second to execute and must not be interrupted. The controller returns a : when the Burn is complete.

**PARAMETERS SAVED DURING BURN:**

AC	CW	GR	OF	VD
BA	DC	IL	OP	VF
BB	EI	KD	PF	VS
BI	EO	KI	PL	VT
BL	ER	KP	SB	
BM	FA	KS	SP	
BO	FL	LZ	TL	
CE	FV	MO	TM	
CN	GA	MT	TR	
CO	GM	OE	VA	

**USAGE:**

While Moving  
In a Program  
Command Line

**DEFAULTS:**

Yes  
Yes  
Yes

Default Value

Default Format

-  
-  
-

**OPERAND USAGE:**

\_BN contains the serial number of the controller.

**EXAMPLES:**

KD 100	Set damping term for X axis
KP 10	Set proportional gain term for X axis
KI 1	Set integral gain term for X axis
AC 200000	Set acceleration
DC 150000	Set deceleration rate
SP 10000	Set speed
MT -1	Set motor type for X axis to be type '-1', reversed polarity servo motor
MO	Turn motor off
BN	Burn parameters; may take up to 15 seconds

# BO (Binary 9F)

**FUNCTION:** Brushless Offset

**DESCRIPTION:**

The BO command sets a fixed offset on command signal outputs for sinusoidally commutated motors. This may be used to offset any bias in the amplifier, or can be used for phase initialization.

**ARGUMENTS:** BO n,n,n or BOX=n where

n is used to specify the voltage and is specified as a decimal value between -10 and 10.

n = ? Return the brushless offset for the specified axis.

**USAGE:**

**DEFAULTS:**

While Moving	No	Default Value	0
In a Program	Yes	Default Format	0
Command Line	Yes		

**OPERAND USAGE:**

\_BOx contains the offset voltage on the DAC for the specified axis.

**EXAMPLES:**

BO -2,,1 Generates the voltages -2 and 1 on the first DAC X, and the second DAC Z of a sinusoidally commutated motor.

**RELATED COMMANDS:**

"BA" on page 24	Brushless Axis
"BB (Binary 9E)" on page 25	Brushless Phase Begins
"BC" on page 26	Brushless Commutation
"BD (Binary 9D)" on page 27	Brushless Degrees
"BI" on page 29	Brushless Inputs
"BM (Binary 9B)" on page 31	Brushless Modulo
"BS" on page 35	Brushless Setup
"BZ" on page 38	Brushless Zero

**HINT:** To assure that the output voltage equals the BO parameters, set the PID and OF parameters to zero.

## BP

**FUNCTION:** Burn Program

**DESCRIPTION::**

The BP command saves the application program in non-volatile EEPROM memory. This command typically takes up to 10 seconds to execute and must not be interrupted. The controller returns a : when the Burn is complete.

**ARGUMENTS:** None

**USAGE:**

**DEFAULTS:**

While Moving	No	Default Value	---
In a Program	No		
Not in a Program	Yes		

**RELATED COMMANDS:**

"BN" on page 32	Burn Parameters
"BV" on page 37	Burn Variable

Note: This command may cause the Galil software to issue the following warning "A time-out occurred while waiting for a response from the controller". This warning is normal and is designed to warn the user when the controller does not respond to a command within the timeout period. This occurs because this command takes more time than the default timeout of 1 sec. The timeout can be changed in the Galil software but this warning does not affect the operation of the controller or software.

**BS**

**FUNCTION:** Brushless Setup

**DESCRIPTION:**

The command BS tests the wiring of a sinusoidally commutated brushless motor. If no Hall sensors are connected, the function tests the wiring of the DAC's. If Hall sensors are connected, the function also tests the wiring of the Hall sensors. This function can be performed with one axis at a time. The first parameter indicates the voltage level to be applied to each phase, and the second parameter indicates the duration in milliseconds that the voltage will be applied.

This command returns status information regarding the setup of brushless motors. The following information will be returned by the controller:

- 1. Correct wiring of the brushless motor phases.
- 2. An approximate value of the motor's magnetic cycle.
- 3. The value of the BB command (If hall sensors are used).
- 4. The results of the hall sensor wiring test (If hall sensors are used).

This command will turn the motor off when done and may be given when the motor is off.

Once the brushless motor is properly setup and the motor configuration has been saved in non-volatile memory, the BS command does not have to be re-issued. The configuration is saved by using the burn command, BN.

**Note:** In order to properly conduct the brushless setup, the motor must be allowed to move a minimum of one magnetic cycle in both directions.

**ARGUMENTS:** BSX= v, n where

v is a real number between 0 and 10  
n is a positive integer between 100 or 1000.

USAGE:	DEFAULTS:		
While Moving	No	Default Value of V	0
In a Program	Yes	Default Value of n	200
Command Line	Yes		

**EXAMPLES:**

BSZ = 2,900                      Apply set up test to Z axis with 2 volts for 900 millisecond on each step.

**RELATED COMMANDS:**

"BA" on page 24	Brushless Axis
"BB" on page 25	Brushless Phase Begins
"BC" on page 26	Brushless Commutation
"BD" on page 27	Brushless Degrees
"BI" on page 29	Brushless Inputs
"BM" on page 31	Brushless Modulo
"BO" on page 33	Brushless Offset
"BZ" on page 38	Brushless Zero

**Note:** When using Galil Windows software, the timeout must be set to a minimum of 10seconds (timeout = 10000) when executing the BS command. This allows the software to retrieve all messages returned from the controller.

# BV

**FUNCTION:** Burn Variables

**DESCRIPTION::**

The BV command saves the controller variables in non-volatile EEPROM memory. This command typically takes up to 2 seconds to execute and must not be interrupted. The controller returns a : when the Burn is complete.

**ARGUMENTS:** None

**USAGE:**

**DEFAULTS:**

While Moving	Yes	Default Value	---
In a Program	Yes		
Not in a Program	Yes		

**RELATED COMMANDS:**

"BP" on page 34	Burn Program
-----------------	--------------

Note: This command may cause the Galil software to issue the following warning "A time-out occurred while waiting for a response from the controller". This warning is normal and is designed to warn the user when the controller does not respond to a command within the timeout period. This occurs because this command takes more time than the default timeout of 1 sec. The timeout can be changed in the Galil software but this warning does not affect the operation of the controller or software.

## BZ

**FUNCTION:** Brushless Zero

**DESCRIPTION:**

The BZ command is used for axes which are configured for sinusoidal commutation. This command drives the motor to zero magnetic phase and then sets the commutation phase to zero.

This command may be given when the motor is off.

**ARGUMENTS:** BZ n,n,n                      or              BZX =n                      where

n is a real numbers between -9.998 and 9.998.

The parameter n will set the voltage to be applied to the amplifier during the initialization. In order to be accurate, the BZ command must be large enough to move the motor. When the argument is positive, when the command completes, the motor will be left in the off state, MO. A negative value causes the motor to end up in the on state, SH.

**Note:** The BZ command causes instantaneous movement of the motor. It is recommended to start with small voltages and increase as needed

**Note:** Always use the Off-On-Error function (OE command) to avoid motor runaway whenever testing sinusoidal commutation.

**USAGE:**

**DEFAULTS:**

While Moving	No	Default Value	0
In a Program	Yes	Default Format	0
Command Line	Yes		

**OPERAND USAGE:**

\_BZx contains the distance in encoder counts from the motor's current position and the position of commutation zero for the specified axis. This can useful to command a motor to move to the commutation zero position for phase initialization.

**EXAMPLES:**

BZ, -3                      Drive the Z axis to zero phase position with 3 volts signal, and end up in SH state.

**RELATED COMMANDS:**

"BA" on page 24	Brushless Axis
"BB (Binary 9E)" on page 25	Brushless Phase Begins
"BC" on page 26	Brushless Commutation
"BD (Binary 9D)" on page 27	Brushless Degrees
"BI" on page 29	Brushless Inputs
"BM (Binary 9B)" on page 31	Brushless Modulo
"BO (Binary 9F)" on page 33	Brushless Offset
"BS" on page 35	Brushless Setup



# CA

**FUNCTION:** Coordinate Axes

**DESCRIPTION:**

The CA command specifies the coordinate system to apply proceeding vector commands. The following commands apply to the current coordinate system as set by the CA command:

CR	ES	LE	LI	LM
TN	VE	VM	VP	

**ARGUMENTS:** CAS or CAT where

CAS specifies that proceeding vector commands shall apply to the S coordinate system

CAT specifies that proceeding vector commands shall apply to the T coordinate system

CA ? returns a 0 if the S coordinate system is active and a 1 if the T coordinate system is active.

**OPERAND USAGE:**

\_CA contains a 0 if the S coordinate system is active and a 1 if the T coordinate system is active.

**USAGE:**

While Moving

In a Program

Command Line

**DEFAULTS:**

Yes

Yes

Yes

Default Value

Default Format

CAS

-

**RELATED COMMANDS:**

"VP" on page 168

"VS" on page 171

"VD" on page 163

"VA" on page 162

"VM" on page 166

"VE" on page 164

"BG" on page 28

Vector Position

Vector Speed

Vector Deceleration

Vector Acceleration

Vector Mode

End Vector

BGS - Begin Sequence

**EXAMPLES:**

CAT

VMXY

VS 10000

CR 1000,0,360

VE

BGT

Specify T coordinate system

Specify vector motion in the X and Y plane

Specify vector speed

Generate circle with radius of 1000 counts, start at 0 degrees and complete one circle in counterclockwise direction.

End Sequence

Start motion of T coordinate system

## CB (Binary EB)

**FUNCTION:** Clear Bit

**DESCRIPTION:**

The CB command sets the specified output bit low. CB can be used to clear the outputs of extended I/O which have been configured as outputs.

**ARGUMENTS:** CB n        where

n is an integer corresponding to the output bit to be cleared. The first output bit is specified as 1.

**USAGE:**

**DEFAULTS:**

While Moving	Yes	Default Value	-
In a Program	Yes	Default Format	-
Command Line	Yes		

**RELATED COMMANDS:**

"SB (Binary EA)" on page 139    Set Bit

"OP (Binary E8)" on page 120    Define output port (byte-wise).

**EXAMPLES:**

CB 7                            Clear output bit 7

# CD (Binary BE)

**FUNCTION:** Contour Data

**DESCRIPTION:**

The CD command specifies the incremental position on X,Y,Z and W axes. The units of the command are in quadrature counts. This command is used only in the Contour Mode (CM).

**ARGUMENTS:** CD n,n,n,n                      or                      CDX=n                      where  
n is an integer in the range of +/-32762

**USAGE:**

While Moving	Yes	Default Value	-
In a Program	Yes	Default Format	-
Command Line	Yes		

**DEFAULTS:**

**RELATED COMMANDS:**

"CM" on page 43	Contour Mode
"WC" on page 173	Wait for Contour
"DT" on page 54	Time Increment
"CS" on page 46	_CS is the Segment Counter

**EXAMPLES:**

CM XYZW	Specify Contour Mode
DT 4	Specify time increment for contour
CD 200,350,-150,500	Specify incremental positions on X,Y,Z and W axes X-axis moves 200 counts Y-axis moves 350 counts Z-axis moves -150 counts W-axis moves 500 counts
WC	Wait for complete
CD 100,200,300,400	New position data
WC	Wait for complete
DT0	Stop Contour
CD 0,0,0,0	Exit Mode

## CE (Binary 8C)

**FUNCTION:** Configure Encoder

**DESCRIPTION:**

The CE command configures the encoder to the quadrature type or the pulse and direction type. It also allows inverting the polarity of the encoders. The configuration applies independently to the four main axes encoders and the four auxiliary encoders.

**ARGUMENTS:** CE n,n,n,n or CEX=n where  
n is an integer in the range of 0 to 3. The values of n are

n =	Main encoder type
0	Normal quadrature
1	Normal pulse and direction
2	Reversed quadrature
3	Reversed pulse and direction

n = ? Returns the value of the encoder configuration for the specified axes.

**USAGE:**

**DEFAULTS:**

While Moving	Yes	Default Value	O
In a Program	Yes	Default Format	2.0
Command Line	Yes		

**OPERAND USAGE:**

\_CEx contains the value of encoder type for the axis specified by 'x'.

**RELATED COMMANDS:**

"MT" on page 111 Specify motor type

**EXAMPLES:**

CE 0, 3, 0, 2	Configure encoders
CE ?,?,?/?	Interrogate configuration
V = _CEX	Assign configuration to a variable

**Note:** When using pulse and direction encoders, the pulse signal is connected to CHA and the direction signal is connected to CHB.

# CM (Binary BD)

**FUNCTION:** Contouring Mode

**DESCRIPTION:**

The Contour Mode is initiated by the instruction CM. This mode allows the generation of an arbitrary motion trajectory with any of the axes. The CD command specified the position increment, and the DT command specifies the time interval.

The command, CM?, can be used to check the status of the Contour Buffer. A value of 1 returned from the command CM? indicates that the Contour Buffer is full. A value of 0 indicates that the Contour Buffer is empty.

**ARGUMENTS:** CM xxxx                      where

x is X,Y,Z,W or any combination to specify the axis (axes) for contour mode

n = ?              Returns a 1 if the contour buffer is full and 0 if the contour buffer is empty.

USAGE:	DEFAULTS:		
While Moving	Yes	Default Value	0
In a Program	Yes	Default Format	2.0
Command Line	Yes		

**OPERAND USAGE:**

\_CM contains a '0' if the contour buffer is empty, otherwise contains a '1'.

**RELATED COMMANDS:**

"CD" on page 41	Contour Data
"WC" on page 173	Wait for Contour
"DT" on page 54	Time Increment

**EXAMPLES:**

V=_CM;V=	Return contour buffer status
CM?	Return contour buffer status
CM XZ	Specify X,Z axes for Contour Mode

## CN (Binary E6)

**FUNCTION:** Configure

**DESCRIPTION:**

The CN command configures the polarity of the limit switches, home switches, latch inputs and the selective abort function.

**ARGUMENTS:** CN m,n,o,p            where

m,n,o are integers with values 1 or -1.

p is an integer, 0 or 1.

m =	1	Limit switches active high
	-1	Limit switches active low
n =	1	Home switch configured to drive motor in forward direction when input is high. See HM and FE commands.
	-1	Home switch configured to drive motor in reverse direction when input is high. See HM and FE commands
o =	1 *	Latch input is active high
	-1	Latch input is active low
p =	1	Configures inputs 5,6,7,8,13,14,15,16 as selective abort inputs for axes A,B,C,D,E,F,G, and H respectively
	0	Inputs 5,6,7,8,13,14,15,16 are configured as general use inputs

**USAGE:**

While Moving  
In a Program  
Command Line

**DEFAULTS:**

Yes  
Yes  
Yes

Default Value            -1,-1,-1,0  
Default Format            2.0

**OPERAND USAGE:**

\_CN0    Contains the limit switch configuration  
\_CN1    Contains the home switch configuration  
\_CN2    Contains the latch input configuration  
\_CN3    Contains the state of the selective abort function (1 enabled, 0 disabled)

**RELATED COMMANDS:**

"AL (Binary EE)" on page 17    Arm latch

**EXAMPLES:**

CN 1,1                            Sets limit and home switches to active high  
CN,, -1                          Sets input latch active low

## CR (Binary B3)

**FUNCTION:** Circle

**DESCRIPTION:**

The CR command specifies a 2-dimensional arc segment of radius,  $r$ , starting at angle,  $\theta$ , and traversing over angle  $\Delta\theta$ . A positive  $\Delta\theta$  denotes counterclockwise traverse, negative  $\Delta\theta$  denotes clockwise. The VE command must be used to denote the end of the motion sequence after all CR and VP segments are specified. The BG (Begin Sequence) command is used to start the motion sequence. All parameters,  $r$ ,  $\theta$ ,  $\Delta\theta$ , must be specified. Radius units are in quadrature counts.  $\theta$  and  $\Delta\theta$  have units of degrees. The parameter  $n$  is optional and describes the vector speed that is attached to the motion segment.

**ARGUMENTS:** CR  $r, \theta, \Delta\theta < n > o$  where

$r$  is an unsigned real number in the range 10 to 6000000 decimal (radius)

$\theta$  a signed number in the range 0 to +/-32000 decimal (starting angle in degrees)

$\Delta\theta$  is a signed real number in the range 0.0001 to +/-32000 decimal (angle in degrees)

$n$  specifies a vector speed to be taken into effect at the execution of the vector segment.  $n$  is an unsigned even integer between 0 and 12,000,000 for servo motor operation and between 0 and 3,000,000 for stepper motors.

$o$  specifies a vector speed to be achieved at the end of the vector segment.  $o$  is an unsigned even integer between 0 and 8,000,000.

**Note:** The product  $r * \Delta\theta$  must be limited to +/-4.5  $10^8$

**USAGE:**

**DEFAULTS:**

While Moving	Yes	Default Value	-
In a Program	Yes	Default Format	-
Command Line	Yes		

**RELATED COMMANDS:**

"VP" on page 168	Vector Position
"VS" on page 171	Vector Speed
"VD" on page 163	Vector Deceleration
"VA" on page 162	Vector Acceleration
"VM" on page 166	Vector Mode
"VE" on page 164	End Vector
"BG" on page 28	BGS - Begin Sequence

**EXAMPLES:**

VMXY	Specify vector motion in the X and Y plane
VS 10000	Specify vector speed
CR 1000,0,360	Generate circle with radius of 1000 counts, start at 0 degrees and complete
CR 1000,0,360 < 40000	Generate circle with radius of 1000 counts, start at 0 degrees and complete
VE	End Sequence
BGS	Start motion

## CS

**FUNCTION:** Clear Sequence

**DESCRIPTION:**

The CS command will remove VP, CR or LI commands stored in a motion sequence for the S or T coordinate systems. After a sequence has been executed, the CS command is not necessary to put in a new sequence. This command is useful when you have incorrectly specified VP, CR or LI commands.

**ARGUMENTS:** CSS        or        CST        where

S and/or T can be used to clear the sequence buffer for the "S" or "T" coordinate system.

**USAGE:**

**DEFAULTS:**

While Moving	No	Default Value	---
In a Program	Yes	Default Format	---
Command Line	Yes		

**OPERAND USAGE:**

\_CSx contains the segment number in the sequence specified by x, S or T. This operand is valid in the Linear mode, LM, Vector mode, VM.

**RELATED COMMANDS:**

"CR (Binary B3)" on page 45	Circular Interpolation Segment
"LI (Binary B1)" on page 98	Linear Interpolation Segment
"LM (Binary B 0)" on page 101	Linear Interpolation Mode
"VM" on page 166	Vector Mode
"VP (Binary B2)" on page 168	Vector Position

**EXAMPLES:**

#CLEAR	Label
CAT	Specify the T coordinate system vector points
VP 1000,2000	Vector position
VP 4000,8000	Vector position
CST	Clear vectors specified in T coordinate system
CAS	Specify the T coordinate system vector points
VP 1000,5000	New vector
VP 8000,9000	New vector
CSS	Clear vectors specified in S coordinate system



## CW

**FUNCTION:** Copyright information / Data Adjustment bit on/off

**DESCRIPTION:**

The CW command has a dual usage. The CW command will return the copyright information when the argument, n is 0. Otherwise, the CW command is used as a communications enhancement for use by the Servo Design Kit software. When turned on, the communication enhancement sets the MSB of unsolicited, returned ASCII characters to 1. Unsolicited ASCII characters are those characters which are returned from the controller without being directly queried from the terminal. This is the case when a program has a command that requires the controller to return a value or string.

**ARGUMENTS:** CW<sub>n,m</sub> where

**n = 0** Causes the controller to return the copyright information

n = 1 Causes the controller to set the MSB of unsolicited returned characters to 1

n = 2 Causes the controller to not set the MSB of unsolicited characters.

**n = ?** Returns the copyright information for the controller.

m is 0 or 1 (optional)

m=0 Causes the controller to pause program execution when output FIFO is full until FIFO no longer full.

m = 1 Causes the controller to continue program execution when output FIFO is full output characters after FIFO is full will be lost.

**USAGE:**

**DEFAULTS:**

While Moving	Yes	Default Value	2, 0
In a Program	Yes	Default Format	
Command Line	Yes		

**OPERAND USAGE:**

CW contains the value of the data adjustment bit. 2 = off, 1 = on

**Note:** The CW command can cause garbled characters to be returned by the controller. The default state of the controller is to disable the CW command, however, the Galil Servo Design Kit software and terminal software may sometimes enable the CW command for internal usage. If the controller is reset while the Galil software is running, the CW command could be reset to the default value which would create difficulty for the software. It may be necessary to re-enable the CW command. The CW command status can be stored in EEPROM.

**Note2:** Specifying both fields of the CW command together is not valid, as these are read as separate commands. If CW2,1 is issued, for example, the controller will not recognize the second data field. Instead, the commands must be issued individually, such as CW,2 ; CW,1.

## DA

**FUNCTION:** Deallocate the Variables & Arrays

**DESCRIPTION:**

The DA command frees the array and/or variable memory space. In this command, more than one array or variable can be specified for memory de-allocation. Different arrays and variables are separated by comma when specified in one command. The argument \* deallocates all the variables, and \*[0] deallocates all the arrays.

**ARGUMENTS:** DA c[0],variable-name        where

c[0] = Defined array name

variable-name = Defined variable name

\* - Deallocates all the variables

\*[0] - Deallocates all the arrays

n = ?        Returns the number of arrays available on the controller.

**USAGE:**

**DEFAULTS:**

While Moving	Yes	Default Value
In a Program	Yes	Default Format
Command Line	Yes	

**OPERAND USAGE:**

\_DA contains the total number of arrays available. For example, before any arrays have been defined, the operand \_DA is 30. If one array is defined, the operand \_DA will return 29.

**RELATED COMMANDS:**

"DM" on page 52        Dimension Array

**EXAMPLES:** 'Cars' and 'Sales' are arrays and 'Total' is a variable.

DM Cars[400],Sales[50]	Dimension 2 arrays
Total=70	Assign 70 to the variable Total
DA Cars[0],Sales[0],Total	Deallocate the 2 arrays & variables
DA*[]	Deallocate all arrays
DA *,*[]	Deallocate all variables and all arrays

**Note:** Since this command deallocates the spaces and compacts the array spaces in the memory, it is possible that execution of this command may take longer than 2ms.

# DC (Binary 91)

**FUNCTION:** Deceleration

**DESCRIPTION:**

The Deceleration command (DC) sets the linear deceleration rate of the motors for independent moves such as PR, PA and JG moves. The parameters will be rounded DOWN to the nearest factor of 1024 and have units of counts per second squared.

**ARGUMENTS:** DC n,n,n,n                      or                      DCX=n                      where

n is an unsigned numbers in the range 1024 to 67107840

n = ?                      Returns the deceleration value for the specified axes.

**USAGE:**

**DEFAULTS:**

While Moving	Yes*	Default Value	256000
In a Program	Yes	Default Format	8.0
Command Line	Yes		

\* When moving, the DC command can only be specified while in the jog mode.

**OPERAND USAGE:**

\_DCx contains the deceleration rate for the specified axis.

**RELATED COMMANDS:**

"AC" on page 14	Acceleration
"PR (Binary A7)" on page 124	Position Relative
"PA (Binary A6)" on page 121	Position Absolute
"SP (Binary 92)" on page 142	Speed
"JG (Binary A8)" on page 88	Jog
"BG" on page 28	Begin
"IT" on page 87	Smoothing

**EXAMPLES:**

PR 10000	Specify position
AC 2000000	Specify acceleration rate
DC 1000000	Specify deceleration rate
SP 5000	Specify slew speed
BG	Begin motion

***Note:** The DC command may be changed during the move in JG move, but not in PR or PA move.*

## DE (Binary 98)

**FUNCTION:** Stepper Encoder Position

**DESCRIPTION:**



The DE command defines the encoder position when used with stepper motors.

**ARGUMENTS:** DE n,n,n,n                      or                      DEX=n                      where

n is a signed integers in the range -2147483647 to 2147483648 decimal

n = ?                      Returns the position of the auxiliary encoders for the specified axes.



n = ? returns the commanded reference position of the motor (in step pulses) when used with a stepper motor. Example: DE 0 This will define the TP or encoder position to 0. This will not effect the DE ? value. (To set the DE value when in stepper mode use the DP command.)

**USAGE:**

**DEFAULTS:**

While Moving	Yes	Default Value	0,0,0,0
In a Program	Yes	Default Format	Position Format
Command Line	Yes		

**OPERAND USAGE:**

\_DEx contains the current position of the specified stepper axis.

**RELATED COMMANDS:**

"PF" on page 122                      Position Formatting

**EXAMPLES:**

DE 0,100,200,400	Set the current stepper encoder position to 0,100,200,400 on X,Y,Z and W axes
DE?,?,?,?	Return encoder positions if using steppers
ENCX=_DEX	Assign stepper encoder position of X-axis to the variable ENCX

## DL

**FUNCTION:** Download

**DESCRIPTION:**

The DL command transfers a data file from the host computer to the controller. Instructions in the file will be accepted as a datastream without line numbers. The file is terminated using <control> Z, <control> Q, <control> D, or \. DO NOT insert spaces before each command.

If no parameter is specified, downloading a data file will clear all programs in the controllers RAM. The data is entered beginning at line 0. If there are too many lines or too many characters per line, the controller will return a ?. To download a program after a label, specify the label name following DL. The argument # may be used with DL to append a file at the end of the program in RAM.

**ARGUMENTS:** DL n        where

n = no argument        Downloads program beginning at line 0. Erases programs in RAM.

n = #Label Begins download at line following #Label

n = #                    Begins download at end of program in RAM.

**USAGE:**

**DEFAULTS:**

While Moving	Yes	Default Value	---
In a Program	No	Default Format	---
Command Line	Yes		

**OPERAND USAGE:**

When used as an operand, \_DL gives the number of available labels.

Controller	Number of available labels
DMC-1812, DMC-1822, DMC-1832, DMC-1842	254

**RELATED COMMANDS:**

"UL" on page 161        Upload

**EXAMPLES:**

DL;	Begin download
#A;PR 4000;BGX	Data
AMX;MG DONE	Data
EN	Data
<control> Z	End download

# DM

**FUNCTION:** Dimension

**DESCRIPTION:**

The DM command defines a single dimensional array with a name and n total elements. The first element of the defined array starts with element number 0 and the last element is at n-1.

**ARGUMENTS:** DM c[n] where

c is a name of up to eight characters, starting with an uppercase alphabetic character. n specifies the size of the array (number of array elements).

n = ? Returns the number of array elements available.

**USAGE:**

**DEFAULTS:**

While Moving	Yes	Default Value	---
In a Program	Yes	Default Format	---
Command Line	Yes		

**OPERAND USAGE:**

\_DM contains the available array space. For example, before any arrays have been defined, the operand \_DM will return 8000. If an array of 100 elements is defined, the operand \_DM will return 7900.

**RELATED COMMANDS:**

"DA" on page 48                      Deallocate Array

**EXAMPLES:**

DM	Define dimension of arrays, pets with 5 elements; Dogs with 2
Pets[5],Dogs[2],Cats[3]	elements; Cats with 3 elements
DM Tests[1600]	Define dimension of array Tests with 1600 elements

# DP (Binary 97)

**FUNCTION:** Define Position

**DESCRIPTION:**

The DP command sets the current motor position and current command positions to a user specified value. The units are in quadrature counts. This command will set both the TP and RP values.



The DP command sets the commanded reference position for axes configured as steppers. The units are in steps. Example: DP 0 This will set the DE value to zero, but will not effect the TP value.

**ARGUMENTS:** DP n,n,n,n or DPX=n where  
n is a signed integer in the range -2147483648 to 2147483647 decimal.  
n = ? Returns the current position of the motor for the specified axes.

USAGE:	DEFAULTS:		
While Moving	No	Default Value	0,0,0,0
In a Program	Yes	Default Format	Position Format
Command Line	Yes		

**OPERAND USAGE:**

\_DPx contains the current position of the specified axis.

**RELATED COMMANDS:**

"PF" on page 122 Position Formatting

**EXAMPLES:**

DP 0,100,200,400	Sets the current position of the X-axis to 0, the Y-axis to 100, the Z-axis to 200, and the W-axis to 400
DP ,-50000	Sets the current position of Y-axis to -50000. The Y,Z and W axes remain unchanged.
DP ?,?,?,?	Interrogate the position of X,Y,Z and W axis.
0000000,-0050000,0000200,0000400	Returns all the motor positions
DP ?	Interrogate the position of X axis
0000000	Returns the X-axis motor position

**Hint:** The DP command is useful to redefine the absolute position. For example, you can manually position the motor by hand using the Motor Off command, MO. Turn the servo motors back on with SH and then use DP0 to redefine the new position as your absolute zero.

## DT (Binary BF)

**FUNCTION:** Delta Time

**DESCRIPTION:**

The DT command sets the time interval for Contouring Mode. Sending the DT command once will set the time interval for all following contour data until a new DT command is sent.  $2^n$  milliseconds is the time interval. Sending DT0 followed by CD0 command terminates the Contour Mode.

**ARGUMENTS:** DT n      where

n is an integer in the range 0 to 8. 0 terminates the Contour Mode. n=1 through 8 specifies the time interval of  $2^n$  samples. By default the sample period is 1 msec (set by the TM command); with n=1, the time interval would be 2 msec

n = ?      Returns the value for the time interval for contour mode.

**USAGE:**

**DEFAULTS:**

While Moving	Yes	Default Value	0
In a Program	Yes	Default Format	1.0
Command Line	Yes		

**OPERAND USAGE:**

\_DT contains the value for the time interval for Contour Mode

**RELATED COMMANDS:**

"CM" on page 43	Contour Mode
"CD" on page 41	Contour Data
"WC" on page 173	Wait for next data

**EXAMPLES:**

DT 4	Specifies time interval to be 16 msec
DT 7	Specifies time interval to be 128 msec
#CONTOUR	Begin
CMXY	Enter Contour Mode
DT 4	Set time interval
CD 1000,2000	Specify data
WC	Wait for contour
CD 2000,4000	New data
WC	Wait
DT0	Stop contour
CD0	Exit Contour Mode
EN	End



**EA**

**FUNCTION:** Choose ECAM master

**DESCRIPTION:**

The EA command selects the master axis for the electronic cam mode. Any axis may be chosen.

**ARGUMENTS:** EA x        where

x is one of the axis specified as X,Y,Z,W

**USAGE:**

**DEFAULTS:**

While Moving	Yes	Default Value
In a Program	Yes	Default Format
Command Line	Yes	

**RELATED COMMANDS:**

"EB (Binary C4)" on page 56	Enable ECAM
"EC (Binary C6)" on page 57	Set ECAM table index
"EG (Binary C3)" on page 59	Engage ECAM
"EM (Binary C1)" on page 63	Specify ECAM cycle
"EP (Binary C2)" on page 67	Specify ECAM table intervals & staring point
"EQ (Binary C5)" on page 68	Disengage ECAM
"ET (Binary CO)" on page 71	ECAM table

**EXAMPLES:**

EAY	Select Y as a master for ECAM
-----	-------------------------------

## EB (Binary C4)

**FUNCTION:** Enable ECAM

**DESCRIPTION:**

The EB function enables or disables the cam mode. In this mode, the starting position of the master axis is specified within the cycle. When the EB command is given, the master axis is modularized.

**ARGUMENTS:** EB n where

n = 1 Starts ECAM mode

n = 0 Stops ECAM mode.

n = ? Returns 0 if ECAM is disabled and a 1 if enabled.

**USAGE:**

**DEFAULTS:**

While Moving	Yes	Default Value
In a Program	Yes	Default Format
Command Line	Yes	

**OPERAND USAGE:**

\_EB contains the state of Ecam mode. 0 = disabled, 1 = enabled

**RELATED COMMANDS:**

"EA" on page 55	Choose ECAM master
"EC (Binary C6)" on page 57	Set ECAM table index
"EG (Binary C3)" on page 59	Engage ECAM
"EM (Binary C1)" on page 63	Specify ECAM cycle
"EP (Binary C2)" on page 67	Specify ECAM table intervals & staring point
"EQ (Binary C5)" on page 68	Disengage ECAM
"ET (Binary CO)" on page 71	ECAM table

**EXAMPLES:**

EB1	Starts ECAM mode
EB0	Stops ECAM mode
B = _EB	Return status of cam mode

# EC (Binary C6)

**FUNCTION:** ECAM Counter

**DESCRIPTION:**

The EC function sets the index into the ECAM table. This command is only useful when entering ECAM table values without index values and is most useful when sending commands in binary. See the command, ET.

**ARGUMENTS:** EC n where

n is an integer between 0 and 256.

n = ? Returns the current value of the index into the ECAM table.

**USAGE:**

**DEFAULTS:**

While Moving	Yes	Default Value
In a Program	Yes	Default Format
Command Line	Yes	

**OPERAND USAGE:**

\_EC contains the current value of the index into the ECAM table.

**RELATED COMMANDS:**

"EA" on page 55	Choose ECAM master
"EB (Binary C4)" on page 56	Enable ECAM
"EG (Binary C3)" on page 59	Engage ECAM
"EM (Binary C1)" on page 63	Specify ECAM cycle
"EP (Binary C2)" on page 67	Specify ECAM table intervals & staring point
"EQ (Binary C5)" on page 68	Disengage ECAM
"ET (Binary CO)" on page 71	ECAM table

**EXAMPLES:**

EC0	Set ECAM index to 0
ET 200,400	Set first ECAM table entries to 200,400
ET 400,800	Set second ECAM table entries to 400,800

## ED

**FUNCTION:** Edit

**DESCRIPTION:**

**Using Galil DOS Terminal Software:** The ED command puts the controller into the Edit subsystem. In the Edit subsystem, programs can be created, changed, or destroyed. The commands in the Edit subsystem are:

<cntrl>D           Deletes a line  
<cntrl>I Inserts a line before the current one  
<cntrl>P Displays the previous line  
<cntrl>Q           Exits the Edit subsystem  
<return> Saves a line

**Using Galil Windows Terminal Software:** The ED command causes the Windows terminal software to open the terminal editor.

**OPERAND USAGE:**

\_ED contains the line number of the last line to have an error.

**EXAMPLES:**

```
ED
000 #START
001 PR 2000
002 BGX
003 SLKJ                   Bad line
004 EN
005 #CMDERR               Routine which occurs upon a command error
006 V=_ED
007 MG "An error has occurred" {n}
008 MG "In line", V{F3.0}
009 ST
010 ZS0
011 EN
```

**Hint:** Remember to quit the Edit Mode prior to executing or listing a program.

# EG (Binary C3)

**FUNCTION:** ECAM go (engage)

**DESCRIPTION:**

The EG command engages an ECAM slave axis at a specified position of the master. If a value is specified outside of the master's range, the slave will engage immediately. Once a slave motor is engaged, its position is redefined to fit within the cycle.

**ARGUMENTS:** EG x,y,z,w or EGX=x where

x,y,z,w are the master positions at which the X,Y,Z,W axis must be engaged.

n = ? Returns 1 if specified axis is engaged and 0 if disengaged.

**USAGE:**

**DEFAULTS:**

While Moving	Yes	Default Value
In a Program	Yes	Default Format
Command Line	Yes	

**OPERAND USAGE:**

\_EGx contains ECAM status for specified axis. 0 = axis is not engaged, 1 = axis is engaged.

**RELATED COMMANDS:**

"EA" on page 55	Choose ECAM master
"EB (Binary C4)" on page 56	Enable ECAM
"EC (Binary C6)" on page 57	Set ECAM table index
"EM (Binary C1)" on page 63	Specify ECAM cycle
"EP (Binary C2)" on page 67	Specify ECAM table intervals & staring point
"EQ (Binary C5)" on page 68	Disengage ECAM
"ET (Binary CO)" on page 71	ECAM table

**EXAMPLES:**

EG 700,1300	Engages the X and Y axes at the master position 700 and 1300 respectively.
B = _EPY	Return the status of Y axis, 1 if engaged

***Note:** This command is not a trippoint. This command will not hold the execution of the program flow. If the execution needs to be held until master position is reached, use MF or MR command.*

## EI (Binary ED)

**FUNCTION:** Enable Interrupts

**DESCRIPTION:**

The EI command enables interrupt conditions such as motion complete or excess error. The conditions are selected by the parameter m where m is the bit mask for the selected conditions as shown below. Prior to using interrupts, interrupts must be configured for your controller. An interrupt service routine must also be incorporated in your host program.

**ARGUMENTS:** EI m,n where

EI 0 clears the interrupt queue

m is interrupt condition mask

n is input mask

BIT NO	m = ( $2^{\text{BIT NO}}$ )	CONDITION	BIT NO	m = ( $2^{\text{BIT NO}}$ )	CONDITION
0	1	X motion complete	8	256	All axes motion complete
1	2	Y motion complete	9	512	Excess position error*
2	4	Z motion complete	10	1024	Limit switch
3	8	W motion complete	11	2048	Watchdog timer
4	16	E motion complete	12	4096	Reserved
5	32	F motion complete	13	8192	Application program stopped
6	64	G motion complete	14	16384	Command done
7	128	H motion complete	15	32768	Inputs* (uses n for mask)

The \* conditions must be re-enabled after each occurrence.

BIT NO	n= ( $2^{\text{BIT NO}}$ )	CONDITION	BIT NO	n= ( $2^{\text{BIT NO}}$ )	CONDITION
0	1	Input 1	4	16	Input 5
1	2	Input 2	5	32	Input 6
2	4	Input 3	6	64	Input 7
3	8	Input 4	7	128	Input 8

**USAGE:**

While Moving  
In a Program  
Command Line

**DEFAULTS:**

Yes  
Yes  
Yes

Default Value  
Default Format

0  
---

**RELATED COMMANDS:**

"UI" on page 160      User interrupt

**EXAMPLES:**

1. Specify interrupts for all axes motion complete and limit switch.

Enable bits 8 and 10.  $m = 2^8 + 2^{10} = 256 + 1024 = 1280$

EI 1280

2. Specify interrupt on Input 3.

Enable bit 15 on m and bit 2 on n.

$m = 2^{15} = 32768$

$n = 2^2 = 4$

EI 32768,4

# ELSE

**FUNCTION:** Else function for use with IF conditional statement

**DESCRIPTION:**

The ELSE command is an optional part of an IF conditional statement. The ELSE command must occur after an IF command and it has no arguments. It allows for the execution of a command only when the argument of the IF command evaluates False. If the argument of the IF command evaluates false, the controller will skip commands until the ELSE command. If the argument for the IF command evaluates true, the controller will execute the commands between the IF and ELSE command.

**ARGUMENTS:** ELSE

**USAGE:**

While Moving  
In a Program  
Command Line

**DEFAULTS:**

Yes                      Default Value  
Yes                      Default Format  
No

**RELATED COMMANDS:**

"IF" on page 83                      Command to begin IF conditional statement  
"ENDIF" on page 65                      End of IF conditional Statement

**EXAMPLES:**

IF (@IN[1]=0)	IF conditional statement based on input 1
IF (@IN[2]=0)	2 <sup>nd</sup> IF conditional statement executed if 1 <sup>st</sup> IF conditional true
MG "INPUT 1 AND 2 ARE ACTIVE"	Message to be executed if 2 <sup>nd</sup> IF conditional is true
ELSE	ELSE command for 2 <sup>nd</sup> IF conditional statement
MG "ONLY INPUT 1 IS ACTIVE"	Message to be executed if 2 <sup>nd</sup> IF conditional is false
ENDIF	End of 2 <sup>nd</sup> conditional statement
ELSE	ELSE command for 1 <sup>st</sup> IF conditional statement
MG"ONLY INPUT 2 IS ACTIVE"	Message to be executed if 1 <sup>st</sup> IF conditional statement
ENDIF	End of 1 <sup>st</sup> conditional statement



# EM (Binary C1)

**FUNCTION:** Cam cycles

**DESCRIPTION:**

The EM command is part of the ECAM mode. It is used to define the change in position over one complete cycle of the master. The field for the master axis is the cycle of the master position. For the slaves, the field defines the net change in one cycle. If a slave will return to its original position at the end of the cycle, the change is zero. If the change is negative, specify the absolute value.

**ARGUMENTS:** EM n,n,n,n or EMX=n where

n is a positive integer in the range between 1 and 8,388,607 for the master axis and between 1 and 2,147,483,647 for a slave axis.

USAGE:	DEFAULTS:	
While Moving	Yes	Default Value
In a Program	Yes	Default Format
Command Line	Yes	

**OPERAND USAGE:**

\_EMx contains the cycle of the specified axis.

**RELATED COMMANDS:**

"EA" on page 55	Choose ECAM master
"EB" on page 56	Enable ECAM
"EC" on page 57	Set ECAM table index
"EG" on page 59	Engage ECAM
"EP" on page 67	Specify ECAM table intervals & staring point
"EQ" on page 68	Disengage ECAM
"ET" on page 71	ECAM table

**EXAMPLES:**

EAZ	Select Z axis as master for ECAM.
EM 0,3000,2000	Define the changes in X and Y to be 0 and 3000 respectively. Define master cycle as 2000.
V = _EMX	Return cycle of X

## EN

**FUNCTION:** End

**DESCRIPTION:**

The EN command is used to designate the end of a program or subroutine. If a subroutine was called by the JS command, the EN command ends the subroutine and returns program flow to the point just after the JS command.

The EN command is used to end the automatic subroutines #MCTIME, and #CMDERR.

**USAGE:**

While Moving  
In a Program  
Command Line

**DEFAULTS:**

Yes  
Yes  
No

Default Value  
Default Format

---

**RELATED COMMANDS:**

“RE” on page 132  
“RI” on page 133

Return from error subroutine  
Return from interrupt subroutine

**EXAMPLES:**

#A	Program A
PR 500	Move X axis forward 500 counts
BGX	Pause the program until the X axis completes the motion
AMX	Move X axis forward 1000 counts
PR 1000	Set another Position Relative move
BGX	Begin motion
EN	End of Program

**Note:** Instead of EN, use the RE command to end the error subroutine, #POSERR, and limit subroutine, #LIMSWI. Use the RI command to end the input interrupt (ININT) subroutine.

# ENDIF

**FUNCTION:** End of IF conditional statement

**DESCRIPTION:**

The ENDIF command is used to designate the end of an IF conditional statement. An IF conditional statement is formed by the combination of an IF and ENDIF command. An ENDIF command must always be executed for every IF command that has been executed. It is recommended that the user not include jump commands inside IF conditional statements since this causes re-direction of command execution. In this case, the command interpreter may not execute an ENDIF command.

**ARGUMENTS:** ENDIF

**USAGE:**

While Moving  
In a Program  
Command Line

**DEFAULTS:**

Yes	Default Value
Yes	Default Format
No	

**RELATED COMMANDS:**

"IF" on page 83	Command to begin IF conditional statement
"ELSE" on page 62	Optional command to be used only after IF command

**EXAMPLES:**

IF (@IN[1]=0)	IF conditional statement based on input 1
MG " INPUT 1 IS ACTIVE	Message to be executed if "IF" conditional is false
ENDIF	End of conditional statement

***Note:** Instead of EN, use the RE command to end the error subroutine and limit subroutine. Use the RI command to end the input interrupt (ININT) subroutine.*

# EO

**FUNCTION:** Echo

**DESCRIPTION:**

The EO command turns the echo on or off. If the echo is off, characters input over the bus will not be echoed back.

**ARGUMENTS:** EO n        where

n = 0        0 turns echo off

n = 1        1 turns echo on.

**USAGE:**

**DEFAULTS:**

While Moving	Yes	Default Value	0
In a Program	Yes	Default Format	1.0
Command Line	Yes		

**EXAMPLES:**

EO 0	Turns echo off
EO 1	Turns echo on

# EP (Binary C2)

**FUNCTION:** Cam table intervals and starting point

**DESCRIPTION:**

The EP command defines the ECAM table intervals and offset. The offset is the master position of the first ECAM table entry. The interval is the difference of the master position between 2 consecutive table entries. This command effectively defines the size of the ECAM table. The parameter m is the interval and n is the starting point. Up to 257 points may be specified.

**ARGUMENTS:** EP m,n where

m is a positive integer in the range between 1 and 32,767

m = ? Returns the value of the interval, m.

n is an integer between -2,147,483,648 and 2,147,483,647.

**USAGE:**

**DEFAULTS:**

While Moving	Yes	Default Value
In a Program	Yes	Default Format
Command Line	Yes	

**OPERAND USAGE:**

\_EP contains the value of the interval m.

**RELATED COMMANDS:**

"EA" on page 55	Choose ECAM master
"EB (Binary C4)" on page 56	Enable ECAM
"EC (Binary C6)" on page 57	Set ECAM table index
"EG (Binary C3)" on page 59	Engage ECAM
"EM (Binary C1)" on page 63	Specify ECAM cycle
"EQ (Binary C5)" on page 68	Disengage ECAM
"ET (Binary CO)" on page 71	ECAM table

**EXAMPLES:**

EP 20,100	Sets the cam master points to 100,120,140 . . .
D = _EP	Contains interval (m)

## EQ (Binary C5)

**FUNCTION:** ECAM quit (disengage)

**DESCRIPTION:**

The EQ command disengages an electronic cam slave axis at the specified master position. Separate points can be specified for each axis. If a value is specified outside of the master's range, the slave will disengage immediately.

**ARGUMENTS:** EQ n,n,n,n or EQX=n where

n is the master positions at which the axes are to be disengaged.

n = ? Returns 1 if engage command issued and axis is waiting to engage, 2 if disengage command issued and axis is waiting to disengage, and 0 if ECAM engaged or disengaged.

**USAGE:**

**DEFAULTS:**

While Moving	Yes	Default Value
In a Program	Yes	Default Format
Command Line	Yes	

**OPERAND USAGE:**

\_EQx contains 1 if engage command issued and axis is waiting to engage, 2 if disengage command issued and axis is waiting to disengage, and 0 if ECAM engaged or disengaged.

**RELATED COMMANDS:**

"EA" on page 55	Choose ECAM master
"EB (Binary C4)" on page 56	Enable ECAM
"EC (Binary C6)" on page 57	Set ECAM table index
"EG (Binary C3)" on page 59	Engage ECAM
"EM (Binary C1)" on page 63	Specify ECAM cycle
"EP (Binary C2)" on page 67	Specify ECAM table intervals & starting point
"ET (Binary CO)" on page 71	ECAM table

**EXAMPLES:**

EQ 300,700 Disengages the X and Y motors at master positions 300 and 700 respectively.

**Note:** This command is not a trippoint. This command will not hold the execution of the program flow. If the execution needs to be held until master position is reached, use MF or MR command.

# ER (Binary 88)

**FUNCTION:** Error Limit

**DESCRIPTION:**

The ER command sets the magnitude of the X,Y,Z and W-axis position errors that will trigger an error condition. When the limit is exceeded, the Error output will go low (true). If the Off On Error (OE1) command is active, the motors will be disabled. The units of ER are quadrature counts.

**ARGUMENTS:** ER n,n,n,n or ERX=n where  
n is an unsigned numbers in the range 1 to 32767  
n = ? Returns the value of the Error limit for the specified axis.

USAGE:	DEFAULTS:		
While Moving	Yes	Default Value	16384
In a Program	Yes	Default Format	Position Format
Command Line	Yes		

**OPERAND USAGE:**  
  
\_ERx contains the value of the Error limit for the specified axis.

**RELATED COMMANDS:**  
"OE (Binary 8D)" on page 118 Off-On Error  
#POSERR Automatic Error Subroutine

**EXAMPLES:**

ER 200,300,400,600	Set the X-axis error limit to 200, the Y-axis error limit to 300, the Z-axis error limit to 400, and the W-axis error limit to 600.
ER ,1000	Sets the Y-axis error limit to 1000, leave the X-axis error limit unchanged.
ER ?,?,?,?	Return X,Y,Z and W values
00200,00100,00400,00600	
ER ?	Return X value
00200	
V1=_ERX	Assigns V1 value of ERX
V1=	Returns V1
00200	

***Hint:** The error limit specified by ER should be high enough as not to be reached during normal operation. Examples of exceeding the error limit would be a mechanical jam, or a fault in a system component such as encoder or amplifier.*

## ES

**FUNCTION:** Ellipse Scale

**DESCRIPTION:**

The ES command divides the resolution of one of the axes in a vector mode (VM). This function allows for correction generation of circular motion when encoder resolutions differ. It also allows for the generation of an ellipse instead of a circle.

The command has two parameters, m and n. The arguments, m and n apply to the axes designated by the command VMxy (x and y are the two axes to be used in vector mode). When  $m > n$ , the resolution of the first axis, x, will be divided by the ratio  $m/n$ . When  $m < n$ , the resolution of the second axis, y, will be divided by  $n/m$ . The resolution change applies for the purpose of generating the VP and CR commands. The result of this command is to cause one axis to move the distance specified by the CR and VP commands and the other axis to move a larger distance.

The ES command will apply to the selected coordinate system, S or T. To select the coordinate system, use the command CAS or CAT.

**ARGUMENTS:** ES m,n                      where

m and n are positive integers in the range between 1 and 65,535.

**USAGE:**

While Moving  
In a Program  
Command Line

**DEFAULTS:**

Yes  
Yes  
Yes

Default Value

1,1

Default Format

**RELATED COMMANDS:**

"VM" on page 166	Vector Mode
"CR" on page 45	Circle move
"VP" on page 168	Vector position

**EXAMPLES:**

VMXY;ES3,4	Divide Y resolution by 4/3
VMZX;ES2,3	Divide X resolution by 3/2



# ET (Binary CO)

**FUNCTION:** Electronic cam table

**DESCRIPTION:**

The ET command sets the ECAM table entries for the slave axes.. The values of the master axes are not required. The slave entry (n) is the position of the slave axes when the master is at the point (n \* i) + o, where i is the interval and o is the offset as determined by the EP command.

**ARGUMENTS:** ET[n] = n,n,n,n where

n is an integer in the range between -2,147,438,648, and 2,147,438,647.

The value n can be left out of the command if the index count has been set using the command, EC. In this mode, each ET command will automatically increment the index count by 1.

USAGE:	DEFAULTS:	
While Moving	Yes	Default Value
In a Program	Yes	Default Format
Command Line	Yes	

**RELATED COMMANDS:**

"EA" on page 55	Choose ECAM master
"EB (Binary C4)" on page 56	Enable ECAM
"EC (Binary C6)" on page 57	Set ECAM table index
"EG (Binary C3)" on page 59	Engage ECAM
"EM (Binary C1)" on page 63u	Specify ECAM cycle
"EP (Binary C2)" on page 67	Specify ECAM table intervals & staring point
"EQ (Binary C5)" on page 68	Disengage ECAM

**EXAMPLES:**

ET[0]=0,,0	Specifies the position of the slave axes X and Z to be synchronized with the starting point of the master.
ET[1]=1200,,400	Specifies the position of the slave axes X and Z to be synchronized with the second point of the master
EC0	Set the table index value to 0, the first element in the table
ET 0,,0	Specifies the position of the slave axes X and Z to be synchronized with the starting point of the master.
ET 1200,,400	Specifies the position of the slave axes X and Z to be synchronized with the second point of the master

## FA (Binary 94)

**FUNCTION:** Acceleration Feedforward

**DESCRIPTION:**

The FA command sets the acceleration feedforward coefficient, or returns the previously set value. This coefficient, when scaled by the acceleration, adds a torque bias voltage during the acceleration phase and subtracts the bias during the deceleration phase of a motion.

$$\text{Acceleration Feedforward Bias} = \text{FA} \cdot \text{AC} \cdot 1.5 \cdot 10^{-7}$$

$$\text{Deceleration Feedforward Bias} = \text{FA} \cdot \text{DC} \cdot 1.5 \cdot 10^{-7}$$

The Feedforward Bias product is limited to 10 Volts. FA operates when commanding motion with PA, PR and JG.

**ARGUMENTS:** FA n,n,n,n or FAX=n where

n is an unsigned number in the range 0 to 8191 decimal with a resolution of 0.25.

n = ? Returns the value of the feedforward acceleration coefficient for the specified axis.

**USAGE:**

**DEFAULTS:**

While Moving	Yes	Default Value	0
In a Program	Yes	Default Format	4.0
Command Line	Yes		

**OPERAND USAGE:**

\_FAx contains the value of the feedforward acceleration coefficient for the specified axis.

**RELATED COMMANDS:**

"FV" on page 76      Velocity feedforward

**EXAMPLES:**

AC 500000,1000000	Set feedforward coefficient to 10 for the X-axis
FA 10,15	and 15 for the Y-axis. The effective bias will be 0.75V for X and 2.25V for Y.
FA ?,?	Return X and Y values
010,015	

**Note:** If the feedforward coefficient is changed during a move, then the change will not take effect until the next move.

# FE (Binary A4)

**FUNCTION:** Find Edge

**DESCRIPTION:**

The FE command moves a motor until a transition is seen on the homing input for that axis. The direction of motion depends on the initial state of the homing input (use the CN command to configure the polarity of the home input). Once the transition is detected, the motor decelerates to a stop.

This command is useful for creating your own homing sequences.

**ARGUMENTS:** FE xxxx                      where  
x is X,Y,Z, or W or any combination to specify the axis or axes  
No argument specifies all axes.

USAGE:	DEFAULTS:	
While Moving	No	Default Value
In a Program	Yes	Default Format
Command Line	Yes	

RELATED COMMANDS:	
"FI" on page 74	Find Index
"HM" on page 80	Home
"BG" on page 28	Begin
"AC" on page 14	Acceleration Rate
"DC" on page 49	Deceleration Rate
"SP (Binary 92)" on page 142	Speed for search

EXAMPLES:	
FE	Set find edge mode
BG	Begin all axes
FEX	Only find edge on X
BGX	
FEY	Only find edge on Y
BGY	
FEZW	Find edge on Z and W
BGZW	

***Hint:** Find Edge only searches for a change in state on the Home Input. Use FI (Find Index) to search for the encoder index. Use HM (Home) to search for both the Home input and the Index. Remember to specify BG after each of these commands.*

## FI (Binary A5)

**FUNCTION:** Find Index

**DESCRIPTION:**

The FI and BG commands move the motor until an encoder index pulse is detected. The controller looks for a transition from low to high. When the transition is detected, motion stops and the position is defined as zero. To improve accuracy, the speed during the search should be specified as 500 counts/s or less. The FI command is useful in custom homing sequences. The direction of motion is specified by the sign of the JG command.

**ARGUMENTS:** FI xxxx                      where

x is X,Y,Z, or W or any combination to specify the axis or sequence

No argument specifies all axes.

**USAGE:**

**DEFAULTS:**

While Moving	No	Default Value
In a Program	Yes	Default Format
Command Line	Yes	

**RELATED COMMANDS:**

"FE" on page 73	Find Edge
"HM" on page 80	Home
"BG" on page 28	Begin
"AC" on page 14	Acceleration Rate
"DC" on page 49	Deceleration Rate
"SP (Binary 92)" on page 142	Search Speed

**EXAMPLES:**

#HOME	Home Routine
JG 500	Set speed and forward direction
FIX	Find index
BGX	Begin motion
AMX	After motion
MG "FOUND INDEX"	

**Hint:** Find Index only searches for a change in state on the Index. Use FE to search for the Home. Use HM (Home) to search for both the Home input and the Index. Remember to specify BG after each of these commands.

# FL (Binary 8E)

**FUNCTION:** Forward Software Limit

**DESCRIPTION:**

The FL command sets the forward software position limit. If this limit is exceeded during motion, motion on that axis will decelerate to a stop. Forward motion beyond this limit is not permitted. The forward limit is activated at X+1, Y+1, Z+1, W+1. The forward limit is disabled at 2147483647. The units are in counts.

When the software limit is activated, the automatic subroutine #LIMSWI will be executed if it is included in the program and a program is executing. See User's Manual, Automatic Subroutine.

**ARGUMENTS:** FL n,n,n,n      or    FLX=n      where

n is a signed integers in the range -2147483648 to 2147483647

n = 2147483647      turns off the forward limit

n = ?      Returns the value of the forward limit switch for the specified axis.

**USAGE:**

**DEFAULTS:**

While Moving	Yes	Default Value	2147483647
In a Program	Yes	Default Format	Position Format
Command Line	Yes		

**OPERAND USAGE:**

\_FLx contains the value of the forward software limit for the specified axis.

**RELATED COMMANDS:**

"BL" on page 30	Reverse Limit
"PF" on page 122	Position Formatting

**EXAMPLES:**

FL 150000	Set forward limit to 150000 counts on the X-axis
#TEST	Test Program
AC 1000000	Acceleration Rate
DC 1000000	Deceleration Rate
FL 15000	Forward Limit
JG 5000	Jog Forward
BGX	Begin
AMX	After Limit
TPX	Tell Position
EN	End

*Hint: Galil controllers also provide hardware limits.*

## FV (Binary 95)

**FUNCTION:** Velocity Feedforward

**DESCRIPTION:**

The FV command sets the velocity feedforward coefficient, or returns the previously set value.

This coefficient, generates an output bias signal in proportions to the commanded velocity.

Velocity feedforward bias =  $1.22 \cdot 10^{-6} \cdot \text{FV} \cdot \text{Velocity}$  [in cts/s].

FV operates when commanding motion with PA, PR, JG, VM, LM, and CM.

For example, if FV=10 and the velocity is 200,000 count/s, the velocity feedforward bias equals 2.44 volts.

**ARGUMENTS:** FV n,n,n,n or FVX=n where

n is an unsigned numbers in the range 0 to 8191 decimal

n = ? Returns the feedforward velocity for the specified axis.

**USAGE:**

**DEFAULTS:**

While Moving	Yes	Default Value	0
In a Program	Yes	Default Format	3.0
Command Line	Yes		

**OPERAND USAGE:**

\_FVx contains the feedforward velocity for the specified axis.

**RELATED COMMANDS:**

"FA" on page 72 Acceleration feedforward

**EXAMPLES:**

FV 10,20	Set feedforward coefficients to 10 and 20 for x
JG 30000,80000	and y respectively. This produces 0.366 volts for x and 1.95 volts for y.
FV ?,?	Return the x and y values.
010,020	

## GA

**FUNCTION:** Master Axis for Gearing

**DESCRIPTION:**

The GA command specifies the master axes for electronic gearing. Multiple masters for gearing may be specified. The masters may be the main encoder input, auxiliary encoder input, or the commanded position of any axis. The master may also be the commanded vector move in a coordinated motion of LM or VM type. When the master is a simple axis, it may move in any direction and the slave follows. When the master is a commanded vector move, the vector move is considered positive and the slave will move forward if the gear ratio is positive, and backward if the gear ratio is negative. The slave axes and ratios are specified with the GR command and gearing is turned off by the command GR0.

**ARGUMENTS:** GA x,x,x,x or GAX=x where

x can be X,Y,Z, or W. The value of x is used to set the specified main encoder axis as the gearing master. The slave axis is specified by the position of the argument. The first position of the argument corresponds to the 'X' axis, the second position corresponds to the 'Y' axis, etc. A comma must be used in place of an argument if the corresponding axes will not be a slave.

x can be CX,CY,CZ, or CW. The value of x is used to set the commanded position of the specified axis as the gearing master.

x can be S or T. S and T are used to specify the vector motion of the coordinated system, S or T, as the gearing master.

x can be DX,DY,DZ, or DW. The value of x is used to set the specified auxiliary encoder axis as the gearing master.

**USAGE:**

While Moving  
In a Program  
Command Line

**DEFAULTS:**

	No	Default Value
	Yes	Default Format
	Yes	

**RELATED COMMANDS:**

"GR" on page 79	Gear Ratio
"GM" on page 78	Gantry Mode

**EXAMPLES:**

#GEAR	Gear program
GA .X.T	Specify X axis as master for Y and vector motion on T as master for Z
GR ..5.-2.5	Specify Y and Z ratios
JG 5000	Specify master jog speed
BGX	Begin motion
WT 10000	Wait 10000 msec
STX	Stop

**Hint:** Using the command position as the master axis is useful for gantry applications. Using the vector motion as master is useful in generating Helical motion.

# GM

**FUNCTION:** Gantry mode

**DESCRIPTION:**

The GM command specifies the axes in which the gearing function is performed in the Gantry mode. In this mode, the gearing will not stop by the ST command or by limit switches. Only GR0 will stop the gearing in this mode.

**ARGUMENTS:** GM n,n,n,n or GMX=n where

n = 0 Disables gantry mode function

n = 1 Enables the gantry mode

n = ? Returns the state of gantry mode for the specified axis: 0 gantry mode disabled, 1 gantry mode enabled

**USAGE:**

While Moving

**DEFAULTS:**

Yes

Default Value

0

In a Program

Yes

Default Format

1.0

Command Line

Yes

**OPERAND USAGE:**

\_GMx contains the state of gantry mode for the specified axis: 0 gantry mode disabled, 1 gantry mode enabled

**RELATED COMMANDS:**

"GR" on page 79

Gear Ratio

"GA" on page 77

Master Axis for Gearing

**EXAMPLES:**

GM 1,1,1,1

Enable GM on all axes

GM 0

Disable GM on X-axis other axes remain unchanged

GM ,,1,1

Enable GM on Z-axis and W-axis other axes remain unchanged

GM 1,0,1,0

Enable GM on X and Z-axis Disable GM on Y and W axis

**Hint:** The GM command is useful for driving heavy load on both sides (Gantry Style).



## GR (Binary 96)

**FUNCTION:** Gear Ratio

**DESCRIPTION:**

GR specifies the Gear Ratios for the geared axes in the electronic gearing mode. The master axis is defined by the GAX or GAY or GAZ or GAW command. The gear ratio may be different for each geared axis and range between +/-127.9999. The slave axis will be geared to the actual position of the master. The master can go in both directions. GR 0,0,0,0 disables gearing for each axis. A limit switch also disables the gearing unless gantry mode has been enabled (see GM command).

**ARGUMENTS:** GR n,n,n,n      or    GRX=n      where

n is a signed numbers in the range +/-127, with a fractional resolution of .0001.

n = 0      Disables gearing

n = ?      Returns the value of the gear ratio for the specified axis.

**USAGE:**

**DEFAULTS:**

While Moving	Yes	Default Value	0
In a Program	Yes	Default Format	3.4
Command Line	Yes		

**OPERAND USAGE:**

\_GRx contains the value of the gear ratio for the specified axis.

**RELATED COMMANDS:**

"GA" on page 77	Master Axis
"GM" on page 78	Gantry Mode

**EXAMPLES:**

#GEAR	
MOY	Turn off servo to Y motor
GAY	Specify master axis as Y
GR .25,,-5	Specify X and Z gear ratios
EN	End program

Now when the Y motor is rotated by hand, the X will rotate at 1/4th the speed and Z will rotate 5 times the speed in the opposite direction.

***Hint:** when the geared motors must be coupled "strongly" to the master, use the gantry mode GM.*

## HM (Binary A3)

**FUNCTION:** Home

**DESCRIPTION:**

The HM command performs a three-stage homing sequence for servo systems and two stage sequence for stepper motor operation.



For servo motor operation: The first stage consists of the motor moving at the user programmed speed until detecting a transition on the homing input for that axis. The direction for this first stage is determined by the initial state of the Homing Input. Once the homing input changes state, the motor decelerates to a stop. The state of the homing input can be configured using the CN command.

The second stage consists of the motor changing directions and slowly approaching the transition again. When the transition is detected, the motor is stopped instantaneously..

The third stage consists of the motor slowly moving forward until it detects an index pulse from the encoder. It stops at this point and defines it as position 0.



For stepper mode operation, the sequence consists of the first two stages. The frequency of the motion in stage 2 is 256 cts or steps/ sec.

**USAGE:**

**DEFAULTS:**

While Moving	No	Default Value
In a Program	Yes	Default Format
Command Line	Yes	

**OPERAND USAGE:**

\_HMx contains the state of the home switch for the specified axis

**RELATED COMMANDS:**

"CN" on page 44	Configure Home
"FI" on page 74	Find Index Only
"FE" on page 73	Find Home Only

**EXAMPLES:**

HM	Set Homing Mode for all axes
BG	Home all axes
BGX	Home only the X-axis
BGY	Home only the Y-axis
BGZ	Home only the Z-axis
BGW	Home only the W-axis

**Hint:** You can create your own custom homing sequence by using the FE (Find Home Sensor only) and FI (Find Index only) commands.

*The speed used in the second stage of homing cannot be altered by the user.*

# HX

**FUNCTION:** Halt Execution

**DESCRIPTION:**

The HX command halts the execution of any of the four programs that may be running independently in multitasking. The parameter n specifies the program to be halted.

**ARGUMENTS:** HXn        where

n is an integer in the range of 0 to 7 which indicates the thread number.

**USAGE:**

While Moving  
In a Program  
Command Line

**DEFAULTS:**

Yes  
Yes  
Yes

Default Value  
Default Format

n = 0

**OPERAND USAGE:**

When used as an operand, \_HXn contains the running status of thread n with:

- 0        Thread not running
- 1        Thread is running
- 2        Thread has stopped at trippoint

**RELATED COMMANDS:**

"XQ" on page 175        Execute program

**EXAMPLES:**

XQ #A	Execute program #A, thread zero
XQ #B,3	Execute program #B, thread three
HX0	Halt thread zero
HX3	Halt thread three

## II (Binary EC)

**FUNCTION:** Input Interrupt

**DESCRIPTION:**

The II command enables the interrupt function for the specified inputs. By default, input interrupts are configured for activation with a logic “0” but can be configured for activation with a logic “1” signal.

If any of the specified inputs are activated during program execution, the program will jump to the subroutine with label #ININT. Any trippoints set by the program will be cleared but can be re-enabled by the proper termination of the interrupt subroutine using RI. The RI command is used to return from the #ININT routine.

**ARGUMENTS:** II m,n,o,p where

m is an integer between 0 and 8 decimal. 0 disables interrupt. The value of m specifies the lowest input to be used for the input interrupt. When n is omitted, only the input specified by m will be enabled.

n is an integer between 2 and 8. This argument is optional and is used with m to specify a range of values for input interrupts. For example, II 2,4 specifies interrupts occurring for Input 2, Input 3 and Input 4.

o is an integer between 1 and 255. This argument is a mask for enabling inputs 1 through 8. For example, 255 enables all 8 input interrupts and 1 enables input 1 only. Using this argument is an alternative to specifying an input range with m,n. If m and n are specified, o will be ignored.

p is an integer between 1 and 255. This argument is a mask for specifying inputs to be activated with a logic “1”. This mask is used on the inputs which have been enabled via the parameters, m,n or o.

**USAGE:**

While Moving  
In a Program  
Command Line

**DEFAULTS:**

Yes  
Yes  
No

Default Value  
Default Format 3.0 (mask only)

**RELATED COMMANDS:**

"RI" on page 133  
#ININT  
"AI" on page 16

Return from Interrupt  
Interrupt Subroutine  
Trippoint for input

**EXAMPLES:**

#A	Program A
II 1	Specify interrupt on input 1
JG 5000;BGX	Specify jog and begin motion on X axis
#LOOP;JP #LOOP	Loop
EN	End Program
#ININT	Interrupt subroutine
STX;MG "INTERRUPT";AMX	Stop X, print message, wait for motion to complete
#CLEAR;JP#CLEAR,@IN[1]=0	Check for interrupt clear
BGX	Begin motion
RI0	Return to main program, don't re-enable trippoints

**IF**

**FUNCTION:** IF conditional statement

**DESCRIPTION:**

The IF command is used in conjunction with an ENDIF command to form an IF conditional statement. The arguments are one or more conditional statements. If the conditional statement(s) evaluates true, the command interpreter will continue executing commands which follow the IF command. If the conditional statement evaluates false, the controller will ignore commands until the associated ENDIF command OR an ELSE command occurs in the program.

**ARGUMENTS:** IF condition where

Conditions are tested with the following logical operators:

< less than or equal to

> greater than

= equal to

$\leq$  less than or equal to

$\geq$  greater than or equal to

$\diamond$  not equal

**USAGE:**

## While Moving

## In a Program

## Command Line

**DEFAULTS:**

Yes

Yes

No

Default Value

—

### Default Format

—

**RELATED COMMANDS:**

"ELSE" on page 62

"ENDIF" on page 65

Optional command to be used only after IF command

End of IF conditional Statement

**EXAMPLES:**

IF (\_TEX<1000)

MG "Motor is within 1000 counts of zero"

ENDIF

IF conditional statement based on X motor position

Message to be executed if “IF” conditional statement

End of IF conditional statement

## IL (Binary 89)

**FUNCTION:** Integrator Limit

**DESCRIPTION:**

The IL command limits the effect of the integrator function in the filter to a certain voltage. For example, IL 2 limits the output of the integrator of the X-axis to the +/-2 Volt range.

A negative parameter also freezes the effect of the integrator during the move. For example, IL -3 limits the integrator output to +/-3V. If, at the start of the motion, the integrator output is 1.6 Volts, that level will be maintained through the move. Note, however, that the KD and KP terms remain active in any case.

**ARGUMENTS:** IL n,n,n,n or ILX=n where

n is a number in the range -9.9988 to 9.9988 Volts with a resolution of 0.0003.

n = ? Returns the value of the integrator limit for the specified axis.

**USAGE:**

**DEFAULTS:**

While Moving	Yes	Default Value	9.9988
In a Program	Yes	Default Format	1.4
Command Line	Yes		

**USAGE:**

\_ILx contains the value of the integrator limit for the specified axis.

**RELATED COMMANDS:**

"KI (Binary 82)" on page 92 Integrator

**EXAMPLES:**

KI 2,3,5,8	Integrator constants
IL 3,2,7,2	Integrator limits
IL ?	Returns the X-axis limit
3.0000	

# IN

**FUNCTION:** Input Variable

**DESCRIPTION:**

The IN command allows a variable to be input from a keyboard. When the IN command is executed in a program, the prompt message is displayed. The operator then enters the variable value followed by a carriage return. The entered value is assigned to the specified variable name.

The IN command holds up execution of the following commands in a program until a carriage return or semicolon is detected. If no value is given prior to a semicolon or carriage return, the previous variable value is kept. Input Interrupts, Error Interrupts and Limit Switch Interrupts will still be active.

The IN command may only be used in thread 0.

**ARGUMENTS:** IN "m",n                      where

m is prompt message

n is the variable name

The limit on the number of characters for n and m are such that the total number of characters per line are 40 characters or less.

**USAGE:**

**DEFAULTS:**

While Moving	Yes	Default Value	
In a Program	Yes	Default Format	Position Format
Command Line	No		

**EXAMPLES:** Operator specifies length of material to be cut in inches and speed in inches/sec (2 pitch lead screw, 2000 counts/rev encoder).

#A	Program A
IN "Enter Speed(in/sec)",V1	Prompt operator for speed
IN "Enter Length(in)",V2	Prompt for length
V3=V1*4000	Convert units to counts/sec
V4=V2*4000	Convert units to counts
SP V3	Speed command
PR V4	Position command
BGX	Begin motion
AMX	Wait for motion complete
MG "MOVE DONE"	Print Message
EN	End Program

## IP

**FUNCTION:** Increment Position

**DESCRIPTION:**

The IP command allows for a change in the command position while the motor is moving. This command does not require a BG. The command has three effects depending on the motion being executed. The units of this are quadrature.

**Case 1:** Motor is standing still

An IP x,y,z,w command is equivalent to a PR x,y,z,w and BG command. The motor will move to the specified position at the requested slew speed and acceleration.

**Case 2:** Motor is moving towards specified position

An IP x,y,z,w command will cause the motor to move to a new position target, which is the old target plus x,y,z,w. x,y,z,w must be in the same direction as the existing motion.

**Case 3:** Motor is in the Jog Mode

An IP x,y,z,w command will cause the motor to instantly try to servo to a position x,y,z,w from the present instantaneous position. The SP and AC parameters have no effect. This command is useful when synchronizing 2 axes in which one of the axis' speed is indeterminate due to a variable diameter pulley.

**Warning:** When the mode is in jog mode, an IP will create an instantaneous position error. In this mode, the IP should only be used to make incremental position movements.

**ARGUMENTS:** IP n,n,n,n or IPX=n where

n is a signed numbers in the range -2147483648 to 2147483647 decimal.

n = ? Returns the current position of the specified axis.

**USAGE:**

**DEFAULTS:**

While Moving	Yes	Default Value	
In a Program	Yes	Default Format	7.0
Command Line	Yes		

**RELATED COMMANDS:**

"PF" on page 122      Position Formatting

**EXAMPLES:**

IP 50	50 counts with set acceleration and speed
#CORRECT	Label
AC 100000	Set acceleration
JG 10000;BGX	Jog at 10000 counts/sec rate
WT 1000	Wait 1000 msec
IP 10	Move the motor 10 counts instantaneously
STX	Stop Motion



# IT (Binary 93)

**FUNCTION:** Independent Time Constant - Smoothing Function

**DESCRIPTION:**

The IT command filters the acceleration and deceleration functions in independent moves of JG, PR, PA type to produce a smooth velocity profile. The resulting profile has continuous acceleration and results in reduced mechanical vibrations. IT sets the bandwidth of the filter where 1 means no filtering and 0.004 means maximum filtering. Note that the filtering results in longer motion time.

The use of IT will not effect the trippoints AR and AD. The trippoints AR & AD monitor the profile prior to the IT filter and therefore can be satisfied before the actual distance has been reached if IT is NOT 1.

**ARGUMENTS:** IT n,n,n,n or ITX=n where

n is a positive numbers in the range between 0.004 and 1.0 with a resolution of 1/256.

n = ? Returns the value of the independent time constant for the specified axis.

**USAGE:**

**DEFAULTS:**

While Moving	Yes	Default Value	1
In a Program	Yes	Default Format	7.0
Command Line	Yes		

**OPERAND USAGE:**

\_ITx contains the value of the independent time constant for the specified 'x' axis.

**RELATED COMMANDS:**

"VT" on page 172 Vector Time Constant for smoothing vector moves

**EXAMPLES:**

IT 0.8, 0.6, 0.9, 0.1 Set independent time constants for x,y,z,w axes  
IT ? Return independent time constant for X-axis  
0.8

## JG (Binary A8)

**FUNCTION:** Jog

**DESCRIPTION:**

The JG command sets the jog mode. The parameters following the JG set the slew speed of the axes. Use of the question mark returns the previously entered value or default value. The units of this are counts/second.

**ARGUMENTS:** JG n,n,n,n or JGX=n where

n is a signed numbers in the range 0 to +/-12,000,000 decimal

For stepper motor operation, the maximum value is 3,000,000 steps/ second

n = ? Returns the absolute value of the jog speed for the specified axis.

**USAGE:**

**DEFAULTS:**

While Moving	Yes	Default Value	16385
In a Program	Yes	Default Format	Position Format
Command Line	Yes		

**OPERAND USAGE:**

\_JGx contains the absolute value of the jog speed for the specified axis.

**RELATED COMMANDS:**

"BG" on page 28	Begin
"ST (Binary A1)" on page 143	Stop
"AC" on page 14	Acceleration
"DC" on page 49	Deceleration
"IP" on page 86	Increment Position
"TV" on page 158	Tell Velocity

**EXAMPLES:**

JG 100,500,2000,5000	Set for jog mode with a slew speed of 100 counts/sec for the X-axis, 500 counts/sec for the Y-axis, 2000 counts/sec for the Z-axis, and 5000 counts/sec for W-axis.
BG	Begin Motion
JG ,,-2000	Change the Z-axis to slew in the negative direction at -2000 counts/sec.

# JP

**FUNCTION:** Jump to Program Location

**DESCRIPTION:**

The JP command causes a jump to a program location on a specified condition. The program location may be any program line number or label. The condition is a conditional statement which uses a logical operator such as equal to or less than. A jump is taken if the specified condition is true.

Multiple conditions can be used in a single jump statement. The conditional statements are combined in pairs using the operands “&” and “|”. The “&” operand between any two conditions, requires that both statements must be true for the combined statement to be true. The “|” operand between any two conditions, requires that only one statement be true for the combined statement to be true. *Note: Each condition must be placed in parenthesis for proper evaluation by the controller.*

**ARGUMENTS:** JP location,condition                      where

location is a program line number or label

condition is a conditional statement using a logical operator

The logical operators are:

- < less than
- > greater than
- = equal to
- <= less than or equal to
- >= greater than or equal to
- <> not equal to

**USAGE:**

**DEFAULTS:**

While Moving	Yes	Default Value
In a Program	Yes	Default Format
Command Line	No	

**EXAMPLES:**

JP #POS1,V1<5	Jump to label #POS1 if variable V1 is less than 5
JP #A,V7*V8=0	Jump to #A if V7 times V8 equals 0
JP #B	Jump to #B (no condition)

**Hint:** JP is similar to an IF, THEN command. Text to the right of the comma is the condition that must be met for a jump to occur. The destination is the specified label before the comma.

# JS

**FUNCTION:** Jump to Subroutine

**DESCRIPTION:**

The JS command will change the sequential order of execution of commands in a program. If the jump is taken, program execution will continue at the line specified by the destination parameter, which can be either a line number or label. The line number of the JS command is saved and after the next EN command is encountered (End of subroutine), program execution will continue with the instruction following the JS command. There can be a JS command within a subroutine.

Multiple conditions can be used in a single jump statement. The conditional statements are combined in pairs using the operands "&" and "I". The "&" operand between any two conditions, requires that both statements must be true for the combined statement to be true. The "I" operand between any two conditions, requires that only one statement be true for the combined statement to be true. *Note: Each condition must be placed in parenthesis for proper evaluation by the controller.*

Note: Subroutines may be nested 16 deep in the controller.

A jump is taken if the specified condition is true. Conditions are tested with logical operators. The logical operators are:

< less than or equal to	<= less than or equal to
> greater than	>= greater than or equal to
= equal to	<> not equal

**ARGUMENTS:** JS destination, condition where

destination is a line number or label

condition is a conditional statement using a logical operator

**USAGE:**

While Moving  
In a Program  
Command Line

**DEFAULTS:**

Yes	Default Value
Yes	Default Format
No	

**RELATED COMMANDS:**

"EN" on page 64	End
-----------------	-----

**EXAMPLES:**

JS #SQUARE,V1<5	Jump to subroutine #SQUARE if V1 is less than 5
JS #LOOP,V1<>0	Jump to #LOOP if V1 is not equal to 0
JS #A	Jump to subroutine #A (no condition)

# KD (Binary 83)

**FUNCTION:** Derivative Constant

**DESCRIPTION:**

KD designates the derivative constant in the controller filter. The filter transfer function is

$$D(z) = 4 \cdot KP + 4 \cdot KD(z-1)/z + KIz/2 (z-1)$$

For further details on the filter see the section Theory of Operation.

**ARGUMENTS:** KD n,n,n,n or KDX=n where

n is an unsigned numbers in the range 0 to 4095.875 with a resolution of 1/8.

n = ? Returns the value of the derivative constant for the specified axis.

**USAGE:**

**DEFAULTS:**

While Moving	Yes	Default Value	64
In a Program	Yes	Default Format	4.2
Command Line	Yes		

**OPERAND USAGE:**

\_KDx contains the value of the derivative constant for the specified axis.

**RELATED COMMANDS:**

"KI (Binary 82)" on page 92	Integrator
"KP (Binary 81)" on page 93	Proportional

**EXAMPLES:**

KD 100,200,300,400.25	Specify KD
KD ?,?,?,?	Return KD
0100.00,0200.00,0300.00,0400.25	

## KI (Binary 82)

**FUNCTION:** Integrator

**DESCRIPTION:**

The KI command sets the integral gain of the control loop. It fits in the control equation as follows:

$$D(z) = 4 \cdot KP + 4 \cdot KD(z-1)/z + KI z/2(z-1)$$

The integrator term will reduce the position error at rest to zero.

**ARGUMENTS:** KI n,n,n,n or KIX=n where

n is an unsigned numbers in the range 0 to 2047.875 with a resolution of 1/128.

n = ? Returns the value of the derivative constant for the specified axis.

**USAGE:**

**DEFAULTS:**

While Moving	Yes	Default Value	0
In a Program	Yes	Default Format	4.0
Command Line	Yes		

**OPERAND USAGE:**

\_KIX contains the value of the derivative constant for the specified axis.

**RELATED COMMANDS:**

"KP (Binary 81)" on page 93	Proportional Constant
"KI (Binary 82)" on page 92	Integrator
"IL" on page 84	Integrator Limit

**EXAMPLES:**

KI 12,14,16,20	Specify x,y,z,w-axis integral
KI 7	Specify x-axis only
KI ,,8	Specify z-axis only
KI ?,?,?,?	Return X,Y,Z,W
0007,0014,0008,0020	KI values

# KP (Binary 81)

**FUNCTION:** Proportional Constant

**DESCRIPTION:**

KP designates the proportional constant in the controller filter. The filter transfer function is

$$D(z) = 4 \cdot KP + 4 \cdot KD(z-1)/z + KI \ z/2(z-1)$$

For further details see the section Theory of Operation.

**ARGUMENTS:** KP n,n,n,n      or    KPX=n      where

n is an unsigned numbers in the range 0 to 1023.875 with a resolution of 1/8.

n = ?      Returns the value of the proportional constant for the specified axis.

**USAGE:**

**DEFAULTS:**

While Moving	Yes	Default Value	6
In a Program	Yes	Default Format	4.2
Command Line	Yes		

**OPERAND USAGE:**

\_KPx contains the value of the proportional constant for the specified axis.

**RELATED COMMANDS:**

- "KI (Binary 82)" on page 92      Integrator
- "IL" on page 84      Integrator Limit

## KS (Binary 86)

**FUNCTION:** Step Motor Smoothing

**DESCRIPTION:**



The KS parameter sets the amount of smoothing of stepper motor pulses. This is most useful when operating in full or half step mode.. Larger values of KS provide greater smoothness. This parameter will also increase the motion time by 3KS sampling periods. KS adds a single pole low pass filter onto the output of the motion profiler.

**Note:** KS will cause a delay in the generation of output steps.

**ARGUMENTS:** KS n,n,n,n or KSX=n where

n is a positive number in the range between .5 and 16 with a resolution of 1/32.

n = ? Returns the value of the derivative constant for the specified axis.

**USAGE:**

**DEFAULTS:**

While Moving	Yes	Default Value	1.313
In a Program	Yes	Default Format	4.0
Command Line	Yes		

**OPERAND USAGE:**

\_KSx contains the value of the derivative constant for the specified axis.

**RELATED COMMANDS:**

“MT” on page 111 Motor Type

**EXAMPLES:**

KS 2,4,8	Specify x,y,z axes
KS 5	Specify x-axis only
KS „15	Specify z-axis only

**Hint:** KS is valid for step motors only.



# LA

**FUNCTION:** List Arrays

**DESCRIPTION:**

The LA command returns a list of all arrays in memory. The listing will be in alphabetical order.  
The size of each array will be included next to each array name in square brackets.

**ARGUMENTS:** None

**USAGE:**

While Moving  
In a Program  
Command Line

**DEFAULTS:**

Yes  
Yes  
Yes

Default Value -  
Default Format -

**RELATED COMMANDS:**

"LL" on page 100	List Labels
"LS" on page 103	List Program
"LV" on page 104	List Variable

**EXAMPLES:**

```
: LA  
CA [10]  
LA [5]  
NY [25]  
VA [17]
```

## LE (Binary B5)

**FUNCTION:** Linear Interpolation End

**DESCRIPTION:** LE

Signifies the end of a linear interpolation sequence. It follows the last LI specification in a linear sequence. After the LE specification, the controller issues commands to decelerate the motors to a stop. The VE command is interchangeable with the LE command.

The LE command will apply to the selected coordinate system, S or T. To select the coordinate system use the command CAS or CAT.

**ARGUMENTS:**

n = ? Returns the total vector move length in encoder counts for the selected coordinate system, S or T. To select the coordinate system use the command CAS or CAT.

**USAGE:**

**DEFAULTS:**

While Moving	Yes	Default Value	-
In a Program	Yes	Default Format	-
Command Line	Yes		

**OPERAND USAGE:**

\_LEx contains the total vector move length in encoder counts.

**RELATED COMMANDS:**

"LI (Binary B1)" on page 98	Linear Distance
"BG" on page 28	BGS - Begin Sequence
"LM (Binary B 0)" on page 101	Linear Interpolation Mode
"VS" on page 171	Vector Speed
"VA" on page 162	Vector Acceleration
"VD" on page 163	Vector Deceleration
"PF" on page 122	Position Formatting

**EXAMPLES:**

CAS	Specify S coordinated motion system
LM ZW	Specify linear interpolation mode for Z and W axes
LI „100,200	Specify linear distance
LE	End linear move
BGS	Begin motion

## **\_LF\***

**FUNCTION:** Forward Limit Switch Operand (Keyword)

**DESCRIPTION:**

The \_LF operand contains the state of the forward limit switch for the specified axis.

The operand is specified as: \_LFx where x is the specified axis.

**Note:** This operand is affected by the configuration of the limit switches set by the command CN:

For CN -1:

\_LFx = 1 when the limit switch input is inactive\*

\_LFx = 0 when the limit switch input is active\*

For CN 1:

\_LFx = 0 when the limit switch input is inactive\*

\_LFx = 1 when the limit switch input is active\*

\* The term “active” refers to the condition when at least 1ma of current is flowing through the input circuitry. The input circuitry can be configured to sink or source current to become active. See Chapter 3 in the DMC-1802 User Manual for further details.

**EXAMPLES:**

MG \_LFX

Display the status of the X axis forward limit switch

**\* This is an Operand - Not a command.**

## LI (Binary B1)

**FUNCTION:** Linear Interpolation Distance

**DESCRIPTION:**

The LI x,y,z,w command specifies the incremental distance of travel for each axis in the Linear Interpolation (LM) mode. LI parameters are relative distances given with respect to the current axis positions. Up to 511 LI specifications may be given ahead of the Begin Sequence (BGS) command. Additional LI commands may be sent during motion when the controller sequence buffer frees additional spaces for new vector segments. The Linear End (LE) command must be given after the last LI specification in a sequence. This command tells the controller to decelerate to a stop at the last LI command. It is the responsibility of the user to keep enough LI segments in the controller's sequence buffer to ensure continuous motion.

LM ? returns the available spaces for LI segments that can be sent to the buffer. 511 returned means the buffer is empty and 511 LI segments can be sent. A zero means the buffer is full and no additional segments can be sent. It should be noted that the controller computes the vector speed based on the axes specified in the LM mode. For example, LM XYZ designates linear interpolation for the X,Y and Z axes. The speed of these axes will be computed from  $VS^2 = XS^2 + YS^2 + ZS^2$  where XS, YS and ZS are the speed of the X,Y and Z axes. If the LI command specifies only X and Y, the speed of Z will still be used in the vector calculations. The controller always uses the axis specifications from LM, not LI, to compute the speed. The parameter n is optional and can be used to define the vector speed that is attached to the motion segment.

The LI command will apply to the selected coordinate system, S or T. To select the coordinate system, use the command CAS or CAT.

**ARGUMENTS:** LI n,n,n,n <o>p or LIX=n where

n is a signed integers in the range -8,388,607 to 8,388,607 and represent incremental move distance

o specifies a vector speed to be taken into effect at the execution of the linear segment. s is an unsigned even integer between 0 and 12,000,000 for servo motor operation and between 0 and 3,000,000 for stepper motors.

p specifies a vector speed to be achieved at the end of the linear segment. o is an unsigned even integer between 0 and 8,000,000.

**USAGE:**

**DEFAULTS:**

While Moving	Yes	Default Value	-
In a Program	Yes	Default Format	-
Command Line	Yes		

(LI cont.)

**RELATED COMMANDS:**

"LE" on page 96	Linear end
"BG" on page 28	BGS - Begin sequence
"LM" on page 101	Linear Interpolation Mode
"CS" on page 46	Clear Sequence
"VS" on page 171	Vector Speed
"VA" on page 162	Vector Acceleration
"VD" on page 163	Vector Deceleration

**EXAMPLES:**

LM XYZ	Specify linear interpolation mode
LI 1000,2000,3000	Specify distance
LE	Last segment
BGS	Begin sequence

# LL

**FUNCTION:** List Labels

**DESCRIPTION:**

The LL command returns a listing of all of the program labels in memory. The listing will be in alphabetical order.

**ARGUMENTS:** None

**USAGE:**

While Moving  
In a Program  
Command Line

**DEFAULTS:**

Yes  
Yes  
Yes

Default Value -  
Default Format -

**RELATED COMMANDS:**

"LA" on page 95	List Arrays
"LS" on page 103	List Program
"LV" on page 104	List Variables

**EXAMPLES:**

: LL  
# FIVE  
# FOUR  
# ONE  
# THREE  
# TWO

# LM (Binary B 0)

**FUNCTION:** Linear Interpolation Mode

**DESCRIPTION:**

The LM XYZW command specifies the linear interpolation mode. Any set of 1,2,3, or 4 axes may be used for linear interpolation. LI x,y,z,w commands are used to specify the travel distance for linear interpolation. The LE command specifies the end of the linear interpolation sequence. Several LI commands may be given as long as the controller sequence buffer has room for additional segments. Once the LM command has been given, it does not need to be given again unless the VM command has been used.

It should be noted that the controller computes the vector speed based on the axes specified in the LM mode. For example, LM XYZ designates linear interpolation for the X,Y, and Z axes. The speed of these axes will be computed from  $VS^2=XS^2+YS^2+ZS^2$ , where XS, YS, and ZS are the speed of the X,Y, and Z axes. The controller always uses the axis specifications from LM, not LI, to compute the speed.

The LM command will apply to the selected coordinate system, S or T. To select the coordinate system, use the command CAS or CAT.

**ARGUMENTS:** LM xxxx                      where

x is X,Y,Z,W or any combination to specify the axis or axes

x = ?              Returns the number of spaces available in the sequence buffer for additional LI commands.

**USAGE:**

**DEFAULTS:**

While Moving	Yes	Default Value	-
In a Program	Yes	Default Format	-
Command Line	Yes		

**OPERAND USAGE:**

\_LMx contains the number of spaces available in the sequence buffer for the 'x' coordinate system, S or T.

**RELATED COMMANDS:**

"LE (Binary B5)" on page 96	Linear end
"LI (Binary B1)" on page 98	Linear Distance
"VA" on page 162	Vector acceleration
"VS" on page 171	Vector Speed
"VD" on page 163	Vector deceleration
"AV" on page 23	Vector distance
"CS" on page 46	_CS - Sequence counter

**EXAMPLES:**

LM XYZW	Specify linear interpolation mode
VS 10000; VA 100000;VD 1000000	Specify vector speed, acceleration and deceleration
LI 100,200,300,400	Specify linear distance
LI 200,300,400,500	Specify linear distance
LE; BGS	Last vector, then begin motion

## **\_LR\***

**FUNCTION:** Reverse Limit Switch Operand (Keyword)

**DESCRIPTION:**

The \_LR operand contains the state of the reverse limit switch for the specified axis.

The operand is specified as: \_LRx where x is the specified axis.

**Note:** This operand is affected by the configuration of the limit switches set by the command CN:

For CN -1:

\_LRx = 1 when the limit switch input is inactive\*

\_LRx = 0 when the limit switch input is active\*

For CN 1:

\_LRx = 0 when the limit switch input is inactive\*

\_LRx = 1 when the limit switch input is active\*

\* The term “active” refers to the condition when at least 1ma of current is flowing through the input circuitry. The input circuitry can be configured to sink or source current to become active. See Chapter 3 in the DMC-1802 User Manual for further details.

**EXAMPLES:**

MG _LR X	Display the status of the X axis reverse limit switch
----------	---

**\*Note: This is an Operand - Not a command**



# LS

**FUNCTION:** List Program

**DESCRIPTION:**

The LS command returns a listing of the programs in memory. The listing will start with the line pointed to by the first parameter, which can be either a line number or a label. If no parameter is specified, it will start with line 0. The listing will end with the line pointed to by the second parameter--again either a line number or label. If no parameter is specified, the listing will go to the last line of the program.

**ARGUMENTS:** LS n,m                      where

n and m are valid numbers from 0 to 999, or labels. n is the first line to be listed, m is the last.

**USAGE:**

While Moving  
In a Program  
Command Line

**DEFAULTS:**

Yes	Default Value	0, Last Line
No	Default Format	-
Yes		

**RELATED COMMANDS:**

"LA" on page 95	List Arrays
"LL" on page 100	List Labels
"LV" on page 104	List Variables

**EXAMPLES:**

:LS #A,6	List program starting at #A through line 6
002 #A	
003 PR 500	
004 BGX	
005 AM	
006 WT 200	

***Hint:** Remember to quit the Edit Mode <cntrl>Q prior to giving the LS command.*

## LV

**FUNCTION:** List Variables

**DESCRIPTION:**

The LV command returns a listing of all of the program labels in memory. The listing will be in alphabetical order.

**ARGUMENTS:** None

**USAGE:**

While Moving  
In a Program  
Command Line

**DEFAULTS:**

Yes  
Yes  
Yes

Default Value -  
Default Format -

**RELATED COMMANDS:**

"LA" on page 95	List Arrays
"LS" on page 103	List Program
"LL" on page 100	List Labels

**EXAMPLES:**

```
: LV  
APPLE = 60.0000  
BOY   = 25.0000  
ZEBRA = 37.0000
```

## LZ (Binary E7)

**FUNCTION:** Leading Zeros

**DESCRIPTION:**

The LZ command is used for formatting the values returned from interrogation commands or interrogation of variables and arrays. By enabling the LZ function, all leading zeros of returned values will be removed.

**ARGUMENTS:** LZ<sub>n</sub>                      where

n = 1	Removes leading zeros
-------	-----------------------

n = 0	Does not remove leading zeros.
-------	--------------------------------

n = ?      Returns the state of the LZ function. '0' does not remove and '1' removes zeros

**USAGE:**

**DEFAULTS:**

While Moving	Yes	Default Value	1
In a Program	Yes	Default Format	-
Command Line	Yes		

**OPERAND USAGE:**

LZ contains the state of the LZ function. ‘0’ is disabled and ‘1’ is enabled.

**EXAMPLES:**

LZ 0	Disable the LZ function
TPX	Interrogate the controller for current position of X axis
0000021645	Value returned by the controller
VAR1=	Request value of variable "VAR1" (previously set to 10)
0000000010.0000	Value of variable returned by controller
LZ1	Enable LZ function
TPX	Interrogate the controller for current position of X axis
21645	Value returned by the controller
VAR1=	Request value of variable "VAR1" (previously set to 10)
10.0000	Value of variable returned by controller

## MC (Binary C9)

**FUNCTION:** Motion Complete - "In Position"

### DESCRIPTION:

The MC command is a trippoint used to control the timing of events. This command will hold up execution of the following commands until the current move on the specified axis or axes is completed and the encoder reaches or passes the specified position. Any combination of axes or a motion sequence may be specified with the MC command. For example, MC XY waits for motion on both the X and Y axis to be complete. MC with no parameter specifies that motion on all axes is complete. TW x,y,z,w sets the timeout to declare an error if the encoder is not in position within the specified time. If a timeout occurs, the trippoint will clear and the stopcode will be set to 99. An application program will jump to the special label #MCTIME.



When used in stepper mode, the controller will hold up execution of the proceeding commands until the controller has generated the same number of steps as specified in the commanded position. The actual number of steps that have been generated can be monitored by using the interrogation command TD. Note: The MC command is useful when operating with stepper motors since the step pulses can be delayed from the commanded position due to the stepper motor smoothing function, KS.

**ARGUMENTS:** MC xxxx where

x is X,Y,Z,W or any combination to specify the axis or axes

No argument specifies that motion on all axes is complete.

### USAGE:

### DEFAULTS:

While Moving	Yes	Default Value	-
In a Program	Yes	Default Format	-
Command Line	Yes		

### RELATED COMMANDS:

"BG" on page 28	Begin
"AM (Binary C8)" on page 18	After Move
"TW (Binary CA)" on page 159	Timeout

### EXAMPLES:

#MOVE	Program MOVE
CAT	Specify T coordinate system
VMYZ	Vector mode for Y and Z on T coordinate system
VP 1000,1000	Vector Move on Y and Z axes
VE	End vector Move
BG T	Start the Y-axis
MC T	After the move is complete on T coordinate system,
MG "DONE"; TP	Print message
EN	End of Program

**Hint:** MC can be used to verify that the actual motion has been completed.

# MF (Binary CB)

**FUNCTION** Forward Motion to Position

**DESCRIPTION:**

The MF command is a trippoint used to control the timing of events. This command will hold up the execution of the following command until the specified motor moves forward and crosses the position specified. The units of the command are in quadrature counts. Only one axis may be specified at a time. The MF command can also be used when the encoder is the master and not under servo control.

**ARGUMENTS:** MF n,n,n,n or MFX=n where  
n is a signed integer in the range -2147483648 to 2147483647 decimal

**USAGE:**

While Moving	Yes	Default Value	-
In a Program	Yes	Default Format	-
Command Line	Yes		

**DEFAULTS:**

**RELATED COMMANDS:**

"AD" on page 15	Trippoint for after Relative Distances
"AP (Binary CE)" on page 19	Trippoint for after Absolute Position

**EXAMPLES:**

#TEST	Program B
DP0	Define zero
JG 1000	Jog mode (speed of 1000 counts/sec)
BG X	Begin move
MF 2000	After passing the position 2000
MG "Position is" ,_TPX	Print Message of current position
ST	Stop
EN	End of Program

**Hint:** The accuracy of the MF command is the number of counts that occur in 2 servo samples. Multiply the speed by 2 servo samples to obtain the maximum error. MF tests for absolute position. The MF command can also be used when the specified motor is driven independently by an external device.

# MG

**FUNCTION:** Message

**DESCRIPTION:**

The MG command sends data out the bus. This can be used to alert an operator, send instructions or return a variable value.

**ARGUMENTS:** MG "m", {^n}, V {Fm.n or \$m,n} {N} {Pn}     where

"m" is a text message including letters, numbers, symbols or <ctrl>G (up to 31 characters).

{^n} is an ASCII character specified by the value n

V is a variable name or array element where the following formats can be used:

{Fm.n} Display variable in decimal format with m digits to left of decimal, and n to the right.

{\$m,n} Display variable in hexadecimal format with m digits to left of decimal, and n to the right.

{Sn} Display variable as a string of length n where n is 1 through 6

{N} Suppress carriage return line feed.

**Note:** Multiple text, variables, and ASCII characters may be used - each must be separated by a comma.

**Note:** The order of arguments is not important.

**USAGE:**

**DEFAULTS:**

While Moving	Yes	Default Value	-
In a Program	Yes	Default Format	Variable Format
Command Line	Yes		

**EXAMPLES:**

Case 1: Message command displays ASCII strings

MG "Good Morning" Displays the string

Case 2: Message command displays variables or arrays

MG "The Answer is", Total {F4.2} Displays the string with the content of variable TOTAL in local format of 4 digits before and 2 digits after the decimal point.

Case 3: Message command sends any ASCII characters to the port.

MG {^13}, {^10}, {^48}, {^055} displays carriage return and the characters 0 and 7.

# MO (Binary A9)

**FUNCTION:** Motor Off

**DESCRIPTION:**

The MO command shuts off the control algorithm. The controller will continue to monitor the motor position. To turn the motor back on use the Servo Here command (SH).

**ARGUMENTS:** MO xxxx                      where

x is X,Y,Z,W or any combination to specify the axis or axes.

No argument specifies all axes.

n = ? returns the state of the motor for the specified axis.

**USAGE:**

**DEFAULTS:**

While Moving	No	Default Value	0
In a Program	Yes	Default Format	1.0
Command Line	Yes		

**OPERAND USAGE:**

\_MOx contains the state of the motor for the specified axis.

**RELATED COMMANDS:**

"SH (Binary AA)" on page 141      Servo Here

**EXAMPLES:**

MO	Turn off all motors
MOX	Turn off the X motor. Leave the other motors unchanged
MOY	Turn off the Y motor. Leave the other motors unchanged
MOZX	Turn off the Z and X motors. Leave the other motors unchanged
SH	Turn all motors on
Bob=_MOX	Sets Bob equal to the X-axis servo status
Bob=	Return value of Bob. If 1, motor is off, If 0, motor is servoed

***Hint:** The MO command is useful for positioning the motors by hand. Turn them back on with the SH command.*

## MR (Binary CC)

**FUNCTION:** Reverse Motion to Position

**DESCRIPTION:**

The MR command is a trippoint used to control the timing of events. This command will hold up the execution of the following command until the specified motor moves backward and crosses the position specified. The units of the command are in quadrature counts. Only one axis may be specified at a time. The MR command can also be used when the encoder is the master and not under servo control.

**ARGUMENTS:** MR n,n,n,n or MRX=n where

n is a signed integers in the range -2147483648 to 2147483647 decimal

**USAGE:**

While Moving

In a Program

Command Line

**DEFAULTS:**

No

Yes

Yes

Default Value

Default Format

**RELATED COMMANDS:**

"AD" on page 15

Trippoint for Relative Distances

"AP (Binary CE)" on page 19

Trippoint for after Absolute Position

**EXAMPLES:**

#TEST

DP0

JG -1000

BG X

MR -3000

V1=\_TPX

MG "Position is", V1= ST

EN

Program B

Define zero

Jog mode (speed of 1000 counts/sec)

Begin move

After passing the position -3000

Assign V1 X position

Print Message Stop

End of Program

**Hint:** The accuracy of the MR command is the number of counts that occur in 2 servo samples. Multiply the speed by 2 servo samples to obtain the maximum error. MR tests for absolute position. The MR command can also be used when the specified motor is driven independently by an external device.



# MT

**FUNCTION:** Motor Type

**DESCRIPTION:**



The MT command selects the type of the motor and the polarity of the drive signal. Motor types include standard servo motors which require a voltage in the range of +/- 10 Volts, and step motors which require pulse and direction signals. The polarity reversal inverts the analog signals for servo motors, and inverts logic level of the pulse train, for step motors.

**ARGUMENTS:** MT n,n,n,n or MTX=n where

- n = 1 Specifies Servo motor
- n = -1 Specifies Servo motor with reversed polarity
- n = -2 Specifies Step motor with active high step pulses
- n = 2 Specifies Step motor with active low step pulses
- n = -2.5 Specifies Step motor with reversed direction and active high step pulses
- n = 2.5 Specifies Step motor with reversed direction and active low step pulses
- n = ? Returns the value of the motor type for the specified axis.

**USAGE:**

- While Moving No
- In a Program Yes
- Command Line Yes

**DEFAULTS:**

- Default Value 1,1,1,1
- Default Format 1

**OPERAND USAGE:**

\_MTx contains the value of the motor type for the specified axis.

**RELATED COMMANDS:**

"CE (Binary 8C)" on page 42 Configure encoder type

**EXAMPLES:**

- MT 1,-1,2,2 Configure x as servo, y as reverse servo, z and w as steppers
- MT ?,? Interrogate motor type
- V=\_MTX Assign motor type to variable

**NB**

**FUNCTION:** Notch Bandwidth

**DESCRIPTION:**

The NB command sets real part of the notch poles

**ARGUMENTS:** NB n,n,n,n or NBX=n where

n is ranges from 0 Hz to  $\frac{1}{(16 \cdot Tm)}$

**USAGE:**

While Moving  
In a Program  
Command Line

**DEFAULTS:**

Yes  
Yes  
Yes

Default Value      0.5  
Default Format

**RELATED COMMANDS:**

"NF" on page 113      Notch Filter  
"NZ" on page 115      Notch Zeros

**EXAMPLES:**

\_NBX = 10      Sets the real part of the notch pole to 10Hz

NF

FUNCTION: Notch Frequency

DESCRIPTION:

The NF command sets the frequency of the notch filter which is placed in series with the PID compensation.

ARGUMENTS: NF n,n,n,n or NFX=n where

n ranges from 1 Hz to  $\frac{1}{(4 \cdot TM)}$  where TM is the update rate (default TM is 1 msec).

n = ? Returns the value of the Notch filter for the specified axis.

USAGE:

DEFAULTS:

While Moving	Yes	Default Value	0
In a Program	Yes	Default Format	
Command Line	Yes		

OPERAND USAGE:

\_NFx contains the value of notch filter for the specified axis.

RELATED COMMANDS:

"NB" on page 112	Notch bandwidth
"NZ" on page 115	Notch Zero

EXAMPLES:

NF, 20	Sets the notch frequency of Y axis to 20 Hz
--------	---

# NO

**FUNCTION:** No Operation

**DESCRIPTION:**

The NO command performs no action in a sequence, but can be used as a comment in a program.  
This helps to document a program.

**ARGUMENTS:** NO m      where

m is any group of letters and numbers

up to 77 characters can follow the NO command

**USAGE:**

**DEFAULTS:**

While Moving	Yes	Default Value
In a Program	Yes	Default Format
Command Line	Yes	

**EXAMPLES:**

#A	Program A
NO	No Operation
NO This Program	No Operation
NO Does Absolutely	No Operation
NO Nothing	No Operation
EN	End of Program

# NZ

**FUNCTION:** Notch Zero

**DESCRIPTION:**

The NZ command sets the imaginary part of the notch poles.

**ARGUMENTS:** NZ n,n,n,n or NZX=n where

n is ranges from 1 Hz to  $\frac{1}{(16 \cdot TM)}$

n = ? Returns the value of the Notch filter zero for the specified axis.

USAGE:	DEFAULTS:		
While Moving	Yes	Default Value	0.5
In a Program	Yes	Default Format	
Command Line	Yes		

**OPERAND USAGE:**

\_NZx contains the value of the Notch filter zero for the specified axis.

**RELATED COMMANDS:**

"NB" on page 112	Notch Bandwidth
"NF" on page 113	Notch Filter

**EXAMPLES:**

NZX = 10 Sets the imaginary part of the notch pole to 10 Hz

## OB (Binary E9)

**FUNCTION:** Output Bit

**DESCRIPTION:**

The OB n, logical expression command defines output bit n = 1 through 8 as either 0 or 1 depending on the result from the logical expression. Any non-zero value of the expression results in a one on the output.

**ARGUMENTS:** OB n, *expression*                      where

n denotes the output bit

*expression* is any valid logical expression, variable, or array element.

**USAGE:**

While Moving

In a Program

Command Line

**DEFAULTS:**

Yes

Yes

Yes

Default Value

Default Format

**EXAMPLES:**

OB 1, POS=1

If POS 1 is non-zero, Bit 1 is high.

If POS 1 is zero, Bit 1 is low

OB 2, @IN[1]&@IN[2]

If Input 1 and Input 2 are both high, then

Output 2 is set high

OB 3, COUNT[1]

If the element 1 in the array is zero, clear bit 3

OB N, COUNT[1]

If element 1 in the array is zero, clear bit N

## OC

**FUNCTION:** Output Compare

**DESCRIPTION:**

The OC command allows the generation of output pulses based on one of the main encoder positions. The output is a low-going pulse with a duration of approximately 600 nanoseconds and is available at the output compare signal (labeled CMP on the ICM-1900 or ICM-2900).

This function cannot be used with any axis configured for a step motor and the auxiliary encoder of the corresponding axis can not be used while using this function.

Note: The OC function requires that the main encoder and auxiliary encoders be configured exactly the same (see the command, CE). For example: CE 0, CE 5, CE 10, or CE 15.

**ARGUMENTS:** OCx = m, n                      where

x = X Y Z or W specifies which encoder input to be used.

m = Absolute position for first pulse. Integer between  $-2 \cdot 10^9$  and  $2 \cdot 10^9$

n = Incremental distance between pulses. Integer between -65535 and 65535.

Notes:

OCx = 0 will disable the Circular Compare function.

The sign of the parameter n will designate the expected direction of motion for the output compare function. When moving in the opposite direction, output compare pulses will occur at the incremental distance of  $65536 - |n|$  where  $|n|$  is the absolute value of n.

**USAGE:**

**DEFAULTS:**

While Moving	Yes	Default Value	-
In a Program	Yes	Default Format	-
Command Line	Yes		

**OPERAND USAGE:**

\_OCx gives the state of the OC function

0 = OC function has been enabled but not generated any pulses.

1 = OC function not enable or has generated the first output pulse.

**EXAMPLES:**

OCX=300,100	Select X encoder as position sensor. First pulse at 300. Following pulses at 400, 500...
-------------	--

## OE (Binary 8D)

**FUNCTION:** Off on Error

**DESCRIPTION:**

The OE command causes the controller to shut off the motor command if a position error exceeds the limit specified by the ER command occurs or an abort occurs from either the abort input or on AB command.

If a position error is detected on an axis, and the motion was under an independent move, only that axis will be shut off. However, if the motion is a coordinated mode of the types VM, LM or CM, all the participating axes will be stopped.

**ARGUMENTS:** OE n,n,n,n or OEX=n where

n = 0 Disables the Off-On-Error function.

n = 1 Enables the Off-On-Error function.

n = ? Returns the state of the off on error function for the specified axis.

**USAGE:**

**DEFAULTS:**

While Moving	Yes	Default Value	0
In a Program	Yes	Default Format	1.0
Command Line	Yes		

**OPERAND USAGE:**

\_OEx contains the status of the off-on-error function for the specified axis. 0 = disabled, 1 = enabled

**RELATED COMMANDS:**

"AB" on page 7	Abort
"ER" on page 69	Error limit
"SH (Binary AA)" on page 141	Servo Here
#POSERR	Error Subroutine

**EXAMPLES:**

OE 1,1,1,1	Enable OE on all axes
OE 0	Disable OE on X-axis other axes remain unchanged
OE „1,1	Enable OE on Z-axis and W-axis other axes remain unchanged
OE 1,0,1,0	Enable OE on X and Z-axis Disable OE on Y and W axis

**Hint:** The OE command is useful for preventing system damage on excessive error.



# OF (Binary 99)

**FUNCTION:** Offset

**DESCRIPTION:**

The OF command sets a bias voltage in the motor command output or returns a previously set value. This can be used to counteract gravity or an offset in an amplifier.

**ARGUMENTS:** OF n,n,n,n or OFX=n where

n is a signed number in the range -9.998 to 9.998 volts with resolution of 0.0003.

n = ? Returns the offset for the specified axis.

**USAGE:**

**DEFAULTS:**

While Moving	Yes	Default Value	0
In a Program	Yes	Default Format	1.0
Command Line	Yes		

**OPERAND USAGE:**

\_OFx contains the offset for the specified axis.

**EXAMPLES:**

OF 1,-2,3,5	Set X-axis offset to 1, the Y-axis offset to -2, the Z-axis to 3, and the W-axis to 5
OF -3	Set X-axis offset to -3 Leave other axes unchanged
OF ,0	Set Y-axis offset to 0 Leave other axes unchanged
OF ?,?,?,?	Return offsets
-3.0000,0.0000,3.0000,5.0000	
OF ?	Return X offset
-3.0000	
OF ,?	Return Y offset
0.0000	

## OP (Binary E8)

**FUNCTION:** Output Port

**DESCRIPTION:**

The OP command sends data to the output port of the controller. You can use the output port to control external switches and relays.

The argument controls the output port (bits 1-8).

**ARGUMENTS:** OP m                      where

m is an integer in the range 0 to 255 decimal, or \$0000 to \$00FF hexadecimal. m is the decimal representation of the general output bits.

m = ? returns the value of the argument

**USAGE:**

While Moving	Yes
In a Program	Yes
Command Line	Yes

**DEFAULTS:**

Default Value	0
Default Format	3.0

**OPERAND USAGE:**

\_OP0 contains the value of the argument m

**RELATED COMMANDS:**

"SB (Binary EA)" on page 139	Set output bit
"CB" on page 40	Clear output bit
"OB (Binary E9)" on page 116	Output Byte

**EXAMPLES:**

OP 0	Clear Output Port -- all bits
OP \$85	Set outputs 1,3,8; clear the others
MG _OP0	Returns the first parameter "m"
MG _OP1	Returns the second parameter "n"

PA (Binary A6)

FUNCTION: Position Absolute

DESCRIPTION:

The PA command will set the final destination of the next move. The position is referenced to the absolute zero. If a ? is used, then the current destination (current command position if not moving, destination if in a move) is returned. For each single move, the largest position move possible is +/-2147483647. Units are in quadrature counts.

ARGUMENTS: PA n,n,n,n or PAX=n where  
n is a signed integers in the range -2147483647 to 2147483648 decimal  
n = ? Returns the commanded position of which motion stopped.

USAGE:	DEFAULTS:		
While Moving	No	Default Value	-
In a Program	Yes	Default Format	Position Format
Command Line	Yes		

OPERAND USAGE:

\_PAx contains the last commanded position at which motion stopped.

RELATED COMMANDS:

"PR (Binary A7)" on page 124	Position relative
"SP (Binary 92)" on page 142	Speed
"AC" on page 14	Acceleration
"DC" on page 49	Deceleration
"BG" on page 28	Begin
"PF" on page 122	Position Formatting

EXAMPLES:

:PA 400,-600,500,200	X-axis will go to 400 counts Y-axis will go to -600 counts Z-axis will go to 500 counts W-axis will go to 200 counts
:PA ?,?,?,?	Returns the current commanded position
400, -600, 500, 200	
:BG	Start the move
:PA 700	X-axis will go to 700 on the next move while the
:BG	Y,Z and W-axis will travel the previously set relative distance if the preceding move was a PR move, or will not move if the preceding move was a PA move.

# PF

**FUNCTION:** Position Format

**DESCRIPTION:**

The PF command allows the user to format the position numbers such as those returned by TP.

The number of digits of integers and the number of digits of fractions can be selected with this command. An extra digit for sign and a digit for decimal point will be added to the total number of digits. If PF is minus, the format will be hexadecimal and a dollar sign will precede the characters. Hex numbers are displayed as 2's complement with the first bit used to signify the sign.

If a number exceeds the format, the number will be displayed as the maximum possible positive or negative number (i.e. 999.99, -999, \$8000 or \$7FF).

The PF command can be used to format values returned from the following commands:

BL ?	LE ?
DE ?	PA ?
DP ?	PR ?
EM ?	TN ?
FL ?	VE ?
IP ?	TE
TP	

**ARGUMENTS:** PF m,n                      where

m is an integer between -8 and 10 which represents the number of places preceding the decimal point. A negative sign for m specifies hexadecimal representation.

n is an integer between 0 and 4 which represent the number of places after the decimal point.

n = ?              Returns the value of m.

**USAGE:**

**DEFAULTS:**

While Moving	Yes	Default Value	10.0
In a Program	Yes	Default Format	10.0
Command Line	Yes		

**OPERAND USAGE:**

\_PF contains the value of 'm' position format parameter.

**EXAMPLES:**

:TPX	Tell position of X
0000000000	Default format
:PF 5.2	Change format to 5 digits of integers and 2 of fractions
:TPX	Tell Position
00021.00	
PF-5.2	New format Change format to hexadecimal*
:TPX	Tell Position
\$00015.00	Report in hex

PL (Binary 87)

FUNCTION: Pole

DESCRIPTION:

The PL command adds a low-pass filter in series with the PID compensation. The digital transfer function of the filter is  $(1 - P) / (Z - P)$  and the equivalent continuous filter is  $A/(S+A)$  where A is the filter cutoff frequency:  $A=(1/T) \ln (1/p)$  rad/sec and T is the sample time.

ARGUMENTS: PL n,n,n,n or PLX=n where

n is a positive number in the range 0 to 0.9999.

n = ? Returns the value of the pole filter for the specified axis.

USAGE:

DEFAULTS:

While Moving	Yes	Default Value	0.0
In a Program	Yes	Default Format	3.0
Not in a Program	Yes		

OPERAND USAGE:

\_PLx contains the value of the pole filter for the specified axis.

RELATED COMMANDS:

"KD (Binary 83)" on page 91	Derivative
"KP (Binary 81)" on page 93	Proportional
"KI (Binary 82)" on page 92	Integral Gain

EXAMPLES:

PL .95,.9,.8,.822	Set X-axis Pole to 0.95, Y-axis to 0.9, Z-axis to 0.8. W-axis pole to 0.822
PL ?,?,?,?	Return all Poles
0.9527,0.8997,0.7994,0.8244	
PL?	Return X Pole only
0.9527	
PL?	Return Y Pole only
0.8997	

## PR (Binary A7)

**FUNCTION:** Position Relative

### DESCRIPTION:

The PR command sets the incremental distance and direction of the next move. The move is referenced with respect to the current position. If a ? is used, then the current incremental distance is returned (even if it was set by a PA command). Units are in quadrature counts.

**ARGUMENTS:** PR n,n,n,n or PRX=n where

n is a signed integer in the range -2147483648 to 2147483647 decimal.

n = ? Returns the current incremental distance for the specified axis.

### USAGE:

### DEFAULTS:

While Moving	No	Default Value	0
In a Program	Yes	Default Format	Position Format
Command Line	Yes		

### OPERAND USAGE:

\_PRx contains the current incremental distance for the specified axis.

### RELATED COMMANDS:

"PA (Binary A6)" on page 121	Position Absolute
"BG" on page 28	Begin
"AC" on page 14	Acceleration
"DC" on page 49	Deceleration
"SP (Binary 92)" on page 142	Speed
"IP" on page 86	Increment Position
"PF" on page 122	Position Formatting

### EXAMPLES:

:PR 100,200,300,400	On the next move the X-axis will go 100 counts,
:BG	the Y-axis will go to 200 counts forward, Z-axis will go 300 counts and the W-axis will go 400 counts.
:PR ?,?,?	Return relative distances
0000000100,0000000200,0000000300	
:PR 500	Set the relative distance for the X axis to 500
:BG	The X-axis will go 500 counts on the next move while the Y-axis will go its previously set relative distance.

# QD

**FUNCTION:** Download Array

**DESCRIPTION:**

The QD command transfers array data from the host computer to the controller. QD array[], start, end requires that the array name be specified along with the first element of the array and last element of the array. The array elements can be separated by a comma ( , ) or by <CR> <LF>. The downloaded array is terminated by a <control>Z, <control>Q, <control>D or \.

**ARGUMENTS:** QD array[],start,end                      where

array[] is valid array name start is first element of array (default=0) end is last element of array (default = last element)

**USAGE:**

**DEFAULTS:**

While Moving	No	Default Value	0
In a Program	Yes	Default Format	Position Format
Command Line	Yes		

**RELATED COMMANDS:**

"QU" on page 127                      Upload array

**HINT:**

Using Galil terminal software, the command can be used in the following manner:

1. Set the timeout to 0
  2. Send the command QD
    - 3a. Use the send file command to send the data file.
- OR
- 3b. Enter data manually from the terminal. End the data entry with the character '\'

## QR

**FUNCTION:** Data Record

**DESCRIPTION:**

The QR command causes the controller to return a record of information regarding controller status. This status information includes 4 bytes of header information and specific blocks of information as specified by the command arguments. The details of the status information is described in Chapter 4 of the user's manual.

**ARGUMENTS:** QR xxxxxx                      where

x is X,Y,Z,W,S,T, or I or any combination to specify the axis, axes, sequence, or I/O status

S and T represent the S and T coordinated motion planes

I represents the status of the I/O

Chapter 4 of the users manual provides the definition of the data record information.

**USAGE:**

**DEFAULTS:**

While Moving	Yes	Default Value	-
In a Program	Yes	Default Format	-
Command Line	Yes		
Controller Usage	<b>ALL CONTROLLERS</b>		

**RELATED COMMANDS:**

"QZ" on page 128                      Return DMA / Data Record information

Note: The Galil windows terminal will not display the results of the QR command since the results are in binary format.



# QU

**FUNCTION:** Upload Array

**DESCRIPTION:**

The QU command transfers array data from the controller to a host computer. The QU requires that the array name be specified along with the first element of the array and last element of the array. The uploaded array will be followed by a <control>Z as an end of text marker.

**ARGUMENTS:** QU array[],start,end,delim                      where

“array[]” is a valid array name

“start” is the number of the first element of the array (default=0)

“end” is the number of the last element of the array (default = last element)

“delim” specifies the character used to delimit the array elements. If delim is 1, then the array elements will be separated by a comma. Otherwise, the elements will be separated by a carriage return.

**USAGE:**

**DEFAULTS:**

While Moving	No	Default Value	0
In a Program	Yes	Default Format	Position Format
Command Line	Yes		

**RELATED COMMANDS:**

"QD" on page 125	Download array
------------------	----------------

# QZ

**FUNCTION:** Return DMA / Data Record information

**DESCRIPTION:**

The QZ command is an interrogation command that returns information regarding DMA transfers (DMC-1700), the secondary FIFO (DMC-1600, DMC-1700, DMC-1800) or the Data Record (DMC-1200, -2000, -2100). The controller's response to this command will be the return of 4 integers separated by commas. The four fields represent the following:

First field returns the number of axes.

Second field returns the number of bytes to be transferred for general status

Third field returns the number bytes to be transferred for coordinated move status

Fourth field returns the number of bytes to be transferred for axis specific information

**ARGUMENTS:** QZ

**USAGE:**

While Moving  
In a Program  
Command Line  
Controller Usage

**DEFAULTS:**

Yes  
Yes  
Yes

Default Value  
Default Format

**ALL CONTROLLERS**

**RELATED COMMANDS:**

“QR” on page 126      Data Record

# RA

**FUNCTION:** Record Array

**DESCRIPTION:**

The RA command selects one through four arrays for automatic data capture. The selected arrays must be dimensioned by the DM command. The data to be captured is specified by the RD command and time interval by the RC command.

**ARGUMENTS:** RA n [],m [],o [],p []                    where

n,m,o, and p are dimensioned arrays as defined by DM command. The [] contain nothing.

**USAGE:**

While Moving  
In a Program  
Command Line

**DEFAULTS:**

Yes	Default Value	-
Yes	Default Format	-
Yes		

**RELATED COMMANDS:**

"DM" on page 52	Dimension Array
"RD" on page 131	Record Data
"RC" on page 130	Record Interval

**EXAMPLES:**

#Record	Label
DM POS[100]	Define array
RA POS[]	Specify Record Mode
RD _TPX	Specify data type for record
RC 1	Begin recording at 2 msec intervals
PR 1000;BG	Start motion
EN	End

***Hint:** The record array mode is useful for recording the real-time motor position during motion. The data is automatically captured in the background and does not interrupt the program sequencer. The record mode can also be used for a teach or learn of a motion path.*

# RC

**FUNCTION:** Record

**DESCRIPTION:**

The RC command begins recording for the Automatic Record Array Mode (RA). RC 0 stops recording.

**ARGUMENTS:** RC n,m                      where

n is an integer 1 thru 8 and specifies 2<sup>n</sup> samples between records. RC 0 stops recording.

m is optional and specifies the number of records to be recorded. If m is not specified, the DM number will be used. A negative number for m causes circular recording over array addresses 0 to m-1. The address for the array element for the next recording can be interrogated with \_RD.

n = ?              Returns status of recording. '1' if recording, '0' if not recording.

**USAGE:**

**DEFAULTS:**

While Moving	Yes	Default Value	-
In a Program	Yes	Default Format	-
Command Line	Yes		

**OPERAND USAGE:**

\_RC contains status of recording. '1' if recording, '0' if not recording.

**RELATED COMMANDS:**

"DM" on page 52	Dimension Array
"RD" on page 131	Record Data
"RA" on page 128	Record Array Mode

**EXAMPLES:**

#RECORD	Record
DM Torque[1000]	Define Array
RA Torque[]	Specify Record Mode
RD _TTX	Specify Data Type
RC 2	Begin recording and set 4 msec between records
JG 1000;BG	Begin motion
#A;JP #A,_RC=1	Loop until done
MG "DONE RECORDING"	Print message
EN	End program

## RD

**FUNCTION:** Record Data

**DESCRIPTION:**

The RD command specifies the data type to be captured for the Record Array (RA) mode. The command type includes:

_DFx	2nd encoder
_TPx	Position
_TE <sub>x</sub>	Position error
_SHx	Commanded position
_RLx	Latched position
_TI	Inputs
_OP	Outputs
_TSx	Switches, only 0-4 bits valid
_SCx	Stop code
_TTx	Tell torque (Note: the values recorded for torque are in the range of +/- 32767 where 0 is 0 torque, -32767 is -10 volt command output, and +32767 is +10 volt.

where 'x' is the axis specifier.

**ARGUMENTS:** RD  $m_1, m_2, m_3, m_4,$                       where

the arguments are data types to be captured using the Record Array feature. The order is important. Each data type corresponds with the array specified in the RA command.

**USAGE:**

**DEFAULTS:**

While Moving	Yes	Default Value	-
In a Program	Yes	Default Format	-
Command Line	Yes		

**OPERAND USAGE:**

\_RD contains the address for the next array element for recording.

**RELATED COMMANDS:**

"RC" on page 130	Record Interval
"DM" on page 52	Dimension Array

**EXAMPLES:**

DM ERRORX[50],ERRORY[50]	Define array
RA ERRORX[],ERRORY[ ]	Specify record mode
RD _TEX,_TEYS	Specify data type
RC1	Begin record
JG 1000;BGX	Begin motion on X axis

## RE

**FUNCTION:** Return from Error Routine

**DESCRIPTION:**

The RE command is used to end a position error handling subroutine or limit switch handling subroutine. The error handling subroutine begins with the #POSERR label. The limit switch handling subroutine begins with the #LIMSWI. An RE at the end of these routines causes a return to the main program. Care should be taken to be sure the error or limit switch conditions no longer occur to avoid re-entering the subroutines. If the program sequencer was waiting for a trippoint to occur, prior to the error interrupt, the trippoint condition is preserved on the return to the program if RE1 is used. RE0 clears the trippoint. To avoid returning to the main program on an interrupt, use the ZS command to zero the subroutine stack.

**ARGUMENTS:** RE n        where

n = 0        Clears the interrupted trippoint

n = 1        Restores state of trippoint

no argument clears the interrupted trippoint

**USAGE:**

While Moving

**DEFAULTS:**

No

Default Value

-

In a Program

Yes

Default Format

-

Command Line

No

**RELATED COMMANDS:**

#POSERR

Error Subroutine

#LIMSWI

Limit Subroutine

**EXAMPLES:**

#A;JP #A;EN

Label for main program

#POSERR

Begin Error Handling Subroutine

MG "ERROR"

Print message

SB1

Set output bit 1

RE

Return to main program and clear trippoint

***Hint:** An applications program must be executing for the #LIMSWI and #POSERR subroutines to function.*

# RI

**FUNCTION:** Return from Interrupt Routine

**DESCRIPTION:**

The RI command is used to end the interrupt subroutine beginning with the label #ININT. An RI at the end of this routine causes a return to the main program. The RI command also re-enables input interrupts. If the program sequencer was interrupted while waiting for a trippoint, such as WT, RI1 restores the trippoint on the return to the program. RI0 clears the trippoint. To avoid returning to the main program on an interrupt, use the command ZS to zero the subroutine stack. This turns the jump subroutine into a jump only.

**ARGUMENTS:** RI n        where

- n = 0     Clears the interrupted trippoint
- n = 1     Restores state of trippoint
- no argument clears the interrupted trippoint

**USAGE:**

While Moving  
In a Program  
Command Line

**DEFAULTS:**

No	Default Value	-
Yes	Default Format	-
No		

**RELATED COMMANDS:**

- #ININT                    Input interrupt subroutine
- "II" on page 82        Enable input interrupts

**EXAMPLES:**

- #A;II1;JP #A;EN        Program label
- #ININT                  Begin interrupt subroutine
- MG "INPUT  
INTERRUPT"              Print Message
- SB 1                    Set output line 1
- RI 1                    Return to the main program and restore trippoint

*Hint:* An applications program must be executing for the #ININT subroutine to function.

## RL (Binary DD)

**FUNCTION:** Report Latched Position

**DESCRIPTION:**

The RL command will return the last position captured by the latch. The latch must first be armed by the AL command and then a 0 must occur on the appropriate input. (Input 1,2,3 and 4 for X,Y,Z and W, respectively). The armed state of the latch can be configured using the CN command.

**ARGUMENTS:** RL xxxx                      where

x is X,Y,Z,W, or any combination to specify the axis or axes

**USAGE:**

**DEFAULTS:**

While Moving	Yes	Default Value	0
In a Program	Yes	Default Format	Position Format
Command Line	Yes		

**OPERAND USAGE:**

\_RLx contains the latched position of the specified axis.

**RELATED COMMAND:**

"AL (Binary EE)" on page 17    Arm Latch

**EXAMPLES:**

JG ,5000	Set up to jog the Y-axis
BGY	Begin jog
ALY	Arm the Y latch; assume that after about 2 seconds, input goes low
RLY	Report the latch
10000	



# RP (Binary D8)

**FUNCTION:** Reference Position

**DESCRIPTION:**

This command returns the commanded reference position of the motor(s).

**ARGUMENTS:** RP xxxx                      where

x is X,Y,Z,W, or any combination to specify the axis or axes

USAGE:	DEFAULTS:		
While Moving	Yes	Default Value	0
In a Program	Yes	Default Format	Position Format
Command Line	Yes		

**OPERAND USAGE:**

\_RPx contains the commanded reference position for the specified axis.

**RELATED COMMAND:**

"TP" on page 154                      Tell Position

**Note:** The relationship between RP, TP, and TE: TEX equals the difference between the reference position, RPX, and the actual position, \_TPX.

**EXAMPLES:** Assume that X,Y,Z, and W axes are commanded to be at the positions 200, -10, 0, -110

respectively. The returned units are in quadrature counts.

:PF 7	Position format of 7
0:RP	
0000200,-0000010,0000000,-0000110	Return X,Y,Z,W reference positions
RPX	
0000200	Return the X motor reference position
RPY	
-0000010	Return the Y motor reference position
PF-6.0	Change to hex format
RP	
\$0000C8,\$FFFFFF6,\$000000,\$FFFF93	Return X,Y,Z,W in hex
Position =_RPX	Assign the variable, Position, the value of RPX



***Hint:** RP command is useful when operating step motors since it provides the commanded position in steps when operating in stepper mode.*

## RS

**FUNCTION:** Reset

**DESCRIPTION:**

The RS command resets the state of the processor to its power-on condition. The previously saved state of the controller, along with parameter values, and saved sequences are restored.

**USAGE:**

**DEFAULTS:**

While Moving	Yes	Default Value	0
In a Program	No	Default Format	-
Command Line	Yes		

**<control>R<control>S**

**FUNCTION:** Master Reset

**DESCRIPTION:**

This command resets the controller to factory default settings and erases EEPROM.

A master reset can also be performed by installing a jumper on the controller at the location labeled MRST and resetting the controller (power cycle or pressing the reset button). Remove the jumper after this procedure.

**USAGE:**

**DEFAULTS:**

While Moving	Yes	Default Value	-
In a Program	No	Default Format	-
Command Line	Yes		

## **<control>R<control>V**

**FUNCTION:** Revision Information

**DESCRIPTION:**

The Revision Information command causes the controller to return firmware revision information.

**USAGE:**

While Moving  
In a Program  
Command Line

**DEFAULTS:**

Yes  
No  
Yes

Default Value -  
Default Format -

# SB (Binary EA)

**FUNCTION:** Set Bit

**DESCRIPTION:**

The SB command sets one of eight bits on the output port.

**ARGUMENTS:** SB n        where

n is an integer in the range 1 to 8 decimal.

**USAGE:**

While Moving  
In a Program  
Command Line

**DEFAULTS:**

Yes  
Yes  
Yes

Default Value	-
Default Format	-

**RELATED COMMAND**

"CB" on page 40	Clear Bit
-----------------	-----------

**EXAMPLES:**

SB 5	Set output line 5
SB 1	Set output line 1

## SC (Binary E1)

**FUNCTION:** Stop Code

**DESCRIPTION:**

The SC command allows the user to determine why a motor stops. The controller responds with the stop code as follows:

CODE	MEANING	CODE	MEANING
0	Motors are running, independent mode	9	Stopped after Finding Edge (FE)
1	Motors stopped at commanded independent position	10	Stopped after homing (HM)
2	Decelerating or stopped by FWD limit switches	11	Stopped by Selective Abort Input
3	Decelerating or stopped by REV limit switches	50	Contour running
4	Decelerating or stopped by Stop Command (ST)	51	Contour Stop
6	Stopped by Abort input	99	MC timeout
7	Stopped by Abort command (AB)	100	Motors are running, vector sequence
8	Decelerating or stopped by Off-on-Error (OE1)	101	Motors stopped at commanded vector

**ARGUMENTS:** SC xxxx                      where

x is X,Y,Z,W or any combination to specify the axis or axes

If no argument is specified then all axes will be given.

**USAGE:**

**DEFAULTS:**

While Moving	Yes	Default Value	-
In a Program	Yes	Default Format	3.0
Command Line	Yes		

**OPERAND USAGE:**

\_SCx contains the value of the stop code for the specified axis.

**EXAMPLES:**

Tom =\_SCW                      Assign the Stop Code of W to variable Tom

# SH (Binary AA)

**FUNCTION:** Servo Here

**DESCRIPTION:**

The SH commands tells the controller to use the current motor position as the command position and to enable servo control here.

This command can be useful when the position of a motor has been manually adjusted following a motor off (MO) command.

**ARGUMENTS:** SH xxxx                      where  
x is X,Y,Z,W, or any combination to specify the axis or axes

USAGE:	DEFAULTS:		
While Moving	No	Default Value	-
In a Program	Yes	Default Format	-
Command Line	Yes		

**RELATED COMMANDS:**

“MO (Binary A9)” on page 109      Motor-off

**EXAMPLES:**

SH	Servo X,Y,Z,W motors
SHX	Only servo the X motor, the Y,Z and W motors remain in its previous state.
SHY	Servo the Y motor; leave the X,Z and W motors unchanged
SHZ	Servo the Z motor; leave the X,Y and W motors unchanged
SHW	Servo the W motor; leave the X,Y and Z motors unchanged

***Note:** The SH command changes the coordinate system. Therefore, all position commands given prior to SH, must be repeated. Otherwise, the controller motion may be unexpected.*

## SP (Binary 92)

**FUNCTION:** Speed

**DESCRIPTION:**

This command sets the slew speed of any or all axes for independent moves, or it will return the previously set value. The parameters input will be rounded down to the nearest factor of 2 and the units of the parameter are in counts per second. Note: Negative values will be interpreted as the absolute value.

**ARGUMENTS:** SP n,n,n,n or SPX=n where

n is an unsigned number in the range 0 to 12,000,000 for servo motors

OR

n is an unsigned number in the range 0 to 3,000,000 for stepper motors

n = ? Returns the speed for the specified axis.

**USAGE:**

While Moving

**DEFAULTS:**

Yes

Default Value

25000

In a Program

Yes

Default Format

Position Format

Command Line

Yes

**OPERAND USAGE:**

\_SPx contains the speed for the specified axis.

**RELATED COMMANDS:**

"AC" on page 14

Acceleration

"DC" on page 49

Deceleration

"PA (Binary A6)" on page 121

Position Absolute

"PR (Binary A7)" on page 124

Position Relation

"BG" on page 28

Begin

**EXAMPLES:**

PR 2000,3000,4000,5000

Specify x,y,z,w parameter

SP 5000,6000,7000,8000

Specify x,y,z,w speeds

BG

Begin motion of all axes

AM Z

After Z motion is complete

**Note:** For vector moves, use the vector speed command (VS) to change the speed. SP is not a "mode" of motion like JOG (JG).



# ST (Binary A1)

**FUNCTION:** Stop

**DESCRIPTION:**

The ST command stops motion on the specified axis. Motors will come to a decelerated stop. If ST is given without an axis specification, program execution will stop in addition to XYZW. XYZW specification will not halt program execution.

**ARGUMENTS:** ST xxxx                      where

x is X,Y,Z,W,S, or T or any combination to specify the axis or sequence

No argument will stop motion on all axes and stop any programs which are executing.

**USAGE:**

**DEFAULTS:**

While Moving	Yes	Default Value	-
In a Program	Yes	Default Format	-
Command Line	Yes		

**RELATED COMMANDS:**

"BG" on page 28	Begin Motion
"AB (Binary A2)" on page 7	Abort Motion
"BC" on page 49	Deceleration rate

**EXAMPLES:**

ST X	Stop X-axis motion
ST S	Stop coordinated sequence on S coordinate system
ST XYZW	Stop X,Y,Z,W motion
ST	Stop program and XYZW motion
ST SZW	Stop coordinated XY sequence, and Z and W motion

***Hint:** Use the after motion complete command, AM, to wait for motion to be stopped.*

## TB

**FUNCTION:** Tell Status Byte

**DESCRIPTION:**

The TB command returns status information from the controller as a decimal number. Each bit of the status byte denotes the following condition when the bit is set (high):

BIT	STATUS
Bit 7	Executing application program
Bit 6 (N/A)	Not used with the DMC-1802 Series Controllers
Bit 5	Contouring
Bit 4	Executing error or limit switch routine
Bit 3	Input interrupt enabled
Bit 2	Executing input interrupt routine
Bit 1 (N/A)	Not used with the DMC-1802 Series Controllers
Bit 0	Echo on

**ARGUMENTS:**

TB ? returns the status byte

**USAGE:**

**DEFAULTS:**

While Moving	Yes	Default Value	-
In a Program	Yes	Default Format	1.0
Command Line	Yes		

**OPERAND USAGE:**

\_TB Contains the status byte

**EXAMPLES:**

"TB" on page 144	Tell status information from the controller
65	Executing program and Echo is on ( $2^6 + 2^0 = 64 + 1 = 65$ )

# TC

**FUNCTION:** Tell Error Code

**DESCRIPTION:**

The TC command returns a number between 1 and 255. This number is a code that reflects why a command was not accepted by the controller. This command is useful when the controller halts execution of a program at a command or when the response to a command is a question mark. Entering the TC command will provide the user with a code as to the reason. After TC has been read, it is set to zero. TC 1 returns the text message as well as the numeric code.

**ARGUMENTS:** TC n where

- n = 0 Returns code only
- n = 1 Returns code and message
- n = ? Returns the error code

No argument will provide the error code for all axes

CODE	EXPLANATION	CODE	EXPLANATION
1	Unrecognized command	50	Not enough fields
2	Command only valid from program	51	Question mark not valid
3	Command not valid in program	52	Missing " or string too long
4	Operand error	53	Error in { }
5	Input buffer full	54	Question mark part of string
6	Number out of range	55	Missing [ or ]
7	Command not valid while running	56	Array index invalid or out of range
8	Command not valid when not running	57	Bad function or array
9	Variable error	58	Unrecognized command in a command response (i.e._GNX)
10	Empty program line or undefined label	59	Mismatched parentheses
11	Invalid label or line number	60	Download error - line too long or too many lines
12	Subroutine more than 16 deep	61	Duplicate or bad label
13	JG only valid when running in jog mode	62	Too many labels
14	EEPROM check sum error	65	IN command must have a comma
15	EEPROM write error	66	Array space full
16	IP incorrect sign during position move or IP given during forced deceleration	67	Too many arrays or variables
17	ED, BN and DL not valid while program running	71	IN only valid in task #0
18	Command not valid when contouring	80	Record mode already running
19	Application strand already executing	81	No array or source specified
20	Begin not valid with motor off	82	Undefined Array

21	Begin not valid while running	83	Not a valid number
22	Begin not possible due to Limit Switch	84	Too many elements
24	Begin not valid because no sequence defined	90	Only X Y Z W valid operand
25	Variable not given in IN command	96	SM jumper needs to be installed for stepper motor operation
28	S operand not valid	100	Not valid when running ECAM
29	Not valid during coordinated move	101	Improper index into ET (must be 0-256)
30	Sequence segment too short	102	No master axis defined for ECAM
31	Total move distance in a sequence > 2 billion	103	Master axis modulus greater than 256*EP value
32	More than 511 segments in a sequence	104	Not valid when axis performing ECAM
41	Contouring record range error	105	EB1 command must be given first
42	Contour data being sent too slowly	118	Controller has GL1600 not GL1800
46	Gear axis both master and follower		

**USAGE:**

While Moving  
In a Program  
Not in a Program

**DEFAULTS:**

Yes  
Yes  
Yes

Default Value ---  
Default Format 3.0

**USAGE:**

\_TC contains the error code

**EXAMPLES:**

:GF32	Bad command
?TC	Tell error code
001	Unrecognized command

# TD (Binary DB)

**FUNCTION:** Tell Stepper Counts

**DESCRIPTION:**



When operating with stepper motors, the TD command returns the number of counts that have been output by the controller.

**ARGUMENTS:** TD xxxx                      where  
x is X,Y,Z,W, or any combination to specify the axis or axes  
No argument will provide the stepper pulses output for all axes

USAGE:	DEFAULTS:		
While Moving	Yes	Default Value	0
In a Program	Yes	Default Format	Position Format
Not in a Program	Yes		

**OPERAND USAGE:**  
\_TDx contains the number of steps output on that axis.

**RELATED COMMANDS:**  
"DE (Binary 98)" on page 50              Dual Encoder

EXAMPLES:	
:PF 7	Position format of 7
:TD	Return X,Y,Z,W Stepper pulses output
0000200,-0000010,0000000,-0000110	
TDX	Return the X motor Stepper pulses
0000200	
DUAL=_TDX	Assign the variable, DUAL, the value of TDX

## TE (Binary DA)

**FUNCTION:** Tell Error

**DESCRIPTION::**

This command returns the current position error of the motor(s). The range of possible error is 2147483647. The Tell Error command is not valid for step motors since they operate open-loop.

**ARGUMENTS:** TE xxxx                      where

x is X,Y,Z,W, or any combination to specify the axis or axes

No argument will provide the position error for all axes

**USAGE:**

**DEFAULTS:**

While Moving	Yes	Default Value	0
In a Program	Yes	Default Format	Position Format
Not in a Program	Yes		

**RELATED COMMANDS:**

"OE (Binary 8D)" on page 118	Off On Error
"ER" on page 69	Error Limit
#POSERR	Error Subroutine
"PF" on page 122	Position Formatting

**EXAMPLES:**

TE	Return all position errors
00005,-00002,00000,00006	
TEX	Return the X motor position error
00005	
TEY	Return the Y motor position error
-00002	
Error =_TEX	Sets the variable, Error, with the X-axis position error

**Hint:** Under normal operating conditions with servo control, the position error should be small. The position error is typically largest during acceleration.

# TI (Binary E0)

**FUNCTION:** Tell Inputs

**DESCRIPTION:**

This command returns the state of the general inputs. The value returned by this command is decimal and represents an 8 bit value (decimal value ranges from 0 to 255). Each bit represents one input.

**ARGUMENTS:** TIn

n = 0 will return the decimal representation for inputs 1 through 8

	TI OR TIO
MSB Bit 7	Input 8
Bit 6	Input 7
Bit 5	Input 6
Bit 4	Input 5
Bit 3	Input 4
Bit 2	Input 3
Bit 1	Input 2
LSB Bit 0	Input 1

n = ? returns the Input Status for Inputs 1 through 8

**USAGE:**

**DEFAULTS:**

While Moving	Yes	Default Value	-
In a Program	Yes	Default Format	1.0
Command Line	Yes		

**OPERAND USAGE:**

\_TIn contains the status byte of the input block. Note that the operand can be masked to return only specified bit information - see the section on Bit-wise operations in the DMC-1802 User Manual.

**EXAMPLES:**

TI	
08	Input 4 is high, others low
TI	
00	All inputs low
Input =_TI	Sets the variable, Input, with the TI value
TI	
255	All inputs high

## TIME\*

**FUNCTION:** Time Operand (Keyword)

**DESCRIPTION:**

\*The TIME operand returns the value of the internal free running, real time clock. The returned value represents the number of servo loop updates and is based on the TM command. The default value for the TM command is 1000. With this update rate, the operand TIME will increase by 1 count every update of approximately 1000usec. Note that a value of 1000 for the update rate (TM command) will actually set an update rate of 1/1024 seconds. Thus the value returned by the TIME operand will be off by 2.4% of the actual time.

The clock is reset to 0 with a standard reset or a master reset.

The keyword, TIME, does not require an underscore "\_" as does the other operands.

**EXAMPLES:**

MG TIME	Display the value of the internal clock
---------	---



# TL (Binary 8a)

**FUNCTION:** Torque Limit

**DESCRIPTION:**

The TL command sets the limit on the motor command output. For example, TL of 5 limits the motor command output to 5 volts. Maximum output of the motor command is 9.998 volts.

**ARGUMENTS:** TL n,n,n,n or TLX=n where

n is an unsigned numbers in the range 0 to 9.998 volts with resolution of 0.003 volts

n = ? Returns the value of the torque limit for the specified axis.

**USAGE:**

**DEFAULTS:**

While Moving	Yes	Default Value	-
In a Program	Yes	Default Format	1.0
Command Line	Yes		

**OPERAND USAGE:**

\_TLx contains the value of the torque limit for the specified axis.

**EXAMPLES:**

TL 1,5,9,7.5	Limit X-axis to 1volt Limit Y-axis to 5 volts Limit Z-axis to 9 volts Limit W-axis to 7.5 volts
TL ?,?,?,?	Return limits
1.0000,5.0000,9.0000,7.5000	
TL ?	Return X-axis limit
1.0000	

## TM (Binary E5)

**FUNCTION:** Update Time

**DESCRIPTION:**

The TM command sets the sampling period of the control loop. Changing the sampling period will uncalibrate the speed and acceleration parameters. A negative number turns off the internal clock allowing for an external source to be used as the time base. The units of this command are  $\mu\text{sec}$ .

**ARGUMENTS:** TM n      where

**With the fast firmware:** n is an integer in the range 125 to 20000 decimal with resolution of 125 microseconds. In the Fast firmware mode the following functions are disabled: Gearing, ECAM, PL, Steppers, Trippoints in main thread, and TV. Using the fast firmware the minimum sample times are the following: 125  $\mu\text{sec}$  for the DMC-1812 and DMC-1822; 250  $\mu\text{sec}$  for the DMC-1832 and DMC-1842.

**With the normal firmware:** In the normal mode the DMC-1812 and DMC-1822 have minimum sample times of 250  $\mu\text{sec}$ ; 375  $\mu\text{sec}$  for the DMC-1832 and DMC-1842.

n = ? returns the value of the sample time.

**USAGE:**

**DEFAULTS:**

While Moving	Yes	Default Value	-
In a Program	Yes	Default Format	1.0
Command Line	Yes		

**OPERAND USAGE:**

\_TM contains the value of the sample time.

**EXAMPLES:**

TM -1000	Turn off internal clock
TM 2000	Set sample rate to 2000 [EQN "[mu]" ]sec (This will cut all speeds in half and all acceleration in fourths)
TM 1000	Return to default sample rate

# TN (Binary B4)

**FUNCTION:** Tangent

**DESCRIPTION:**

The TN m,n command describes the tangent axis to the coordinated motion path. m is the scale factor in counts/degree of the tangent axis. n is the absolute position of the tangent axis where the tangent axis is aligned with zero degrees in the coordinated motion plane. The tangent axis is specified with the VM n,m,p command where p is the tangent axis. The tangent function is useful for cutting applications where a cutting tool must remain tangent to the part.

**ARGUMENTS:** TN m,n                      where

m is the scale factor in counts/degree, in the range between -127 and 127 with a fractional resolution of 0.004

m = ?              Returns the first position value for the tangent axis.



When operating with stepper motors, m is the scale factor in steps / degree

n is the absolute position at which the tangent angle is zero, in the range between +/-2 • 10<sup>9</sup>

**USAGE:**

**DEFAULTS:**

While Moving	Yes	Default Value	-
In a Program	Yes	Default Format	--
Command Line	Yes		

**OPERAND USAGE:**

\_TN contains the first position value for the tangent axis. This allows the user to correctly position the tangent axis before the motion begins.

**RELATED COMMANDS:**

- "VM " on page 166                      Vector mode
- "CR (Binary B3)" on page 45      Circular Command

**EXAMPLES:**

CAS	Specify the S coordinate system
VM X,Y,Z	Specify coordinated mode for X and Y-axis; Z-axis is tangent to the motion path
TN 100,50	Specify scale factor as 100 counts/degree and 50 counts at which tangent angle is zero
VP 1000,2000	Specify vector position X,Y
VE	End Vector
BGS	Begin coordinated motion with tangent axis

## TP (Binary D9)

**FUNCTION:** Tell Position

**DESCRIPTION:**

This command returns the current position of the motor(s).

**ARGUMENTS:** TP xxxx                      where

x is X,Y,Z,W, or any combination to specify the axis or axes

**USAGE:**

**DEFAULTS:**

While Moving	Yes	Default Value	-
In a Program	Yes	Default Format	--
Command Line	Yes		

**OPERAND USAGE:**

\_TPx contains the current position value for the specified axis.

No argument will provide the encoder position for all axes

**RELATED COMMANDS:**

"PF" on page 122                      Position Formatting

**EXAMPLES:**

Assume the X-axis is at the position 200 (decimal), the Y-axis is at the position -10 (decimal), the Z-axis is at position 0, and the W-axis is at -110 (decimal). The returned parameter units are in quadrature counts.

:PF 7	Position format of 7
:TP	Return X,Y,Z,W positions
0000200,-0000010,0000000,-0000110	
TPX	Return the X motor position
0000200	
TPY	Return the Y motor position
-0000010	
PF-6.0	Change to hex format
TP	Return X,Y,Z,W in hex
\$0000C8,\$FFFFFF6,\$000000,\$FFFF93	
Position =_TPX	Assign the variable, Position, the value of TPX

# TR

**FUNCTION:** Trace

**DESCRIPTION:**

The TR command causes each instruction in a program to be sent out the communications port prior to execution. TR1 enables this function and TR0 disables it. The trace command is useful in debugging programs.

**ARGUMENTS:** TR n        where

n = 0        Disables the trace function

n = 1        Enables the trace function

No argument disables the trace function

**USAGE:**

**DEFAULTS:**

While Moving	Yes	Default Value	TR0
In a Program	Yes	Default Format	--
Command Line	Yes		

## TS (Binary DF)

**FUNCTION:** Tell Switches

**DESCRIPTION:**

TS returns status information of the Home switch, Forward Limit switch and Reverse Limit switch, error conditions, motion condition and motor state. The value returned by this command is decimal and represents an 8 bit value (decimal value ranges from 0 to 255). Each bit represents the following status information:

Bit	Status
Bit 7	Axis in motion if high
Bit 6	Axis error exceeds error limit if high
Bit 5	x motor off if high
Bit 4	Undefined
Bit 3	Forward Limit Switch Status inactive if high
Bit 2	Reverse Limit Switch Status inactive if high
Bit 1	Home x Switch Status
Bit 0	Latched

**Note:** For active high or active low configuration (CN command), these bits are '1' when the switch is inactive and '0' when active.

**ARGUMENTS:** TS xxxx                      where

x is X,Y,Z,W or any combination to specify the axis or axes

No argument will provide the status for all axes

**USAGE:**

**DEFAULTS:**

While Moving	Yes	Default Value	-
In a Program	Yes	Default Format	3.0
Command Line	Yes		

**OPERAND USAGE:**

\_TS contains the current status of the switches.

**EXAMPLES:**

V1=_TSY	Assigns value of TSY to the variable V1
V1=	Interrogate value of variable V1
015 (returned value)	Decimal value corresponding to bit pattern 00001111
	Y axis not in motion (bit 7 - has a value of 0)
	Y axis error limit not exceeded (bit 6 has a value of 0)
	Y axis motor is on (bit 5 has a value of 0)
	Y axis forward limit is inactive (bit 3 has a value of 1)
	Y axis reverse limit is inactive (bit 2 has a value of 1)
	Y axis home switch is high (bit 1 has a value of 1)
	Y axis latch is not armed (bit 0 has a value of 1)

**TT (Binary DE)**

**FUNCTION:** Tell Torque

**DESCRIPTION:**

The TT command reports the value of the analog output signal, which is a number between -9.998 and 9.998 volts.

**ARGUMENTS:** TT xxxx                      where  
x is X,Y,Z,W, or any combination to specify the axis or axes  
No argument will provide the torque for all axes

USAGE:	DEFAULTS:		
While Moving	Yes	Default Value	-
In a Program	Yes	Default Format	1.4
Command Line	Yes		

**OPERAND USAGE:**  
\_TTx contains the value of the torque for the specified axis.

**RELATED COMMANDS:**  
"TL" on page 151                      Torque Limit

**EXAMPLES:**  
V1=\_TTX                      Assigns value of TTX to variable, V1  
TTX                      Report torque on X  
-0.2843                      Torque is -.2843 volts

## TV (Binary DC)

**FUNCTION:** Tell Velocity

**DESCRIPTION:**

The TV command returns the actual velocity of the axes in units of quadrature count/s. The value returned includes the sign.

**ARGUMENTS:** TV xxxx                      where

x is X,Y,Z,W, or any combination to specify the axis or axes

No argument will provide the dual encoder position for all axes

**USAGE:**

**DEFAULTS:**

While Moving	Yes	Default Value	-
In a Program	Yes	Default Format	7.0
Command Line	Yes		

**OPERAND USAGE:**

\_TVx contains the value of the velocity for the specified axis.

**EXAMPLES:**

VELX=_TVX	Assigns value of X-axis velocity to the variable VELX
TVX	Returns the Y-axis velocity
0003420	

**Note:** The TV command is computed using a special averaging filter (over approximately .25 sec). Therefore, TV will return average velocity, not instantaneous velocity.



# TW (Binary CA)

**FUNCTION:** Timeout for IN-Position (MC)

**DESCRIPTION:**

The TW x,y,z,w command sets the timeout in msec to declare an error if the MC command is active and the motor is not at or beyond the actual position within n msec after the completion of the motion profile. If a timeout occurs, then the MC trippoint will clear and the stopcode will be set to 99. An application program will jump to the special label #MCTIME. The RE command should be used to return from the #MCTIME subroutine.

**ARGUMENTS:** TW n,n,n,n or TWX=n where

n specifies the timeout in msec. n ranges from 0 to 32767 msec

n = -1 Disables the timeout.

n = ? Returns the timeout in msec for the MC command for the specified axis.

**USAGE:**

**DEFAULTS:**

While Moving	Yes	Default Value	32766
In a Program	Yes	Default Format	
Command Line	Yes		

**OPERAND USAGE:**

\_TWx contains the timeout in msec for the MC command for the specified axis.

**RELATED COMMANDS:**

"MC (Binary C9)" on page 106 Motion Complete trippoint

# UI

**FUNCTION:** User Interrupt

**DESCRIPTION:**

The UI command causes an interrupt on the selected IRQ line. There are 16 user interrupts. Prior to using the UI command, one IRQ line must be enabled on the controller and the data 2 and 4 written to the control register at address N + 1. Interrupts may be enabled through the Plug and Play feature. An interrupt service routine must also be incorporated in your host program. The interrupt condition can be read by writing a 6 to address N + 1 and then reading address N + 1. Refer to the DMC-1802 User Manual for additional information.

**ARGUMENTS:** UI n    where

n is an integer between 0 and 15.

**USAGE:**

While Moving  
In a Program  
Command Line

**DEFAULTS:**

Yes  
Yes  
Yes

Default Value	0
Default Format	-

**EXAMPLES:**

#I	Label
PR 10000	Position relative
SP 5000	Speed
BGX	Begin motion
AS	Wait for at speed
UI 1	Send interrupt 1
EN	End program

This program sends an interrupt to the selected IRQ line. The host writes a 6 to address N + 1 and then reads address N + 1 to receive data E1 which corresponds to UI1.

# UL

**FUNCTION:** Upload

**DESCRIPTION:**

The UL command transfers data from the controller to a host computer through port 1. Programs are sent without line numbers. The Uploaded program will be followed by a <control>Z or a \ as an end of text marker.

**ARGUMENTS:** None

**USAGE:**

		<b>DEFAULTS:</b>	
While Moving	Yes	Default Value	0
In a Program	No	Default Format	-
Command Line	Yes		

**OPERAND USAGE:**

When used as an operand, \_UL gives the number of available variables. The number of available variables is 254.

**RELATED COMMAND:**

"DL" on page 51	Download
-----------------	----------

**EXAMPLES:**

UL;	Begin upload
#A	Line 0
NO This is an Example	Line 1
NO Program	Line 2
EN	Line 3
<cntrl>Z	Terminator

## VA (Binary B7)

**FUNCTION:** Vector Acceleration

**DESCRIPTION:**

This command sets the acceleration rate of the vector in a coordinated motion sequence. The parameter input will be rounded DOWN to the nearest factor of 1024. The units of the parameter is counts per second squared.

**ARGUMENTS:** VA s,t                      where

s and t are unsigned integers in the range 1024 to 68,431,360. s represents the vector acceleration for the S coordinate system and t represents the vector acceleration for the T coordinate system.

s = ?              Returns the value of the vector acceleration for the S coordinate plane.

t = ?              Returns the value of the vector acceleration for the T coordinate plane.

**USAGE:**

While Moving	Yes	Default Value	262144
In a Program	Yes	Default Format	Position Format
Command Line	Yes		

**DEFAULTS:**

**OPERAND USAGE:**

\_VAx contains the value of the vector acceleration for the specified axis.

**RELATED COMMANDS:**

"VS" on page 171	Vector Speed
"VP" on page 168	Vector Position
"VE" on page 164	End Vector
"CR" on page 45	Circle
"VM" on page 166	Vector Mode
"BG" on page 28	Begin Sequence
"VD" on page 163	Vector Deceleration
"VT" on page 172	Vector smoothing constant - S-curve

**EXAMPLES:**

VA 1024	Set vector acceleration to 1024 counts/sec <sup>2</sup>
VA ?	Return vector acceleration
00001024	
VA 20000	Set vector acceleration
VA ?	
0019456	Return vector acceleration
ACCEL=_VA	Assign variable, ACCEL, the value of VA

**Note:** This command is not valid in the DMC-1812.

# VD (Binary B8)

**FUNCTION:** Vector Deceleration

**DESCRIPTION:**

This command sets the deceleration rate of the vector in a coordinated motion sequence. The parameter input will be rounded DOWN to the nearest factor of 1024. The units of the parameter is counts per second squared.

**ARGUMENTS:** VD s,t                      where

s and t are unsigned integers in the range 1024 to 68431360. s represents the vector deceleration for the S coordinate system and t represents the vector acceleration for the T coordinate system.

s = ?              Returns the value of the vector deceleration for the S coordinate plane.

t = ?              Returns the value of the vector deceleration for the T coordinate plane.

**USAGE:**

**DEFAULTS:**

While Moving	No	Default Value	262144
In a Program	Yes	Default Format	Position Format
Command Line	Yes		

**OPERAND USAGE:**

\_VDx contains the value of the vector deceleration for the specified coordinate system, S or T.

**RELATED COMMANDS:**

"VA" on page 162	Vector Acceleration
"VS" on page 171	Vector Speed
"VP" on page 168	Vector Position
"CR" on page 45	Circle
"VE" on page 164	Vector End
"VM" on page 166	Vector Mode
"BG" on page 28	Begin Sequence
"VT" on page 172	Smoothing constant - S-curve

**EXAMPLES:**

#VECTOR	Vector Program Label
VMXY	Specify plane of motion
VA1000000	Vector Acceleration
VD 5000000	Vector Deceleration
VS 2000	Vector Speed
VP 10000, 20000	Vector Position
VE	End Vector
BGS	Begin Sequence

*Note: This command is not valid in the DMC-1812.*

# VE

**FUNCTION:** Vector Sequence End

**DESCRIPTION:**

VE is required to specify the end segment of a coordinated move sequence. VE would follow the final VP or CR command in a sequence. VE is equivalent to the LE command.

The VE command will apply to the selected coordinate system, S or T. To select the coordinate system, use the command CAS or CAT.

**ARGUMENTS:** VE n

No argument specifies the end of a vector sequence

n = ?      Returns the length of the vector in counts.

**USAGE:**

While Moving  
In a Program  
Command Line

**DEFAULTS:**

Yes  
Yes  
Yes

Default Value      -  
Default Format      -

**OPERAND USAGE:**

\_VEx contains the length of the vector in counts for the specified coordinate system, S or T.

**RELATED COMMANDS:**

"VM" on page 166	Vector Mode
"VS" on page 171	Vector Speed
"VA" on page 162	Vector Acceleration
"VD" on page 163	Vector Deceleration
"CR" on page 45	Circle
"VP" on page 168	Vector Position
"BG" on page 28	Begin Sequence
"CS" on page 46	Clear Sequence

**EXAMPLES:**

VM XY	Vector move in XY
VP 1000,2000	Linear segment
CR 0,90,180	Arc segment
VP 0,0	Linear segment
VE	End sequence
BGS	Begin motion

## VF

**FUNCTION:** Variable Format

**DESCRIPTION:**

The VF command allows the variables and arrays to be formatted for number of digits before and after the decimal point. When displayed, the value m represents the number of digits before the decimal point, and the value n represents the number of digits after the decimal point. When in hexadecimal, the string will be preceded by a \$. Hex numbers are displayed as 2's complement with the first bit used to signify the sign.

If a number exceeds the format, the number will be displayed as the maximum possible positive or negative number (i.e. 999.99, -999, \$8000 or \$7FF).

**ARGUMENTS:** VF<sub>m,n</sub>                      where

m and n are unsigned numbers in the range  $0 < m < 10$  and  $0 < n < 4$ . A negative m specifies hexadecimal format.

**m = ?** Returns the value of the format for variables and arrays.

**USAGE:**

**DEFAULTS:**

While Moving	Yes	Default Value	10.4
In a Program	Yes	Default Format	2.1
Command Line	Yes		

**OPERAND USAGE:**

**\_VF** contains the value of the format for variables and arrays.

### RELATED COMMANDS:

"PF" on page 122                      Vector Position

**EXAMPLES:**

VF 5.3	Sets 5 digits of integers and 3 digits after the decimal point
VF 8.0	Sets 8 digits of integers and no fractions
VF -4.0	Specify hexadecimal format with 4 bytes to the left of the decimal

## VM

**FUNCTION:** Coordinated Motion Mode

**DESCRIPTION:**

The VM command specifies the coordinated motion mode and the plane of motion. This mode may be specified for motion on any set of two axes.

The motion is specified by the instructions VP and CR, which specify linear and circular segments. Up to 511 segments may be given before the Begin Sequence (BGS or BGT) command. Additional segments may be given during the motion when the buffer frees additional spaces for new segments. It is the responsibility of the user to keep enough motion segments in the buffer to ensure continuous motion.

The Vector End (VE) command must be given after the last segment. This allows the controller to properly decelerate.

The VM command will apply to the selected coordinate system, S or T. To select the coordinate system, use the command CAS or CAT.

**ARGUMENTS:** VM n,m,p                      where

n and m specify plane of vector motion and can be any two axes. Vector Motion can be specified for one axis by specifying the parameter, m, as N. Specifying one axis is useful for obtaining sinusoidal motion on 1 axis.

p is the tangent axis and can be specified as any axis. A value of N for the parameter, p, turns off tangent function.

n = ?       Returns the available spaces for motion segments that can be sent to the buffer. A value of zero means that the buffer is full and no additional segments may be sent.

**USAGE:**

**DEFAULTS:**

While Moving	No	Default Value	X,Y
In a Program	Yes	Default Format	-
Command Line	Yes		

**OPERAND USAGE:**

\_VMx contains instantaneous commanded vector velocity for the specified coordinate system, S or T.



**RELATED COMMANDS:**

"VP" on page 168	Vector Position
"VS" on page 171	Vector Speed
"VA" on page 162	Vector Acceleration
"VD" on page 163	Vector Deceleration
"CR" on page 45	Circle
"VE" on page 164	End Vector Sequence
"CS" on page 46	Clear Sequence
"VT" on page 172	Vector smoothing constant -- S-curve
"AV" on page 23	Trippoint for Vector distance

**EXAMPLES:**

CAS	Specify S coordinate system
VM XY	Specify coordinated mode for X,Y
CR 500,0,180	Specify arc segment
VP 100,200	Specify linear segment
VE	End vector
BGS	Begin sequence

## VP (Binary B2)

**FUNCTION** Vector Position

### DESCRIPTION:

The VP command defines the target coordinates of a straight line segment in a 2 axis motion sequence which have been selected by the VM command. The units are in quadrature counts, and are a function of the vector scale factor set using the command VS.

For three or four axis linear interpolation, use the LI command.

The VP command will apply to the selected coordinate system, S or T. To select the coordinate system, use the command CAS or CAT.

**ARGUMENTS:** VP n,m < o > p      where

n and m are signed integers in the range -2147483648 to 2147483647 The length of each segment must be limited to  $8 \cdot 10^6$ . The values for n and m will specify a coordinate system from the beginning of the sequence.

o specifies a vector speed to be taken into effect at the execution of the vector segment. n is an unsigned even integer between 0 and 12,000,000 for servo motor operation and between 0 and 3,000,000 for stepper motors.

p specifies a vector speed to be achieved at the end of the vector segment. p is an unsigned even integer between 0 and 8,000,000.

### USAGE:

While Moving  
In a Program  
Command Line

### DEFAULTS:

Yes  
Yes  
Yes

Default Value      -  
Default Format      -

### OPERAND USAGE:

\_VPx contains the absolute coordinate of the axes at the last intersection along the sequence.

For example, during the first motion segment, this instruction returns the coordinate at the start of the sequence. The use as an operand is valid in the linear mode, LM, and in the Vector mode, VM.

### RELATED COMMANDS:

"CR" on page 45	Circle
"VM" on page 166	Vector Mode
"VA" on page 162	Vector Acceleration
"VD" on page 163	Vector Deceleration
"VE" on page 164	Vector End
"VS" on page 171	Vector Speed
"BG" on page 28	Begin Sequence
"VT" on page 172	Vector smoothing

### EXAMPLES:

#A	Program A
CAS	Specify S coordinate system
VM XY	Specify motion plane
VP 1000,2000	Specify vector position X,Y

CR 1000,0,360	Specify arc
VE	Vector end
VS 2000	Specify vector speed
VA 400000	Specify vector acceleration
BGS	Begin motion sequence
EN	End Program

**Note:** This command is not valid in the DMC-1812. Non-sequential axes do not require comma delimitation.

**Hint:** The first vector in a coordinated motion sequence defines the origin for that sequence. All other vectors in the sequence are defined by their endpoints with respect to the start of the move sequence.

## VR (Binary BA)

**FUNCTION:** Vector Speed Ratio

**DESCRIPTION:**

The VR sets a ratio to be used as a multiplier of the current vector speed. The vector speed can be set by the command VS or the operators < and > used with CR, VP and LI commands. The ratio can be a value between 0 and 10 with a resolution of .0001. VR takes effect immediately and will ratio all the following vector speed commands. VR doesn't ratio acceleration or deceleration, but the change in speed is accomplished by accelerating or decelerating at the rate specified by VA and VD.

**ARGUMENTS:** VR s,t                      where

s and t are between 0 and 10 with a resolution of .0001. The value specified by s is the vector ratio to apply to the S coordinate system and t is the value to apply to the T coordinate system.

s = ?              Returns the value of the vector speed ratio for the S coordinate plane.

t = ?              Returns the value of the vector speed ratio for the T coordinate plane.

**USAGE:**

While Moving  
In a Program  
Command Line

**DEFAULTS:**

Yes  
Yes  
Yes

Default Value              1  
Default Format              -

**OPERAND USAGE:**

\_VRx contains the vector speed ratio of the specified coordinate system, S or T.

**RELATED COMMANDS:**

"VS" on page 171              Vector Speed

**EXAMPLES:**

#A	Vector Program
VMXY	Vector Mode
VP 1000,2000	Vector Position
CR 1000,0,360	Specify Arc
VE	End Sequence
VS 2000	Vector Speed
BGS	Begin Sequence
AMS	After Motion
JP#A	Repeat Move
#SPEED	Speed Override
VR@AN[1]*.1	Read analog input compute ratio
JP#SPEED	Loop
XQ#A,0; XQ#SPEED,1	Execute task 0 and 1 simultaneously

**Note:** VR is useful for feedrate override, particularly when specifying the speed of individual segments using the operator '<' and '>'.

# VS (Binary B9)

**FUNCTION:** Vector Speed

**DESCRIPTION:**

The VS command specifies the speed of the vector in a coordinated motion sequence in either the LM or VM modes. The parameter input is rounded down to the nearest factor of 2. The units are counts per second. VS may be changed during motion.

Vector Speed can be calculated by taking the square root of the sum of the squared values of speed for each axis specified for vector or linear interpolated motion.

**ARGUMENTS:** VS s,t                      where

s and t are unsigned numbers in the range 2 to 12,000,000 for servo motors and 2 to 3,000,000 for stepper motors. s is the speed to apply to the S coordinate system and t is the speed to apply to the T coordinate system.

s = ?              Returns the value of the vector speed for the S coordinate plane.

t = ?              Returns the value of the vector speed for the T coordinate plane.

**USAGE:**

**DEFAULTS:**

While Moving	Yes	Default Value	8192
In a Program	Yes	Default Format	-
Command Line	Yes		

**OPERAND USAGE:**

\_VSx contains the vector speed of the specified coordinate system, S or T

**RELATED COMMANDS:**

"VA" on page 162	Vector Acceleration
"VP" on page 168	Vector Position
"CR" on page 45	Circle
"LM (Binary B 0)" on page 101	Linear Interpolation
"VM" on page 166	Vector Mode
"BG" on page 28	Begin Sequence
"VE" on page 164	Vector End

**EXAMPLES:**

VS 2000	Define vector speed of S coordinate system
VS ?	Return vector speed of S coordinate system
002000	

***Hint:** Vector speed can be attached to individual vector segments. For more information, see description of VP, CR, and LI commands.*

## VT (Binary B6)

**FUNCTION:** Vector Time Constant - S curve

**DESCRIPTION:**

The VT command filters the acceleration and deceleration functions in vector moves of VM, LM type to produce a smooth velocity profile. The resulting profile has continuous acceleration and results in reduced mechanical vibrations. VT sets the bandwidth of the filter, where 1 means no filtering and 0.004 means maximum filtering. Note that the filtering results in longer motion time.

**ARGUMENTS:** VT s,t                      where

s and t are unsigned numbers in the range between 0.004 and 1.0, with a resolution of 1/256. The value s applies to the S coordinate system and t applies to the T coordinate system.

s = ?              Returns the value of the vector time constant for the S coordinate plane.

t = ?              Returns the value of the vector time constant for the T coordinate plane.

**USAGE:**

While Moving  
In a Program  
Command Line

**DEFAULTS:**

Yes  
Yes  
Yes

Default Value              1.0  
Default Format             1.4

**OPERAND USAGE:**

\_VT contains the vector time constant.

**RELATED COMMANDS:**

"IT" on page 87              Independent Time Constant for smoothing independent moves

**EXAMPLES:**

VT 0.8                      Set vector time constant for S coordinate system  
VT ?                        Return vector time constant for S coordinate system  
0.8

# WC (Binary D4)

**FUNCTION:** Wait for Contour Data

**DESCRIPTION:**

The WC command acts as a flag in the Contour Mode. After this command is executed, the controller does not receive any new data until the internal contour data buffer is ready to accept new commands. This command prevents the contour data from overwriting on itself in the contour data buffer.

**USAGE:**

While Moving                      Yes  
In a Program                      Yes  
Command Line                      Yes

**DEFAULTS:**

Default Value                      1.0  
Default Format                      1.4

**RELATED COMMANDS:**

"CM" on page 43                      Contour Mode  
"CD" on page 41                      Contour Data  
"DT" on page 54                      Contour Time

**EXAMPLES:**

CM XYZW                      Specify contour mode  
DT 4                      Specify time increment for contour  
CD 200,350,-150,500                      Specify incremental position on X,Y,Z and W X-axis moves 200 counts Y-axis moves 300 counts Z-axis moves -150 counts W-axis moves 500 counts  
WC                      Wait for contour data to complete  
CD 100,200,300,400  
WC                      Wait for contour data to complete  
DT 0                      Stop contour  
CD 0,0,0,0                      Exit mode

## WT (Binary D3)

**FUNCTION:** Wait

**DESCRIPTION:**

The WT command is a trippoint used to time events. After this command is executed, the controller will wait for the number of samples specified before executing the next command. If the TM command has not been used to change the sample rate from 1 msec, then the units of the Wait command are milliseconds.

**ARGUMENTS:** WT n      where

n is an integer in the range 0 to 2 Billion decimal

**USAGE:**

While Moving  
In a Program  
Command Line

**DEFAULTS:**

Yes  
Yes  
Yes

Default Value      -  
Default Format      -

**EXAMPLES:** Assume that 10 seconds after a move is over a relay must be closed.

#A	Program A
PR 50000	Position relative move
BGX	Begin the move
AMX	After the move is over
WT 10000	Wait 10 seconds
SB 0	Turn on relay
EN	End Program

**Hint:** To achieve longer wait intervals, just stack multiple WT commands.



# XQ

**FUNCTION:** Execute Program

**DESCRIPTION:**

The XQ command begins execution of a program residing in the program memory of the controller. Execution will start at the label or line number specified. Up to 8 programs may be executed with the controller.

**ARGUMENTS:** XQ #A,n XQm,n where

A is a program name of up to seven characters.

m is a line number

n is an integer representing the thread number for multitasking

n is an integer in the range of 0 to 7.

**NOTE:** The arguments for the command, XQ, are optional. If no arguments are given, the first program in memory will be executed as thread 0.

**USAGE:**

**DEFAULTS:**

While Moving	Yes	Default Value of n:	0
In a Program	Yes	Default Format	-
Command Line	Yes		

**OPERAND USAGE:**

\_XQn contains the current line number of execution for thread n, and -1 if thread n is not running.

**RELATED COMMANDS:**

"HX" on page 81      Halt execution

**EXAMPLES:**

XQ #Apple,0	Start execution at label Apple, thread zero
XQ #data,2	Start execution at label data, thread two
XQ 0	Start execution at line 0

**Hint:** Don't forget to quit the edit mode first before executing a program!

## ZS

**FUNCTION:** Zero Subroutine Stack

**DESCRIPTION:**

The ZS command is only valid in an application program and is used to avoid returning from an interrupt (either input or error). ZS alone returns the stack to its original condition. ZS1 adjusts the stack to eliminate one return. This turns the jump to subroutine into a jump. Do not use RI (Return from Interrupt) when using ZS. To re-enable interrupts, you must use II command again.

The status of the stack can be interrogated with the operand `_ZSx` - see operand usage below.

**ARGUMENTS:** ZS n      where

- n = 0      Returns stack to original condition
- n = 1      Eliminates one return on stack

**USAGE:**

**DEFAULTS:**

While Moving	Yes	Default Value	0
In a Program	Yes	Default Format	3.0
Command Line	No		

**OPERAND USAGE:**

`_ZSn` contains the stack level for the specified thread where n = 0,1,2 or 3. Note: n can also be specified using X (thread 0), Y(thread1), Z(thread2) or W (thread3) .

**EXAMPLES:**

II1	Input Interrupt on 1
#A;JP #A;EN	Main program
#ININT	Input Interrupt
MG "INTERRUPT"	Print message
S=_ZS	Interrogate stack
S=	Print stack
ZS	Zero stack
S=_ZS	Interrogate stack
S=	Print stack
EN	End

# Index

## A

- Abort 13
  - Off-On-Error 13, 118
  - Stop Motion 143, 145, 147, 148, 154, 156, 157, 158
- Absolute Position 19–20, 53, 107, 110, 153
- Absolute Value 63
- Acceleration 14, 21, 24, 26, 27, 29, 31, 35, 72, 86, 152, 162–64
- Address 130, 160
- Arm Latch 17
- Array 48, 52, 105, 116, 125, 165
- Automatic Subroutine
  - LIMSWI 132
  - MCTIME 106, 159
  - POSERR 69, 118, 132
- Auxiliary Encoder 42, 77

## B

- Binary 1, 4, 5
- Burn 32
  - EEPROM 32, 137
  - Variables 37

## C

- Capture Data
  - Record 129
- Circle 39, 45, 70
- Circular Interpolation 130, 166
- Clear Bit 40
- Clear Sequence 46
- Clock 150, 152
  - Update Rate 150
- Code 1, 17, 42, 50, 69, 73, 77, 80, 85, 106, 107, 110, 140, 159
- Command

Syntax **Error! Not a valid bookmark in entry on page 2**

- Commanded Position 77
- Communication 47
- Conditional jump 16, 89
- Configuration
  - Jumper 137
- Contour Mode 41, 43, 46, 54, 173
- Control Filter
  - Gain 92
  - Integrator 84
- Coordinated Motion 77, 153, 162–63, 166, 169, 171
  - Circular 130, 166
  - Contour Mode 41, 43, 46, 54, 173
  - Ecam 55, 59, 62, 63, 67, 71
  - Electronic Cam 55, 68, 71
  - Electronic Gearing 77, 79
  - Gearing 77, 79
  - Linear Interpolation 96, 98–101, 168
  - Vector Mode 70, 168
- Cycle Time
  - Clock 150, 152

## D

- Data Capture 129
- Data Output
  - Set Bit 40, 139
- Debugging 155
- Deceleration 13, 21, 49, 72, 87, 172
- Default Setting 137
  - Master Reset 3, 137, 138, 150
- Digital Output
  - Clear Bit 40
- Dip Switch
  - Address 130, 160
- DMA 126, 128, 152
- Download 51, 125

## E

- Ecam 55, 59, 62, 63, 67, 71
  - Electronic Cam 55, 68, 71
- Echo 66, 144
- Edit Mode 58, 103, 175
- EEPROM 32, 137
- Electronic Cam 55, 68, 71
- Electronic Gearing 77, 79
- Ellipse Scale 70
- Encoder
  - Auxiliary Encoder 42, 77
  - Index Pulse 74, 80
  - Quadrature 15, 19, 20, 23, 30, 39, 41, 45, 53, 69, 86, 107, 110, 121, 124, 135, 154, 158, 168

Error  
  Codes 145, 146  
Error Code 1, 17, 42, 50, 69, 73, 77, 80, 85, 106, 107, 110, 140, 159  
Error Handling 132  
Error Limit 69, 156  
  Off-On-Error 13, 118  
Execute Program 175

## F

Feedforward Acceleration 72  
*Feedrate* 170  
Filter Parameter  
  Gain 92  
  Integrator 84  
Find Edge 73  
Formatting 105  
Function 62, 63

## G

Gain 92  
Gear Ratio 77, 79  
Gearing 77, 79

## H

Halt 16, 18, 81, 143  
  Abort 13  
  Off-On-Error 13, 118  
  Stop Motion 143, 145, 147, 148, 154, 156, 157, 158  
Hardware 30, 75, 137  
  Address 130, 160  
  Clear Bit 40  
  Jumper 137  
  Set Bit 40, 139  
  Torque Limit 151  
Home Input 73  
Homing 73, 80  
  Find Edge 73

## I

I/O  
  Clear Bit 40  
  Home Input 73  
  Set Bit 40, 139  
Independent Motion  
  Jog 49, 86, 88, 142  
Index Pulse 74, 80  
ININT 16, 64, 65, 82, 133  
Input Interrupt 64, 65, 82, 83, 144  
  ININT 16, 64, 65, 82, 133

Integrator 84  
Internal Variable 18  
Interrogation 86, 105  
Interrupt 32, 60, 64, 65, 82, 83, 85, 129, 132, 144, 160, 176  
Invert 42, 111

## J

Jog 49, 86, 88, 142  
Jumper 137

## K

Keyword 97, 102, 150  
  TIME 150  
KS 94

## L

Label 51, 82, 89, 103, 106, 132, 137, 159, 175  
  Special Label 106, 159  
Latch 17, 44, 134  
  Arm Latch 17  
  Data Capture 129  
  Position Capture 17  
  Record 129  
  Teach 129  
Limit Switch 44, 75, 79, 85, 97, 102, 132, 140, 144  
LIMSWI 132  
Linear Interpolation 96, 98–101, 168  
  Clear Sequence 46  
Logical Operator 89

## M

Master Reset 3, 137, 138, 150  
Math Function  
  Absolute Value 63  
  Logical Operator 89  
MCTIME 106, 159  
Memory 32, 48, 103  
  Array 48, 52, 105, 116, 125, 165  
  Download 51, 125  
  Upload 161  
Message 85  
Motion Complete  
  MCTIME 106, 159  
Motion Smoothing  
  S-Curve 21  
Motor Command 118, 151  
Moving  
  Acceleration 14, 21, 24, 26, 27, 29, 31, 35, 72, 86, 152, 162–64  
  Circular 130, 166

Multitasking 81, 175  
  Execute Program 175  
  Halt 16, 18, 81, 143

## N

Non-volatile memory  
  Burn 32

## O

OE  
  Off-On-Error 13, 118  
Off-On-Error 13, 118  
Operand  
  Internal Variable 18  
Optoisolation  
  Home Input 73  
Output  
  Motor Command 118, 151  
Output of Data  
  Clear Bit 40  
  Set Bit 40, 139

## P

Plug and Play 60  
POSERR 69, 118, 132  
  Position Error 15, 92, 118, 135  
Position Capture 17  
  Latch 17, 44, 134  
  Teach 129  
Position Error 15, 92, 118, 135  
  POSERR 69, 118, 132  
Position Limit 75  
Program Flow 59, 68  
  Interrupt 32, 60, 64, 65, 82, 83, 85, 129, 132, 144, 160, 176  
  Stack 82, 132, 174, 176  
Programmable  
  EEPROM 32, 137  
Programming  
  Halt 16, 18, 81, 143  
Protection  
  Error Limit 69, 156  
  Torque Limit 151

## Q

Quadrature 15, 19, 20, 23, 30, 39, 41, 45, 53, 69, 86, 107,  
  110, 121, 124, 135, 154, 158, 168  
Quit  
  Abort 13  
  Stop Motion 143, 145, 147, 148, 154, 156, 157, 158

## R

Record 129  
  Latch 17, 44, 134  
  Position Capture 17  
  Teach 129  
Register 160  
Reset 3, 47, 136–37, 150  
  Master Reset 3, 137, 138, 150  
  Standard 150

## S

Sample Time  
  Update Rate 150  
Save  
  Burn 32  
SB  
  Set Bit 40, 139  
Scaling  
  Ellipse Scale 70  
S-Curve 21  
Selecting Address 130, 160  
Set Bit 40, 139  
Slew 86, 88, 142  
Smoothing 87, 94  
  KS 94  
Special Label 106, 159  
Specification 96, 98–101, 143, 170  
Stack 82, 132, 174, 176  
Standard Reset 150  
Status 43, 47, 48, 59, 81, 118, 130, 144, 149, 156, 176  
  Interrogation 86, 105  
  Stop Code 140  
Step Motor 94, 111  
  KS, Smoothing 87, 94  
  Smoothing 94  
Stop  
  Abort 13  
Stop Code 1, 17, 42, 50, 69, 73, 77, 80, 85, 106, 107, 110,  
  140, 159  
Stop Motion 143, 145, 147, 148, 154, 156, 157, 158  
Subroutine 65, 82, 90, 132, 159, 176  
Syntax **Error! Not a valid bookmark in entry on page 2**

## T

Tangent 153, 166  
Teach 129  
  Data Capture 129  
  Latch 17, 44, 134  
  Position Capture 17  
  Record 129  
Tell Error

- Position Error 15, 92, 118, 135
- Terminal 47
- Theory 91, 93
- Time
  - Clock 150, 152
  - Update Rate 150
- TIME 150
- Time Interval 43, 54, 129
- Timeout 106, 159
  - MCTIME 106, 159
- Torque Limit 151
- Trigger 21, 69
- Trippoint 15, 18, 19, 20, 59, 68, 81–82, 106, 107, 110, 132, 159, 174

## U

- Update Rate 150
- Upload 161

## V

- Variable
  - Internal 18
- Vector Acceleration 162–64
- Vector Mode 70, 168
  - Circle 39, 45, 70
  - Circular Interpolation 130, 166
  - Clear Sequence 46
  - Ellipse Scale 70
  - Feedrate* 170
  - Tangent 153, 166
- Vector Speed 39, 45, 98–101, 142

## X

- XQ
  - Execute Program 175