

A502 PAN AIR Code

Panel Method Aerodynamic Code for Subsonic and
Supersonic Flow Analysis Around An Arbitrary
Configuration



What Can PAN AIR Do?

- Surface flow properties
- 3D surface pressure forces and moments
- Configuration forces and moments
- Sectional pressure forces and moments along user-specified plane
- Flow-field properties – on and off surface
- Streamlines in the flow field

What PAN AIR Cannot Do?

- Predict flow dominated by viscous effects
- Predict flow dominated by transonic effects
- Predict flow with different total pressures:
 - Configuration inside a jet plume with supersonic flow
 - Configuration inside a propeller slipstream swirl
- Determine wake shapes



Where To Find PAN AIR?

- Public Domain Aeronautical Software

<http://www.pdas.com/panair.html>

- PAN AIR Documentation

<https://docs.google.com/file/d/0B2UKsBO-ZMVgS1k5VEINamx1cUk/edit>

- PAN AIR Executable

<http://www.pdas.com/packages/panairexec.zip>

- PAN AIR Source Code

<http://www.pdas.com/packages/panair.zip>

General Comments

- All input numbers must be decimals
 - PAN AIR will misinterpret input numbers without decimal points
 - Number may be input as X. or .X as necessary
 - The maximum number of digits after decimal point is 4 (example XX.XXX)
- Input segments are 10 spaces long
 - Multiple commands for the same input block may be inputted in a single line:

```
=ISINGS      IGEOMP      ISINGP      ICONTP      IBCONP
0.           0.           0.           0.           0.
12345678901234567890123456789012345678901234567890
```

- Column 71 onwards is usually reserved for string type inputs
- Use of a text editor (example Matlab Editor) that shows text column makes editing of input files easier

General Comments (contd.)

- First Character of the Line:
 - '\$' Marks the beginning of a data block
 - '*' Marks the beginning of a data sub-block
 - '=' Used for defining symbols above a line of input
 - '!' Creates a comment line
- PAN AIR has no units
 - User is responsible for ensuring inputs are in consistent units
 - Similar to ANSYS APDL
- Empty line(s) will generate error when input file is read
 - Create comment lines with '!' if white space is desired
- PAN AIR input file is **NOT** case sensitive


General Comments (Contd.)

- Data blocks may be placed in any order except start, end and sub-blocks
 - These blocks are defined later in the presentation

- Comments in data block titles:

`$POINTS - DEFINES THE WINGTIP PANELS`

- Only the first word of the data block is processed
- Rest of the line may be used for commenting the purpose of the block



First And Last Data Block

- PAN AIR Input Begins with:

\$TITLE

<COMMENT LINE #1>

...

<COMMENT LINE #n>

- Title block begins a new PAN AIR input
- Lines following the \$TITLE are comments used to clearly identify the input file or configuration details. These lines are reproduced in output files.
- Note that no special character precedes the comments

- PAN AIR Ends With:

\$END

Process Control

- PAN AIR has archaic features:
 - Software allows for processing the input file for errors, solution, or restarting solution
 - Modern desktop typically takes 15 to 30 seconds to run; making restart solution feature obsolete

\$SOLUTION

- Solves the boundary-value problem and computes flow properties

\$DATACHECK

=NDTCHK

1 .

- Complete data check and provides detailed examination of input data
- For other options for NDTCHK, see manual

Symmetry

- Symmetry functions are powerful tools
 - Reduces workload of defining panel (**Very Important!**)
 - Symmetry can be defined only along primary axis planes (i.e. on global axis planes)

- PAN AIR Axis system


- X axis: Through the configuration
- Y axis: Out of right wing
- Z axis: Up

\$SYMMETRY - XZ PLANE OF SYMMETRY


=MISYMM MJSYMM

1. 0.

- MISYMM is symmetry about XZ-plane
- MJSYMM is symmetry about YZ-plane
- 0. – No symmetry, 1. – Symmetry, and -1. – Anti-symmetry




PLANE OF SYMMETRY



TWO PLANES OF SYMMETRY

Flow Conditions

- Mach Number
 - Determines the compressibility effects on the flow
 - Note that PAN AIR can solve supersonic flow, however, not transonic flow
 - $0 < \text{Mach No.} < 0.99$ and $1.01 < \text{Mach No.} < 4.0$
 - Flow Mach number cannot be altered during a solution run



\$MACH NUMBER

=AMACH

0.1

!AMACH - MACH NUMBER (DEFAULT VALUE 0)

Flow Conditions (Contd.)

- Flow Cases

- A maximum of 4 solution cases may be run at once

\$CASES - NO. OF SOLUTIONS

=NACASE

4.

! NACASE - NUMBER OF CASES

- Angles of Attack

\$ANGLE OF ATTACK IN DEGREES

=ALPC

0.

!ALPC - DIRECTION OF COMPRESSIBILITY EFFECTS

=ALPHA(1) ALPHA(2) ALPHA(3) ALPHA(4)


-6.

-5.

-4.

-3.

- Similarly beta for corresponding angles of attack may be defined
(see manual for additional details)



Reference Quantities

- Reference quantities include non-dimensionalization quantities and moment reference locations

\$REFERENCE DATA FOR 3-D CONFIGURATION FORCES AND MOMENTS

=xref yref zref

0.5208 0. 0.

=sref bref cref dref

0.5000 1.0000 0.5000 1.0000

!XREF - X COMPONENT OF MOMENT REFERENCE LOCATION

!YREF - Y COMPONENT OF MOMENT REFERENCE LOCATION

!ZREF - Z COMPONENT OF MOMENT REFERENCE LOCATION

!SREF - FULL AIRPLANE REFERENCE AREA **(EVEN WITH SYMMETRY INPUT)**

!BREF - REFERENCE LENGTH OF MX (SPAN)

!CREF - REFERENCE LENGTH OF MY (CHORD)

!DREF - REFERENCE LENGTH OF MZ (SPAN)

Output or Print Options

- Text files are the only form of output from PAN AIR

\$PRINT - OPTIONS

=ISINGS	IGEOMP	ISINGP	ICONTP	IBCONP
---------	--------	--------	--------	--------

0.	0.	0.	0.	0.
----	----	----	----	----

=IEDGEP	IPRAIC	NEXDGN	IOUTPR	IFMCPR
---------	--------	--------	--------	--------

0.	0.	0.	0.	-1.
----	----	----	----	-----

!IFMCPR - FORCE AND MOMENT SUMMERY OUTPUTS

!IFMCPR = -1 : OMITS OUTPUT


!IFMCPR = 0 : FORCE & MOMENTS FOR PER COLUMN & ACCUMULATION

!IFMCPR = 1 : FORCE & MOMENTS FOR PER NETWORK & ACCUMULATION

- IFMCPR provides force and moment data
- Other commands are rarely used
- See manual for details on other commands

Panel Networks

- Panels are defined by specifying network of points in a right-hand sense
 - Right-Hand Network: As shown in figure, column direction crossed with row direction (marked with arrow) should point outside the model. Use right hand for cross product.
 - PAN AIR requires separated row inputs. Note that column 2 data point begins in a new line.
 - Each network requires boundary condition definition with variable 'KT'. Commonly used boundary conditions are:
 1. KT = 1: Represents Solid Surfaces – wings, body etc.
 2. KT = 5: Represents Separated Flow – bases for wings nacelles etc.
- For more details, see manual.



COMPUTER INPUT FOR NETWORK FROM:

nm	nn	
x11	y11	z11
x12	y12	z12
x13	y13	z13
x21	y21	z21
x22	y22	z22
x23	y23	z23
x31	y31	z31
...		

| netname

Panel Networks (Contd.)

\$POINTS

=KN

1.

!NUMBER OF NETWORK INPUT FOR THIS GROUP

=KT

1.

!KT - PARAMETER DEFINING BOUNDARY CONDITIONS ***IMPORTANT***

=NM MM

NETNAME

47. 3.

WING

!NM - NUMBER OF POINTS IN A NETWORK COLUMN (ROWS)

!MM - NUMBER OF POINT COLUMN IN A NETWORK

!NETNAME - NETWORK NAME; PLACED IN COLUMN 71-80

=X(1,1)	Y(1,1)	Z(1,1)	X(*,*)	Y(*,*)	Z(*,*)
---------	--------	--------	--------	--------	--------

0.0000	0.0000	-0.0000	0.0208	0.0271	-0.0099
--------	--------	---------	--------	--------	---------

0.0417	0.0384	-0.0140	0.0625	0.0470	-0.0171
--------	--------	---------	--------	--------	---------

.


.

Panel Networks (Contd.)

```
.  
0.8708      0.1063      -0.0126      0.9208      0.1045      -0.0174  
0.9708      0.1015      -0.0258      1.0208      0.0979      -0.0356  
1.0417      0.0940      -0.0342  
0.0000      0.0000      0.0000      0.0208      0.0289      0.0000  
0.0417      0.0408      0.0000      0.0625      0.0500      0.0000  
.br/>.
```


- Continue defining points until all rows are completed
- \$POINTS can be used repeatedly until all networks are defined
- Note the above space for a missing point only occurs when there are odd number of rows in a network

Panel Networks (Contd.)



Wake Definition

- PAN AIR cannot calculate wake shape, however, PAN AIR can solve the boundary value problem without any wakes defined
- PAN AIR does not have wake relaxation/roll-up features
- PAN AIR has two methods of specifying wakes:
 1. Inbuilt block: \$TRAILING is used when wake surface is in contact with only the trailing edge (in the aerodynamic sense) of the surface that produced the wake
 2. Define a network as for body surfaces with wake boundary condition
- In most cases, a flat wake is sufficient for aerodynamic analysis
- Wake may be terminated at a convenient location behind the configuration for Trefftz plane analysis



Wake Definition (Contd.)

- Wake Definition with \$TRAILING
 - The boundary condition parameter for wake, KT, is 18

\$TRAILING

=KN

1.

!NUMBER OF NETWORK INPUT FOR THIS GROUP

=KT

18.

!KT - PARAMETER DEFINING BOUNDARY CONDITIONS ***IMPORTANT***

=INAT	INSD	XWAKE	TWAKE	NETNAME
FW	1.	1.25	0.	FWWAKE

!INAT - USER-ASSIGNED NETWORK NAME FOR WAKE ATTACHMENT

!INSD - EDGE NUMBER OF NETWORK INAT TO WHICH SIDE OF WAKE IS ATTACHED

!XWAKE - X COORDINATE FOR DOWNSTREAM EDGE OF THE WAKE

!TWAKE = 0 : WAKE PARALLEL TO REFERENCE X AXIS

!TWAKE = 1 : WAKE PARALLEL TO DIRECTION OF COMPRESSIBILITY

- Remember this function can be used when the only one edge of the wake is in contact with another body i.e. for horizontal and vertical stabilizers or winglets

Photo Credit: FGR

Wakes that may be defined with \$TRAILING



Wake Definition (Contd.)

- Defining Wake with \$POINTS

\$POINTS

=KN

1.

=KT

20.


=NM MM

6. 2.

=X(1,1) Y(1,1) Z(1,1) X(*,*) Y(*,*) Z(*,*)


<NETWORK POINTS>

- Wake can only connect with a network (wake or body) edge and not a column/row line





Abutment of Panel Networks

- Abutment is necessary to maintain continuity of doublet strength across network edges
- User is responsible for reviewing and accepting the abutments formed by PAN AIR
- \$EAT or liberalized abutment connects the networks within a specified tolerance. This capability cannot be turned off by the user
- \$PEA or partial or full edge abutment can be used for input geometry mismatched points along abutting network edges. Requires user to identify network edges and points to be abutted.
- \$ABU or forced full-doublet network edge abutment can be used to match finer network edge points to coarser network edge points



Abutment of Panel Networks (Contd.)

- Panel network edge numbers and points
- Panel edge numbers are defined as shown in figure
- Panel edge point number can reverse order as shown in the two figures
- Make a rough drawing to keep track of points and edge numbers




Liberalized Edge Abutment

- Input not required but may be included as:

\$EAT

=EPSGEO	IGEOIN	IGEOUT	NWXREF	TRIINT	IABSUM
	0.	0.	0.	0.	0.



Partial Or Full Edge Abutment

- Used for important abutments such as wing-body etc.

\$PEA - PARTIAL OR FULL EDGE ABUTMENTS

=NFPA IOPFOR IPEAPT

1. 0. 1.

!NFPA - NUMBER OF PARTIAL/FORCED NETWORK EDGE ABUTMENTS

!IOPFOR - FORMS ABUTMENT EDGE FROM STRAIGHT LINES

!IOPFOR = 0 OR BLANK : FIRST SPECIFIED NETWORK EDGE EQUIVALENT POINTS (PREFERRED)

!IOPFOR = 1.0 : AVERAGE LOCATION OF EQUIVALENT POINTS

!IPEAPT - CONTROLS FORCED PARTIAL NETWORK EDGE PRINTOUT

!IOPFOR = 0 OR BLANK : ABUTMENT MATCHING EDGE POINT NUMBERS AND DISTANCE MOVED BY EACH POINT

!IPEAPT = 1.0 : ABOVE+PLUS ORIGINAL COORDINATE POINTS

!IPEAPT = -1.0 : NO PARTIAL NETWORK EDGE PRINTOUT

.
.

Partial Or Full Edge Abutment (Contd.)

.

.

=NNE PEATOL

2. 0.0001

!NNE - NUMBER OF NETWORK EDGES SPECIFIED IN CURRENT ABUTMENT

!PEATOL - TOLERANCE (DISTANCE) USED TO ESTABLISH EQUIVALENT POINTS

=NN EN EPINIT EPLAST

FW 4. 11. 21.

UP 4. 33. 23.

!NN - USER ASSIGNED NETWORK NAME FROM NETWORK INPUTS OR NUMBER

!EN - EDGE NUMBER ***IMPORTANT - CHECK CONVENTION***

!EPINIT - FIRST NETWORK EDGE-POINT NUMBER IN ABUTMENT; FIRST AND LAST # INTERCHANGEABLE

!EPLAST - LAST NETWORK EDGE-POINT NUMBER IN ABUTMENT

How to run PAN AIR?

- Download executable
- Save input in the same folder as the executable
- Double-click the executable file
- Type in the name of the input file with extension
- Press enter

If Errors Persist...

- Ensure spacing of input parameters is correct
- Compare inputs with sample input files that come with the executable
- Check if network points are not too close to each other
- Check abutment edge and point numbers
- Compare your .out file to the one in user manual – line for line
- Ensure Jupiter is not in retrograde and offer sacrifices to the Gods of PAN AIR





No! The Pilot didn't forget to turn off the chem-trails