

# Enterprise SONiC Distribution by Dell Technologies

Quick Start Guide Release 4.4.1

## Notes, cautions, and warnings

 **NOTE:** A NOTE indicates important information that helps you make better use of your product.

 **CAUTION:** A CAUTION indicates either potential damage to hardware or loss of data and tells you how to avoid the problem.

 **WARNING:** A WARNING indicates a potential for property damage, personal injury, or death.

<b>Chapter 1: SONiC overview.....</b>	<b>4</b>
SONiC and Dell Technologies.....	4
Additional Enterprise SONiC documentation.....	5
<b>Chapter 2: Quick start.....</b>	<b>7</b>
Download Enterprise SONiC image.....	7
UEFI Secure Boot.....	7
Install Enterprise SONiC image.....	10
CA-signed certificates for HTTPS REST gRPC Telemetry service.....	12
Install Enterprise SONiC on an OS10 switch.....	13
<b>Chapter 3: Command reference.....</b>	<b>14</b>
Start the CLI.....	14
Initial configurations.....	16
<b>Chapter 4: Support resources.....</b>	<b>26</b>

# SONiC overview

SONiC is an open-source, Linux-based network operating system (NOS) that runs on switches from multiple vendors and ASICs. SONiC stands for Software for Open Networking in the Cloud. It implements standard Layer 2 and Layer 3 protocols, and provides developers with a straightforward way to add new features.

SONiC offers teams the flexibility to create data center networking solutions, while using the collective strength of a large ecosystem with an active developer community. SONiC is designed for scalability and is in production today in large data center fabrics.

The benefits of SONiC include:

- Hardware independence
- Containerized architecture
- Open-sourced
- Access to a growing community

## Topics:

- [SONiC and Dell Technologies](#)
- [Additional Enterprise SONiC documentation](#)

## SONiC and Dell Technologies

Dell Technologies introduces Enterprise SONiC Distribution as a hardened, validated, and supported version of SONiC for switch configuration and monitoring. It includes distribution of open-source community SONiC, and additional features to support the ecosystem and partners.

Enterprise SONiC supports an intuitive command-line interface, and object-based administration through a REST interface and Google's gRPC Network Management Interface (gNMI).

### Enterprise SONiC Distribution by Dell Technologies

Enterprise SONiC is offered in the following bundles. Customers can deploy the most appropriate bundle for their network requirements:

- Cloud Standard
- Cloud Premium
- Enterprise Standard
- Enterprise Premium
- Lite

**NOTE:** The Lite bundle is supported only on S3248T-ON, N3248P-ON, N3248X-ON, N3248PXE-ON, N3248TE-ON, E3248P-ON, and E3248PXE-ON switches. These Dell PowerSwitch platforms cannot run the Cloud and Enterprise bundles. All other Dell PowerSwitch platforms cannot run the Lite bundle.

### Dell PowerSwitch platforms

Enterprise SONiC is supported on the following ONIE-enabled Dell PowerSwitch platforms (which may have a different SONiC network operating system (NOS) or OS10 installed) with the specified port speeds:


- Yes means Supported; No means Not Supported. Default means default speed at access (user) ports.
- Dell PowerSwitches that are marked with \* (asterisk) support Power over Ethernet (PoE).

**Table 1. Speeds supported in Enterprise SONiC on Dell PowerSwitch Platforms**

Dell PowerSwitch	800G	400G	200G	100G	50G	40G	25G	10G	5G	2.5G	1G	100M	10M
Z9864F-ON	Default	Yes	Yes	Yes	No	No	No	Yes	No	No	Yes	No	No
Z9664F-ON	No	Default	Yes	Yes	No	Yes	Yes	Yes	No	No	Yes	No	No

**Table 1. Speeds supported in Enterprise SONiC on Dell PowerSwitch Platforms (continued)**

Dell PowerSwitch	800G	400G	200G	100G	50G	40G	25G	10G	5G	2.5G	1G	100M	10M
Z9432F-ON	No	Default	Yes	Yes	Yes	Yes	Yes	Yes	No	No	Yes	No	No
Z9332F-ON	No	Default	Yes	Yes	No	Yes	Yes	Yes	No	No	Yes	No	No
Z9264F-ON	No	No	No	Default	No	Yes	Yes	Yes	No	No	Yes	No	No
S5448F-ON	No	Yes	Yes	Default	Yes	Yes	Yes	Yes	No	No	Yes	No	No
S5296F-ON	No	No	No	Yes	No	Yes	Default	Yes	No	No	Yes	No	No
S5248F-ON	No	No	No	Yes	No	Yes	Default	Yes	No	No	Yes	No	No
S5232F-ON	No	No	No	Default	Yes	Yes	Yes	Yes	No	No	Yes	No	No
S5224F-ON	No	No	No	Yes	No	Yes	Default	Yes	No	No	Yes	No	No
S5212F-ON	No	No	No	Yes	No	Yes	Default	Yes	No	No	Yes	No	No
S4348F-ON	No	No	No	Yes	No	Yes	Yes	Default	No	No	Yes	No	No
S3248T-ON	No	No	No	Yes	No	Yes	Yes	Yes	No	No	Default	Yes	Yes
N3248PXE-ON*	No	No	No	Yes	No	Yes	Yes	Default	Yes	Yes	Yes	Yes	Yes
N3248X-ON	No	No	No	Yes	No	Yes	Yes	Default	Yes	Yes	Yes	Yes	Yes
N3248TE-ON	No	No	No	Yes	No	Yes	Yes	Yes	No	No	Default	Yes	Yes
N3248P-ON	No	No	No	Yes	No	Yes	Yes	Yes	No	No	Default	Yes	Yes
E3248PXE-ON*	No	No	No	Yes	No	Yes	Yes	Default	Yes	Yes	Yes	Yes	Yes
E3248P-ON*	No	No	No	Yes	No	Yes	Yes	Yes	No	No	Default	Yes	Yes

 **NOTE:** For information on the breakout modes, cables, and optics supported on each switch, contact your designated sales representative.

**Table 2. Dell PowerSwitches supported in each bundle**

Enterprise SONiC bundle	Z-Series: Z9864F-ON, Z9664F-ON, Z9432F-ON, Z9332F-ON, Z9264F-ON	S-Series: S5448F-ON, S5296F-ON, S5248F-ON, S5232F-ON, S5224F-ON, S5212F-ON	S-Series: S3248T-ON	N-Series: N3248P-ON, N3248PXE-ON, N3248TE-ON, N3248X-ON	E-Series: E3248PXE-ON, E3248P-ON
Cloud Standard	<b>Supported</b>	<b>Supported</b>	Not Supported	Not Supported	Not Supported
Cloud Premium	<b>Supported</b>	<b>Supported</b>	Not Supported	Not Supported	Not Supported
Enterprise Standard	<b>Supported</b>	<b>Supported</b>	Not Supported	Not Supported	Not Supported
Enterprise Premium	<b>Supported</b>	<b>Supported</b>	Not Supported	Not Supported	Not Supported
Lite	Not Supported	Not Supported	<b>Supported</b>	<b>Supported</b>	<b>Supported</b>


## Additional Enterprise SONiC documentation

**Table 3. Additional documentation**

Document	Description
<i>Enterprise SONiC Distribution by Dell Technologies, 4.4.0 User Guide</i>	Product description and software configuration tasks

**Table 3. Additional documentation (continued)**

Document	Description
<i>Enterprise SONiC Distribution by Dell Technologies, 4.4.0 Management Framework CLI Reference Guide</i>	Management Framework CLI command syntaxes and examples
<i>Enterprise SONiC Distribution by Dell Technologies, 4.4.0 Compatibility Matrix</i>	Supported software features, scalability, interfaces, breakouts, cables, and optics
<i>Enterprise SONiC Distribution by Dell Technologies, 4.4.0 High Power Optics</i>	Supported high-power optics, thresholds, and switch ports
<i>Enterprise SONiC Distribution by Dell Technologies, 4.4.0 Release Notes</i>	New features introduced in the release; known and fixed issues

 **NOTE:** This guide may contain language from third-party content that is not under Dell Technology control and is not consistent with Dell Technology guidelines. Dell Technology plans to update this reference guide when the third party updates their content.

# Quick start

This chapter describes how to install an Enterprise SONiC image on your Dell PowerSwitch.


## Requirements

- ONIE-enabled Dell PowerSwitch, which may have another SONiC network operating system or OS10 installed on a supported Dell PowerSwitch — see [SONiC and Dell Technologies](#).
- Available DHCP server for automatic installation
- Valid [Dell Digital Locker](#) (DDL) account with sufficient license capacity
- HTTP, TFTP, or FTP server, or USB thumb drive with 4GB space available

## Before you start

Verify that you have connected the ONIE-enabled device correctly:

1. Connect a serial cable or terminal emulator to the console serial port — required serial port settings are 115200, 8 data bits, and no parity.
2. Connect the Management port to the network if you prefer downloading an image over a network.

 **NOTE:** The front panel ports that connect to the switching ASIC are not available in an ONIE installation.

See the *Getting Started Guide* shipped with your specific PowerSwitch to locate the Console and Management ports, or go to [Manuals](#) and search on the Dell PowerSwitch name to find the platform-specific *Installation Guide*.

### Topics:

- [Download Enterprise SONiC image](#)
- [UEFI Secure Boot](#)
- [Install Enterprise SONiC image](#)
- [CA-signed certificates for HTTPS REST gRPC Telemetry service](#)
- [Install Enterprise SONiC on an OS10 switch](#)

## Download Enterprise SONiC image

1. Sign into [DDL](#) using your account credentials.
2. Locate your entitlement ID or order number and select the product name.
3. Select the **Available Downloads** tab on the Product page.
4. Select the Enterprise SONiC image to download and click **Download**.
5. Read the Dell End-User License Agreement. Scroll to the end of the agreement and click **Yes, I agree**.
6. Select how to download the software files and click **Download Now**.
7. Extract the files from the downloaded .zip file.
8. Follow the instructions in the README for Enterprise SONiC to verify the signature of the `bin` file that contains the image.

After you verify the image, install the image on the switch by using a USB thumb drive or over the network. See [Install Enterprise SONiC image](#).

## UEFI Secure Boot

Selected Dell PowerSwitch platforms include a Trusted Platform Module (TPM) that provides hardware-based encryption services to applications, such as UEFI Secure Boot. UEFI Secure Boot is a component of the BIOS that verifies and ensures the

file integrity of the network operating system (NOS) to boot. A Dell PowerSwitch, such as the Z9432F-ON, includes TPM and has UEFI Secure Boot enabled by default in the BIOS to allow only signed NOSs to be installed successfully.

Enterprise SONiC 4.2.0 and later releases support UEFI Secure Boot on the following platforms:

- Z9864F-ON
- Z9664F-ON
- Z9432F-ON
- S5448F-ON

On these platforms, by default, UEFI Secure Boot is enabled. If you have disabled UEFI Secure Boot previously, to use Secure Boot, use the following procedure to enable it:

**NOTE:** If you are already running Enterprise SONiC 4.1.x or a previous version on these platforms, secure boot is already disabled in the BIOS.

To check if your device supports secure boot or enabled, use the following command:

On a platform that does not support Secure Boot:

```
sonic# show platform sbstatus
SecureBoot is not supported on this system
```

On a platform that supports Secure Boot:

```
sonic# show platform sbstatus
SecureBoot is Disabled
```

### Prerequisites to use secure boot

- Enable the Secure Boot in the BIOS firmware.
- If you are already running Enterprise SONiC 4.1.x or a previous version and would like to use the Secure Boot feature in the 4.2.0 or a later release, Install Enterprise SONiC only using the ONIE.
- The file names of the image and the signature file are the same.

### Enable UEFI Secure Boot

**CAUTION:** Before entering BIOS to enable Secure Boot, backup your existing configuration file.

To enable UEFI Secure Boot in the BIOS firmware:

1. Attach a console to the serial port on the switch.
2. Power cycle the switch.
3. After the POWER-ON tests finish, press DEL or F2 when prompted to enter the BIOS menu. If prompted for a password, enter the service tag of the switch followed by an exclamation sign (!); for example: G0K8PK2 !
4. When the BIOS menu is displayed, open the Security tab, select **Enable Secure Boot**, and press Enter and select **Enabled**.
5. Press F4 to save the change, exit the BIOS menu, and reboot the switch.




Figure 1. Enable secure Boot in BIOS menu



## If you do not want to use Secure Boot

If you do not want to use UEFI Secure Boot, or if you use Enterprise SONiC 4.1.x or a previous version, disable UEFI Secure Boot to install or boot Enterprise SONiC on TPM-enabled switches, such as the Z9432F-ON, Z9664F-ON, and S5448F-ON.


### Error messages

If you do not disable UEFI Secure Boot, the following error messages are displayed in the serial console during installation:

```
ONIE:~ # onie-nos-install http://ip-address/tftpboot/SONIC/dell_sonic/  
Enterprise_SONiC_OS_4.4.0_Enterprise_Premium.bin  
discover: Rescue mode detected. No discover stopped.  
Connecting to ip-address  
installer 100% |*****| 937M 0:00:00 ETA  
ONIE: Executing installer: http://ip-address/tftpboot/SONIC/dell_sonic/  
Enterprise_SONiC_OS_4.4.0_Enterprise_Premium.bin  
Failure: sig file is not found  
ONIE:~ #
```

Or later when Enterprise SONiC boots with Secure Boot enabled:

```
Version 2.19.1266. Copyright (C) 2018 American Megatrends, Inc.  
BIOS Date: 12/05/2018 22:05:29 Ver: 0ACHI032  
Press <DEL> or <F2> to enter setup.  
Entering Setup...
```



**Figure 2. Secure Boot error message**

### Disable UEFI Secure Boot

To disable UEFI Secure Boot in the BIOS firmware:

1. Attach a console to the serial port on the switch.
2. Power cycle the switch.
3. After the POWER-ON tests finish, press DEL or F2 when prompted to enter the BIOS menu. If prompted for a password, enter the service tag of the switch followed by an exclamation sign (!); for example: G0K8PK2!
4. When the BIOS menu is displayed, open the Security tab, select `Enable Secure Boot`, and press Enter to disable UEFI Secure Boot.
5. Press F4 to save the change, exit the BIOS menu, and reboot the switch.




Figure 3. BIOS menu

## Install Enterprise SONiC image

This section describes how to install an Enterprise SONiC image on your Dell PowerSwitch.

When you turn on the ONIE-enabled device, the boot menu is visible and accessible using the console:

- **Install OS** — Installs an Enterprise SONiC image offering both zero-touch through DHCP or manual installation.
- **Rescue** — Provides access to troubleshoot or reinstall an ONIE image.
- **Uninstall OS** — Deletes the contents of all disk partitions except ONIE.
- **Update ONIE** — Installs a new ONIE image.
- **Embed ONIE** — Formats an empty disk and installs ONIE.

### For Secure Boot-enabled devices

If you use Secure Boot, place the signature (.sig) file that came with the Enterprise SONiC image (.bin) file in the same location. For example, if you install the image from a USB drive, place the image file `Enterprise_SONiC_OS_4.4.0_Enterprise_Premium.bin` and the signature file `Enterprise_SONiC_OS_4.4.0_Enterprise_Premium.bin.sig` in the same folder on the USB drive. Without the signature file, a Secure Boot-enabled device does not install or boot into Enterprise SONiC.

### Automatic installation

You can automatically (zero-touch) install an Enterprise SONiC image using the ONIE discovery process. Before you start installation, ensure that the image file follows the naming convention that is required for ONIE autodiscovery. The image file name must start with the keyword `onie-installer`.

### Manual installation

If zero-touch not available, there are several other ways to install the Enterprise SONiC image. This section describes how to install the Enterprise SONiC image over a network.

To start the installation process, the IP address of the Management interface is required, along with the IP address of the file server, and the path of the ONIE image. If an IP address for the Management interface is not found when the switch boots, 192.168.3.10 is automatically assigned by default.

1. Store the Enterprise SONiC image on an HTTP, TFTP, or FTP server.
2. Power up the switch and boot ONIE.
3. Select **ONIE: Install OS** for manual installation. If prompted, enter your username and password. The default username/password is `root/service-tag!`.

**NOTE:** If the switch is running any other operating system, such as OS10, use the down arrow to select **ONIE: Uninstall OS** and uninstall the operating system. Then select **ONIE: Install OS**.

```
+-----+
|*ONIE: Install OS      <----- Select this one|
| ONIE: Rescue          |
| ONIE: Uninstall OS    |
| ONIE: Update ONIE     |
| ONIE: Embed ONIE      |
+-----+
```

4. Stop the ONIE discovery process if using manual installation.

```
ONIE:/# onie-discovery-stop
```

5. If a DHCP server is not available, configure the Management port IP address. Once you configure the Management port, the response should be up.

```
ONIE:/# ifconfig eth0 192.168.0.2 netmask 255.255.255.0
```

6. (Optional) Configure the default gateway.

```
ONIE:/# route add default gw <gateway-IP>
ONIE:/# echo "nameserver 8.8.8.8" > /etc/resolv.conf
```

7. Install the Enterprise SONiC image on the switch.

```
ONIE:/# onie-nos-install https://192.168.2.210/
Enterprise_SONiC_OS_4.4.0_Enterprise_Premium.bin
```

When the installation finishes, the PowerSwitch reboots into Enterprise SONiC by default.

## USB installation

You can manually install the Enterprise SONiC image using USB media. Verify that the USB storage device supports FAT, EXT2, EXT3, or EXT4 file system. Plug the USB storage device into the USB port on the device.

1. (Optional) If the device boots to **ONIE: Install OS**, stop the ONIE discovery process.

```
ONIE:/# onie-discovery-stop
```

2. Select **ONIE: Rescue** or **ONIE: Install OS**.
3. Create a USB mount location on the system.

```
ONIE:/# mkdir /mnt/usb
```

4. Mount the USB media plugged into the USB port on the device. You can use either command based on the file system of the USB storage device (FAT or Linux).

```
ONIE:/# mount -t vfat /dev/sdb /mnt/usb
```

Or

```
ONIE:/# mount -t ext2 /dev/sdb /mnt/usb
```

5. Install the software from the USB, where `/mnt/media` specifies the path where the USB partition is mounted.

```
ONIE:/# onie-nos-install /mnt/usb/image_file
```

The ONIE autodiscovery process discovers the image file at the specified USB path, loads the software image, and reboots.

## Default login

The Management interface is configured as DHCP by default to acquire an IP address automatically.

**i** **NOTE:** Enterprise SONiC uses SSHv2 as its connection protocol for secure connectivity over a network. In this document, references to "SSH" mean "SSHv2".

1. Log in to the Linux shell from the console or through an SSH connection using the default username `admin` and password `YourPaSsWoRd`.

```
At Console:
Debian GNU/Linux 11 sonic ttyS1

sonic login: admin
Password: YourPaSsWoRd

SSH from any remote server to sonic can be done by connecting to the IP address of
the Management interface
user@debug:~$ ssh admin@sonic_ip_address(or SONIC DNS Name)
admin@sonic's password:
```

2. When you log in for the first time, you are prompted to change your password (minimum 8 characters).

```
You are required to change your password immediately (administrator enforced)
Changing password for admin.
(current) UNIX password: YourPaSsWoRd
Enter new UNIX password: *****
Retype new UNIX password: *****
Linux sonic 5.10.0-21-amd64 #1 SMP Debian 5.10.162-1 (2023-01-21) x86_64
You are on

/ _ _ | / _ _ \ | _ _ | / _ _ |
S _ _ | O _ _ | N _ _ | I _ _ |
_ _ _ | _ _ _ | _ _ _ | _ _ _ |

-- Software for Open Networking in the Cloud --

Unauthorized access and/or use are prohibited.
All access and/or use are subject to monitoring.

Help:      https://sonic-net.github.io/SONiC/

admin@sonic:~$
```

## Get the system ready

Before you can start configuration, you must verify that the system is ready. Use `show system status` and wait until the system reports ready before continuing.

```
admin@sonic:~$ show system status brief
System is ready

admin@sonic:~$
```

## CA-signed certificates for HTTPS REST gRPC Telemetry service

This chapter describes how to install an Enterprise SONiC image on your Dell PowerSwitch.


By default, Enterprise SONiC does not have preconfigured certificates for the HTTPS REST and gRPC telemetry servers. Because there are no preconfigured certificates for these services, they generate their own self-signed certificates at startup. The self-signed certificates are valid for two years.

Regardless of the validity period, Dell Technologies recommends that you do not use self-signed certificates. Instead, install your own CA-signed certificates. See the *Enterprise SONiC Distribution User Guide: gNMI certificate authentication* and *REST certificate authentication* sections for instructions on how to configure CA-signed certificates and restart the REST and telemetry servers.

After you install your own CA-signed certificates, the REST and telemetry servers continue to use them at a specified directory path after the switch reloads.


## Install Enterprise SONiC on an OS10 switch

On an ONIE-enabled Dell PowerSwitch that is running OS10, you can uninstall OS10 (or any SONiC NOS) and install Enterprise SONiC. A Dell PowerSwitch switch provides an environment where hardware and software are fully modular.

 **NOTE:** When you install an Enterprise SONiC image on an ONIE-enabled OS10 switch, the factory-installed perpetual license for OS10 is uninstalled and the license is removed. **This process is not reversible.**

To install an Enterprise SONiC image on an ONIE-enabled OS10 switch, use an automatic or manual installation as described in [Install Enterprise SONiC image](#):

- For automatic installation, configure ZTP to discover the DHCP server, connect to an image server, and download and install an ONIE-enabled Enterprise SONiC image — see the **Zero Touch Provisioning** chapter in the *Dell EMC Enterprise SONiC Distribution User Guide*. For more information, see [Third-Party NOS Installation Guide for Dell EMC PowerSwitch Data Center Switches](#).
- For manual installation if a DHCP or HTTP server is not available, when the switch boots into the ONIE menu, select the ONIE: `Install OS` option.

 **CAUTION:** Installing Enterprise SONiC or a third-party NOS image erases all OS10 configurations on the switch. The configuration settings are not recoverable. Back up all software configurations and installed licenses on the switch before performing operating system updates or changes. Store a regular backup of the switch configuration off the switch.

# Command reference

This chapter describes how to start the command-line interface (CLI). SONiC includes commands to view platform, transceivers, Layer 2, IP, BGP status, and so on. All SONiC devices support both a serial console-based and SSH-based login. If you use an SSH login, log in to the Management interface (Management0) IP address.

### Topics:

- Start the CLI
- Initial configurations

## Start the CLI

1. Log in to the Linux shell from the console or through an SSH connection using the default username `admin` and password `YourPaSsWoRd`.

```
At Console:
Debian GNU/Linux 11 sonic ttyS1

sonic login: admin
Password: YourPaSsWoRd

SSH from any remote server to sonic can be done by connecting to the IP address of
the Management interface
user@debug:~$ ssh admin@sonic_ip_address(or SONIC DNS Name)
admin@sonic's password:
```

2. When you log in for the first time, you are prompted to change your password (minimum 8 characters). Follow the instructions to change your password and log in to the Linux shell. If this is not your first login, go to Step 3.

```
You are required to change your password immediately (administrator enforced)
Changing password for admin.
(current) UNIX password: YourPaSsWoRd
Enter new UNIX password: *****
Retype new UNIX password: *****
Linux sonic 5.10.0-21-amd64 #1 SMP Debian 5.10.162-1 (2023-01-21) x86_64
You are on
```

/-----/ /-----/ /-----/ /-----/ /-----/  
 \-----\ \-----\ \-----\ \-----\ \-----\  
 )-----) )-----) )-----) )-----) )-----)  
 |-----| |-----| |-----| |-----| |-----|


```
-- Software for Open Networking in the Cloud --
```

Unauthorized access and/or use are prohibited.  
All access and/or use are subject to monitoring.

Help: <https://sonic-net.github.io/SONiC/>

```
admin@sonic:~$
```

3. To access the Management Framework CLI, enter `sonic-cli` from the Linux shell. You are placed at the command-line interface in Exec mode (`sonic#`). From this mode, you can run `show` commands to monitor various functions on the switch or `debug` commands to troubleshoot switch operation. Use `?` to display the available commands.

 **NOTE:** You cannot run the `sonic-cli` command from the root user level.

**NOTE:** By default, command output that cannot shown on one screen displays `-- more --` at the bottom of the output. To view the remainder of the output, press the Space bar or Enter key. To display complete output (scroll down to view it all) each time, use the `show example command | no-more` command.

```
admin@sonic:~$ sonic-cli
sonic# ?
alarm          Alarm related commands
clear          Clear commands
configure      Enter configuration mode
consistency-check Performs consistency check
copy           Perform file operations
crypto         Configure PKI
debug          Enter debugsh mode
delete         Delete the file from local filesystem
dir            Show folder contents
exit           Exit from the CLI
fast-reboot    fast-reboot
image          Image related commands
interface      interfaces Utility
locator-led    Locator Chassis LED Utility
logger         Enter messages into the system log
ls             Show folder contents
no             No commands under Exec mode
ping           Send ICMP ECHO_REQUEST to network hosts
ping6          Send ICMPv6 ECHO_REQUEST to network hosts
poe            Reset PoE Port(s)
reboot         reboot
renew          Renew commands
show           Display running system information
terminal       Set terminal settings
test           Run diagnostics test program
tpcm           SONiC image installation manager
tracertoute    Print the route packets take to the host
tracertoute6   Print the route packets take to the IPv6 host
usb            Mount or un-mount usb partitions
warm-reboot    warm-reboot
write          Save config
```

#### 4. Access Configuration mode to configure switch settings.

```
sonic# config terminal
sonic(config)#
```

In Configuration mode, you can change the current running configuration. Configuration changes are not automatically saved by default. You must use the `write memory` command in Exec mode.

```
sonic(config)# exit
sonic# write memory
```

To return to the Linux shell from Configuration mode:

```
sonic# exit
admin@sonic:~$
```

From Configuration mode, you can enter EXEC-level commands by using the `do` command; for example:

```
sonic(config)# do show running-configuration
```

# Initial configurations

## Change interface naming mode

**NOTE:** Dell Technologies recommends that you use the standard interface-naming mode instead of the default native mode.

### Native interface-naming mode

By default, an Ethernet interface is identified in *native* mode in the command-line interface as `Ethernet number` or `Ethernetnumber` — with or without a blank space; for example:

```
sonic(config)# interface Ethernet 4
sonic(config-if-Ethernet4)#
```

Or

```
sonic(config)# interface Ethernet4
sonic(config-if-Ethernet4)#
```

In native interface-naming mode, Ethernet interfaces display in show outputs as:

```
sonic# show vlan
Q: A - Access (Untagged), T - Tagged
NUM      Status      Q  Ports      Autostate  Dynamic
2         Inactive    A  Ethernet8  Enable     No
                T  Ethernet18 No
                T  Ethernet36 No
...
sonic# show interface status
-----
Name      Description  Oper  Reason      AutoNeg  Speed  MTU  Alternate Name
-----
Ethernet0 -          down  admin-down  off       100000  9100  Eth1/1
Ethernet4 -          down  admin-down  off       100000  9100  Eth1/2
...
```

### Standard interface-naming mode

To easily identify the front-panel port associated with an interface, enable *standard* interface-naming mode. In standard mode, non-breakout interfaces and breakout subinterfaces are identified in the CLI and displays in the format `Ethslot/port[/breakout-port]`; for example:

```
sonic(config)# interface Eth1/2
sonic(config-if-Eth1/2)#
```

```
sonic(config)# interface Eth1/2/4
sonic(config-if-Eth1/2/4)#
```

In standard interface-naming mode, Ethernet interfaces display in show outputs as:

```
sonic# show vlan
Q: A - Access (Untagged), T - Tagged
NUM      Status      Q  Ports      Autostate  Dynamic
2         Inactive    A  Eth1/3     Enable     No
                T  Eth1/5/2
                T  Eth1/10
...
sonic# show interface status
-----
Name      Description  Oper  Reason      AutoNeg  Speed  MTU  Alternate Name
-----
Eth1/1  -          down  admin-down  off       100000  9100  Ethernet0
Eth1/2  -          down  admin-down  off       100000  9100  Ethernet4
...
```



## Enable standard mode

To enable standard interface naming:

```
sonic(config)# interface-naming standard
```

To return to the default native interface naming:

```
sonic(config)# no interface-naming standard
```

After you change the interface-naming mode from native to standard or from standard to native, you are prompted to restart your Enterprise SONiC session:

```
Broadcast message: Interface naming mode has changed. Users running 'sonic-cli' are
required to restart your session.
sonic(config)# end
sonic#
sonic# exit
admin@sonic:~$
admin@sonic:~$ sonic-cli
sonic#
```

For more information, see the *Enterprise SONiC Distribution by Dell Technologies 4.4.0 User Guide*.

## Configure username and password

You can add new users with the `username` command. Enter a password that is 8 characters minimum. You can enter multiple roles for a username. Separate role entries with a comma.

```
sonic# config terminal
sonic(config)# username newuser password password role {admin | operator | secadmin |
netadmin}
```

For example:

```
sonic(config)# username tango password sample248 role operator
sonic(config)# username alpha password adminsenior role secadmin,netadmin
```

## Basic show commands

### System commands

- `show version` — Displays the software version and docker containers in the running Enterprise SONiC image.

```
sonic# show version

Software Version   : 4.4.0-Cloud_Premium_Build106
Product           : Enterprise SONiC Distribution by Dell Technologies
Distribution       : Debian 11.9
Kernel            : 5.10.0-21-amd64
Config DB Version  : version_4_3_1
Build Commit      : 8595cec683
Build Date        : Sun Jul  7 14:06:57 UTC 2024
Built By          : sonicbld@bld-lvn-csg-10
Platform          : x86_64-dell_z9864f-r0
HwSKU             : Dell-Z9864f-O64
ASIC              : broadcom
Serial Number     :
Uptime            : 20:24:24 up 0 min, 1 user, load average: 4.37, 1.08, 0.36

REPOSITORY          TAG                IMAGE ID          SIZE
docker-database     4.4.0-Cloud_Premium_Build106  6daaca363758     400MB
docker-database     latest            6daaca363758     400MB
docker-dhcp-relay-cloud-advanced  4.4.0-Cloud_Premium_Build106  d0f2d9bb80bc     452MB
docker-dhcp-relay-cloud-advanced  latest            d0f2d9bb80bc     452MB
docker-eventd       4.4.0-Cloud_Premium_Build106  5fe29840d970     402MB
docker-eventd       latest            5fe29840d970     402MB
docker-fpm-fr       4.4.0-Cloud_Premium_Build106  31e8678ad6fb     484MB
```

docker-fpm-frr	latest	31e8678ad6fb	484MB
docker-gbsyncd-brcm	4.4.0-Cloud_Premium_Build106	76fbf6736e48	932MB
docker-gbsyncd-brcm	latest	76fbf6736e48	932MB
docker-iccpd	4.4.0-Cloud_Premium_Build106	e9c10f757c3f	451MB
docker-iccpd	latest	e9c10f757c3f	451MB
docker-lldp	4.4.0-Cloud_Premium_Build106	d0445105f4ec	490MB
docker-lldp	latest	d0445105f4ec	490MB
docker-nat	4.4.0-Cloud_Premium_Build106	3e3aebf63cc4	450MB
docker-nat	latest	3e3aebf63cc4	450MB
docker-platform-monitor	4.4.0-Cloud_Premium_Build106	a224dc75f700	576MB
docker-platform-monitor	latest	a224dc75f700	576MB
docker-router-advertiser	4.4.0-Cloud_Premium_Build106	10b1f3000ed3	400MB
docker-router-advertiser	latest	10b1f3000ed3	400MB
docker-sflow	4.4.0-Cloud_Premium_Build106	3e6be54cc324	450MB
docker-sflow	latest	3e6be54cc324	450MB
docker-snmp	4.4.0-Cloud_Premium_Build106	fde213b4beab	429MB
docker-snmp	latest	fde213b4beab	429MB
docker-sonic-mgmt-framework	4.4.0-Cloud_Premium_Build106	2c98e0666f39	656MB
docker-sonic-mgmt-framework	latest	2c98e0666f39	656MB
docker-sonic-telemetry	4.4.0-Cloud_Premium_Build106	f2a373ebbfbe	582MB
docker-sonic-telemetry	latest	f2a373ebbfbe	582MB
docker-swss-brcm-cld-advanced	4.4.0-Cloud_Premium_Build106	653b62b7dff0	445MB
docker-swss-brcm-cld-advanced	latest	653b62b7dff0	445MB
docker-syncd-brcm-cld-advanced	4.4.0-Cloud_Premium_Build106	cb5194da67e5	900MB
docker-syncd-brcm-cld-advanced	latest	cb5194da67e5	900MB
docker-tam	4.4.0-Cloud_Premium_Build106	00ee9a02af1b	442MB
docker-tam	latest	00ee9a02af1b	442MB
docker-teamd	4.4.0-Cloud_Premium_Build106	9dfb60527c59	448MB
docker-teamd	latest	9dfb60527c59	448MB
docker-udld	4.4.0-Cloud_Premium_Build106	20a37f2744c9	454MB
docker-udld	latest	20a37f2744c9	454MB
docker-vrrp	4.4.0-Cloud_Premium_Build106	0758a10afa8b	456MB
docker-vrrp	latest	0758a10afa8b	456MB

- show platform firmware — Displays the firmware installed on a switch.

```
sonic# show platform firmware
```

Chassis	Module	Component	Version	Description
Z9864F-ON	N/A	BIOS	1CAWT005	Performs initialization of hardware...
		BMC	3.03	Platform management controller for...
		FPGA	9.0	Used for managing the system LEDs
		PCIe	2.12	ASIC PCIe firmware
		Secondary CPLD 1	6.0	Used for managing SFP28/QSFP28 port...
		Secondary CPLD 2	6.0	Used for managing SFP28/QSFP28 port...
		System CPLD	15.0	Used for managing the CPU power sequence...

```
sonic# show platform firmware detail
```

```
-----  
Platform Firmware Information  
-----
```

```
Chassis:      Z9864F-ON  
Module:       N/A  
Component:    BIOS  
Firmware Version: 1CAWT005  
Description:   Performs initialization of hardware components during booting
```

```
Chassis:      Z9864F-ON  
Module:       N/A  
Component:    BMC  
Firmware Version: 3.03  
Description:   Platform management controller for on-board temperature monitoring, in-chassis power, Fan and LED control
```

```
Chassis:      Z9864F-ON  
Module:       N/A  
Component:    FPGA  
Firmware Version: 9.0  
Description:   Used for managing the system LEDs
```

```
Chassis:      Z9864F-ON  
Module:       N/A  
Component:    PCIe  
Firmware Version: 2.12
```

```

Description:      ASIC PCIe firmware

Chassis:          Z9864F-ON
Module:           N/A
Component:        Secondary CPLD 1
Firmware Version: 6.0
Description:      Used for managing OSFP112 port transceivers (OSFP112 1-32)

Chassis:          Z9864F-ON
Module:           N/A
Component:        Secondary CPLD 2
Firmware Version: 6.0
Description:      Used for managing OSFP112 port transceivers (OSFP112 33-64)

Chassis:          Z9864F-ON
Module:           N/A
Component:        System CPLD
Firmware Version: 15.0
Description:      Used for managing the CPU power sequence and CPU states

```

- `show system` — Displays hostname, current time, boot time, and other system details.

```

sonic# show system
-----
Attribute          Value/State
-----
Boot Time           :00:02:27
Current Datetime    :2024-07-09T20:26:08Z
Hostname            :sonic

```

- `show system status` — Displays the status of core system services.

```

sonic# show system status
System is ready

Service-Name      Service-Status    App-Ready-Status  Down-Reason
swss               OK                OK                 -
bgp                OK                OK                 -
teamd             OK                OK                 -
pmon              OK                OK                 -
syncd             OK                OK                 -
database          OK                OK                 -
mgmt-framework    OK                OK                 -
gbsyncd           OK                OK                 -
auditd            OK                OK                 -
autobreakoutmgrd  OK                OK                 -
cacldmgrd         OK                OK                 -
ccd               OK                OK                 -
config-chassisdb  OK                OK                 -
config-setup      OK                OK                 -
containerd        OK                OK                 -
critical-monitoring OK                OK                 -
cron              OK                OK                 -
database-chassis  OK                OK                 -
db-post-startup   OK                OK                 -
determine-reboot-cause OK               OK                 -
dhcp_relay        OK                OK                 -
disk-log-rotate-daemon OK               OK                 -
docker            OK                OK                 -
eventd            OK                OK                 -
export            OK                OK                 -
hamd              OK                OK                 -
histogram         OK                OK                 -
hostcfgd          OK                OK                 -
hostname-config   OK                OK                 -
iccpd             OK                OK                 -
in-memory-log-rotate-daemon OK               OK                 -
in-memory         OK                OK                 -
interfaces-config OK                OK                 -
ccdkdump-tools    OK                -                  -
lacp-helper       OK                OK                 -
lldp              OK                OK                 -
nat               OK                OK                 -

```

netfilter-persistent	OK	OK	-
ntp-config	OK	OK	-
ntp	OK	OK	-
openssl-modules	OK	OK	-
platform-init	OK	OK	-
platfprm-modules-z9864f	OK	OK	-
platform-ready	OK	OK	-
portinitdone	OK	OK	-
procdockerstatsd	OK	OK	-
radv	OK	OK	-
ras-mc-ctl	OK	OK	-
resrcmgrd	OK	OK	-
rsyslog-config	OK	OK	-
rsyslog	OK	OK	-
sflow	OK	OK	-
snmp	OK	OK	-
sonic-hostservice	OK	OK	-
sonic-init-updatedb	OK	OK	-
ssh	OK	OK	-
sysmonitor	OK	OK	-
tam	OK	OK	-
telemetry	OK	OK	-
tcpm@default	OK	OK	-
udld	OK	OK	-
updategraph	OK	OK	-
vrrp	OK	OK	-
warmboot-finalizer	OK	OK	-
watchdog-control	OK	OK	-
ztp-config	OK	OK	-
system-health	OK	OK	-

- `show system cpu` — Displays CPU usage details per core and consolidated CPU usage.

```
sonic# show system cpu
Polling Interval: 120.0 seconds
```

CPU	%KERNEL	%USER	%IDLE
CPU-ALL	3	8	87
CPU-0	3	8	87
CPU-1	3	8	87
CPU-2	3	9	86
CPU-3	3	8	87
CPU-4	3	8	87
CPU-5	5	9	85
CPU-6	3	9	87
CPU-7	4	9	86

- `show system memory` — Displays memory usage and availability information.

```
sonic# show system memory
```

Attribute	Value/State
Total	:15819320
Used	:5310036
Free	:4613004
Buff/Cache	:5896280

- `show system processes` — Displays brief information about all the processes running in the host system.

```
sonic# show system processes
```

PID	%CPU	%MEMORY	MEM-USAGE (Bytes)	NAME
1	0	0	58761216	/sbin/init
10	0	0	0	[lru-add-drain]
100	0	0	0	[scsi_eh_0]
1000	0	0	409763840	docker
101	0	0	0	[scsi_tmfs_0]
10179	0	0	12124160	/bin/bash
102	0	0	0	[scsi_eh_1]
10217	0	0	42135552	python

103	0	0	0	[scsi_tmf_1]
107	0	0	0	[bioset]
10862	0	0	256139264	/usr/sbin/rsyslogd
109	0	0	0	[kworker/3:1H]
11	0	0	0	[watchdog/0]
110	0	0	0	[kworker/2:1H]
11044	0	0	111427584	containerd-shim
11088	0	0	109920256	containerd-shim
111	0	0	0	[kworker/0:1H]
11119	0	0	109920256	containerd-shim
11140	0	0	59592704	/usr/bin/python
11177	0	0	111362048	containerd-shim
112	0	0	0	[kworker/1:1H]
11204	0	0	59600896	/usr/bin/python
11223	0	0	61095936	/usr/bin/python
11272	0	0	189263872	/usr/bin/orchagent
11308	0	0	58249216	/usr/bin/python

- `show system processes pid` — Displays detailed information of a specified process.

```
sonic# show system processes pid 1
-----
Attribute                Value/State
-----
Cpu Usage System         :720
Cpu Usage User           :574
Cpu Utilization          :1
Memory Usage             :11726848
Memory Utilization       :0
Name                     :/sbin/init
Pid                      :1
Start Time               :2023-03-17 21:12:28+0000
Uptime                   :00:19:12
```

- `show system processes mem-util` — Displays detailed information about the memory utilities.

```
sonic# show system processes mem-util
-----
PID      %CPU    %MEMORY  MEM-USAGE(Bytes)  NAME
-----
4333     22      2        1833492480       /usr/bin/syncd
6822     0        1        1597079552       /usr/sbin/rest_server
6881     0        1        1057107968       telemetry
9868     0        1        355176448        /usr/lib/frr/ospfd
1        0        0        59277312         /sbin/init
10       0        0        0                [lru-add-drain]
10007    0        0        12148736         /bin/bash
10011    0        0        409763840        docker
10118    0        0        100298752        /usr/sbin/ntpd
10266    0        0        49336320         python2.7
10303    1        0        164511744        /usr/bin/python
10333    0        0        84725760         /usr/sbin/snmpd
10377    3        0        365019136        python3.6
10384    0        0        293613568        python3.6
104      0        0        0                [ata_sff]
105      0        0        0                [ixgbe]
10988    0        0        0                [kworker/1:0]
11       0        0        0                watchdog/0]
1112     0        0        112869376        containerd-shim
1128     0        0        59650048         /usr/bin/python
11614    0        0        0                [kworker/3:2]
--more--
```

- `show platform environment` — Displays available environment information.

```
sonic# show platform environment
Onboard Temperature Sensors :
  CPU Temp           : 30.0 degrees C
  NPU Temp           : 63.0 degrees C
  NPU Rear Temp      : 32.0 degrees C
  INLET Left Temp    : 26.0 degrees C
  INLET Right Temp   : 26.0 degrees C
  OUTLET Left Temp   : 21.0 degrees C
```

```

OUTLET Right Temp      : 22.0 degrees C
OSFP Rear Temp         : 26.0 degrees C
CPUCD Front Temp      : 23.0 degrees C
PSU1 AF Temp          : 31.0 degrees C
PSU1 MID Temp         : 45.0 degrees C
PSU1 Rear Temp        : 43.0 degrees C
PSU2 AF Temp          : 32.0 degrees C
PSU2 MID Temp         : 41.0 degrees C
PSU2 Rear Temp        : 43.0 degrees C
Fan Trays :
FanTray1 :
    Fan1 Speed      : 7504 RPM
    Fan1 State      : Normal
    Fan1 Airflow     : Exhaust
    Fan2 Speed      : 6901 RPM
    Fan2 State      : Normal
    Fan2 Airflow     : Exhaust

FanTray2 :
    Fan1 Speed      : 7504 RPM
    Fan1 State      : Normal
    Fan1 Airflow     : Exhaust
    Fan2 Speed      : 6968 RPM
    Fan2 State      : Normal
    Fan2 Airflow     : Exhaust

FanTray3 :
    Fan1 Speed      : 7504 RPM
    Fan1 State      : Normal
    Fan1 Airflow     : Exhaust
    Fan2 Speed      : 6968 RPM
    Fan2 State      : Normal
    Fan2 Airflow     : Exhaust

FanTray4 :
    Fan1 Speed      : 7571 RPM
    Fan1 State      : Normal
    Fan1 Airflow     : Exhaust
    Fan2 Speed      : 6968 RPM
    Fan2 State      : Normal
    Fan2 Airflow     : Exhaust

PSUs :
PSU1 :
    Input Voltage      : 207.0 Volts
    Input Power        : 432.0 Watts
    Input Current       : 2.1 Amps
    Output Current      : 33.6 Amps
    Output Power        : 408.0 Watts
    Output Voltage      : 12.0 Volts
    AF Temp Temperature : 31.0 degrees C
    MID Temp Temperature : 45.0 degrees C
    Rear Temp Temperature : 43.0 degrees C
    FAN RPM             : 6885 RPM
    Airflow             : Exhaust

PSU2 :
    Input Voltage      : 207.0 Volts
    Input Power        : 432.0 Watts
    Input Current       : 2.1 Amps
    Output Current      : 33.6 Amps
    Output Power        : 408.0 Watts
    Output Voltage      : 12.0 Volts
    AF Temp Temperature : 32.0 degrees C
    MID Temp Temperature : 41.0 degrees C
    Rear Temp Temperature : 43.0 degrees C
    FAN RPM             : 7395 RPM
    Airflow             : Exhaust

```

- `show platform psustatus` — Displays the power supply status.

```
sonic# show platform psustatus
```

PSU	Status
PSU 1	OK
PSU 2	OK

- `show platform psusummary` — Displays power supply information and status.

```
sonic# show platform psusummary
PSU 1:
  Description :02RPHXA00
  Mfg Name :DELL
  Fans :1
  Oper Status :OK
  Serial Number :CNDED0092L0084
  Status LED: :N/A
  Type (AC/DC) :AC
  Input Current: 0.32 Amps
  Input Power: 80 Watts
  Input Voltage: 209 Volts
  Output Current (A) :5.50
  Output Power (W) :70.00
  Output Voltage (V) :12.40
  Fan Speed (RPM) :7680
  Fan Direction :exhaust
PSU 2:
  Description :02RPHXA00
  Mfg Name :DELL
  Fans :1
  Oper Status :OK
  Serial Number :CNDED0092L008N
  Status LED: :N/A
  Type (AC/DC) :AC
  Input Current: 0.32 Amps
  Input Power: 70 Watts
  Input Voltage: 209 Volts
  Output Current (A) :4.50
  Output Power (W) :50.00
  Output Voltage (V) :12.50
  Fan Speed (RPM) :7440
  Fan Direction :exhaust
```

- `show platform syseeprom` — Displays system EEPROM data.

```
sonic# show platform syseeprom
-----
Attribute                               Value/State
-----
Base Mac Address                        :e8:b2:65:b9:cc:5b
Crc 32                                 :0xAA6EFAC6
Platform                               :x86_64-dell_z9864f-r0
Device Version                          :1
Diag Version                            :v2.0.0
Hardware Version                        :X02a
Product Name                           :Z9864F-ON
Location                               :Slot 1
Mac Addresses                           :768
Manufacture Country                     :TW
Mfg Date                               :2024-02-20
Mfg Name                               :DNT00
Onie Version                            :v2.0.0
Part Number                             :0V1Y60
Serial Number                           :TW0V1Y60DNT004250007
Service Tag                             :8XXM9Q3
Vendor Ext                              :0x00 0x00 0x02 0xA2
Vendor Name                             :Dell
```

## Interface commands

- `show interface status` — Displays a brief summary of the interfaces.

```
sonic# show interface status
-----
Name      Description Oper Reason AutoNeg Speed MTU Alternate Name
```

```

-----
Ethernet0      -      up      oper-up      off      10000  9100  Eth1/1
Ethernet1      -      down    admin-down  off      10000  9100  Eth1/2
Ethernet2      -      down    admin-down  off      10000  9100  Eth1/3
Ethernet3      -      up      oper-up      off      10000  9100  Eth1/4
Ethernet4      -      down    admin-down  off      10000  9100  Eth1/5
Ethernet5      -      down    admin-down  off      10000  9100  Eth1/6
...

```

- `show interface Ethernet id` — Displays details about a specific interface.

```

show interface Ethernet 120

Ethernet120 is up, line protocol is up, reason oper-up
Hardware is Eth, address is 20:04:0f:37:1b:4c
Mode of IPV4 address assignment: not-set
IPV6 address is fe80::2204:fff:fe37:1b4c/64
Mode of IPV6 address assignment: MANUAL
IP MTU 9100 bytes
LineSpeed 100GB, Auto-negotiation off
Link-training: off
Unreliable-LOS: off
FEC: DISABLED
Events:
  initialized at 2023-03-17T07:26:27.376716Z
  admin-up at 2023-03-17T07:26:32.059165Z
  xcvr-status-down at 2023-03-17T07:27:25.633885Z
  xcvr-status-up at 2023-03-17T07:27:26.735729Z
  port-enabled at 2023-03-17T07:27:26.776707Z
  phy-link-up at 2023-03-17T07:29:00.699229Z
Last clearing of "show interface" counters: never
10 seconds input rate 151130 packets/sec, 1204171624 bits/sec, 150521453 Bytes/sec
10 seconds output rate 4 packets/sec, 2912 bits/sec, 364 Bytes/sec
Input statistics:
  38546944236 packets, 38391775150833 octets
  34857 Multicasts, 0 Broadcasts, 38546909384 Unicasts
  0 error, 0 discarded, 0 Oversize
  19 Packets (128 to 255 Octects)
Output statistics:
  23150229 packets, 22184672240 octets
  34849 Multicasts, 0 Broadcasts, 23115380 Unicasts
  0 error, 0 discarded, 0 Oversize
Time since last interface status change: 2d22h56m

```

- `show interface Ethernet` — Displays details about all physical interfaces.

```

sonic# show interface Ethernet

Ethernet0 is up, line protocol is up, reason oper-up
Hardware is Eth, address is 20:04:0f:37:1b:4c
Mode of IPV4 address assignment: not-set
IPV6 address is fe80::2204:fff:fe37:1b4c/64
Mode of IPV6 address assignment: MANUAL
IP MTU 9100 bytes
LineSpeed 100GB, Auto-negotiation off
Link-training: off
Unreliable-LOS: off
FEC: DISABLED
Events:
  initialized at 2023-03-17T07:26:27.376716Z
  admin-up at 2023-03-17T07:26:32.059165Z
  xcvr-status-down at 2023-03-17T07:27:25.633885Z
  xcvr-status-up at 2023-03-17T07:27:26.735729Z
  port-enabled at 2023-03-17T07:27:26.776707Z
  phy-link-up at 2023-03-17T07:29:00.699229Z
Last clearing of "show interface" counters: never
10 seconds input rate 151130 packets/sec, 1204178928 bits/sec, 150522366 Bytes/sec
10 seconds output rate 4 packets/sec, 2944 bits/sec, 368 Bytes/sec
Input statistics:
  38556004382 packets, 38400798810498 octets
  34866 Multicasts, 0 Broadcasts, 38555969521 Unicasts
  0 error, 0 discarded, 0 Oversize
  19 Packets (128 to 255 Octects)

```



```

Output statistics:
    23150479 packets, 22184695325 octets
    34857 Multicasts, 0 Broadcasts, 23115622 Unicasts
    0 error, 0 discarded, 0 Oversize
Time since last interface status change: 2d22h57m

Ethernet4 is up, line protocol is up, reason oper-up
Hardware is Eth, address is 20:04:0f:37:1b:4c
Mode of IPV4 address assignment: not-set
IPV6 address is fe80::2204:fff:fe37:1b4c/64
Mode of IPV6 address assignment: MANUAL
IP MTU 9100 bytes
LineSpeed 100GB, Auto-negotiation off
Link-training: off
Unreliable-LOS: off
FEC: DISABLED
...

```

- `show interface counters` — Displays port statistics of all physical interfaces.

```

sonic# show interface counters
-----
Interface  State RX_OK   RX_ERR RX_DRP RX_OVERSIZE TX_OK   TX_ERR TX_DRP TX_OVERSIZE
-----
Ethernet28 U      201809144 0      0      0          201809148 0      0      0
Ethernet32 U      201803931 0      0      0          201803929 0      0      0
Ethernet36 D      0          0      0      0          0          0      0      0

```

### Secure Boot command

- `show platform sbstatus` — Displays whether Secure Boot is supported on an Enterprise SONiC switch. (The Z9864F-ON, Z9664F-ON, Z9432F-ON, and S5448-ON switches support Secure Boot.)
  - If a switch supports secure boot:

```

sonic# show platform sbstatus
SecureBoot is Enabled

```

- If a switch does not support secure boot:

```

sonic# show platform sbstatus
SecureBoot is not supported on this system

```

## Support resources

The Dell Support site provides a range of documents and tools to assist you with effectively using Dell devices. Through the support site you can obtain technical information regarding Dell products, access software upgrades and patches, download available management software, and manage your open cases. The Dell support site provides integrated, secure access to these services.

To access the Dell Technologies Support site, go to [Welcome to Dell Support](#). To display information in your language, scroll down to the bottom of the page and select your country or region from the drop-down menu.

- To obtain product-specific information, enter the 7-character service tag or 11-digit express service code of your switch and click **Submit**.
- To view the service tag or express service code, pull out the luggage tag on the chassis or enter the `show chassis` command from the CLI.
- To receive additional kinds of technical support, click **Contact Us**, then click **Technical Support**.

To access Enterprise SONiC documentation, search on **Enterprise SONiC Distribution**, then click on the **Documentation** tab and scroll down to **Manuals and Documents**.

To search for drivers and downloads, go to [Enterprise SONiC Distribution](#), sign in, and click the **Drivers & Downloads** tab.

To participate in Dell community blogs and forums, go to [Dell Community](#).