

fw_ver()

 dexterindustries.com/GoPiGo/learning-2/python-programming-for-the-raspberry-pi-gopigo/fw_ver/

Read the firmware version of the GoPiGo

Read the firmware version of the GoPiGo.

It can be from 0.9 onwards.

1.0 is the latest firmware

Syntax

```
fw_ver()
```

Parameter:

None

Return:

Firmware version on success

-1 on failure

Example

```
from gopigo import *  
print fw_ver()
```