

set_left_speed()

 dexterindustries.com/GoPiGo/programming__trashed/python-programming-for-the-raspberry-pi-gopigo__trashed/set_left_speed/

Set the speed of the left motor on GoPiGo

The speed of the GoPiGo can be between 0-255. The default speed is 200.

You can use `set_left_speed()` to set the speed of the of the left motor between 0 and 255. Any speed above 255 will be made as 255 and any speed below 0 will be made 0.

Syntax

```
set_left_speed(speed)
```

Parameter:

speed: valid speed value between 0-255

Return:

None

Example

```
from gopigo import *  
set_left_speed(150)
```