

enable_servo()

 dexterindustries.com/GoPiGo/programming__trashed/python-programming-for-the-raspberry-pi-gopigo__trashed/enable_servo/

[Sign Out](#)

[Programming](#) » [Python Programming](#) » `enable_servo()`

Enables the servo

Enables the Servo to be used by the GoPiGo

Syntax

```
enable_servo()
```

Parameter:

None

Return:

None

Example

```
from gopigo import *  
import time  
enable_servo()  
for i in range(180):  
    servo(i)  
    time.sleep(100)
```

Specifications

- Difficulty
- Ages 10+
- Tech Raspberry Pi & Windows 10
- Languages Python, Scratch, Java, NodeJS, C/C++



GoPiGo

- Price \$99-\$199

[Buy Now](#)

© 2017 Dexter Industries · Built by [Nav](#).

—

Real-time

—

9

Visitors right now

Need Technical Help?
Visit our forums