
Table of Contents

| | |
|---|-----|
| Description..... | 333 |
| Fuel System Components..... | 333 |
| Removal and Disassembly..... | 338 |
| Intake Air Duct..... | 338 |
| Secondary Fuel Filter..... | 338 |
| Fuel System Tubing..... | 340 |
| Horizontal Fuel Conditioning Module (HFCM)..... | 340 |
| Disassembly of the HFCM..... | 340 |
| Fuel Injectors..... | 341 |
| Cleaning and Inspection..... | 341 |
| Assembly and Installation..... | 342 |
| Assembly of the HFCM..... | 342 |
| HFCM..... | 343 |
| Secondary Fuel Filter..... | 343 |
| Fuel System Tubing..... | 345 |
| Intake Air Duct..... | 346 |
| Fuel Injectors..... | 346 |
| Specifications..... | 347 |
| Special Torque..... | 347 |
| Special Service Tools..... | 347 |

Description

Fuel System Components

Parts Information

The fuel system consists of the following components:

- Fuel tank(s) and fuel level sending device
- Chassis mounted fuel conditioning module consisting of an electric pump, fuel heater, water separator, and primary filter
- Fuel tubing
- Secondary fuel filter and pressure regulator module
- Six fuel injector assemblies



WARNING: To avoid serious personal injury, possible death, or damage to the engine or vehicle, comply with the following when draining fuel:

- Do not smoke
- Keep away from open flames and sparks.



WARNING: Disconnect both battery ground cables. See "Safety Information (page 3)."




Figure 556 Horizontal Fuel Conditioning Module (HFCM)

- | | | |
|--------------------------------|--|-------------------------------------|
| 1. Primary filter element cap | 6. Self-tapping screw, #10 (3) | 10. O-ring seal |
| 2. Cap O-ring seal | 7. Thermo recirculating valve assembly | 11. Water drain knob |
| 3. Primary fuel filter element | 8. Cover plate gasket | 12. Screw, M5 x 23 (4) |
| 4. Primary fuel filter housing | 9. Cover plate | 13. Mounting grommet (3) |
| 5. Electric fuel pump | | 14. Bolt with shoulder, M8 x 40 (3) |




Figure 557 HFCM (chassis mounted)

- | | | |
|---------------------------------|--|--------------------------------------|
| 1. Fuel supply port to engine | 5. Electric pump connection | 8. Mounting grommet (3) |
| 2. Fuel return port from engine | 6. Water in fuel electrical connection | 9. Fuel heater electrical connection |
| 3. Fuel return port to tank | 7. Water drain knob | 10. Primary filter element cap |
| 4. Fuel supply port to HFCM | | |




Figure 558 Fuel system schematic

Removal and Disassembly

Intake Air Duct

! WARNING: To avoid serious personal injury, possible death, or damage to the engine or vehicle, do not turn "KEY ON" during any phase of disassembly. This engine is equipped with an electric fuel pump. Turning on the ignition key could pump fuel to disconnected tubing, resulting in fire if an ignition source is available.




Figure 559 Intake air duct mounting bolt

1. Remove bolt (M6 x 16) securing intake air duct to intake manifold.
2. Remove intake air duct clamp at turbocharger.
3. Remove air inlet breather hose and intake air duct as an assembly.
4. Install Turbocharger Inlet Guard or protective cap onto turbocharger inlet. See Special Service Tools (page 347).

Secondary Fuel Filter




Figure 560 Secondary fuel filtration tubing

1. Fuel return (to tank)
2. Fuel supply (from tank)
3. Diagnostic port plug, M12
4. Fuel supply tube to left cylinder head
5. Fuel supply tube to right cylinder head

1. Drain the fuel filter housing by placing a suitable container beneath the fuel diagnostic port plug. Remove plug, then crack open fuel filter cap to allow air into filter housing. Place plug back into port when filter housing is empty.
2. Remove all tube connections attached to fuel filter assembly as follows:




Figure 561 Fuel supply tube and fitting gaskets

- a. Remove fuel filter banjo bolt and discard copper washers.



Figure 562 Fuel return tube fitting

- b. Using backup wrenches, disconnect fuel return tube fitting and discard O-rings.
- c. Using backup wrenches, disconnect left and right cylinder head fuel tubing and discard O-rings.
3. Using the Cap Kit (all), cap all open ports on the secondary fuel filter housing. See Special Service Tools (page 347).
4. Remove secondary fuel filter assembly mounting screws (M6 x 25) for further disassembly and inspection.
5. Remove secondary fuel filter assembly.




Figure 563 Pressure regulator poppet assembly

1. Oil filter assembly
2. Fuel filter assembly
3. Screw, M6 x 25 (3)
4. Pressure regulator cover gasket
5. Viton O-ring, size #115
6. Poppet gasket seal
7. Brass poppet
8. Pressure regulator valve spring

6. Removing the filter assembly exposes the pressure regulator poppet components. Remove these parts for later inspection.




Figure 564 Fuel filter assembly

1. Fuel filter cap
 2. O-ring seal
 3. Fuel filter element
 4. Fuel return tube assembly
 5. Screw, 8/32 x 3/8 in (2)
 6. Viton O-ring, size #112
 7. Fuel filter housing
 8. Fuel return fitting, M16
 9. Left and right cylinder head fuel tube assembly fitting, M12 (2)
 10. Diagnostic pressure test port plug, M12
7. Loosen fuel filter cap and discard O-ring seal.
 8. Before removing filter, depress filter to verify spring loaded fuel return tube is free.

9. Lift out secondary fuel filter element and discard.

Fuel System Tubing

1. Remove one bolt (M6 x 16) securing fuel return and supply tubing to oil pan.
2. Remove one bolt (M10 x 16) securing fuel return and supply tubing to left cylinder head.
3. Remove nut (M6) securing right fuel supply tube to intake air elbow.
4. Remove banjo bolt securing each fuel supply tube to its respective cylinder head. Discard copper washers.

Horizontal Fuel Conditioning Module (HFCM)

The HFCM is mounted in different locations for the CF and stripped chassis applications.

The CF application has the HFCM mounted on the vehicle frame rail on the driver's side.

The stripped chassis application has the HFCM mounted on a bracket attached to the transmission housing on the passenger side.

For both applications, see "Horizontal Fuel Conditioning Module (HFCM)" (Figure 556) when doing the following steps:

1. Place a container under HFCM to drain fuel and any accumulated water. Rotate drain knob to release fuel pressure and drain module.
2. Disconnect fuel pump, fuel heater, and water-in-fuel electrical connectors.
3. Press in retaining clips to release fuel hoses from housing.
4. Disconnect fuel hoses and discard fuel hose retaining clips
5. Remove three mounting nuts (M8) and fuel conditioning module from chassis.

Disassembly of the HFCM

1. Remove primary filter cap and discard O-ring seal.
2. Remove primary filter element and discard.
3. Remove four cover plate screws (M5 x 23) and discard cover plate gasket.

4. Remove heater assembly.
5. Remove drain plug assembly.
6. Remove the thermo recirculating valve assembly.
7. Remove three fuel pump screws (#10 self-tapping) and discard O-rings.

Fuel Injectors


NOTE: See the Cylinder Head and Valve Train section for fuel injector removal procedure.

Cleaning and Inspection

1. Inspect fuel lines for misalignment, chaffing or other signs of damage. Replace fuel lines if necessary.

2. Check poppet valve and spring for signs of misalignment. Inspect poppet gasket seal (Figure 563) for signs of uneven seating with the fuel filter housing.
3. Check fuel return tube for broken or cracking pieces.
4. Clean out any accumulated sediment in the bottom of the secondary fuel filter housing and HFCM housing.
5. Wash all fuel filter components in a suitable solvent and dry with filtered compressed air. See "Safety Information (page 3)."
6. Check HFCM fuel heater for open or unusually high resistance if a diagnostic trouble code (DTC) was encountered. Refer to *Engine Diagnostics*.

Assembly and Installation



J11062

Figure 565 Horizontal Fuel Conditioning Module (HFCM)

- | | | |
|--------------------------------|--|-------------------------------------|
| 1. Primary filter element cap | 6. Self-tapping screw, #10 (3) | 10. O-ring seal |
| 2. Cap O-ring seal | 7. Thermo recirculating valve assembly | 11. Water drain knob |
| 3. Primary fuel filter element | 8. Cover plate gasket | 12. Screw, M5 x 23 (4) |
| 4. Primary fuel filter housing | 9. Cover plate | 13. Mounting grommet (3) |
| 5. Electric fuel pump | | 14. Bolt with shoulder, M8 x 40 (3) |

Assembly of the HFCM

1. Install the thermo recirculating valve assembly into housing.
2. Install heater assembly.
3. Install drain plug assembly.
4. Place cover plate gasket onto cover plate.
5. Position cover plate onto housing and thread in four screws (M5 x 23). Tighten screws to the Special Torque (page 347).
6. Install new O-rings onto the fuel pump and lubricate with clean fuel.

7. Install fuel pump assembly with three screws (#10 self-tapping). Tighten screws to the Special Torque (page 347).
8. Install primary filter element.
9. Coat a new O-ring gasket seal with fuel and install onto primary filter cap. Thread cap into HFCM housing and tighten to the Special Torque (page 347).

HFCM

1. CF – Install HFCM to chassis rail. Thread three mounting nuts (M8) onto mounting bolts (M8 x 40) and tighten to the Special Torque (page 347).

Stripped chassis – Install HFCM to transmission housing mounting bracket. Thread three mounting nuts (M8) onto mounting bolts (M8 x 40) and tighten to the Special Torque (page 347).

2. Install new retaining clips onto fuel hoses.
3. Install fuel hoses onto HFCM cover plate.
4. Connect the water-in-fuel, fuel heater, and fuel pump electrical connectors.
5. Close water drain knob assembly.

Secondary Fuel Filter




Figure 566 Fuel filter assembly

1. Fuel filter cap
2. O-ring seal
3. Fuel filter element
4. Fuel return tube assembly
5. Screw, 8/32 x 3/8 in (2)
6. Viton O-ring, size #112
7. Fuel filter housing
8. Fuel return fitting assembly, M16
9. Left and right cylinder head fuel tube assembly fitting, M12 (2)
10. Diagnostic pressure test port plug, M12

1. Assemble fuel filter as shown in the preceding illustration:

- a. Place a new O-ring gasket into the base of the fuel filter housing.
- b. Place return tube assembly over O-ring and secure with two screws (8/32 x 3/8 in). Tighten screws to the Special Torque (page 347).
- c. Position fuel filter element over return tube. Rotate element slightly until filter engages teeth and can be moved up and down against spring pressure.
- d. Apply a coating of diesel fuel to a new O-ring and install onto fuel filter cap. Thread fuel filter cap onto filter housing and tighten to the Special Torque (page 347).
- e. If fuel inlet and outlet fittings have been removed from housing, you must install new O-rings onto fittings. These O-rings are serviceable, however are not included in the preceding illustration. Refer to Fuel System Components (engine) (Figure 555) for additional details.
- f. If removed, install fuel inlet and outlet fittings onto filter housing.

CAUTION: To prevent engine damage, tighten fuel cap on fuel filter assembly. The engine will not run without the fuel filter element in place. The fuel filter element is required to open the valve in the fuel return tube assembly, allowing fuel to flow into the filter. This feature protects injectors from contamination if element is not installed.




Figure 567 Pressure regulator poppet assembly

1. Oil filter assembly
2. Fuel filter assembly
3. Screw, M6 x 25 (3)
4. Pressure regulator cover gasket
5. Viton O-ring, size #115
6. Poppet gasket seal
7. Brass poppet
8. Pressure regulator valve spring

2. Install fuel filter pressure regulator components as follows:
 - a. Place a new pressure regulator cover gasket and new O-ring into their respective recesses within the fuel filter housing.
 - b. Make sure brass poppet has a new gasket seal on it before placing assembly into fuel filter housing. Brass poppet goes in first, spring is oriented toward oil filter side.
 - c. Place three screws (M6 x 25) through the fuel filter housing and attach them to the oil filter assembly. Thread screws in evenly, watching the alignment of gasket, O-ring and poppet spring.

3. Install the secondary fuel filter assembly onto oil filter assembly.

Fuel System Tubing

1. Uncap all ports on fuel filter housing.
2. Install all tubing connections (hand tight) to fuel filter assembly, cylinder heads, and anchoring points as follows:

NOTE: Tighten all fittings and anchoring clamps to the respective torque value only after all tubing connections have been hand threaded.




Figure 568 Fuel supply banjo bolt

- a. Install a new copper washer onto banjo bolt. Slide screw and gasket through fuel supply tubing. Place another new copper washer onto banjo bolt and thread tubing into filter housing. Tighten screw to the Special Torque (page 347).
- b. Using backup wrench, connect and tighten fuel return tube fitting to the Special Torque (page 347).




Figure 569 Secondary fuel filtration tubing

1. Fuel return (to tank)
2. Fuel supply (from tank)
3. Diagnostic port plug, M12
4. Fuel supply tube to left cylinder head
5. Fuel supply tube to right cylinder head

- c. Connect left and right cylinder head fuel tubes to fuel filter assembly.
- d. Place a new O-ring seal on diagnostic port plug (M12) and tighten to the Special Torque (page 347).



Figure 570 Fuel return tube

3. Install new copper washers onto left and right banjo bolt fittings.
4. Connect banjo bolt fittings to the left and right cylinder heads. Tighten fittings to the Special Torque (page 347).

5. Anchor right fuel tubing to air inlet elbow stud. Tighten nut (M6) to the Special Torque (page 347).
6. Install one bolt (M10 x 16) to secure fuel return and supply tubing to the left cylinder head. Tighten bolt to the Standard Torque (page 405).
7. Install one bolt (M6 x 16) to secure fuel return and supply tubing to oil pan. Tighten bolt to the Standard Torque (page 405).

Intake Air Duct

1. Remove intake guard or protective cap from turbocharger air inlet.
2. Install air inlet breather hose elbow and intake air duct as an assembly.



Figure 571 Air inlet duct mounting bolt

3. Install bolt (M6 x 16) to secure air inlet duct to intake manifold. Position clamp at turbocharger air inlet. Tighten bolt and clamp to the Special Torque (page 347).

Fuel Injectors

NOTE: See the Cylinder Head and Valve Train section for fuel injector installation instructions.

Specifications

| Fuel System Components | |
|---|---------------------------|
| Horizontal Fuel Conditioning Module (HFCM) | |
| Electric heater | 150 W |
| Filter efficiency | 10 micron |
| Rated flow capacity | 98 L/hr (26 gph @ 60 psi) |
| Secondary Fuel Filter | |
| Filter efficiency | 4 micron |
| Maximum fuel pressure in secondary filter | 400 kPa (58 psi @ 35 gph) |
| Valve unseating pressure | 310 ± 28 kPa (45 ± 4 psi) |

Special Torque

| Fuel System Components | |
|---|------------------------|
| Banjo bolt, 12 mm | 38 N·m (28 lbf·ft) |
| Diagnostic port plug, M12 | 4-9 N·m (35-75 lbf·in) |
| Fuel filter cap (secondary) | 14 N·m (124 lbf·in) |
| Fuel filter housing mounting screws, M6 x 25 | 10 N·m (88 lbf·in) |
| Fuel supply hollow screw, M14 | 35 N·m (26 lbf·ft) |
| Fuel pump mounting screws | 5 N·m (44 lbf·in) |
| Fuel return tube at filter | 25 N·m (19 lbf·ft) |
| Fuel return tube mounting screws, 8/32 x 3/8 | 2-3 N·m (20-25 lbf·in) |
| HFCM cover plate screws | 5 N·m (44 lbf·in) |
| HFCM housing nuts (M8) | 15 N·m (132 lbf·in) |
| Left and right cylinder head supply tubing at filter | 25 N·m (18 lbf·ft) |
| Oil supply tube bolt, M6 x 20 | 13 N·m (120 lbf·in) |
| Plug assembly, M12 (rear of cylinder head) | 36 N·m (27 lbf·ft) |
| Primary filter cap | 25 N·m (18 lbf·ft) |
| Right cylinder head supply tubing anchor at inlet elbow | 11 N·m (96 lbf·in) |

Special Service Tools

| Fuel System Tools | |
|--------------------------|-------------|
| Description | Tool Number |
| Cap Kit (all) | ZTSE4610 |
| Turbocharger Inlet Guard | ZTSE4293 |

Table of Contents

| | |
|--|-----|
| Related Components..... | 351 |
| Removal..... | 353 |
| Ring Gear Runout Check..... | 353 |
| Flywheel..... | 353 |
| Rear Main Seal and Wear Sleeve..... | 355 |
| CF Applications..... | 355 |
| Stripped Chassis Applications..... | 357 |
| Crankshaft Secondary Flange (Stripped Chassis Only)..... | 358 |
| Rear Cover..... | 360 |
| Cleaning and Inspection..... | 362 |
| All Components..... | 362 |
| Installation..... | 363 |
| Rear Cover | 363 |
| Crankshaft Secondary Flange (Stripped Chassis Only)..... | 365 |
| Rear Main Oil Seal and Wear Sleeve..... | 366 |
| CF Applications..... | 366 |
| Stripped Chassis Applications..... | 368 |
| Flywheel..... | 370 |
| Specifications..... | 372 |
| Special Torque..... | 372 |
| Special Service Tools..... | 372 |

Related Components

NOTE: There are two different rear cover assemblies in use depending upon vehicle application.





Figure 572 Rear cover and related components (stripped chassis)

- | | | |
|---|-----------------------------------|---|
| 1. Bolt, M8 x 55 (5), Refer to (Figure 593) | 8. Rear seal carrier gasket | 16. Flywheel assembly |
| 2. Gasket | 9. Rear oil seal carrier assembly | 17. Adapter hub |
| 3. O-ring seal | 10. Bolt, M8 x 25 (6) | 18. Dowel pin, 0.250 x 0.625 mm |
| 4. Cover | 11. Bolt, M8 x 70 (2) | 19. Crankshaft rear oil seal assembly (service) |
| 5. Bolt, M8 x 55 (2) | 12. Bolt, M10 x 77 (10) | 20. Dowel pin, 1/4 x 5/8 in. |
| 6. Rear cover (SAE 2) | 13. Reinforcement ring | 21. Dowel pin, M8 x 25 |
| 7. Crankshaft flange | 14. Bolt, M10 x 35 (12) | |
| | 15. Converter housing adapter | |



**Figure 573 Rear cover and related components
(CF chassis)**

1. Bolt, M8 x 35 (8)
2. Rear cover
3. Gasket
4. Crankshaft rear oil seal (service)
5. Flywheel adapter
6. Flywheel
7. Bolt, M10 x 31 (10)
8. Dowel sleeve (2)

Removal

Ring Gear Runout Check

CAUTION: To prevent engine damage, check flywheel surface runout. These checks are performed to ensure proper engine to transmission alignment. Failure to ensure proper bore concentricity and face runout may result in reduced clutch and/or transmission life.

1. Check for ring gear damage associated with the starter pinion. If damage is found, skip ring gear surface run out check. Flywheel should be replaced.




Figure 574 Checking ring gear for a run out condition (typical)

2. Measure flywheel ring gear for surface run out.

NOTE: Keep the crankshaft end play at zero in the same direction for all measurements.

- A. Attach a Dial Indicator with Magnetic Base onto engine. Place dial indicator tip against surface of ring gear. See Special Service Tools (page 372).
 - B. Zero the dial indicator.
 - C. Rotate crankshaft slowly (clockwise) and record total indicator runout. See Specifications (page 372).
3. Replace ring gear if total indicator runout has been determined to be out of specifications.

Flywheel

! WARNING: To avoid serious personal injury or possible death, do not reuse the flywheel bolts.



Figure 575 Removing the transmission adapter ring bolts (stripped chassis)

NOTE: Stripped chassis applications only – In order to remove the flywheel assembly, remove all 12 bolts (M10 x 35) securing the transmission adapter ring to the rear cover.



Figure 576 Removing the flywheel bolts (typical)

1. Remove 10 flywheel mounting bolts (M10 x 31 - CF) (M10 x 77 - stripped chassis) and discard bolts.

NOTE: The 10 flywheel mounting bolts are not reusable.




Figure 577 Removing the flywheel (typical)

2. Remove flywheel assembly.

CAUTION: (CF applications only) – To prevent engine damage, place the heel bar onto the head of a rear cover bolt to remove the rear flywheel adapter. This will prevent cracking of the aluminum housing.




Figure 578 Removing the rear flywheel adapter (CF)

1. Rear cover bolt head locations (2)
2. Placement of the heel bar

CAUTION: To prevent engine damage, carefully remove and store flywheel adapter or adapter hub. Damage to the adapter sealing surface can result in a rear oil seal leak.

3. Use the head of the rear cover bolt for supporting the heel bar to remove the flywheel adapter.
4. Place the heel bar on the head of the rear cover bolt and the hook under the lip of the flywheel adapter.
5. Alternate between the two rear cover head bolts to pry off the flywheel adapter.




Figure 579 Flywheel adapter removed (CF)

1. Dowel pin
2. Pin recess
3. Dust seal lip surface

6. Remove flywheel adapter or adapter hub.

**Rear Main Seal and Wear Sleeve
CF Applications**

! WARNING: To avoid serious personal injury or possible death, wear safety glasses with side shields when performing the following procedure. See "Safety Information (page 3)."



Figure 580 Drilling starter holes (CF)

1. Use an awl or 1/8 inch drill bit to make two small starter holes approximately 180° apart in rear main seal.




Figure 581 Removing the rear main oil seal (CF)

2. Thread slide hammer screw into one of the starter holes. To remove seal evenly, use slide hammer on one side then alternate to other side.
3. Remove and discard rear main oil seal.

NOTE: When removing the rear main oil seal, it should be noted that production engines not previously serviced, will not have a wear sleeve. Wear sleeves are only available as a service item included with the rear main oil seal service kit.




Figure 582 Installing the Rear / Wear Sleeve Removal Tool (CF)

4. Install the Rear / Wear Sleeve Removal Tool (tri-shell components).




Figure 583 Installing the outer ring (CF)

5. Install the Rear / Wear Sleeve Removal Tool (outer ring component). Make sure wear sleeve removal tool shells are securely in place behind wear sleeve prior to applying any force to threaded shaft.




Figure 584 Wear sleeve removed (CF)

6. Thread puller shaft tool in and remove wear sleeve.

Stripped Chassis Applications

! WARNING: To avoid serious personal injury or possible death, wear safety glasses with side shields when performing the following procedure. See "Safety Information (page 3)."




Figure 585 Drilling starter holes (stripped chassis)

1. Use an awl or 1/8 inch drill bit to make two small starter holes approximately 180° apart in rear main seal.




Figure 586 Removing the rear main oil seal (stripped chassis)

2. Thread slide hammer screw into one of the starter holes. To remove seal evenly, use slide hammer on one side then alternate to other side.
3. Remove and discard rear main oil seal.

NOTE: When replacing the rear main seal, please note that production engines will not have a wear sleeve. Wear sleeves are only available as a service item included with the replacement rear main oil seal.

4. Install the Rear / Wear Sleeve Removal Tool (tri-shell components) around the wear sleeve.




Figure 587 Removing the wear sleeve (stripped chassis)

5. Install the Rear / Wear Sleeve Removal Tool (outer ring component). Make sure wear sleeve removal tool shells are securely in place behind wear sleeve prior to applying any force to threaded shaft.




Figure 588 Wear sleeve removed (stripped chassis)

1. Wear sleeve removal tool
2. Wear sleeve

6. Turn the threaded shaft clockwise until the wear sleeve is free of the crankshaft flange.

Crankshaft Secondary Flange (Stripped Chassis Only)




Figure 589 Rear oil seal carrier bolts (stripped chassis)

1. Bolts, M8 x 25 (6)
2. Bolts, M8 x 70 (2)

1. Remove eight rear oil seal carrier bolts (M8).




Figure 590 Removing the rear oil seal carrier (stripped chassis)

1. Gasket

2. Remove rear oil seal carrier and discard gasket.




Figure 591 Removing the crankshaft secondary flange (stripped chassis)

3. Use a gear puller to remove the crankshaft secondary flange.




Figure 592 Crankshaft secondary flange removed (stripped chassis)

Rear Cover




Figure 593 Rear cover bolt arrangement (stripped chassis)

1. Bolt, M8 x 55 (5)
2. Bolt, M10 x 60 (4)
3. Bolt, M10 x 70 (2)
4. Crankshaft rear oil seal carrier
5. Bolt, M8 x 25 (6)
6. Bolt, M8 x 70 (2)




Figure 594 Rear cover bolt arrangement (CF)

1. Bolt, M8 x 35 (8)

1. Stripped Chassis – Remove necessary rear cover mounting bolts. Refer to (Figure 593) for rear cover bolt pattern.

CF Chassis – Remove eight rear cover mounting bolts (M8 x 35). Refer to (Figure 594) for rear cover bolt pattern.

CAUTION: To prevent engine damage when removing the rear cover, cut the sealant where the crankcase and lower crankcase meet.

Cut sealant where the crankcase, high-pressure oil pump cover and rear cover meet.

Failure to adequately cut sealant prior to removing rear cover could result in upper and lower crankcase gaskets being pulled out. Complete engine removal and disassembly would be required to replace the lower crankcase gasket.




Figure 595 Removing the rear cover with a rubber hammer (typical)

2. Use a rubber hammer to help loosen the rear cover from its seat.
3. When the rear cover becomes loose, pull back on the rear cover but do not remove completely.

CAUTION: To prevent engine damage, (if high-pressure oil pump cover is in place), make sure the high-pressure oil pump cover gasket does not pull out when removing the rear cover.




Figure 596 Cutting the rear cover gasket (typical)

4. Cut the rear cover gasket from under the high-pressure pump housing in order to remove the rear cover. Pull the rear cover back, but do not remove.



Figure 597 Separating the rear cover from the lower crankcase gasket (typical)

5. Use a thin gasket scraper to separate sealant between the upper and lower crankcase seals and rear cover assembly. When removing the rear cover assembly, separate the sealant at all joints with the rear cover to avoid pulling these gaskets out.




Figure 598 Removing the rear cover assembly (CF)

1. Alignment dowels

6. Remove the rear cover assembly.

! WARNING: (Stripped chassis applications only) – To avoid serious personal injury or possible death, have an assistant help with the removal of the rear cover as it is considerably heavier than the CF chassis version. See "Safety Information (page 3)."




Figure 599 Removing the rear cover gasket (typical)

7. Remove the rear cover gasket and discard.

Cleaning and Inspection

All Components

1. Clean all foreign material from crankcase and rear cover gasket surfaces. Use a scraper or wire brush to remove sealant from any gasket surfaces.
2. Gasket surfaces must be kept oil free for good adhesion of liquid gasket during assembly. Use a commercially available, non-caustic brake cleaner to clean crankcase and rear cover gasket surfaces.
3. Clean sealant from under the hydraulic oil pump cover while it is still in place.

! WARNING: To avoid serious personal injury or possible death, wear safety glasses with side shields when using compressed air for cleaning to reduce the danger from flying debris. Limit the air pressure to 207 kPa (30 psi). See "Safety Information (page 3)."

4. Wash flywheel, rear cover, flywheel adapter or adapter hub with a suitable solvent. Dry with filtered compressed air.
5. Inspect flywheel for evidence of cracking around webbing and ring gear weldment locations. Replace flywheel if any evidence of cracking is found.
6. Inspect all ring gear teeth for evidence of starter pinion damage. Replace flywheel if necessary.

Installation

Rear Cover

CAUTION: To prevent engine damage, before installing the rear cover, replace dowel sleeves in crankcase if damaged or missing.




Figure 600 Installing the rear cover gasket (typical)

1. Install a new rear cover gasket onto rear cover.




Figure 601 Application of sealant (typical)

2. Apply Liquid Gasket (RTV) at two locations, where the crankcase and lower crankcase join. See Special Service Tools (page 372).

CAUTION: To prevent engine damage, do not allow Liquid Gasket (RTV) to set longer than 10 minutes prior to tightening joint.




Figure 602 Applying Liquid Gasket (RTV) under the high-pressure pump cover (typical)

3. Apply a small amount of Liquid Gasket (RTV) under the high-pressure pump cover.

CAUTION: To prevent engine damage, do not allow Liquid Gasket (RTV) to set longer than 10 minutes prior to tightening joint.




Figure 603 Applying oil to the high-pressure pump cover gasket (typical)

4. Apply a small amount of oil to the high-pressure pump cover gasket.

! WARNING: (Stripped chassis applications only) – To avoid serious personal injury or possible death, have an assistant help with the installation of the rear cover as it is considerably heavier than the CF chassis version. See "Safety Information (page 3)."




Figure 604 Installing the rear cover (CF)

1. Dowel pins (2)
5. Install rear cover assembly by aligning dowel sleeves on crankcase with rear cover. Push rear cover onto dowel sleeves.




Figure 605 Rear cover bolt arrangement (CF)

1. Bolt, M8 x 35 (8)




Figure 606 Torquing the rear cover mounting bolts (typical)

6. CF Chassis – Install eight rear cover mounting bolts (M8 x 35) and tighten to the Standard Torque (page 405). Refer to (Figure 605).




Figure 607 Rear cover bolt arrangement (stripped chassis)

1. Bolt, M8 x 55 (5)
2. Bolt, M10 x 60 (4)
3. Bolt, M10 x 70 (2)
4. Crankshaft rear oil seal carrier
5. Bolt, M8 x 25 (6)
6. Bolt, M8 x 70 (2)

Stripped Chassis – Refer to (Figure 607) for rear cover bolt pattern. Tighten all bolts to the Standard Torque (page 405).

Crankshaft Secondary Flange (Stripped Chassis Only)



Figure 608 Crankshaft secondary flange sealant location

1. Place a 360° bead of Loctite® Hydraulic Sealant onto the forward edge of the crankshaft secondary flange (primary flange mating surface). See Special Service Tools (page 372).
2. Install crankshaft secondary flange by aligning the dowel pin hole with the crankshaft dowel pin.




Figure 609 Installing the crankshaft secondary flange

1. Crankshaft Secondary Flange Installation Studs (2)
3. Install two Crankshaft Secondary Installation Studs (page 372) 180° apart through the crankshaft secondary flange and into the

crankshaft primary flange. Make certain the studs are completely threaded into the crankshaft primary flange and tight. Pull crankshaft secondary flange into place by tightening and alternating stud nuts. Remove studs after flange has been thoroughly seated.




Figure 610 Installing the rear oil seal carrier (stripped chassis)

1. Gasket
4. Place a new gasket onto rear oil seal carrier.




Figure 611 Rear oil seal carrier bolts (stripped chassis)

1. Bolts, M8 x 25 (6)
2. Bolts, M8 x 70 (2)
5. Install two rear oil seal carrier bolts (M8 x 70) in lower holes (Figure 611). Install six remaining rear

oil seal carrier bolts (M8 x 25) to secure rear oil seal carrier to rear cover. Tighten all bolts to the Standard Torque (page 405).

Rear Main Oil Seal and Wear Sleeve

CF Applications

CAUTION: To prevent engine damage, do not separate wear sleeve from the new oil seal, damage to seal and engine will result.

NOTE: When replacing the rear main oil seal it should be noted that production engines not previously serviced, will not have a wear sleeve. Wear sleeves are only available as a service item included with a rear main oil seal service kit.

1. Clean primary crankshaft flange with suitable solvent. Dry with filtered compressed air.



Figure 612 Applying sealant to the crankshaft primary flange (CF)

2. Place a 360° bead of Loctite® Hydraulic Sealant onto the rear edge of the crankshaft primary flange prior to wear sleeve and rear main oil seal installation. See Special Service Tools (page 372).




Figure 613 Installing the rear seal / wear sleeve installer (CF)

3. Bolt rear main seal/wear sleeve installation tool onto end of crankshaft. Make sure crankshaft dowel fits in installation tool dowel recess hole.

NOTE: Lubricate outer diameter of rubber seal with a solution of dish washing soap and water (approximately 50/50 mix) prior to assembly. Do not use any other type of lubricant.



Figure 614 Applying soap to the rear seal

4. Before installing, lubricate the outer diameter of rubber seal with a solution of dish washing soap and water (approximately 50/50 mix) prior to assembly. Do not use any other type of lubricant.




Figure 615 Rear main oil seal and wear sleeve orientation

1. Dust seal lip
2. Rear main oil seal
3. Crankshaft side (forward)
4. Wear sleeve (internal bevel)




Figure 616 Installing the Rear Seal / Wear Sleeve Installer

1. Base
 2. Rear main oil seal and wear sleeve
 3. Rear Seal / Wear Sleeve Installer
5. Position rear main oil seal and wear sleeve combination on the rear seal / wear sleeve installer. Make sure the beveled edge of the wear sleeve is oriented toward the crankshaft.




Figure 617 Installing the rear main seal / wear sleeve onto crankshaft

1. Rear Seal / Wear Sleeve Installer
2. Rear main oil seal
3. Thrust bearing
4. Drive nut

6. Place thrust bearing and drive nut onto threaded shaft. Tighten nut until rear main oil seal bottoms out onto rear oil seal carrier.

7. Remove the Rear Seal/Wear Sleeve Installer tool.




Figure 618 Installing the rear flywheel adaptor

1. Dowel pin
2. Pin recess

CAUTION: To prevent engine damage, do not scratch or mar crankshaft primary flange sealing surface.

8. Place flywheel adaptor onto crankshaft primary flange. Be sure to line up dowel pin. If necessary, tap with soft hammer to start and seat.

Stripped Chassis Applications

CAUTION: To prevent engine damage, do not separate wear sleeve from oil seal, damage to the seal and to the engine will result.

NOTE: When replacing the rear main oil seal, note that production engines will not have a wear sleeve. Wear sleeves are only available as a service item included with the replacement rear main oil seal.




Figure 619 Apply sealant to the crankshaft secondary flange

1. Place a 360° bead of Loctite® Hydraulic Sealant onto the rear edge of the crankshaft secondary flange prior to wear sleeve and rear main oil seal installation. See Special Service Tools (page 372).




Figure 620 Rear / Wear Sleeve Installer

2. Bolt Rear/Wear Sleeve Installer (page 372) onto end of secondary crankshaft flange. Make sure crankshaft alignment dowel fits in dowel recess hole in the rear/wear sleeve installer.




Figure 621 Rear main oil seal and wear sleeve orientation

1. Dust seal lip
 2. Rear main oil seal
 3. Crankshaft side (forward)
 4. Wear sleeve (internal bevel)
3. Orient seal as shown in (Figure 621) and slide on rear/wear sleeve installer. Make sure the beveled edge of the wear sleeve is oriented toward the crankshaft.



Figure 622 Applying soap to the rear seal

4. Before installing, lubricate the outer diameter of rubber seal with a solution of dish washing soap and water (approximately 50/50 mix) prior to assembly. Do not use any other type of lubricant.




Figure 623 Rear oil seal and wear sleeve installer

1. Base
2. Rear main oil seal and wear sleeve
3. Rear/wear sleeve installer

5. Position rear main oil seal and wear sleeve combination on the rear/wear sleeve installer.




Figure 624 Installing rear main oil seal and wear sleeve combination onto crankshaft

1. Rear/wear sleeve installer
 2. Rear main oil seal
 3. Drive nut
 4. Thrust bearing
6. Place thrust bearing and drive nut onto threaded shaft. Tighten nut until rear main oil seal bottoms out in rear oil seal carrier.

Flywheel

CAUTION: To prevent engine damage, you must always install new flywheel mounting bolts when installing the flywheel.

CAUTION: To prevent engine damage, do not use anti-seize compounds or grease on the new flywheel mounting bolts.




Figure 625 Typical flywheel torque sequence (typical)

1. Align crankshaft dowel pin with flywheel alignment hole.
2. Install 10 new flywheel bolts.
 - CF series – M10 x 31
 - Stripped chassis – M10 x 77




Figure 626 Installing the flywheel (typical)

3. Using an alternating pattern across the center, evenly tighten all flywheel bolts to the Special Torque (page 372) using the torque sequence illustration (Figure 625).




Figure 627 Checking ring gear for a run out condition

4. Inspect flywheel ring gear for run out.

NOTE: Keep the crankshaft end play at zero in the same direction for all measurements.

- A. Attach Dial Indicator with Magnetic Base onto lower oil pan. Place dial indicator tip against surface of flywheel ring gear. See Special Service Tools (page 372).
- B. Zero the dial indicator.
- C. Rotate crankshaft slowly in a clockwise direction. Compare total dial indicator variation. See Specifications (page 372).
- D. Compare the result to the flywheel surface runout specification. Replace if necessary. See Specifications (page 372).
5. Stripped Chassis Only – Place ring adapter onto rear cover assembly and install 12 bolts (M10 x 35). Tighten bolts to the Standard Torque (page 405).

Specifications

| Flywheel and Rear Cover | |
|---------------------------------------|--------------------|
| Flywheel | |
| Max. flywheel ring gear T.I.R. runout | 1.27 mm (0.050 in) |
| Rear Cover | |
| Rear cover face maximum runout | 0.51 mm (0.020 in) |

Special Torque

| | |
|---|--|
| Flywheel | |
| Flywheel mounting bolts (all applications) new bolts only | 94 N·m (69 lbf·ft) flywheel torque sequence (Figure 625) |

Special Service Tools

| Flywheel and Rear Cover | |
|--|----------------|
| Description | Tool Number |
| Dial Indicator with Magnetic Base | Obtain locally |
| Liquid Gasket (RTV) (6 oz. tube) | 1830858C1 |
| Loctite® Hydraulic Sealant | Obtain locally |
| Rear Seal/Wear Sleeve Installer ¹ | ZTSE4515A |
| Rear/Wear Sleeve Removal Tool | ZTSE4518 |
| Slide Hammer | ZTSE4398A |
| Crankshaft Secondary Flange Installation Studs (2) | ZTSE4720 |
| Gear Puller (for secondary flange) | ZTSE4520 |

¹ CF bolts - M10 x 40, Stripped Chassis bolts - M10 x 70

Table of Contents

| | |
|-----------------------------|-----|
| Rocker Arm Replacement..... | 375 |
| Special Service Tools..... | 379 |

Rocker Arm Replacement

Prior to performing any rocker arm replacement, the following components must be removed as outlined elsewhere in this engine service manual:

- Turbocharger inlet air ducting
- Valve cover(s)
- High-pressure oil rail(s)



WARNING: To avoid serious personal injury, possible death, or damage to the engine or vehicle, make sure the transmission is in neutral, parking brake is set, and wheels are blocked before doing diagnostic or service procedures on engine or vehicle. Read all safety instructions in the "Safety Information" section of the service manual for this engine.



WARNING: To avoid serious personal injury, possible death, or damage to the engine or vehicle, make sure that the engine has cooled down sufficiently before attempting to remove any engine components.

CAUTION: To prevent engine damage, position clean shop towels (refer to TSI-02-12-16) or rubber hose into each of the holes prior to fuel injector removal. This practice will ensure that small parts (or broken pieces) will not get into the oil supply should they become dislodged. Potentially damaging components include:

- $\frac{3}{8}$ " rocker arm pivot balls
- Rocker arm pivots and pivot retainers

Be certain to account for all parts (or pieces of) before removing shop towels or rubber hose after rocker arm has been installed.

1. Locate dowel hole in vibration damper. The hole is located between two of the four bolt heads.




Figure 628 Dowel hole in vibration damper

2. Rotate crankshaft until the dowel hole is at the 12:00 O'clock position.

Wiggle both rocker arms at the #1 cylinder. If the rockers do not move freely, rotate crankshaft one complete revolution (360°). The #1 cylinder rocker arms should now feel free of valve train loading. Rocker arm replacement can be performed at cylinders 1, 2, and 4.

Rotate crankshaft one additional revolution (360°) to service both rocker arms for cylinders 3, 5, and 6.

3. Disconnect and remove the fuel injector electrical connection at the rocker arm carrier using the Injector Connector Remover. See Special Service Tools (page 379).
4. Remove the fuel injector hold down clamp assembly using the Fuel Injector Hold Down Wrench. See Special Service Tools (page 379).
5. Place injector into Fuel Injector Rack Holder. See Special Service Tools (page 379).

CAUTION: To prevent engine damage, place a clean paper towel inside the injector sleeve to prohibit the entrance of any foreign material.




Figure 629 On Engine Valve Spring Compressor Tool

1. Valve Spring Compressor Plate
2. Valve Spring Compressor Base
3. Valve Spring Compressor Bolt




Figure 630 Hold down clamp and base

1. Locating notch / index feature
6. Using the On Engine Valve Spring Compressor Tool, insert the Valve Spring Compressor Base into an injector hold down clamp, making sure the notch in the base aligns with index feature on hold down clamp. Install assembly between the valve bridges as if installing an injector.




Figure 631 Valve Spring Compressor Base installed

NOTE: While centering Valve Spring Compressor Base between the two valve bridges, lightly tighten hold down bolt, but do not torque.




Figure 632 Creating clearance between rocker arm and valve bridge

1. Valve Spring Compressor Plate
2. Valve bridge (2)
3. Small pry bar
7. Install Valve Spring Compressor Plate onto the top of each valve bridge, locating the small point of plate between the exhaust rocker and valve bridge.
 - a. If exhaust rocker is severely worn, insert a small pry bar between the exhaust rocker arm and valve bridge. By compressing

the valve bridge down and raising the rocker slightly you should gain enough clearance to rotate the small point of the Valve Spring Compressor Plate between the two components.

- b. Once the Valve Spring Compressor Plate is in position, install the Valve Spring Compressor Bolt through the Valve Spring Compressor Plate and into Valve Spring Compressor Base.
- c. Using a hand wrench, tighten bolt to compress valve springs until Valve Spring Compressor Plate contacts top of Valve Spring Compressor Base.

CAUTION: To prevent engine damage, do not use any type of power tools.




Figure 633 Valve Spring Compressor Plate installed

1. Plate properly positioned on top of valve bridges
 2. Exhaust rocker arm
8. Disengage rocker arm from push rod while rotating rocker arm and compressing rocker arm clip simultaneously. Repeat procedure for adjacent rocker arm.

CAUTION: To prevent engine damage, make sure you can account for the two $\frac{3}{8}$ " rocker arm pivot balls. If balls fall onto cylinder head, use a magnet to retrieve them.

CAUTION: To prevent engine damage, you must account for each rocker arm pivot and pivot retainer. Failure to account for broken pieces would require the removal of the oil pan to retrieve, if shop towels or hoses were not placed within the oil drain holes.

9. With rocker arms removed, back out Valve Spring Compressor Bolt and remove Valve Spring Compressor Plate to gain access to valve bridges.
10. Replace valve bridges as necessary. Compress valves again to enable installation of new rocker arms.
11. Place a dab of wheel bearing grease onto new rocker arm socket (to hold new $\frac{3}{8}$ " ball in place while installing rocker arm).
12. Position $\frac{3}{8}$ " ball and rocker arm underneath fulcrum and rotate rocker arm into place making sure push rod is seated within rocker arm.




Figure 634 Position "A" in first then slide "B" around fulcrum plate

1. Fulcrum plate
2. Rocker arm retaining clip

13. Install new plastic rocker arm retaining clip (Figure 634) by positioning top of clip to top of rocker arm opening and rotating clip until snapping around fulcrum plate.




Figure 635 Retaining clip in correct position

1. Fulcrum plate
 2. Rocker arm retaining clip
14. Refer to above illustration for correctly installed clip. Repeat procedure with adjacent rocker arm.
15. Remove Valve Spring Compressor Bolt making sure rocker arm remains in place and $\frac{3}{8}$ " ball have not fallen out. Repeat procedure on remaining cylinders for this crankshaft position session.
16. After all desired rocker arms and valve bridges have been replaced for cylinders 1, 2, and 4, the crankshaft can be rotated one complete revolution (360°) to service rocker arms at cylinders 3, 5 and 6.
17. Install a new O-ring seal kit onto each of the fuel injectors as outlined in Cylinder Head and Valve Train section of this manual.
18. Remove paper towels from injector bores and install injectors.
19. Look for small broken particles (visually and using a magnet) before removing shop towels or rubber hose from oil drain holes.
20. Continue to install the following components as outlined in this engine service manual:
- High-pressure oil rail(s)
 - Valve cover(s)
 - Turbocharger inlet air ducting

Special Service Tools

| In Chassis Service | |
|--|--------------------|
| Description | Tool Number |
| Fuel Injector Hold Down Wrench | ZTSE4524 |
| Quick Release Tool kit | ZTSE4454 |
| Fuel Injector Rack Holder | ZTSE4299B |
| Injector Connector Remover | ZTSE4650 |
| On Engine Valve Spring Compressor Tool | ZTSE4697 |

Table of Contents

Terminology.....383

Terminology

Accessory work – The work per cycle required to drive engine accessories (normally, only those essential to engine operation).

Actuator – A device that performs work in response to an input signal.

Aeration – The entrainment of air or combustion gas in coolant, lubricant, or fuel.

Aftercooler (Charge Air Cooler) – A heat exchanger mounted in the charge air path between the turbocharger and engine intake manifold. The aftercooler reduces the charge air temperature by transferring heat from the charge air to a cooling medium (usually air).

Ambient temperature – The environmental air temperature in which a unit is operating. In general, the temperature is measured in the shade (no solar radiation) and represents the air temperature for other engine cooling performance measurement purposes. Air entering the radiator may or may not be the same ambient due to possible heating from other sources or recirculation. (SAE J1004 SEP81)

Ampere (amp) – The standard unit for measuring the strength of an electrical current. The flow rate of a charge in a conductor or conducting medium of one coulomb per second. (SAE J1213 NOV82)

Analog – A continuously variable voltage.

Analog to digital converter (A/D) – A circuit in the ECM processing section that converts an analog signal (DC or AC) to a usable digital signal for the microprocessor.

American Trucking Association (ATA) Datalink – A serial datalink specified by the American Trucking Association and the SAE.

Boost pressure – 1. The pressure of the charge air leaving the turbocharger.

2. Inlet manifold pressure that is greater than atmospheric pressure. Obtained by turbocharging.

Bottom Dead Center (BDC) – The lowest position of the piston during the stroke.

Brake Horsepower (bhp) – The power output from an engine, not the indicated horsepower. The power output of an engine, sometimes-called flywheel horsepower is less than the indicated horsepower by

the amount of friction horsepower consumed in the engine.

Brake Horsepower (bhp) net – Net brake horsepower is measured with all engine components. The power of an engine when configured as a fully equipped engine. (SAE J1349 JUN90)

Calibration – The data values used by the strategy to solve equations and make decisions. Calibration values are stored in ROM and put into the processor during programming to allow the engine to operate within certain parameters.

Catalyst – A substance that produces a chemical reaction without undergoing a chemical change itself.

Catalytic converter – An antipollution device in the exhaust system that contains a catalyst for chemically converting some pollutants in the exhaust gases (carbon monoxide, unburned hydrocarbons, and oxides of nitrogen) into harmless compounds.

Cavitation – A dynamic condition in a fluid system that forms gas-filled bubbles (cavities) in the fluid.

Cetane number – 1. The auto-ignition quality of diesel fuel.

2. A rating applied to diesel fuel similar to octane rating for gasoline.

3. A measure of how readily diesel fuel starts to burn (autoignites) at high compression temperature.

Diesel fuel with a high cetane number autoignites shortly after injection into the combustion chamber. Therefore, it has a short ignition delay time. Diesel fuel with a low cetane number resists autoignition. Therefore, it has a longer ignition delay time.

Charge air – Dense, pressurized, heated air discharged from the turbocharger.

Charge Air Cooler (CAC) – See **Aftercooler**.

Closed crankcase – A crankcase ventilation that recycles crankcase gases through a breather, then back to the clean air intake.

Closed loop operation – A system that uses a sensor to provide feedback to the ECM. The ECM uses the sensor to continuously monitor variables and adjust to match engine requirements.

Cloud point – The point when wax crystals occur in fuel, making fuel cloudy or hazy. Usually below -12 °C (10 °F).

Cold cranking ampere rating (battery rating) – The sustained constant current (in amperes) needed to produce a minimum terminal voltage under a load of 7.2 volts per battery after 30 seconds.

Continuous Monitor Test – An ECM function that continuously monitors the inputs and outputs to ensure that readings are within set limits.

Coolant – A fluid used to transport heat from one point to another.

Coolant level switch – A switch sensor used to indicate low coolant level.

Crankcase – The housing that encloses the crankshaft, connecting rods, and allied parts.

Crankcase breather – A vent for the crankcase to release excess interior air pressure.

Crankcase pressure – The force of air inside the crankcase against the crankcase housing.

Current – The flow of electrons passing through a conductor. Measured in amperes.

Damper – A device that reduces the amplitude of torsional vibration. (SAE J1479 JAN85)

Deaeration – The removal or purging of gases (air or combustion gas) entrained in coolant or lubricating oil.

Deaeration tank – A separate tank in the cooling system used for one or more of the following functions:

- Deaeration
- Coolant reservoir (fluid expansion and afterboil)
- Coolant retention
- Filling
- Fluid level indication (visible)

Diagnostic Trouble Code (DTC) – Formerly called a Fault Code or Flash Code. A DTC is a three digit numeric code used for troubleshooting.

Digital Multimeter (DMM) – An electronic meter that uses a digital display to indicate a measured value. Preferred for use on microprocessor systems because it has a very high internal impedance and will not load down the circuit being measured.

Disable – A computer decision that deactivates a system and prevents operation of the system.

Displacement – The stroke of the piston multiplied by the area of the cylinder bore multiplied by the number of cylinders in the engine.

Driver (high side) – A transistor within an electronic module that controls the power to an actuator circuit.

Driver (low side) – A transistor within an electronic module that controls the ground to an actuator circuit.

Duty cycle – A control signal that has a controlled on/off time measurement from 0 to 100%. Normally used to control solenoids.

Engine lamp – An instrument panel lamp that comes on when DTCs are set. DTCs can be read as flash codes (red and amber instrument panel lamps).

Engine OFF tests – Tests that are done with the ignition switch ON and the engine OFF.

Engine rating – Engine rating includes **Rated hp** and **Rated rpm**.

Engine RUNNING tests – Tests done with the engine running.

Exhaust brake – A brake device using engine exhaust back pressure as a retarding medium.

Exhaust manifold – Exhaust gases flow through the exhaust manifold to the turbocharger exhaust inlet and are directed to the EGR cooler.

Fault detection/management – An alternate control strategy that reduces adverse effects that can be caused by a system failure. If a sensor fails, the ECM substitutes a good sensor signal or assumed sensor value in its place. A lit amber instrument panel lamp signals that the vehicle needs service.

Filter restriction – A blockage, usually from contaminants, that prevents the flow of fluid through a filter.

Flash code – See **Diagnostic Trouble Code (DTC)**.

Fuel inlet restriction – A blockage, usually from contaminants, that prevents the flow of fluid through the fuel inlet line.

Fuel pressure – The force that the fuel exerts on the fuel system as it is pumped through the fuel system.

Fuel strainer – A pre-filter in the fuel system that keeps larger contaminants from entering the fuel system.

Fully equipped engine – A fully equipped engine is an engine equipped with only those accessories necessary to perform its intended service. A fully equipped engine does not include components that are used to power auxiliary systems. If these components are integral with the engine or for any reason are included on the test engine, the power absorbed may be determined and added to the net brake power. (SAE J1995 JUN90)

Fusible link (fuse link) – A fusible link is a special section of low tension cable designed to open the circuit when subjected to an extreme current overload. (SAE J1156 APR86)

Gradeability – The maximum percent grade which the vehicle can transverse for a specified time at a specified speed. The gradeability limit is the grade upon which the vehicle can just move forward. (SAE J227a)

Gross Combined Weight Rating (GCWR) – Maximum combined weight of towing vehicle (including passengers and cargo) and the trailer. The GCWR indicates the maximum loaded weight that the vehicle is allowed to tow.

Gross brake horsepower – The power of a complete basic engine, with air cleaner, without fan, and alternator and air compressor not charging.

Hall effect – The development of a transverse electric potential gradient in a current-carrying conductor or semiconductor when a magnetic field is applied.

Hall effect sensor – Generates a digital on/off signal that indicates speed and timing.

High speed digital inputs – Inputs to the ECM from a sensor that generates varying frequencies (engine speed and vehicle speed sensors).

Horsepower (hp) – Horsepower is the unit of work done in a given period of time, equal to 33,000 pounds multiplied by one foot per minute. **1hp = 33,000 lb x 1 ft /1 min.**

Hydrocarbons – Unburned or partially burned fuel molecules.

Idle speed –

- Low idle is minimum rpm at no load.
- High idle is maximum rpm at no load.

Intake manifold – A collection of tubes through which the fuel-air mixture flows from the fuel injector to the intake valves of the cylinders.

International NGV Tool Utilized for Next Generation Electronics (INTUNE) – The diagnostics software for chassis related components and systems.

Low speed digital inputs – Switched sensor inputs that generate an on/off (high/low) signal to the ECM. The input to the ECM from the sensor could be from a high input source switch (usually 5 or 12 volts) or from a grounding switch that grounds the signal from a current limiting resistor in the ECM that creates a low signal (0 volts).

Lubricity – Lubricity is the ability of a substance to reduce friction between solid surfaces in relative motion under loaded conditions.

Lug (engine) – A condition when the engine is operating at or below maximum torque speed.

Manometer – A double-leg liquid-column gauge, or a single inclined gauge, used to measure the difference between two fluid pressures. Typically, a manometer records in inches of water.

MasterDiagnostics® (MD) – The diagnostics software for engine related components and systems.

Microprocessor – An integrated circuit in a microcomputer that controls information flow.

Nitrogen Oxides (NO_x) – Nitrogen oxides form by a reaction between nitrogen and oxygen at high temperatures and pressures in the combustion chamber.

Normally closed – Refers to a switch that remains closed when no control force is acting on it.

Normally open – Refers to a switch that remains open when no control force is acting on it.

Ohm (Ω) – The unit of resistance. One ohm is the value of resistance through which a potential of one volt will maintain a current of one ampere. (SAE J1213 NOV82)

On demand test – A self test that the technician initiates using the EST and is run from a program in the processor.

Output Circuit Check (OCC) – An On demand test done during an Engine OFF self test to check the continuity of selected actuators.

Output State Test (OST) – An On demand test that forces the processor to activate actuators (High or Low) for additional diagnostics.

pH – A measure of the acidity or alkalinity of a solution.

Particulate matter – Particulate matter includes mostly burned particles of fuel and engine oil.

Piezometer – An instrument for measuring fluid pressure.

Positive On Shaft Excluder (POSE) – A Positive On Shaft Excluder is a separate piece from the rest of the front or rear seal used to keep out dust / debris.

Power – Power is a measure of the rate at which work is done. Compare with **Torque**.

Power TakeOff (PTO) – Accessory output, usually from the transmission, used to power a hydraulic pump for a special auxiliary feature (garbage packing, lift equipment, etc).

Pulse Width Modulation (PWM) – The time that an actuator, such as an injector, remains energized.

Random Access Memory (RAM) – Computer memory that stores information. Information can be written to and read from RAM. Input information (current engine speed or temperature) can be stored in RAM to be compared to values stored in Read Only Memory (ROM). All memory in RAM is lost when the ignition switch is turned off.

Rated gross horsepower – Engine gross horsepower at rated speed as declared by the manufacturer. (SAE J1995 JUN90)

Rated horsepower – Maximum brake horsepower output of an engine as certified by the engine manufacturer. The power of an engine when configured as a basic engine. (SAE J1995 JUN90)

Rated net horsepower – Engine net horsepower at rated speed as declared by the manufacturer. (SAE J1349 JUN90)

Rated speed – The speed, as determined by the manufacturer, at which the engine is rated. (SAE J1995 JUN90)

Rated torque – Maximum torque produced by an engine as certified by the manufacturer.

Ratiometric Voltage – In a Micro Strain Gauge (MSG) sensor pressure to be measured exerts force

on a pressure vessel that stretches and compresses to change resistance of strain gauges bonded to the surface of the pressure vessel. Internal sensor electronics convert the changes in resistance to a ratiometric voltage output.

Read Only Memory (ROM) – Computer memory that stores permanent information for calibration tables and operating strategies. Permanently stored information in ROM cannot be changed or lost by turning the engine off or when ECM power is interrupted.

Reference voltage (V_{REF}) – A 5 volt reference supplied by the ECM to operate the engine sensors.

Reserve capacity – Time in minutes that a fully charged battery can be discharged to 10.5 volts at 25 amperes.

Signal ground – The common ground wire to the ECM for the sensors.

Speed Control Command Switches (SCCS) – A set of switches used for cruise control, Power TakeOff (PTO), and remote hand throttle system.

Steady state condition – An engine operating at a constant speed and load and at stabilized temperatures and pressures. (SAE J215 JAN80)

Strategy – A plan or set of operating instructions that the microprocessor follows for a desired goal. Strategy is the computer program itself, including all equations and decision making logic. Strategy is always stored in ROM and cannot be changed during calibration.

Stroke – Stroke is the movement of the piston from Top Dead Center (TDC) to Bottom Dead Center (BDC).

Substrate – Material that supports the washcoating or catalytic materials.

Sulfur dioxide (SO_2) – Sulfur dioxide is caused by oxidation of sulfur contained in fuel.

System restriction (air) – The static pressure differential that occurs at a given air flow from air entrance through air exit in a system. Usually measured in inches (millimeters) of water. (SAE J1004 SEP81)

Tachometer output signal – Engine speed signal for remote tachometers.

Thermistor – A semiconductor device. A sensing element that changes resistance as the temperature changes.

Thrust load – A thrust load pushes or reacts through a bearing in a direction parallel to the shaft.

Top Dead Center (TDC) – The uppermost position of the piston during the stroke.

Torque – A force having a twisting or turning effect. For a single force, the cross product of a vector from some reference point to the point of application of the force within the force itself. Also known as moment of force or rotation moment. Torque is a measure of the ability of an engine to do work.

Truck Computer Analysis of Performance and Economy (TCAPE) – Truck Computer Analysis of Performance and Economy is a computer program that simulates the performance and fuel economy of trucks.

Turbocharger – A turbine driven compressor mounted to the exhaust manifold. The turbocharger increases the pressure, temperature and density of intake air to charge air.

Variable capacitance sensor – A variable capacitance sensor is measures pressure. The pressure forces a ceramic material closer to a thin metal disc in the sensor, changing the capacitance of the sensor.

Vehicle Electronic System Programming System – The computer system used to program electronically controlled vehicles.

Vehicle Retarder Enable/Engage – Output from the ECM to a vehicle retarder.

Vehicle Speed Sensor (VSS) – Normally a magnetic pickup sensor mounted in the tailshaft housing of the transmission, used to indicate ground speed.

Viscosity – The internal resistance to the flow of any fluid.

Viscous fan – A fan drive that is activated when a thermostat, sensing high air temperature, forces fluid through a special coupling. The fluid activates the fan.

Volt (v) – A unit of electromotive force that will move a current of one ampere through a resistance of one Ohm.

Voltage – Electrical potential expressed in volts.

Voltage drop – Reduction in applied voltage from the current flowing through a circuit or portion of the circuit current multiplied by resistance.

Voltage ignition – Voltage supplied by the ignition switch when the key is ON.

Washcoat – A layer of alumina applied to the substrate in a monolith-type converter.

Table of Contents

| | |
|--|-----|
| Specifications..... | 391 |
| Dual Turbocharger and Exhaust Tubing..... | 391 |
| Manifolds and Exhaust Gas Recirculation (EGR)..... | 391 |
| Cylinder Head and Valve Train..... | 391 |
| Front Cover, Vibration Damper, and Gerotor Oil Pump..... | 393 |
| Power Cylinder..... | 395 |
| Crankcase, Crankshaft, and Camshaft..... | 396 |
| Oil Cooler and Filter Housing..... | 398 |
| Engine Electrical Components..... | 399 |
| High-pressure Oil Pump..... | 399 |
| Fuel System..... | 399 |
| Rear Cover..... | 400 |

Specifications

Dual Turbocharger and Exhaust Tubing

| | |
|---|----------------------|
| Turbocharger Shaft | |
| Maximum turbine shaft axial end play (LP turbocharger) | 0.091 mm (0.0036 in) |
| Maximum turbine shaft radial shaft movement (clearance) (LP turbocharger) | 0.5 mm (0.02 in) |
| Maximum turbine shaft axial end play (HP turbocharger) | 0.091 mm (0.0036 in) |
| Maximum turbine shaft radial shaft movement (clearance) (HP turbocharger) | 0.5 mm (0.02 in) |

Manifolds and Exhaust Gas Recirculation (EGR)

| | |
|--|--------------------|
| Manifolds and Exhaust Gas Recirculation (EGR) | |
| Exhaust Manifolds | |
| Maximum allowable warpage | 0.08 mm (0.003 in) |
| Intake Manifold | |
| Maximum allowable warpage | 0.08 mm (0.003 in) |

Cylinder Head and Valve Train

| | |
|---|---|
| Cylinder Head and Valve Train | |
| Exhaust Valves | |
| Stem diameter | 6.947 to 6.965 mm (0.2735 to 0.2742 in) |
| Stem to guide clearance (max. allowable before replacement) | 0.140 mm (0.0055 in) |
| Face to stem runout (T.I.R. max.) | 0.038 mm (0.0015 in) |
| Valve face angle | 37.5° |
| Valve margin (minimum) | 1.35 mm (0.053 in) |
| Valve recession in head | 0.50 ± 0.18 mm (0.020 ± 0.007 in) |
| Intake Valves | |
| Stem diameter | 6.947 to 6.965 mm (0.2735 to 0.2742 in) |
| Stem to guide clearance (max. allowable before replacement) | 0.140 mm (0.0055 in) |
| Face to stem runout (T.I.R. max.) | 0.0038 mm (0.0015 in) |
| Valve face angle | 30.0° |
| Valve margin (minimum) | 1.40 mm (0.055 in) |
| Valve recession in head | 0.50 ± 0.18 mm (0.020 ± 0.007 in) |
| Cylinder Heads | |

| | |
|---|---|
| Valve guide inside diameter | 7.003 to 7.029 mm (0.276 to 0.277 in) |
| Valve guide bore runout | 0.05 mm (0.002 in) |
| Valve guide taper (maximum) | 0.10 mm (0.004 in) |
| Valve seat width (intake) | 1.80 to 2.56 mm (0.071 to 0.101 in) |
| Valve seat width (exhaust) | 1.48 to 2.24 mm (0.058 to 0.088 in) |
| Valve seat angle (intake) | 30.0° |
| Valve seat angle (exhaust) | 37.5° |
| Valve seat runout (T.I.R. max.) | 0.035 mm (0.0014 in) |
| Gasket surface flatness | 0.05 mm (0.002 in) per 51 mm (2 in) |
| | 0.10 mm (0.004 in) per total surface area |
| Overall thickness of cylinder head (deck-to-deck) | 95 mm (3.74 in) |
| Valve head recession relative to deck (surface of cylinder head) | 0.32 to 0.68 mm (0.0126 to 0.0268 in) |
| Valve Spring: | |
| Free length | 51.96 mm (2.045 in) |
| Compressed* (first test) | 46.30 mm @ 340 ± 17 N (1.82 in @ 76.5 ± 3.8 lbf) |
| Compressed* (second test) | 38.30 mm @ 850 ± 43 N (1.51 in @ 191.1 ± 9.7 lbf) |
| * Spring must be compressed to a solid height before checking test loads. | |
| Push Rods | |
| Runout (maximum) | 0.25 mm (0.01 in) |

Front Cover, Vibration Damper, and Gerotor Oil Pump

| | |
|---|---------------------------------------|
| Front Cover, Vibration Damper, and Gerotor Oil Pump | |
| Vibration Damper | |
| Face runout (maximum) | 0.635 mm (0.025 in) |
| Rubber bulging (maximum) | 1.5 mm (0.060 in) |
| Lubricating Oil Pump and Pressure Regulator | |
| Type | Gerotor |
| Drive | Crankshaft |
| Location | Gerotor oil pump housing |
| • Engine oil pressure, low idle (min. @ 110°C (230°F) oil temp.) | 69 kPa (10 psi) |
| • Engine oil pressure, high idle (min. @ 110°C (230°F) oil temp.) | 276 kPa (40 psi) |
| • Oil pump discharge pressure (2,500 rpm) | 483 to 621 kPa (70 to 90 psi) |
| End clearance (inner and outer rotor to housing) | 0.025 to 0.095 mm (0.001 to 0.004 in) |
| Radial clearance (between outer rotor and housing) | 0.15 to 0.28 mm (0.006 to 0.011 in) |
| Pressure Regulating Valve: | |
| Plunger bore | 18.81 ± 0.02 mm (0.741 0.001) |
| Thermostat | |
| Type | Balanced pressure, wax pellet |
| Normal operating temperature, >10 mm (0.394 in) stroke | 104°C (219°F) |




Figure 636 Accessories drive belt routing

- | | | |
|------------------|------------------------|------------------------------------|
| 1. Alternator | 5. Flat idler | 9. Tensioner square |
| 2. Drive belt | 6. Power steering pump | 10. Tensioner pulley |
| 3. Flat idler | 7. Water pump | 11. AC compressor or non AC pulley |
| 4. Grooved idler | 8. Crankshaft damper | 12. Grooved idler |

Power Cylinder**Power Cylinder****Connecting Rods**

| | |
|---|---|
| Connecting rod length (center to center) | 176 mm (6.929 in) |
| Bushing bore diameter (pin end) | 36.98 to 37.02 mm (1.456 to 1.457 in) |
| Piston pin bushing inside diameter | 34.0140 to 34.0215 mm (1.3391 to 1.3394 in) |
| Bearing bore diameter (crankshaft end) | 72.987 to 73.013 mm (2.8735 to 2.8745 in) |
| Bearing bore maximum out-of-round | 0.013 mm (0.0005 in) |
| Bearing bore maximum taper per 25 mm (1 inch) | 0.013 mm (0.0005 in) |
| Connecting rod bearing inside diameter | 69.027 to 69.077 mm (2.7176 to 2.7196 in) |
| Connecting rod bearing running clearance (diameter) | 0.0203 to 0.0837 mm (0.0008 to 0.0033 in) |
| Connecting rod side clearance | 0.3 to 0.6 mm (0.012 to 0.024 in) |
| Weight (complete rod without bearing) | 1201.5 to 1215.5 g (2.649 to 2.679 lb) |

Pistons

| | |
|-----------------------------|---|
| Material | Aluminum Alloy |
| Skirt diameter ¹ | 94.9460 to 94.9186 mm (3.737 to 3.738 in) |

¹ Measure 14.68 mm (0.578 in) from bottom, at 90° to the piston pin. Measure only at room temperature of 19 to 21°C (66 to 70°F).

Service Piston:

| | |
|--|---|
| Standard size | 94.9460 to 94.9186 mm (3.737 to 3.738 in) |
| 0.254 mm (0.010 in) oversize | 95.1738 to 95.1992 mm (3.747 to 3.748 in) |
| 0.508 mm (0.020 in) oversize | 95.4278 to 95.4532 mm (3.757 to 3.758 in) |
| 0.762 mm (0.030 in) oversize | 95.6818 to 95.7072 mm (3.767 to 3.768 in) |
| Top compression ring groove width (measured over 2.08 mm (0.082 in) gauge pins): | |
| Upper limit | 94.469 mm (3.7192 in) |
| Replacement limit | 94.290 mm (3.7122 in) |
| Piston height above crankcase deck (protrusion) | 0.900 mm (0.0354 in) |
| Piston skirt clearance (1 - 8) | 0.0441 to 0.0909 mm (0.0017 to 0.0036 in) |

Piston Pins

| | |
|---|---|
| Length | 65.073 to 65.327 mm (2.5619 to 2.5719 in) |
| Diameter | 33.9975 to 34.0025 mm (1.3385 to 1.3387 in) |
| Pin fit at room temperature of 19 to 21°C (66 to 70°F): | |
| Clearance in connecting rod (piston pin bushing) | 0.0115 to 0.0240 mm (0.00045 to 0.00094 in) |

| | |
|---|---|
| Clearance in piston | 0.013 to 0.022 mm (0.0005 to 0.0009 in) |
| End clearance | 0.24 mm (0.009 in) |
| Piston Rings | |
| Ring diameter (standard): | 95 mm (3.74 in) |
| Fit in groove (side clearance in bore): | |
| Intermediate compression | 0.051 to 0.102 mm (0.0020 to 0.0040 in) |
| Oil control | 0.038 to 0.084 mm (0.0015 to 0.0033 in) |
| Ring gap in bore: | |
| Top compression | 0.29 to 0.55 mm (0.011 to 0.021 in) |
| Intermediate compression | 1.40 to 1.66 mm (0.055 to 0.065 in) |
| Oil control | 0.24 to 0.50 mm (0.009 to 0.019 in) |

Crankcase, Crankshaft, and Camshaft

| | |
|---|---|
| Crankshaft | |
| Crankshaft end play (maximum) | 0.222 mm (0.0087 in) |
| Crankshaft gear backlash (maximum) | 0.32 mm (0.012 in) |
| Crankshaft connecting rod out of round | 0.006 mm (0.00024 in) |
| Crankshaft main journal out of round | 0.006 mm (0.00024 in) |
| Main bearing thrust face maximum runout | 0.051 mm (0.002 in) |
| Oil seal journal maximum runout | 0.025 mm (0.001 in) |
| Vibration damper mounting area maximum runout | 0.05 mm (0.002 in) |
| Flywheel mounting surface maximum runout | 0.05 mm (0.002 in) |
| Main bearing to crankshaft running clearance | 0.025 to 0.076 mm (0.001 to 0.003 in) |
| Main Bearing Journal Diameter | |
| • Standard size | 80.987 to 81.012 mm (3.188 to 3.150 in) |
| • 0.254 mm (0.010 in) under size | 80.733 to 80.758 mm (3.178 to 3.140 in) |
| • 0.508 mm (0.020 in) under size | 80.479 to 80.504 mm (3.168 to 3.130 in) |
| • 0.762 mm (0.030 in) under size | 80.225 to 80.250 mm (3.158 to 3.120 in) |
| Connecting Rod Journal Diameter | |
| • Standard size | 68.99 to 69.01 mm (2.716 to 2.717 in) |
| • 0.254 mm (0.010 in) under size | 68.73 to 68.75 mm (2.706 to 2.707 in) |
| • 0.508 mm (0.020 in) under size | 68.48 to 68.50 mm (2.696 to 2.697 in) |
| • 0.762 mm (0.030 in) under size | 68.23 to 68.25 mm (2.686 to 2.687 in) |

Camshaft and Bushings

| | |
|--|---|
| Camshaft journal diameter (all journals) | 61.987 to 62.013 mm (2.440 to 2.441 in) |
| Bushing inside diameter | 62.05 to 62.14 mm (2.443 to 2.446 in) |
| Journal and bushing running clearance | 0.037 to 0.153 mm (0.0015 to 0.0060 in) |
| Camshaft end play | 0.051 to 0.211 mm (0.002 to 0.008 in) |
| Camshaft gear backlash | 0.179 to 0.315 mm (0.007 to 0.012 in) |
| Maximum permissible cam lobe wear | 0.51 mm (0.02 in) |
| Camshaft thrust plate thickness | 3.589 to 3.649 mm (0.1413 to 0.1436 in) |
| Balance shaft end play | 1.77 mm (0.070 in) |
| Balance shaft gear backlash | 0.184 to 0.306 mm (0.007 to 0.012 in) |
| Balance shaft bearing clearance | 0.123 mm (0.005 in) |

Camshaft lobe lift (maximum)

- | | |
|-----------|----------------------|
| • Intake | 5.820 mm (0.2291 in) |
| • Exhaust | 5.906 mm (0.2325 in) |

Valve timing no. 1 cylinder (top of lobe)

- | | |
|------------------|------------|
| • Intake open | 16.2° BTDC |
| • Intake closed | 50.4° ABDC |
| • Exhaust open | 47.5° BBDC |
| • Exhaust closed | 14.9° ATDC |

Crankcase and Main Bearings

Crankcase

| | |
|--|--|
| Cylinder block top surface of crankcase flatness | Total deck surface: 0.10 mm (0.004 in) 150 mm ² (36 in ²) area: 0.05 mm (0.02 in) 25 mm ² (1 in ²) area: 0.025 mm (0.001 in) |
| Crankcase main bearing bore diameter | 85.99 to 86.01 mm (3.3854 to 3.3862 in) |
| Crankcase cam bearing bore diameter | 65.98 to 66.02 mm (2.597 to 2.599 in) |
| Roller follower bore diameter | 23.44 to 23.48 mm (0.923 to 0.924 in) |
| Roller follower outside diameter | 23.39 to 23.41 mm (0.921 to 0.923 in) |
| Cylinder bore diameter | 94.991 to 95.001 mm (3.740 to 3.741 in) |
| Cylinder bore maximum out-of-round | 0.008 mm (0.0003 in) |
| Cylinder stroke | 105 mm (4.13 in) |
| Coolant heater element rating | 1,000 watts, 120 volts |

Main Bearings

| | |
|-------------------------|-----------------------------|
| Material | Steel backed copper/lead |
| Number of main bearings | 4 |
| Thrust bearing location | No. 3 main upper |
| Lower crankcase | Four bolts per main journal |

Oil Cooler and Filter Housing

Oil Cooler and Oil Filter Assemblies

Oil Cooler

| | |
|---------------|---------------------------------------|
| Type | Full-flow: 11 fins oil, 11 fins water |
| Heat transfer | 1650 BTU / min / 60° ETD |
| Location | Engine valley (forward) |

Oil Filter

| | |
|------------------------|-----------------------------------|
| Type | Cartridge, full flow - disposable |
| Filtering efficiency | 20 microns and larger |
| Location | Front, oil cooler mounted |
| Filter bypass location | Oil filter return tube assembly |

Engine Electrical Components

Engine Electrical

Glow Plugs

| | |
|-----------------|--------------|
| Applied voltage | 10.9 - 11.1V |
|-----------------|--------------|

Intake Air Heater

| | |
|-----------------|---------|
| Amperage rating | 60 Amps |
|-----------------|---------|

Camshaft Position (CMP) Sensor

| | |
|-----------------|---------------|
| Operating speed | 30 - 3000 rpm |
|-----------------|---------------|

Crankshaft Position (CKP) Sensor

| | |
|--------------------------|-------------------------------|
| Operating actuator speed | 15 to 2,000 rpm |
| Operating temperature | -40 to +130°C (-40 to +266°F) |

Injection Pressure Regulator (IPR) Valve

| | |
|-----------------------------|-------------------------------|
| Operating temperature range | -40 to +220°C (-40 to +428°F) |
| Maximum operating pressure | 28 MPa (4,061 psi) |

High-pressure Oil Pump

IPR Valve and ICP Sensor
Injection Control Pressure (ICP) Sensor

| | |
|--------------------------|------------------------------|
| Operating pressure range | 0 to 30 MPa (0 to 4,350 psi) |
|--------------------------|------------------------------|

Injection Pressure Regulator (IPR) Valve

| | |
|----------------------------|--------------------|
| IPR valve relief pressure | 31 MPa (4,500 psi) |
| IPR valve maximum pressure | 38 MPa (5,500 psi) |

Fuel System

Fuel System Components

Horizontal Fuel Conditioning Module (HFCM)

| | |
|---------------------|---------------------------|
| Electric heater | 150 W |
| Filter efficiency | 10 micron |
| Rated flow capacity | 98 L/hr (26 gph @ 60 psi) |

Secondary Fuel Filter

| | |
|---|---------------------------|
| Filter efficiency | 4 micron |
| Maximum fuel pressure in secondary filter | 400 kPa (58 psi @ 35 gph) |
| Valve unseating pressure | 310 ± 28 kPa (45 ± 4 psi) |

Rear Cover

Flywheel and Rear Cover**Flywheel**

| | |
|---------------------------------------|--------------------|
| Max. flywheel ring gear T.I.R. runout | 1.27 mm (0.050 in) |
|---------------------------------------|--------------------|

Rear Cover

| | |
|--------------------------------|--------------------|
| Rear cover face maximum runout | 0.51 mm (0.020 in) |
|--------------------------------|--------------------|

Table of Contents

| | |
|--|-----|
| General Torque Guidelines..... | 405 |
| Standard Torques..... | 405 |
| Using a Torque Wrench Extension..... | 407 |
| Special Torques..... | 408 |
| Mounting Engine on Stand..... | 408 |
| Dual Turbocharger and Exhaust Tubing..... | 408 |
| Manifolds and Exhaust Gas Recirculation (EGR)..... | 409 |
| Cylinder Head and Valve Train..... | 409 |
| Front Cover, Vibration Damper, and Gerotor Oil Pump..... | 410 |
| Power Cylinder..... | 410 |
| Crankcase, Crankshaft and Camshaft..... | 410 |
| Oil Cooler and Filter Housing..... | 411 |
| Engine Electrical Components..... | 411 |
| High-pressure Oil Pump..... | 411 |
| Fuel System..... | 412 |
| Rear Cover..... | 412 |

General Torque Guidelines

CAUTION: To prevent engine damage, do not substitute fasteners. Original equipment standard hardware is defined as **Class 10.9 metric or Grade 8 standard coarse thread bolts and nuts and hardened flat washers (Rockwell "C" 38-45), all phosphate coated.**

The standard torque charts provide the tightening torque for general purpose applications using original equipment standard hardware as listed in the Parts Catalog for the application involved.

NOTE: Visually inspect parts for cleanliness and obvious defects prior to assembly.

Standard Torques

Standard Torques – Pipe Thread

| Thread Size | Torque ¹ |
|-------------|---------------------|
| 1/8 in NPT | 11 N·m (90 lbf·in) |
| 1/4 in NPT | 14 N·m (120 lbf·in) |
| 3/8 in NPT | 20 N·m (180 lbf·in) |
| 1/2 in NPT | 34 N·m (25 lbf·ft) |
| 3/4 in NPT | 41 N·m (30 lbf·ft) |

¹ Tolerances are ±10% of nominal value.

Standard Torques – Class 10.9 Metric Bolts and Studs









| Thread Diameter | Thread Pitch (mm/thread) | Torque ¹ |
|-----------------|--------------------------|----------------------|
| 6 mm | 1 | 13 N·m (115 lbf·in) |
| 8 mm | 1.25 | 31 N·m (23 lbf·ft) |
| 10 mm | 1.5 | 62 N·m (45 lbf·ft) |
| 12 mm | 1.75 | 107 N·m (79 lbf·ft) |
| 14 mm | 2 | 172 N·m (127 lbf·ft) |
| 15 mm | 2 | 216 N·m (159 lbf·ft) |
| 16 mm | 2 | 266 N·m (196 lbf·ft) |
| 18 mm | 2.5 | 368 N·m (272 lbf·ft) |
| 20 mm | 2.5 | 520 N·m (384 lbf·ft) |

¹ Tolerances are ±10% of nominal value.

Standard Torques – Class 12.9 Metric Bolts and Studs







| Thread Diameter | Thread Pitch (mm/thread) | Torque ¹ |
|-----------------|--------------------------|----------------------|
| 6 mm | 1 | 15 N·m (132 lbf·in) |
| 8 mm | 1.25 | 36 N·m (27 lbf·ft) |
| 10 mm | 1.5 | 72 N·m (53 lbf·ft) |
| 12 mm | 1.75 | 126 N·m (93 lbf·ft) |
| 14 mm | 2 | 201 N·m (148 lbf·ft) |
| 15 mm | 2 | 252 N·m (186 lbf·ft) |
| 16 mm | 2 | 311 N·m (230 lbf·ft) |
| 18 mm | 2.5 | 430 N·m (317 lbf·ft) |
| 20 mm | 2.5 | 608 N·m (448 lbf·ft) |

¹ Tolerances are ±10% of nominal value.

| DESIGNATION | | MATERIAL TYPE | THERMAL TREATMENT | HEAD MARKING | |
|---------------------|-------------|--|---------------------|---|---|
| INTERNATIONAL CLASS | ISO R 898 I | | | PREFERRED | OPTIONAL |
| 5.8 | 5.8 | LOW OR MEDIUM CARBON STEEL | NON REQUIRED |  |  |
| 8.8 | 8.8 | MEDIUM CARBON OR MEDIUM CARBON ALLOY STEEL OR LOW CARBON BORON STEEL | QUENCH AND TEMPERED |  |  |
| 9.8 | – | | |  |  |
| 10.9 | 10.9 | | |  |  |

d31209

Figure 637 Classification and Identification – Metric Fasteners

| INTERNATIONAL DESIGNATION | TYPE OF MATERIAL | THERMAL TREATMENT | HEAD MARKING | |
|------------------------------|--|---|---|---|
| | | | PREFERRED | OPTIONAL |
| CLASS | METRIC FASTENERS | | | |
| 10.9R | MEDIUM CARBON, MEDIUM CARBON ALLOY STEEL | QUENCH AND TEMPERED, ROLL THREADED AFTER HEAT TREATMENT |  |  |
| 12.9 | MEDIUM CARBON ALLOY STEEL | QUENCH AND TEMPERED |  |  |
| 12.9R | | QUENCH AND TEMPERED, ROLL THREADED AFTER HEAT TREATMENT |  |  |

d31210

Figure 638 Classification and Identification – Special Use Fasteners

Many conditions affect torque and the results of torque applications. The major purpose in tightening a fastener to a specified torque is to obtain tension in the fastener (bolt and nut), which in turn develops a clamping load which exceeds any possible loading imposed on parts due to engine rpm or vibration.

New phosphate coated fasteners do not require oil lubrication during assembly and torque application. Reused fasteners (even if originally phosphate coated) do require oil lubrication to the threads and under head area for proper torque application.

Threads that are dry, excessively rough, battered or filled with dirt require considerable effort just to rotate. Then when the clamping load is developed or the bolt tension is applied, the torque reading mounts rapidly (due to thread friction) to the specified torque value. However, the desired bolt tension and maximum clamping effect is not achieved. This condition can lead to failure of the fastener to maintain component integrity. The proper bolt tension and clamping effect can never be attained if the fastener is dry. The fastener threads must have a film of clean lubricant (engine oil) to be considered lubricated.

Using a Torque Wrench Extension

Occasionally the need will arise to use an extension, crowfoot, or other type of adapter with your torque wrench to torque a bolt or line fitting. Sometimes an extension or adapter is necessary to reach a bolt in a hard to reach location. Adding adapters or extensions will alter the actual clamping force at the faster. By using the following formula you can determine what the torque wrench setting should be to achieve the known standard or special torque value.




Figure 639 Torque wrench extension

- F – Force applied by service technician
- L – Length through which force is applied to fastener
- L_E – Length of extension
- L_W – Length of torque wrench
- T_E – Torque applied at fastener
- T_W – Torque applied at end of torque wrench
- T_S – Torque wrench setting

$$T_S = T_E (L_W / (L_W + L_E))$$

Example:

A component has a known torque value of 88 N·m (65 lbf·ft) and an extension is required to reach it. What will the torque wrench setting have to be in order to compensate for the additional extension?

- Torque wrench = 12 inches
- Extension = 6 inches

$$T_S = 65 \text{ lbf·ft} (12 \text{ in} / (12 \text{ in} + 6 \text{ in}))$$

$$T_S = 65 \text{ lbf·ft} (12 \text{ in} / 18 \text{ in})$$

$$T_S = 65 \text{ lbf·ft} (0.666)$$

$$T_S = \mathbf{43.3 \text{ lbf·ft or } 58.9 \text{ N·m}}$$

Special Torques

Mounting Engine on Stand

| Mounting Engine on Stand | |
|--------------------------|--------------------|
| Oil pan drain plug | 44 N·m (32 lbf·ft) |

Dual Turbocharger and Exhaust Tubing

| Turbocharger Related Torque Values | |
|---|------------------------------|
| Air inlet duct hose clamp | 4 to 5 N·m (36 to 48 lbf·in) |
| Boost control solenoid mounting bolt, M6 x 25 | 9 N·m (79 lbf·in) |
| Crossover V-band | 7 N·m (62 lbf·in) |
| EGR cooler inlet V-band clamp | 12 N·m (106 lbf·in) |
| Exhaust tubing bolts (at manifold) ¹ | 27 N·m (20 lbf·ft) |
| Exhaust tubing bolts (at turbocharger) ² | 49 N·m (36 lbf·ft) |
| Low-pressure turbine exhaust outlet studs (3) | 22 N·m (16 lbf·ft) |
| Oil drain tubing bolts | 23 N·m (17 lbf·ft) |
| Oil fill extension tube | 14 N·m (124 lbf·in) |
| Oil supply tube (fittings) | 17 N·m (150 lbf·in) |
| V-clamp | 10 N·m (88 lbf·in) |

¹ Apply anti-seize compound to bolt threads prior to assembly

² Apply anti-seize compound to bolt threads prior to assembly

Manifolds and Exhaust Gas Recirculation (EGR)**Manifolds and Exhaust Gas Recirculation (EGR)**

| | |
|--|--|
| Intake air heater element (cable nut) | 4 N·m (35 lbf·in) |
| Air intake heater (to manifold) | 61 N·m (45 lbf·ft) |
| Coolant deaeration fitting | 10 N·m (90 lbf·in) |
| EGR cooler mounting bolt assembly, M6 | 11 N·m (97 lbf·in) |
| EGR cooler to manifold stud bolts | 11 N·m (97 lbf·in) |
| EGR valve mounting bolts | 11 N·m (97 lbf·in) |
| Exhaust manifold hex flange bolts ¹ | See Exhaust Manifold Torque Sequence (page 106) |
| Intake air elbow, M6 hex flange and stud bolt | 11 N·m (97 lbf·in) |
| Intake manifold bolts, M6 hex flange and stud bolt | 11 N·m (97 lbf·in) (Figure 134) |

¹ Apply anti-seize compound to bolt threads prior to assembly

Cylinder Head and Valve Train**Cylinder Head and Valve Train**

| | |
|---|--|
| Case-to-head tube assembly | 82 N·m (60 lbf·ft) |
| Cylinder head bolt torque and sequence | (Cylinder Head Torque Instructions and Tightening Sequence, page 150) |
| Crankcase breather bolts | 11 N·m (96 lbf·in) |
| Fuel injector hold down bolt | 33 N·m (24 lbf·ft) |
| Glow plugs | 18 N·m (159 lbf·in) |
| Injection Control Pressure (ICP) sensor | 12 N·m (105 lbf·in) |
| Lifting eye, front (M10 x 30) | 41 N·m (30 lbf·ft) |
| Lifting eye, rear (M10 x 35) | 41 N·m (30 lbf·ft) |
| Rocker arm fulcrum plate (M8 x 45) | 31 N·m (23 lbf·ft) |
| Valve cover bolt assemblies (M6) | 9 N·m (84 lbf·in) |

Front Cover, Vibration Damper, and Gerotor Oil Pump

| Front Cover, Vibration Damper, and Gerotor Oil Pump | |
|---|---|
| Water pump / fan drive pulley | 36 N·m (26 lbf·ft) |
| Front cover module bolts | 24 N·m (18 lbf·ft) |
| Nut (heater feed to lifting eye) | 41 N·m (35 lbf·ft) |
| Oil pressure regulator end cap | 27 N·m (240 lbf·in) |
| Gerotor oil pump cover | 13 N·m (110 lbf·in) |
| Thermostat stud bolts | 22 N·m (200 lbf·in) |
| Vibration damper mounting bolts | New bolts only: 68 N·m (50 lbf·ft) + 90° rotation |
| Water pump mounting bolts | 23 N·m (17 lbf·ft) |

Power Cylinder

| Power Cylinder | | |
|------------------------------|---------|--------------------|
| Connecting rod bearing bolts | Initial | 45 N·m (33 lbf·ft) |
| | Final | 68 N·m (50 lbf·ft) |

Crankcase, Crankshaft and Camshaft

| Crankcase, Crankshaft and Camshaft | |
|--|--|
| Lower crankcase main bearing cap bolts | See tightening procedure and sequence (page 242) |
| Coolant heater element or plug | 41 N·m (30 lbf·ft) |
| Crankcase coolant drain plug / O-ring, M16 | 20 N·m (15 lbf·ft) |

Oil Cooler and Filter Housing

Oil Cooler and Oil Filter Assemblies

| | |
|---|---------------------|
| Oil filter base assembly (M6 x 25) | 10 N·m (85 lbf·in) |
| Oil filter base assembly (M8 x 45) | 11 N·m (97 lbf·in) |
| Oil filter base assembly (M8 x 23) | 23 N·m (17 lbf·ft) |
| Oil bypass / filter inlet guide valve (M5 x 18) | 7 N·m (62 lbf·in) |
| Oil cooler mounting bolts (M6 x 25) | 15 N·m (132 lbf·in) |
| Diagnostic valve | 16 N·m (144 lbf·in) |
| Oil filter cap | 25 N·m (18 lbf·ft) |

Engine Electrical Components

Engine Electrical

| | |
|--|---------------------|
| Intake air heater element (cable nut) | 4 N·m (35 lbf·in) |
| Engine Coolant Temperature (ECT) sensor | 18 N·m (158 lbf·in) |
| Engine Oil Temperature (EOT) sensor | 19 N·m (168 lbf·in) |
| Engine Oil Pressure (EOP) switch | 14 N·m (123 lbf·in) |
| Glow plug | 19 N·m (14 lbf·ft) |
| Injection Control Pressure (ICP) sensor | 12 N·m (106 lbf·in) |
| Injection Pressure Regulator (IPR) valve | 50 N·m (37 lbf·ft) |
| Manifold Absolute Pressure (MAP) sensor | 12 N·m (108 lbf·in) |
| Manifold Air Temperature (MAT) sensor | 18 N·m (156 lbf·in) |

High-pressure Oil Pump

High-pressure System Components

| | |
|------------------------------------|--------------------|
| Case-to-head tube | 60 N·m (82 lbf·ft) |
| Injection Pressure Regulator (IPR) | 50 N·m (37 lbf·ft) |
| Prime port plug | 8 N·m (71 lbf·in) |
| High-pressure pump plug | 35 N·m (26 lbf·ft) |

Fuel System

| Fuel System Components | |
|---|------------------------|
| Banjo bolt, 12 mm | 38 N·m (28 lbf·ft) |
| Diagnostic port plug, M12 | 4-9 N·m (35-75 lbf·in) |
| Fuel filter cap (secondary) | 14 N·m (124 lbf·in) |
| Fuel filter housing mounting screws, M6 x 25 | 10 N·m (88 lbf·in) |
| Fuel supply hollow screw, M14 | 35 N·m (26 lbf·ft) |
| Fuel pump mounting screws | 5 N·m (44 lbf·in) |
| Fuel return tube at filter | 25 N·m (19 lbf·ft) |
| Fuel return tube mounting screws, 8/32 x 3/8 | 2-3 N·m (20-25 lbf·in) |
| HFCM cover plate screws | 5 N·m (44 lbf·in) |
| HFCM housing nuts (M8) | 15 N·m (132 lbf·in) |
| Left and right cylinder head supply tubing at filter | 25 N·m (18 lbf·ft) |
| Oil supply tube bolt, M6 x 20 | 13 N·m (120 lbf·in) |
| Plug assembly, M12 (rear of cylinder head) | 36 N·m (27 lbf·ft) |
| Primary filter cap | 25 N·m (18 lbf·ft) |
| Right cylinder head supply tubing anchor at inlet elbow | 11 N·m (96 lbf·in) |

Rear Cover

Flywheel

| | |
|---|---|
| Flywheel mounting bolts, new bolts only | 94 N·m (69 lbf·ft) flywheel torque sequence (Figure 625) |
|---|---|

Table of Contents

| | |
|---|------------|
| Special Service Tools..... | 415 |
| Mounting Engine on Stand..... | 415 |
| Dual Turbocharger and Exhaust Tubing..... | 415 |
| Manifolds and Exhaust Gas Recirculation (EGR)..... | 415 |
| Cylinder Head and Valve Train..... | 416 |
| Front Cover, Vibration Damper, and Gerotor Oil Pump..... | 417 |
| Power Cylinder..... | 417 |
| Crankcase, Crankshaft and Camshaft..... | 418 |
| Oil Cooler and Filter Housing..... | 418 |
| Engine Electrical Components..... | 418 |
| High-pressure Oil Pump..... | 419 |
| Fuel System..... | 419 |
| Rear Cover..... | 419 |
| In Chassis Service..... | 419 |
| Special Tool Photos..... | 420 |
| Photos of Essential Tools from VT 275 Essential Tool Kit, ZTSE5010..... | 420 |
| Photos of Essential Tools from VT 365 Essential Tool Kit, ZTSE5000..... | 422 |
| Photos of Essential Tools from T 444E Essential Tool Kit, ZTSE4350..... | 425 |

Special Service Tools

Special tools for the VT 275 engine can be ordered from the SPX Corporation, 1-800-520-2584.

Mounting Engine on Stand

| Mounting Engine on Stand | |
|-------------------------------|-------------|
| Description | TOOL NUMBER |
| Engine Stand Mounting Bracket | ZTSE4507 |
| Engine Stand | OTC1750A |

Dual Turbocharger and Exhaust Tubing

| Turbocharger | |
|---|----------------|
| Description | Tool Number |
| Cap Kit (all) | ZTSE4610 |
| Dial Indicator with Magnetic Base | Obtain locally |
| Intake Guard | ZTSE4293 |
| Turbo Crossover Tube Seal Remover / Installer | ZTSE4676 |
| Slide Hammer | ZTSE4398A |

Manifolds and Exhaust Gas Recirculation (EGR)

| Manifolds and Exhaust Gas Recirculation (EGR) | |
|--|----------------|
| Description | Tool Number |
| Anti-Seize Compound | Obtain locally |
| Cap Kit (all) | ZTSE4610 |
| EGR Cooler Pressure Test Plates | ZTSE4545 |
| EGR Valve Puller | ZTSE4669 |
| EGR Valve Puller Arm (offset) | ZTSE4685 |
| Feeler Gauge | Obtain locally |
| Intake Manifold Pressure Test Plates | ZTSE4527 |
| Intake Manifold Pressure Test Plug | ZTSE4544 |
| Intake Manifold Pressure Test Cap | ZTSE4682 |
| Magnetic Covers for Cylinder Head Intake Ports | ZTSE4559 |

Cylinder Head and Valve Train

| Cylinder Head and Valve Train | |
|---|--------------------|
| Description | TOOL NUMBER |
| Case-To-Head Tube Removal Tool | ZTSE4694 |
| Cylinder Head Lifting Bracket | ZTSE4661 |
| Cylinder Head Pressure Test Plate | ZTSE4534 |
| Dye Penetrant Kit | PT-7191 |
| Fuel Gallery Cleaning Brush | ZTSE4541 |
| Fuel Injector Hold Down Wrench | ZTSE4524 |
| Fuel Injector Rack Holder | ZTSE4299B |
| Fuel Injector Tip Cleaning Brush | ZTSE4301 |
| Glow Plug Sleeve Brush (nylon) | ZTSE4533 |
| Glow Plug Sleeve Installer | ZTSE4532 |
| Glow Plug Sleeve Remover (consists of: tap, bolt and adapter) | ZTSE4531 |
| Glow Plug Sleeve Seat Wire Brush | ZTSE4589 |
| Head Bolt Bottoming Tap | ZTSE4508 |
| Injector Connector Remover | ZTSE4650 |
| Injector Sleeve Brush | ZTSE43041 |
| Injector Sleeve Flat Bottom Brush | ZTSE43042 |
| Injector Sleeve Installer | ZTSE4529 |
| Injector Sleeve Remover (consists of: tap and adapter) | ZTSE4528 |
| Intake Port Covers on Heads | ZTSE4559 |
| Loctite® #620 | Obtain locally |
| Slide Hammer Kit | ZTSE4398A |
| Straightedge | Obtain locally |
| Valve Guide Gauge Tool | ZTSE4577 |
| Valve Spring Compressor | ZTSE1846 |
| Valve Spring Tester | Obtain locally |

Front Cover, Vibration Damper, and Gerotor Oil Pump

| Front Cover, Vibration Damper, and Gerotor Oil Pump | |
|---|----------------|
| Description | Tool Number |
| Dial Indicator with Magnetic Base | Obtain locally |
| Fan Hub Wrench (2 inch) | ZTSE43972 |
| Fan Wrench (pulley bolts) | ZTSE4587 |
| Front Seal / Wear Sleeve Installer | ZTSE4680 |
| Front Wear Sleeve Remover | ZTSE4517 |
| Liquid Gasket (RTV) (6 oz. tube) | 1830858C1 |
| Loctite® Hydraulic Sealant | Obtain locally |

Power Cylinder

| Power Cylinder | |
|-----------------------------------|----------------|
| Description | Tool Number |
| Dial Indicator with Magnetic Base | Obtain locally |
| Feeler Gauge | Obtain locally |
| Piston Gauge Pins (0.082 in) | ZTSE4513 |
| Piston Ring Compressor (Cope) | ZTSE4514 |
| Piston Ring Expansion Pliers | Obtain locally |
| Telescoping Gauge Set | Obtain locally |

Crankcase, Crankshaft and Camshaft

| Crankcase, Crankshaft and Camshaft | |
|---|--------------------|
| Description | Tool Number |
| Camshaft Bushing Kit | ZTSE2893B |
| Camshaft Bushing Remover/Installer (expanding collet) | ZTSE4489 |
| Crankshaft Timing Tool | ZTSE4687 |
| Cylinder Bore Gauge | Obtain locally |
| De-glazing Hone (four-inch) | Obtain locally |
| Dial Indicator with Magnetic Base | Obtain locally |
| Feeler Gauge | Obtain locally |
| Freeze Plug Installer | ZTSE4509 |
| Front Seal/Wear Sleeve Installer | ZTSE4680 |
| Front Wear Sleeve Remover | ZTSE4517 |
| Head Bolt Bottoming Tap | ZTSE4508 |
| Loctite® #242 Threadlocker | Obtain locally |
| Loctite® #620 Compound | Obtain locally |
| Micrometer, 2-3 in | Obtain locally |
| Micrometer, 3-4 in | Obtain locally |
| Oil Gallery Cleaning Brush | ZTSE4511 |
| Oil Gallery Plug Driver | ZTSE4512 |
| Straightedge | Obtain locally |
| Telescoping Gauge Set | Obtain locally |

Oil Cooler and Filter Housing

| Oil Cooler Cover Assembly | |
|----------------------------------|--------------------|
| Description | Tool Number |
| Magnetic Covers | ZTSE4557 |
| Oil Cooler Pressure Test Plate | ZTSE4525 |

Engine Electrical Components

| Engine Electrical | |
|---|--------------------|
| Description | Tool Number |
| Glow Plug Connector Remover / Installer | ZTSE4670 |
| IPR Valve Socket | ZTSE4666 |

High-pressure Oil Pump

| High-pressure System | |
|---------------------------------|--------------------|
| Description | Tool Number |
| IPR Valve Socket | ZTSE4666 |
| Liquid Gasket (RTV, 6 oz. tube) | 1830858C1 |
| #10 Quick Release Tool | ZTSE4581 |

Fuel System

| Fuel System Tools | |
|--------------------------|--------------------|
| Description | Tool Number |
| Cap Kit (all) | ZTSE4610 |
| Turbocharger Inlet Guard | ZTSE4293 |

Rear Cover

| Flywheel and Rear Cover | |
|--|--------------------|
| Description | Tool Number |
| Dial Indicator with Magnetic Base | Obtain locally |
| Liquid Gasket (RTV) (6 oz. tube) | 1830858C1 |
| Loctite® Hydraulic Sealant | Obtain locally |
| Rear Seal/Wear Sleeve Installer ¹ | ZTSE4515A |
| Rear/Wear Sleeve Removal Tool | ZTSE4518 |
| Slide Hammer | ZTSE4398A |

¹ **CF** bolts - M10 x 40, **Stripped Chassis** bolts - M10 x 70

In Chassis Service

| In Chassis Service | |
|--|--------------------|
| Description | Tool Number |
| Fuel Injector Hold Down Wrench | ZTSE4524 |
| Quick Release Tool kit | ZTSE4454 |
| Fuel Injector Rack Holder | ZTSE4299B |
| Injector Connector Remover | ZTSE4650 |
| On Engine Valve Spring Compressor Tool | ZTSE4697 |

Special Tool Photos

Photos of Essential Tools from VT 275 Essential Tool Kit, ZTSE5010



Figure 640 Injector Connector Remover, ZTSE4650




Figure 642 IPR Valve Socket, ZTSE4666



Figure 643 Glow Plug Connector Remover, ZTSE4670




Figure 641 Cylinder Head Lifting Bracket, ZTSE4661




Figure 644 Turbo Crossover Tube Seal Remover and Installer, ZTSE4676



Figure 645 Front Seal Installer / Wear Sleeve Installer, ZTSE4680




Figure 647 Intake Manifold Pressure Test Cap, ZTSE4682



Figure 646 Quick Release Tool (#8 and #10), ZTSE4581



Figure 648 EGR Valve Puller, ZTSE4685




Figure 649 Crankshaft Timing Tool, ZTSE4687




Figure 650 Case-to-Head Tube Removal Tool, ZTSE4694

Photos of Essential Tools from VT 365 Essential Tool Kit, ZTSE5000




Figure 651 Piston Gauge Pins (0.082 in), ZTSE4513



Figure 652 Crankshaft Rear Seal / Wear Sleeve Installer, ZTSE4515A




Figure 653 Front Wear Sleeve Remover, ZTSE4517



Figure 654 Crankshaft Rear Wear Sleeve Remover, ZTSE4518




Figure 655 Oil Cooler Test Plate / Pressure Adapter, ZTSE4525




Figure 656 Intake Manifold Test Plates, ZTSE4527



Figure 657 Injector Sleeve Remover, ZTSE4528



Figure 658 Injector Sleeve Installer, ZTSE4529



Figure 659 Glow Plug Sleeve Remover, ZTSE4531



Figure 660 Glow Plug Sleeve Installer, ZTSE4532




Figure 661 Glow Plug Sleeve Brush (nylon), ZTSE4533




Figure 662 Cylinder Head Pressure Test Plate, ZTSE4534



Figure 663 Intake Manifold Pressure Test Plug (EGR Valve), ZTSE4544




Figure 664 EGR Cooler Test Plates, ZTSE4545




Figure 665 Oil Cooler Reservoir / High-pressure Pump Magnetic Covers, ZTSE4557




Figure 666 Magnetic Covers for Cylinder Head Intake Ports, ZTSE4559



Figure 667 Fan Wrench (pulley bolts), ZTSE4587



Figure 668 Slide Hammer Kit 5/8 in, ZTSE4398A




Figure 670 Crankshaft Secondary Flange Installation Studs, ZTSE4720



Figure 669 V - Engines Supplemental Service Tool Kit, ZTSE4721



Figure 671 On Engine Valve Spring Compressor, ZTSE4697

Photos of Essential Tools from T 444E Essential Tool Kit, ZTSE4350




Figure 672 Injector Tip Cleaning Brush, ZTSE4301




Figure 673 Injector Sleeve Brush, ZTSE43041



Figure 675 Fan Hub Wrench (2 inch), ZTSE43972



Figure 674 Injector Sleeve Flat Bottom Brush, ZTSE43042

Printed in the United States of America