

2.OLED display normally when booting.

Before you start Jetbotmini, the OLED will not display if the WiFi network card is not plugged in.
After plugging in the WiFi network card, restart Jetbotmini, the OLED will display normally.