

User Manual

Samsung 7 kg Fully-Automatic Top Loading Washing Machine

[Samsung website](#)

Table of Contents

Introduction :-

\

A washing machine (laundry machine, clothes washer, washer, or simply wash) is a home appliance used to wash laundry. The term is mostly applied to machines that use water as opposed to dry cleaning (which uses alternative cleaning fluids and is performed by specialist businesses) or ultrasonic cleaners.

Before purchase

Look out for the SAFETY Mark when purchasing washing machines and check that the registration number is valid by entering either the model number or the 8-digit registration number into the Register of Registered Controlled Goods.

Prevent overloading of the washer or dryer by buying one that caters to your family's laundry capacity.

Ensure that the plugs supplied are suitable for local use.

Ensure that qualified personnel carry out the installation of the washer or dryer.

During use

Keep the area around the washer or dryer free from combustible items.

Always read the instruction manual and follow the directions given to ensure proper usage and maintenance.

Ensure that the machines are properly ventilated and the exhaust vents are not obstructed.

Clean the lint filter before and after each load of laundry.

Refer to the operating instructions prior to washing or drying a clothing that has been soiled with substances such as oil or paint.

Always engage the authorized servicing agent or supplier to conduct regular servicing, repairs or when there are signs of faults or defects.

General Safety Precautions:-

Before cleaning or carrying out maintenance, unplug the appliance from the electrical outlet or set the (On/Off) button to Off.

- Make sure that the pockets of all clothing to be washed are empty. Hard, sharp objects, such as coins, safety pins, nails, screws, or stones can cause extensive damage to the appliance.
- Always unplug the appliance and turn off the water after use.

- Before you open the door of the appliance, check that the water has drained. Do not open the door if you can still see water.
- Pets and small children may climb into the appliance. Check the appliance before each use.
- The glass door becomes very hot during the washing cycle. Keep children away from the appliance while it is in use.
- Do not attempt to repair the appliance yourself. Repairs made by inexperienced or unqualified persons may cause injury and/or make more serious repairs to the appliance necessary.
- If the plug (power supply cord) is damaged, it must be replaced by the manufacturer or its service agent or a similar qualified person in order to avoid a hazard.

Electrical Safety

Before cleaning or carrying out maintenance, unplug the appliance from the electrical outlet or set the (On/Off) button to Off. Make sure that the pockets of all clothing to be washed are empty.

General safety :-

Keep children away during installation of the washing machine . Keep the packaging materials (plastic bags, polystyrene parts, etc .) out of reach of children, during and after the installation of the washing machine . Use protective gloves to perform all unpacking and installation operations .

Installation guidance for washing machine :-

Choose the right spot. Depending on your living situation, you may be limited in your options of places to put a washing machine. However, you should try to find a spot that will reduce the risk of uneven loads, leaks, and potential damage to your appliance or your home. It is also important to have access to hot and cold water, a drain and an electrical outlet that can support your washer and dryer.

Before washer installation can begin, you must remove your old washing machine.

Check the drum to ensure the washing machine is empty.

Turn off the washing machine and unplug it.

Pull the machine away from the wall to give you access to its water supply valves. Turn off both the hot- and cold-water valves.

With a bucket or pan ready to catch any water still in the supply hoses, disconnect the supply lines. You may need to use pliers or a wrench to loosen and remove the hoses.

Remove the waste-water hose by simply pulling it out of its entry spot in the wall or floor.

Warranty and Support:-

Consider Typical Warranty Periods

If your appliance breaks down within 30 days of purchase, you can be certain it's still under warranty. In fact, the store you bought it from may accept an exchange or return. Call to inquire about the store's return policy to make sure.

Most manufacturers offer a 1-year warranty, so if it's been less than 12 months since you purchased the appliance, it's most likely still covered.

Check Your Receipt or User's Manual

Generalities are useful for determining whether even to bother looking for the receipt or user's manual. Just remember, even if it's been over a year, you may have purchased an extended warranty or other insurance services. The best way to find out for sure is to check product documentation. This is why it's important to hold onto receipts and user's manuals for major appliances and other high-ticket items.

Check the Manufacturer's Website

If you can't find the paperwork for your appliance purchase, the manufacturer's website is the next best place to look. Here, you can verify the length of the limited warranty and discover extended warranty information. This may jog your memory if you're trying to recall whether you purchased extended coverage or not.

Contact the Retailer

To retrieve specific details about your transaction, try contacting the retailer. You can also ask about customer rewards programs you might be a part of that provide an extended warranty or return period.

Look into Your Credit Card's Consumer Protection Package

Did you purchase your appliance with a credit card? Many credit card companies offer free extended warranty coverage up to one year past the manufacturer's warranty period as part of their consumer protection package. Contact your credit card company to learn if this applies to you.

Schedule Appliance Repair Today

Whether your appliance warranty is valid or not, you still need to have your machine fixed. Leaving the job to a professional technician at Mr. Appliance is your best option, not only because you prevent voiding an active warranty, but because you enjoy reliable services you can count on.

And speaking of warranties, our repairs come with a 1-year parts and labour warranty for your peace of mind. This way, you never need to worry about us installing a faulty part or performing substandard work. Instead, we go above and beyond to provide you with the best-quality parts and exceptional customer service!

Any Doubts please contact
samsung.machines.com