

Realtek Wi-Fi SDK for Android O 8.x
ver. 1.0.1

Contents

Release History	2
Introduction	3
1. Copy Necessary Files into SDK.....	4
2. Platform Related Files	4
2.1. BoardConfig.mk.....	4
2.2. init.xxx.rc.....	6
2.3. Others.....	8
3. System Resource Configurations	9
4. wpa_supplicant_8	11
5. Driver Configurations for Android 8.0	11
6. FAQ	13
6.1. Wi-Fi (STA mode)	13
6.1.1. Why Wi-Fi can't enable?	13
6.2. Portable Wi-Fi hotspot (AP mode)	14
6.2.1. Why Portable Wi-Fi hotspot can't enable?	14
6.3. Wi-Fi Direct (P2P mode).....	14
6.3.1. There is no Wi-Fi Direct UI shown?	14
6.3.2. Wi-Fi Direct can't scan any peer?	14

Release History

1.0.0	2017/08/25	1. First formal release
1.0.1	2018/02/26	1. Support wifi_hal

Realtek

SDK packages

- I hardware/realtek/*
Folder to store private code from Realtek.

Introduction

This document provides a simple guide to help engineers to apply Realtek Wi-Fi solution onto their Android O 8.0 system. For now, we have supported the following two scenarios:

- I **STA/AP** – Switch between STA mode and AP mode
- I **(STA+P2P)/AP** – Switch between STA+P2P(Wi-Fi Direct) concurrent mode and AP mode

To port Realtek Wi-Fi driver onto Android 8.0 platform, you can go through the following guide with reference codes within our driver package's [realtek_wifi_SDK_for_android_O_8.0_20180227.tar.gz](#).

Because Android's SDK may differ from platform to platform, our reference codes may not be applied on every platform without modifications. You should check if our reference code is suitable for you to use.

In this document, ANDROID_SDK is the path of top folder of the target Android SDK; this term is used in the following paragraphs.

1. Copy Necessary Files into SDK

After unzipping [realtek_wifi_SDK_for_android_O_8.0_20180227.tar.gz](#), copy the following folder into ANDROID_SDK/hardware/folder:

- 1 hardware/realtek

2. Platform Related Files

2.1. BoardConfig.mk

To apply Realtek Wi-Fi solution onto your Android 8.0 system, you need to define some compile-time variables in BoardConfig.mk of your platform. In general, the BoardConfig.mk file is located in:

ANDROID_SDK /device/<soc_vendor_name>/<board_name>/

Take Hikey board for example:

ANDROID_SDK/device/linaro/hikey/BoardConfigCommon.mk

```

BOARD_WIFI_VENDOR := realtek
ifeq ($(BOARD_WIFI_VENDOR), realtek)
    WPA_SUPPLICANT_VERSION := VER_0_8_X
    BOARD_WPA_SUPPLICANT_DRIVER := NL80211
    BOARD_WPA_SUPPLICANT_PRIVATE_LIB := lib_driver_cmd_rtl
    BOARD_HOSTAPD_DRIVER := NL80211
    BOARD_HOSTAPD_PRIVATE_LIB := lib_driver_cmd_rtl

    BOARD_WLAN_DEVICE := realtek
endif

```

I BOARD_WIFI_VENDOR := realtek

To distinguish the platform Wi-Fi device from products of other vendors, we define variable BOARD_WIFI_VENDOR as realtek. This is for compile-time choices to be applied for Realtek Wi-Fi solutions.

I WPA_SUPPLICANT_VERSION := VER_0_8_X

For Android L, please set WPA_SUPPLICANT_VERSION as VER_0_8_X to

use wpa_supplicant_8.

```
I BOARD_WPA_SUPPLICANT_DRIVER := NL80211
I BOARD_WPA_SUPPLICANT_PRIVATE_LIB := lib_driver_cmd_rtl
I BOARD_HOSTAPD_DRIVER          := NL80211
I BOARD_HOSTAPD_PRIVATE_LIB     := lib_driver_cmd_rtl
```

We use NL80211 as the driver interface for wpa_supplicant and hostapd to communicate with driver and provide lib_driver_cmd_rtl as the private library.

```
I BOARD_WLAN_DEVICE
```

In Android 8.X, BOARD_WLAN_DEVICE is used to choose which vendor wifi_hal should be applied. You have to set **BOARD_WLAN_DEVICE := realtek** to use realtek's wifi_hal.

2.2. init.xxx.rc

For Wi-Fi to operate properly, we need some actions and daemons to be defined as service inside init.xxx.rc. In general, the init.xxx.rc file is located in:

ANDROID_SDK/device/<soc_vendor_name>/<board_name>/

Take Hikey board for example:

ANDROID_SDK/linaro/hikey /init.common.rc

Please add the service definitions below:

1 insmod

Please select one of action definitions below according to your requirement.

Meanwhile, please make sure your **wlan.ko** has right seclabel and mode as

```
-rw-r--r-- 1 root root u:object_r:vendor_file:s0 3429448 1970-01-01 00:19 wlan.ko
```

You can use command “ls -alZ” to check seclabel of wlan.ko.

(For concurrent mode)

```
on boot

exec u:r:vendor_modprobe:s0 root root -- /vendor/bin/toybox_vendor insmod
/vendor/modules/wlan.ko ifname=wlan0 if2name=p2p0
```

(For STA only)

```
on boot

exec u:r:vendor_modprobe:s0 root root -- /vendor/bin/toybox_vendor insmod
/vendor/modules/wlan.ko ifname=wlan0
```

I wpa_supplicant

Please select one of service definitions below according to your requirement.

(For concurrent mode)

```
service wpa_supplicant /system/vendor/bin/hw/wpa_supplicant \  
-ip2p0 -Dnl80211 -c/data/misc/wifi/p2p_supplicant.conf \  
-e/data/misc/wifi/entropy.bin -N \  
-iwlan0 -Dnl80211 -c/data/misc/wifi/wpa_supplicant.conf \  
-O/data/misc/wifi/sockets \  
-g@android:wpa_wlan0  
socket wpa_wlan0 dgram 660 wifi wifi  
class main  
disabled  
oneshot
```

(For STA only)

```
service wpa_supplicant /system/vendor/bin/hw/wpa_supplicant \  
-iwlan0 -Dnl80211 -c/data/misc/wifi/wpa_supplicant.conf \  
-O/data/misc/wifi/sockets \  
-e/data/misc/wifi/entropy.bin -g@android:wpa_wlan0  
socket wpa_wlan0 dgram 660 wifi wifi  
class main  
disabled  
oneshot
```


2.3. Others

For topics mentioned here, you can add the following code segments in any .mk file which your platform will use. Take Hikey board for example:

ANDROID_SDK /device/linaro/hikey/device-common.mk.

I Add wifi related packages

These packages are needed for Wifi support in Android O, please make sure these packages are added in .mk

```
PRODUCT_PACKAGES += \  
libwpa_client wpa_supplicant hostapd wificond wifilogd wpa_supplicant.conf  
hostapd.conf libwifi-hal android.hardware.wifi.suplicant@1.0-service  
android.hardware.wifi@1.0-service
```

I Add android.hardware.wifi.xml

To claim Wi-Fi support for your device, please add the rule in the PRODUCT_COPY_FILES variable to copy the permission definition file of Wi-Fi to the /system/etc/permissions/ folder of your system image.

```
PRODUCT_COPY_FILES += \  
frameworks/native/data/etc/android.hardware.wifi.xml:system/etc/permissions/android.hardware.wifi.xml
```

I Add android.hardware.wifi.direct.xml

To claim Wi-Fi Direct (P2P) support for your device, please add the rule in the PRODUCT_COPY_FILES variable to copy the permission definition file of Wi-Fi Direct to the /system/etc/permissions/ folder of your system image.

```
PRODUCT_COPY_FILES += \  
frameworks/native/data/etc/android.hardware.wifi.direct.xml:system/etc/permissions/android.hardware.wifi.direct.xml
```

Make sure your driver is configured for STA+P2P concurrent mode or you may encounter error when you open the Wi-Fi. Please refer to “**5. Driver Configurations for Android 8.x**”

I Set wifi.interface

To specify the wifi interface name in Android, a system property named “wifi.interface” is used. For Realtek Wi-Fi driver, Wi-Fi interface name is assigned with “wlan%d”. In general, you should set wifi.interface as “wlan0”.

```
PRODUCT_PROPERTY_OVERRIDES += \
    wifi.interface=wlan0
```

I Set wifi.direct.interface

If you require p2p support, you have to set wifi.direct.interface as “p2p0”

```
PRODUCT_PROPERTY_OVERRIDES += \
    wifi.direct.interface=p2p0
```

I Toybox_vendor

In android 8.x, we need toybox_vendor to insmod. If you do not set the config in device.mk
PRODUCT_SHIPPING_API_LEVEL := 26

You should modify \$ANDROID_SDK/external/toybox/Android.mk as below to build toybox_vendor

```
#ifeq ($(PRODUCT_FULL_TREBLE),true)
#####
# static version to be installed in /vendor
#
....
LOCAL_MODULE := toybox_vendor
....
include $(BUILD_EXECUTABLE)
#endif
```

I wifi_hal

To support wifi_hal, you have to patch \$ANDROID_SDK/frameworks/opt/net/wifi/libwifi_hal/Android.mk as below.

```
# Pick a vendor provided HAL implementation library.
# =====
LIB_WIFI_HAL := libwifi-hal-fallback
....
else ifeq ($(BOARD_WLAN_DEVICE), realtek)
# support RTK WIFI HAL
LIB_WIFI_HAL := libwifi-hal-rtk
endif
....
```

I Device manifest file

The Device manifest file is provided by the device. It lives in the Android source tree at device/\${VENDOR}/\${DEVICE}/manifest.xml and on the device at /vendor/manifest.xml

RTK wifi needs **IWifi** and **ISupplicant**. Please check device/\${VENDOR}/\${DEVICE}/manifest.xml, It should have IWifi and ISupplicant description as below.

```
<hal format="hidl">
  <name>android.hardware.wifi</name>
  <transport>hwbinder</transport>
  <version>1.0</version>
  <interface>
    <name>IWifi</name>
    <instance>default</instance>
  </interface>
</hal>
<hal format="hidl">
  <name>android.hardware.wifi.supPLICANT</name>
  <transport>hwbinder</transport>
  <version>1.0</version>
  <interface>
    <name>ISupplicant</name>
    <instance>default</instance>
  </interface>
</hal>
```

3. System Resource Configurations

You should set the following four resource configurations for your platform to configure the network function and enable the corresponding UI interface. In general, you can set the following configurations in your platform dependent config.xml file. Take Hikey board for example:

ANDROID_SDK/device/linaro/hikey/overlay/frameworks/base/core/res/res/values/config.xml

Or the global config.xml file:

ANDROID_SDK/frameworks/base/core/res/res/values/config.xml

I networkAttributes

To define the system's available network interfaces, make sure the wifi interface items is defined in the networkAttributes resource configuration in the config.xml.

For example:

```
<string-array translatable="false" name="networkAttributes">
  <item>"wifi,1,1,1,-1,true"</item>
  <item>"bluetooth,7,7,0,-1,true"</item>
  <item>"ethernet,9,9,2,-1,true"</item>
</string-array>
```

I radioAttributes

To define the system's available network interfaces, we need to define interface items for wifi in the radioAttributes resource configuration. For example:

```
<string-array translatable="false" name="radioAttributes">
    <item>"1,1"</item>
    <item>"7,1"</item>
    <item>"9,1"</item>
</string-array>
```

I config_tether_wifi_regexs

The interfaces set here are tetherable Wi-Fi interfaces which will be used as interfaces for Wi-Fi LAN port. We use 'wlan0' by default when our Wi-Fi is set as softap mode. So it needs to set 'wlan0' here. For example:

```
<string-array translatable="false" name="config_tether_wifi_regexs">
    <item>"wlan0"</item>
</string-array>
```

I config_tether_upstream_types

The connection types set here are used as the interfaces for WAN port to connect to internet. For example, adding Wi-Fi and Ethernet:

```
<integer-array translatable="false" name="config_tether_upstream_types">
    <item>1</item>
    <item>9</item>
</integer-array>
```

At least one item should be declared here to enable the “Tethering & portable hotspot” option of WirelessSettings in Settings.apk.

To know the definition and set other upstream connection types, please refer to `ANDROID_SDK/frameworks/base/core/java/android/net/ConnectivityManager.java`.

I config_enableWifiDisplay

To enable Wi-Fi Display(Miracast) function, set `config_enableWifiDisplay` to true:

```
<bool name="config_enableWifiDisplay">true</bool>
```

4. wpa_supplicant_8

We provide [wpa_supplicant_8_O_8.x_rtw_r24597.20171025.tar.gz](#) or newer version in the wpa_supplicant_hostapd/ of our SW release package. You can:

I Use the [wpa_supplicant_8_O_8.0_rtw_xxxx](#) instead of the original

1. Backup and remove the original external/wpa_supplicant_8/ folder
2. Extract and copy the [wpa_supplicant_8_O_8.0_rtw_xxxx](#) tar file to the external/ folder of your Android SDK.
3. Rename [wpa_supplicant_8_O_8.0_rtw_xxxx](#) as [wpa_supplicant_8](#).

5. Driver Configurations for Android 8.x

Android 8.x support two scenarios for Wi-Fi solution:

I STA/AP – Switch between STA and AP mode

I (STA+P2P)/AP – Switch between STA+P2P concurrent and AP mode

The configuration of driver to fit the requirement of each scenario, see the following table:

MACRO	STA /AP	(STA+P2P)/AP	Kernel ver.
CONFIG_IOCTL_CFG80211	Defined	Defined	ver. >= 2.6.35
RTW_USE_CFG80211_STA_EVENT	Defined	Defined	ver. >= 3.2.0
CONFIG_RADIO_WORK	Defined	Defined	-
CONFIG_CONCURRENT_MODE	Undefined	Defined	-
RTW_ENABLE_WIFI_CONTROL_FUNC	Defined for platform device/driver mechanism		
CONFIG_RTW_WIFI_HAL	Defined if android version >= 8.x		

I **CONFIG_IOCTL_CFG80211** is used for driver to enable cfg80211 ioctl interface, which is required by Realtek Wi-Fi to operate on Android 8.0 system.

- I **RTW_USE_CFG80211_STA_EVENT** is used for driver to indicate new cfg80211 STA event, which is required by wpa_supplicant_8 of Android 8.0. Linux kernel supports this feature after kernel 3.2. For kernel version between 3.0 and 3.2, please refer to the patch file:
linux-3.0.42_STATION_INFO_ASSOC_REQ_IES.diff
- I **CONFIG_RADIO_WORK** is used for driver to fit 'radio work' mechanism of Android 8's wpa_supplicant_8. If this MACRO doesn't exist in driver's source code, please contact with Realtek technical windows for suitable driver.
- I **CONFIG_CONCURRENT_MODE** is used for driver to enable concurrent mode, which is required by STA+P2P concurrent mode of Android 8.0.
- I **RTW_ENABLE_WIFI_CONTROL_FUNC** is used to register platform driver callbacks. If your platform needs those callbacks, please define this macro to register platform driver callback functions. For example, these functions include:

```
static struct platform_driver wifi_device = {
    .probe          = wifi_probe,
    .remove         = wifi_remove,
```

By default, the probe callback is used to set up Wi-Fi power and remove callback is used to close Wi-Fi power.

To compile Realtek Wi-Fi driver with the above setting, please refer to the following document:

[document/Quick_Start_Guide_for_Driver_Compilation_and_Installation.pdf](#)

Adding platform selection and setting sections for compilation settings of your platform.

For example, if you want to configure Realtek Wi-Fi driver for the (STA+P2P)/AP scenario, make sure the macros: CONFIG_IOCTL_CFG80211, RTW_USE_CFG80211_STA_EVENT, **CONFIG_RADIO_WORK** and CONFIG_CONCURRENT_MODE are defined into the EXTRA_CFLAGS settings as following:

```

CONFIG_PLATFORM_ANDROID_M60_SAMPLE = y
...
...
...
ifeq ($(CONFIG_PLATFORM_ANDROID_ML0_SAMPLE), y)
EXTRA_CFLAGS += -DCONFIG_LITTLE_ENDIAN
EXTRA_CFLAGS += -DCONFIG_CONCURRENT_MODE
EXTRA_CFLAGS += -DCONFIG_IOCTL_CFG80211 -DRTW_USE_CFG80211_STA_EVENT
EXTRA_CFLAGS += -DCONFIG_RADIO_WORK
ARCH := arm
CROSS_COMPILE := /toolchain/bin/arm-none-linux-gnueabi-
KSRC := / android_sdk/android_1/ kernel
endif

```

- I **CONFIG_RTW_WIFI_HAL** is defined if android version is $\geq 8.x$:
For supporting Android version $\geq 8.x$, make sure **CONFIG_RTW_WIFI_HAL** is set to “y” in **Makefile** as follows,

```

...
CONFIG_RTW_WIFI_HAL = y
...

```

6. FAQ

6.1. Wi-Fi (STA mode)

6.1.1. Why Wi-Fi can't enable?

The whole Wi-Fi enabling procedure includes the following three main check points. Please check in sequence:

I Is network interface(s) created?

- n** insmod driver success
- n** Wi-Fi device is recognized
- n** wlan0 is created

I Does wpa_supplicant run successfully?

- n** wpa_supplicant.conf (and p2p_supplicant.conf) exists and is correct
- n** Service definition of wpa_supplicant exists and is correct
- n** Binary file wpa_supplicant exists and is executable

I Do connections of communication socket setup?

- n** Make sure the communication socket settings is matched below:
 - u** ctrl_interface in:
/data/misc/wifi/wpa_supplicant.conf
(and /data/misc/wifi/p2p_supplicant.conf)
 - u** Service definition of wpa_supplicant
 - u** Paths of communication socket in wifi.c

6.2. Portable Wi-Fi hotspot (AP mode)

6.2.1. Why Portable Wi-Fi hotspot can't enable?

The whole Portable Wi-Fi hotspot enabling procedure includes the following three main check points. Please check in sequence:

- I Is network interface created?**
 - n** insmod driver success
 - n** Wi-Fi device is recognized
 - n** wlan0 is created

- I Does netd and hostapd run successfully?**
 - n** /data/misc/wifi/hostapd.conf exists and is correct
 - n** Binary file netd and hostapd exist and are executable

- I Does dnsmasq run successfully?**
 - n** Binary file dnsmasq exist and are executable

6.3. Wi-Fi Direct (P2P mode)

6.3.1. There is no Wi-Fi Direct UI shown?

Please refer to “**Add android.hardware.wifi.direct.xml**” in chapter **2.3. Others** to enable Wi-Fi Direct functionality of Android O.

6.3.2. Wi-Fi Direct can't scan any peer?

First, make sure you have workable Wi-Fi Direct device nearby. Make them into Wi-Fi Direct scanning state. Push “SEARCH FOR DEVICES” button also in our device and wait for a while.

If there is still no peer shown the problem is usually caused by wrong service definition of wpa_supplicant services. Please refer to “**wpa_supplicant**” in chapter **2.2. init.xxx.rc** to check your service definition of wpa_supplicant.