

Proview Installation Guide Ubuntu

Release Ubuntu 9.04

System Requirements:

Platform: x86


Kernel >= 2.6.27

glibc >= 2.8-0ubuntu7


P ackage pwr46

Download the development package pwr46 and save to disk. It is saved in the Desktop catalog by default and viewed with an icon on the desktop.

Doubleclick on the pwr46 package icon to install the development package.



Click on the Install Package button to start the installation.



Login as user pwrp and start the Project Administrator by clicking on the Proview desktop icon. If you are new to Proview, read the Proview Getting Started Guide available at www.proview.se

Package pwrdemo

Download the pwrdemo package and save to disk. It is saved in the Desktop catalog by default and viewed with an icon on the desktop.

Doubleclick on the pwrdemo package icon to install the demo project.

Click on the Install Package button to start the installation.

When the installation is finished, login as user pwrp and click on the Pwrdemo icon on the desktop.

The runtime monitor for the demoproject is now started. Start the runtime environment by clicking on the 'Start Runtime' button.




Fig Runtime monitor

When the label has switched from 'Down' to 'Running' activate *File/Start Operator Environment* in the menu. The operator window is now opened.




Fig Operator window

Acknowledge the alarms by clicking on the tick buttons to the left (this will remove the beep). Activate the PwrDemo, LevelControl and TemperatureControl buttons to view the demo project graphs.

Package pwrtrt

Download the pwrtrt package and save to disk. It is stored in the Desktop catalog by default and viewed with an icon on the desktop.

Doubleclick on the pwrtrt package icon to install the runtime package.

The runtime package should be installed "stand-alone" without the pwr46-package.

A linux-system with the pwrtrt-package is your control- or HMI-system. Proview will be started automatically at boot-time.

Package pwrsev

Install mysql-client and mysql-server.

Download the pwrsev package and save to disk. It is stored in the Desktop catalog by default and viewed with an icon on the desktop.

Doubleclick on the pwrsev package icon to install the package.

The storage environment package should be installed "stand-alone" without the pwr46 or pwrrt package.