

Troubleshoot the Kinetix 6200 and Kinetix 6500 Drive System

This chapter provides troubleshooting tables for your Kinetix® 6200 and Kinetix 6500 system components.

Topic	Page
Safety Precautions	187
Interpret Status Indicators	188
General System Anomalies	200
Logix 5000 Controller and Drive Behavior	202

Safety Precautions

Observe the following safety precautions when troubleshooting your Kinetix 6200 and Kinetix 6500 drive.



ATTENTION: Capacitors on the DC bus may retain hazardous voltages after input power has been removed. Before working on the drive, measure the DC bus voltage to verify it has reached a safe level or wait the full time interval as indicated in the warning on the front of the drive. Failure to observe this precaution could result in severe bodily injury or loss of life.



ATTENTION: Do not attempt to defeat or override the drive fault circuits. You must determine the cause of a fault and correct it before you attempt to operate the system. Failure to correct the fault could result in personal injury and/or damage to equipment as a result of uncontrolled machine operation.



ATTENTION: Provide an earth ground for test equipment (oscilloscope) used in troubleshooting. Failure to ground the test equipment could result in personal injury.

Interpret Status Indicators

Refer to these troubleshooting tables to identify faults, potential causes, and the appropriate actions to resolve the fault. If the fault persists after attempting to troubleshoot the system, please contact your Rockwell Automation sales representative for further assistance.

Kinetix 6000M IDM System Error Codes

The IAM module reports a single, generic IPIM Fault whenever a fault occurs on any IPIM in the same backplane as the IAM module. All IPIM faults result in an open contactor. The Logix Axis Tag for this fault is IPIMFault.

The IPIM module is not a Sercos device, so the IAM module reports any IPIM faults to the Logix motion subsystem. IPIM faults are reset by performing a fault reset on the IAM module. Issuing a fault reset command to the IAM module also generates a fault reset to all the IPIM modules in the same backplane as the IAM. Detailed information about the IPIM fault status may be obtained by messaging to the IAM module.

Connecting the IPIM module into the Logix environment as an EtherNet/IP device does not disable fault reporting through the IAM module. Only the IAM fault reporting lets the Logix motion sub-system take action based on the IPIM module fault status. IPIM faults are also reported to Logix over the Ethernet connection. However, IPIM faults must be reset by applying a fault reset instruction to the IAM module. The integration of the IPIM module into the Logix environment through the EtherNet/IP network provides additional capabilities you may choose to take advantage of in your Logix program.

Refer to the Kinetix 6000M Integrated Drive-Motor System User Manual, publication [2094-UM003](#), for more information on troubleshooting the IDM drive-motor system.

Four-character Display Messages

The control modules include a four-character display for status and fault messages. The display scrolls to display long text strings.

The Four-character Display Messages table lists the messages along with their priorities. When messages of different priorities need to be displayed, for example, when the drive has both a fault and an alarm, only the higher priority message is displayed. When messages of equal priority are needed, for example, when there is more than one fault, the messages are displayed in a round-robin fashion.

The IP address is displayed only once after powerup and an IP address has been acquired. The safety signature ID is displayed for 20 seconds when a new safety configuration is applied from the safety configuration tool.

Refer to the table on [page 181](#) for a description of the messages that scroll across the display during powerup.

Table 87 - Four-character Display Messages

Drive Condition	Display String			Priority	Maximum Number of Messages Displayed
	Auxiliary Feedback Not Configured as Feedback Only	Auxiliary Feedback Configured as Feedback Only			
	Axis 1	Axis 1	Axis 2		
IP Address Display ⁽¹⁾	IP = xxx.xxx.xxx.xxx			1	2
Sercos Node Address Display ⁽²⁾	Sercos NODE = xx			1	2
Safety Signature ID ⁽³⁾	SAFETY SIGNATURE = xxxxxxxx				
Firmware Upgrade	FIRMWARE UPDATE			2	2
Decelerating to a Stop as a Result of a Fault	ABORTING		Refer to footnote ⁽⁴⁾		
Initialization Fault - Std. and Fault Code ⁽⁵⁾	INIT FLT Sxx	X1:INIT FLT Sxx	X2:INIT FLT Sxx	3	4 ⁽⁶⁾
Initialization Fault - Mfg. and Fault Code ⁽⁵⁾	INIT FLT Mxx	X1:INIT FLT Mxx	X2:INIT FLT Mxx		
Safety Fault ⁽⁵⁾	SAFE FLT xx		Refer to footnote ⁽⁴⁾		
Node Fault ⁽⁵⁾	NODE FLT xx		Refer to footnote ⁽⁴⁾		
Major Fault - Std. and Fault Code ⁽⁵⁾	FLT Sxx	X1:FLT Sxx	X2:FLT Sxx		
Major Fault - Mfg. and Fault Code ⁽⁵⁾	FLT Mxx	X1:FLT Mxx	X2:FLT Mxx	4	3 ⁽⁷⁾
Minor Fault - Std. and Fault Code ⁽⁵⁾	FLT Sxx	X1:FLT Sxx	X2:FLT Sxx		
Minor Fault - Mfg. and Fault Code ⁽⁵⁾	FLT Mxx	X1:FLT Mxx	X2:FLT Mxx		
Inhibit - Std. and Fault Code ⁽⁵⁾	INHIBIT Sxx		Refer to footnote ⁽⁴⁾	5	2
Inhibit Fault - Mfg. and Fault Code ⁽⁵⁾	INHIBIT Mxx		Refer to footnote ⁽⁴⁾		
Safe Limited Speed	SAFE LIMITED SPEED		Refer to footnote ⁽⁴⁾	6	10
Power-up ⁽⁸⁾	'BOOT'...'INIT'...'LOAD'...'DONE'...'BOOT'...'INIT'...'DONE'...'LOAD'...'TEST'...FW Version: X.XXX				
Waiting for CIP™ connection	STANDBY				
Connecting	CONNECTING				
Configuring Drive Attributes	CONFIGURING				
Synchronizing ⁽¹⁾	SYNCING				
Waiting for DC-bus Up	PRE-CHARGE				
Drive has been Shutdown	SHUTDOWN		Refer to footnote ⁽⁴⁾		
Drive Axis has Stopped	STOPPED		Refer to footnote ⁽⁹⁾		
Drive is Starting	STARTING		Refer to footnote ⁽⁴⁾		
Drive is Running	RUNNING		Refer to footnote ⁽⁴⁾		
Drive is Executing a Test Procedure	TESTING		Refer to footnote ⁽⁴⁾		
Decelerating to a Stop as a Result of a Disable	STOPPING		Refer to footnote ⁽⁴⁾		
Alarm Fault - Standard Fault Code ⁽⁵⁾	ALARM Sxx	X1:ALARM Sxx	X2:ALARM Sxx		
Alarm Fault - Mfg. Specific Fault Code ⁽⁵⁾	ALARM Mxx	X1:ALARM Mxx	X2:ALARM Mxx		
Node Alarm	NODE ALARM xx		Refer to footnote ⁽⁴⁾		

(1) Applies to only 2094-EN02D-M01-Sx EtherNet/IP control modules.

(2) Applies to only 2094-SE02F-M00-Sx Sercos control modules.

(3) Applies to only 2094-xx02x-M0x-S1 (Safe Speed Monitor) control modules.

(4) Condition not supported by auxiliary feedback-only axis.

(5) A short descriptive string follows the displayed code.

(6) One node fault, two initialization, safety, major, or minor faults for axis 1, and one initialization, major, or minor fault for axis 2.

(7) One node fault, one initialization, safety, major, or minor faults for axis 1, and one initialization, major, or minor fault for axis 2.

(8) Text in single quotation marks, 'BOOT' for example, is shown one word at a time (not scrolled).

(9) Condition not displayed.

Fault Codes

These fault code tables are designed to help you resolve anomalies. When a fault is detected, the four-character status indicator scrolls the display message. This is repeated until the fault code is cleared.

For information on troubleshooting SAFE FLT fault codes, refer to the Kinetix 6200 and Kinetix 6500 Safe Speed Monitoring Safety Reference Manual, publication [2094-RM001](#).

Table 88 - Fault Code Summary

Fault Code Type	Description
FLT Sxx	Standard runtime anomalies.
FLT Mxx	
INIT FLT Sxx	Anomalies that prevent normal operation and occur during the initialization process.
INIT FLT Mxx	
NODE FLTxx	Anomalies that prevent normal operation of all drives on the power rail.
NODE ALARM xx	Anomalies that prevent normal operation of all drives on the power rail, but do not result in any action other than reporting the alarm to the controller.
INHIBIT Sxx	Conditions that prevent normal operation and indicate that the drive module is prevented from being enabled.
INHIBIT Mxx	
ALARM Sxx	Warnings of conditions that may affect normal operation, but do not result in any action other than reporting the alarm to the controller.
ALARM Mxx	



Fault codes triggered by conditions that fall outside factory-set limits are identified by FL at the end of the display message. For example, FLT S03...MTR OVERSPEED FL.

Fault codes triggered by conditions that fall outside user-set limits are identified by UL at the end of the display message. For example, FLT S04...MTR OVERSPEED UL.

Table 89 - FLT Sxx Fault Codes

Four-character Display Message	Logix Designer Fault Message	Problem or Symptom	Potential Cause	Possible Resolution
FLT S02...MTR COMMUTATION	Illegal Hall State	State of Hall feedback inputs is incorrect.	Improper connections.	<ul style="list-style-type: none"> Check Hall wiring at motor feedback (MF) connector. Check 5V power supply to the encoder.
FLT S03...MTR OVERSPEED FL	Motor Overspeed	Motor speed has exceeded 125% of maximum rated speed.		<ul style="list-style-type: none"> Check cables for noise. Check tuning.
FLT S04...MTR OVERSPEED UL (Kinetix 6500 drives only)	Motor Overspeed	Motor speed has exceeded user velocity limits.		
FLT S05...MTR OVERTEMP FL nn	Motor Overtemperature	The motor thermostat, motor thermistor, or encoder temperature sensor indicates that the motor factory temperature limit has been exceeded. The nn sub-code is defined as follows:	High motor ambient temperature and/or Excessive Current.	<ul style="list-style-type: none"> Operate within (not above) the continuous torque rating for the ambient temperature. Lower ambient temperature or increase motor cooling.
		01: Motor Thermostat or Thermistor.	Motor wiring error.	Check motor wiring at motor feedback (MF) connector.
		02: Encoder Temperature Sensor.	Incorrect motor selection.	Verify the proper motor has been selected.
FLT S06...MTR OVERTEMP UL nn (Kinetix 6500 drives only)	Motor Overtemperature	The motor thermostat, motor thermistor, or encoder temperature sensor indicates that the motor factory temperature limit has been exceeded. The nn sub-code is defined as follows:	High motor ambient temperature and/or Excessive Current.	<ul style="list-style-type: none"> Operate within (not above) the continuous torque rating for the ambient temperature. Lower ambient temperature or increase motor cooling.
		01: Motor Thermostat or Thermistor.	Motor wiring error.	Check motor wiring at motor feedback (MF) connector.
		02: Encoder Temperature Sensor.	Incorrect motor selection.	Verify the proper motor has been selected.
FLT S07...MTR OVERLOAD FL	Motor Thermal Protection	The thermal model for the motor indicates that the temperature has exceeded 110% of its rating.	The machine duty cycle requires an RMS current exceeding the continuous rating of the motor.	Change the command profile to reduce speed or increase time.
FLT S08...MTR OVERLOAD UL (Kinetix 6500 drives only)	Motor Thermal Protection	The thermal model for the motor indicates that the temperature has exceeded a user programmable limit.		

Table 89 - FLT Sxx Fault Codes (continued)

Four-character Display Message	Logix Designer Fault Message	Problem or Symptom	Potential Cause	Possible Resolution
FLT S10...INV OVERCURRENT	IPM Fault	The IPM fault output indicates that the power transistors were turned off because of overcurrent, overtemperature, or power supply problems.	Motor cables shorted.	Verify continuity of motor power cable and connector.
			Motor winding shorted internally.	Disconnect motor power cables from the motor. If the motor is difficult to turn by hand, it may need to be replaced.
			The drive temperature is too high.	<ul style="list-style-type: none"> Check for clogged vents or defective fan. Make sure cooling is not restricted by insufficient space around the unit. Verify ambient temperature is not too high.
			Operation above continuous power rating and/or product environmental ratings.	<ul style="list-style-type: none"> Operate within the continuous power rating. Reduce acceleration rates. Reduce deceleration rates.
			The drive has a short circuit, overcurrent, or failed component.	Remove all power and motor connections, and perform a continuity check from the DC bus to the U, V, and W motor outputs. If a continuity exists, check for wire fibers between terminals, or send drive in for repair.
FLT S11...INV OVERTEMP FL	Inverter Overtemperature	Inverter thermal switch tripped.	IAM or AM power module fan failed.	Replace the failed module.
			The cabinet ambient temperature is above rating.	Check the cabinet temperature.
			The machine duty cycle requires an RMS current exceeding the continuous rating of the inverter.	Change the command profile to reduce speed or increase time.
			The airflow access to the drive system is limited or blocked.	Check airflow and re-route cables away from the drive system.
FLT S13...INV OVERLOAD FL	Inverter Thermal Protection	The thermal model for the power transistors indicates that the temperature has exceeded 110% of its rating.	The machine duty cycle requires an RMS current exceeding the continuous rating of the inverter.	Change the command profile to reduce speed or increase time.
FLT S14...INV OVERLOAD UL (Kinetix 6500 drives only)	Inverter Thermal Protection	The thermal model for the power transistors indicates that the temperature has exceeded the user-programmable limit.		
FLT S16...GROUND CURRENT	Ground Fault	Excessive ground current was detected in the converter.	Wiring error.	<ul style="list-style-type: none"> Check motor power wiring. Check input power wiring.
			Motor internal ground short.	Replace motor.
			Internal malfunction.	Disconnect motor power cable from drive and enable drive with current limit set to 0. If fault clears, then a wiring error or motor internal anomaly exists. If fault remains, call your sales representative.
FLT S18...CONV OVERTEMP FL	Converter Overtemperature	Converter thermal switch tripped.	Excessive heat exists in the power circuitry.	<ul style="list-style-type: none"> Reduce acceleration rates. Reduce duty cycle (ON/OFF) of commanded motion. Increase time permitted for motion. Use larger IAM power module. Check for clogged vents or defective fan. Make sure cooling is not restricted by insufficient space around the unit.
FLT S20...CONV OVERLOAD FL	Converter Thermal Protection	The thermal model for the converter indicates that the temperature has exceeded its rating.	Excessive current is being drawn by the power circuitry.	<ul style="list-style-type: none"> Reduce acceleration rates. Reduce duty cycle (ON/OFF) of commanded motion. Increase time permitted for motion. Use larger IAM power module.
FLT S21...CONV OVERLOAD UL (Kinetix 6500 drives only)	Converter Thermal Protection	The thermal model for the converter indicates that the temperature has exceeded a user-programmable limit.		
FLT S22...AC POWER LOSS	AC Power Loss	All three AC input phases are detected as absent when an axis is enabled.	Axis was enabled when main (three-phase) power was removed.	Disable axis before removing power.
FLT S23...AC PHASE LOSS nn	AC Phase Loss	Some, but not all AC input phases are detected as absent. The nn sub-code is defined as follows: 01: L1 is missing. 02: L2 is missing. 03: L3 is missing.	Faulty AC line control equipment.	Check input AC voltage on all phases.
FLT S25...PRECHARGE FAILURE	Pre-charge Failure	The converter precharge circuit detected that the DC bus did not reach an appropriate voltage level after charging for a period of time.	Low AC input voltage.	Check input AC voltage on all phases
			Internal malfunction.	Call your sales representative.

Table 89 - FLT Sxx Fault Codes (continued)

Four-character Display Message	Logix Designer Fault Message	Problem or Symptom	Potential Cause	Possible Resolution
FLT S29...SHUNT OVERLOAD FL	Shunt Thermal Protection	The thermal model for the shunt circuitry indicates that the temperature has exceeded its rating.		<ul style="list-style-type: none"> Use a properly sized shunt or modify duty cycle of the application. System uses internal shunt and requires external shunt for additional capacity.
FLT S30...SHUNT OVERLOAD UL (Kinetix 6500 drives only)	Shunt Thermal Protection	The thermal model for the shunt circuitry indicates that the temperature has exceeded a user-programmable limit.		
FLT S31...SHUNT MODULE	Shunt Module Fault	The shunt module in a multi-axis system has a fault.	Over-temperature fault indicator on Bulletin 2094 shunt module is steady red.	Refer to Temperature Fault Status Indicator on page 200.
			Shunt-fault indicator on Bulletin 2094 shunt module is steady red.	Refer to Shunt Fault Status Indicator on page 200.
			Bulletin 2094 shunt module is missing from power rail.	Install missing module on power rail. Fill empty slot with slot-filler module.
FLT S33...BUS UNDERVOLT FL	Bus Undervoltage	With three-phase power present, the DC bus voltage is below limits. DC bus voltage fell below the undervoltage limit while an axis on the follower power rail was enabled.	DC bus voltage for 460V system is below 275V.	<ul style="list-style-type: none"> Verify voltage level of the incoming AC power. Check AC power source for glitches or line drop. Install an uninterruptible power supply (UPS) on your AC input. Disable follower axis before removing power.
FLT S34...BUS UNDERVOLT UL (Kinetix 6500 drives only)	Bus Undervoltage	The DC bus voltage is measured below a user limit when the DC bus was expected to be charged.		
FLT S35...BUS OVERVOLT FL	Bus Overvoltage	The DC bus voltage is measured above a factory limit.	Excessive regeneration of power.	Change the deceleration or motion profile.
			When the motor is driven by an external mechanical power source, it may regenerate too much peak energy through the drive power supply. The system faults to save itself from an overload.	Use a larger system (motor and drive).
			DC bus voltage for 460V system is over 820V.	Install shunt module.
FLT S38...FUSE BLOWN	Blown Fuse (Bus Loss)	A blown fuse was detected in the power structure.	Blown fuse.	Call your Rockwell Automation sales representative to return module for repair.
FLT S41...MTR AQB STATE FL	Motor Feedback State Error	The number of illegal state transitions of the AQB encoder signals has exceeded a factory limit.	The motor feedback wiring is open, shorted, or missing.	<ul style="list-style-type: none"> Use shielded cables with twisted pair wires. Route the feedback away from potential noise sources. Check the system grounds. Replace the motor/encoder.
FLT S41...AUX AQB STATE FL	Aux Feedback State Error		The auxiliary feedback wiring is open, shorted, or missing.	
FLT S42...MTR AQB STATE UL	Motor Feedback State Error	The number of illegal state transitions of the AQB encoder signals has exceeded a user limit.	The motor feedback wiring is open, shorted, or missing.	<ul style="list-style-type: none"> Use shielded cables with twisted pair wires. Route the feedback away from potential noise sources. Check the system grounds. Replace the motor/encoder.
FLT S42...AUX AQB STATE UL	Aux Feedback State Error		The auxiliary feedback wiring is open, shorted, or missing.	
FLT S43...MTR FDBK LOSS FL	Feedback Loss	<ul style="list-style-type: none"> On sin/cos encoders, the sum of the square of the sin/cos signals has been measured below a factory limit. On TTL encoders, the absolute value of the differential A/B signals is below a factory limit. 	The motor feedback wiring is open, shorted, or missing.	<ul style="list-style-type: none"> Check motor encoder wiring. Run Hookup test in the Logix Designer application.
FLT S43...AUX FDBK LOSS FL			The auxiliary feedback wiring is open, shorted, or missing.	
FLT S44...MTR FDBK LOSS UL (Kinetix 6500 drives only)	Motor Feedback Loss	<ul style="list-style-type: none"> On sin/cos encoders, the sum of the square of the sin/cos signals has been measured below a user limit. On TTL encoders, the absolute value of the differential A/B signals is below a user limit. 	The motor feedback wiring is open, shorted, or missing.	<ul style="list-style-type: none"> Check motor encoder wiring. Run Hookup test in the Logix Designer application.
FLT S44...AUX FDBK LOSS UL (Kinetix 6500 drives only)	Aux Feedback Loss		The auxiliary feedback wiring is open, shorted, or missing.	
FLT S45...MTR FDBK COMM FL	Feedback Serial Comms	The number of consecutive missed or corrupted serial data packets from the feedback device has exceeded a factory set limit.	Communication was not established with an intelligent encoder.	<ul style="list-style-type: none"> Verify motor selection. Verify the motor supports automatic identification. Verify motor encoder wiring. Consult Possible Solutions for FLT S47
FLT S45...AUX FDBK COMM FL				
FLT S46...MTR FDBK COMM UL (Kinetix 6500 drives only)	Motor Fdbk Serial Comms	The number of consecutive missed or corrupted serial data packets from the feedback device has exceeded a user set limit.	Communication was not established with an intelligent encoder.	<ul style="list-style-type: none"> Verify motor selection. Verify the motor supports automatic identification. Verify motor encoder wiring.
FLT S46...AUX FDBK COMM UL (Kinetix 6500 drives only)	Aux Feedback Serial Comms			

Table 89 - FLT Sxx Fault Codes (continued)

Four-character Display Message	Logix Designer Fault Message	Problem or Symptom	Potential Cause	Possible Resolution
FLT S47...MTR ENC SELF TEST nn	Feedback Self Test	The Hiperface feedback device has detected an internal error. The nn sub-code is defined as follows: 01: INCORRECT ALIGNMENT DATA 02: INCORRECT INTERNAL ANGULAR OFFSET 03: DATA FIELD PARTITIONING TABLE DESTROYED 04: ANALOG LIMIT VALUES NOT AVAILABLE 05: INTERNAL I2C BUS INOPERATIVE 06: INTERNAL CHECKSUM ERROR 07: ENCODER RESET OCCURRED AS A RESULT OF PROGRAM MONITORING 08: COUNTER OVERFLOW 09: PARITY ERROR 10: CHECKSUM OF TRANSMITTED DATA IS INCORRECT 11: UNKNOWN COMMAND CODE 12: NUMBER OF TRANSMITTED DATA IS INCORRECT 13: TRANSMITTED COMMAND ARGUMENT IS NOT ALLOWED 14: THE SELECTED DATA FIELD MAY NOT BE WRITTEN TO 15: INCORRECT ACCESS CODE 16: SIZE OF SPECIFIED DATA FIELD CANNOT BE CHANGED 17: SPECIFIED WORD ADDRESS LIES OUTSIDE THE DATA FIELD 18: ACCESS TO NON-EXISTENT DATA FIELD 28: VALUE MONITORING OF THE ANALOG SIGNALS (process data) 29: TRANSMITTER CURRENT CRITICAL (contamination, transmitter breakage) 30: ENCODER TEMPERATURE CRITICAL 31: SPEED TOO HIGH, NO POSITION FORMATION POSSIBLE 32: SINGLETURN POSITION UNRELIABLE 33: MULTITURN POSITION ERROR 34: MULTITURN POSITION ERROR 35: MULTITURN POSITION ERROR		<ul style="list-style-type: none"> Check motor feedback cable for proper connectivity and continuity Check motor phasing (U, V, W) and Hiperface feedback 15-pin wire connections at the drive Review Electrical Noise Reduction on page 36 <ul style="list-style-type: none"> See bonding painted panels on page 37 See wire-braid bonding on page 38 Cycle control power Check feedback shield connection Reduce shock and vibration to motor Upgrade firmware, revision 2.045 or later (Kinetix 6200 drives) Upgrade firmware, revision 2.010 or later (Kinetix 6500 drives) Replace motor if fault continues
FLT S47...AUX ENC SELF TEST nn				
FLT S50...POS HW OTRAVEL	Hardware Overtravel - Positive	Axis moved beyond the physical travel limits in the positive direction.	Dedicated overtravel input is inactive.	<ul style="list-style-type: none"> Check wiring. Verify motion profile. Verify axis configuration in software.
FLT S51...NEG HW OTRAVEL	Hardware Overtravel - Negative	Axis moved beyond the physical travel limits in the negative direction.		
FLT S52...POS SW OTRAVEL (Kinetix 6200 drives only)	Software Overtravel - Positive	Axis position exceeded maximum software setting.		<ul style="list-style-type: none"> Verify motion profile. Verify overtravel settings are appropriate.
FLT S53...NEG SW OTRAVEL (Kinetix 6200 drives only)	Software Overtravel - Negative			
FLT S54...POSN ERROR	Excessive Position Error	Position error limit was exceeded.	Improperly sized drive or motor.	<ul style="list-style-type: none"> Increase the feed forward gain. Increase following error limit or time. Check position loop tuning. Verify sizing of system.
			Mechanical system out of specifications.	<ul style="list-style-type: none"> Verify mechanical integrity of system within specification limits. Check motor power wiring.
FLT S55...VEL ERROR nn	Excessive Velocity Error	The velocity error has exceeded a limit for a period of time. The nn sub-code is defined as follows: 00: Velocity error referenced to the velocity loop feedback. 01: Velocity error referenced to the nonvelocity feedback (in dual-feedback configurations).	Improperly sized drive or motor.	<ul style="list-style-type: none"> Increase velocity error limit or time. Check velocity loop tuning. Verify sizing of system.
			Mechanical system out of specifications.	<ul style="list-style-type: none"> Verify mechanical integrity of system within specification limits. Check motor power wiring. Reduce acceleration.
FLT S56...OVERTORQUE (Kinetix 6500 drives only)	Overtorque Limit	Motor torque has exceeded a user-programmable setting.	<ul style="list-style-type: none"> Overly aggressive motion profile Mechanical binding 	<ul style="list-style-type: none"> Verify motion profile. Verify Overtorque settings are appropriate. Verify sizing of system. Verify torque offset
			Mechanical system out of specifications.	<ul style="list-style-type: none"> Verify mechanical integrity of system within specification limits.
FLT S57...UNDERTORQUE (Kinetix 6500 drives only)	Undertorque Limit	Motor torque has fallen below a user-programmable setting.	<ul style="list-style-type: none"> Improperly configured limit Improperly configured motion Improperly drive/motor sizing 	<ul style="list-style-type: none"> Verify motion profile. Verify Overtorque settings are appropriate. Verify sizing of system.
			Mechanical system out of specifications.	<ul style="list-style-type: none"> Verify mechanical integrity of system within specification limits.
FLT S60...ILLEGAL MODE	Illegal Control mode	An illegal mode of operation was attempted.	Axis 1 was configured for dual feedback or load feedback with Axis 2 also configured for Feedback Only operation, but with different feedback attribute values.	<ul style="list-style-type: none"> Use Aux Feedback for one axis only. Verify Axis 1 and Axis 2 have identical feedback configuration for aux feedback.

Table 89 - FLT Sxx Fault Codes (continued)

Four-character Display Message	Logix Designer Fault Message	Problem or Symptom	Potential Cause	Possible Resolution
FLT S61...ENABLE INPUT	Drive Enable Input	The hardware enable input was deactivated while the drive was enabled.	An attempt was made to enable the axis through software while the Drive Enable hardware input was inactive. The Drive Enable input transitioned from active to inactive while the axis was enabled.	Disable the Drive Enable Input fault. Verify that Drive Enable hardware input is active whenever the drive is enabled through software.
FLT S62...CONTROLLER (Kinetix 6500 drives only)	Controller Initiated Exception	The controller has requested the drive to generate an exception.	User configured software overtravel	<ul style="list-style-type: none"> Move axis out of soft overtravel range. Clear soft overtravel fault. Check soft overtravel configuration. Consult controller documentation.

Table 90 - FLT Mxx Fault Codes

Four-character Display Message	Logix Designer Fault Message	Problem or Symptom	Potential Cause	Possible Resolution
FLT M01...SELF SENSING	Self-sensing Startup Fault	The self-sensing commutation start-up algorithm failed.	Extremely light or heavy load on the motor.	Clear faults and re-try.
			Mechanical obstruction.	<ul style="list-style-type: none">• Reduce friction.• Check for mechanical obstruction.
FLT M02...MOTOR VOLTAGE	Motor Voltage Mismatch	Motor voltage incompatible with drive voltage.	Check the Logix Designer configuration.	Correct the Logix Designer configuration.
			Wrong motor connected to drive.	Connect appropriate motor to drive.
FLT M04...MTR FDBK FILTER nn (Kinetix 6500 drives only)	Motor Feedback Filter	Excessive levels of noise have been detected by the digital feedback filter. The nn field is defined as follows: 01: Sine or A channel 02: Cosine or B channel	The motor feedback wiring is open, shorted, or missing.	<ul style="list-style-type: none">• Use shielded cables with twisted pair wires.• Route the feedback away from potential noise sources.• Check the system grounds.• Replace the motor/encoder.
FLT M04...AUX FDBK FILTER nn (Kinetix 6500 drives only)	Aux Feedback Filter		The auxiliary feedback wiring is open, shorted, or missing.	
FLT M05...MTR FDBK BATT LOSS	Motor Encoder Battery Loss	The battery voltage on a battery-backed motor encoder is low enough such that absolute position is no longer available.	Weak battery or poor battery connection.	<ul style="list-style-type: none">• Replace battery.• Check battery connection.
FLT M06...MTR FDBK BATT LOW	Motor Encoder Battery Caution	The battery voltage on a battery-backed motor encoder is below a caution level.		
FLT M07...MTR INCR LOSS	Motor Incremental Position Loss	The periodic check of the incremental encoder position against the absolute encoder position or Hall edges (when available) indicates they are out of tolerance.	The motor feedback wiring is open, shorted, or missing.	<ul style="list-style-type: none">• Check motor encoder wiring.• Run Hookup test in the Logix Designer application.
FLT M07...AUX INCR LOSS	Aux Incremental Position Loss		The auxiliary feedback wiring is open, shorted, or missing.	
FLT M10...CTRL OVERTEMP FL	Control Module Overtemperature	The control module temperature has exceeded its limit.	Cabinet ambient temperature has exceeded 50 °C (122 °F).	Reduce cabinet ambient temperature.
FLT M11...CTRL OVERTEMP UL (Kinetix 6500 drives only)	Control Module Overtemperature	The control module temperature has exceeded a user limit.		
FLT M12...POWER CYCLE FL	Pre-charge Overload	The converter estimates that the precharge circuit has exceeded its limit due to excessive power cycling.	The DC bus power has been cycled too frequently.	Limit power cycles to two per minute maximum.
FLT M13...POWER CYCLE UL (Kinetix 6500 drives only)	Pre-charge Overload	The converter estimates that the precharge circuit is approaching its user-defined limit due to excessive power cycling.		
FLT M14...CURR FDBK OFFSET	Excessive Current Feedback Offset	Current feedback hardware fault detected.		Replace the power module.
FLT M15...REGEN PWR SUPPLY	Regenerative Power Supply Fault	The hardware Regeneration OK input was deactivated while the drive was enabled.	Regen unit faulted.	Reset faulted regen unit.
FLT M18...TORQUE PROVE FAILURE (Kinetix 6500 drives only)	Torque Prove Failure	Torque prove test has failed.	One or more phases of motor wiring is open or incorrect.	Check motor power wiring.
FLT M19...DC BUS LIMIT	DC Bus Limited Position Error	During a DC bus limit condition, the position error exceeded a user limit for a programmable period of time.	Excessive load drawn from DC bus by application.	Modify application to reduce loading on DC Bus. Increase converter size to provide additional bus capacity.
FLT M25...COMMON BUS	DC Common Bus Fault	AC Power was detected by the drive while configured for Common Bus Follower operation.	Improper configuration or connection.	Check IAM power configuration and wire accordingly.
FLT M26...RUNTIME ERROR	Runtime Drive Error	The drive firmware encountered an unrecoverable runtime error.		Cycle control power. Replace Module

Table 90 - FLT Mxx Fault Codes (continued)

Four-character Display Message	Logix Designer Fault Message	Problem or Symptom	Potential Cause	Possible Resolution
FLT M27...BACKPLANE COMM	Backplane COM	Communication over the backplane detected a problem.	Electrical Noise.	Cycle control power.
			Poor module connection.	With power off, reseal power module in rail and control module in power module.
			Faulty module.	Replace module.
FLT M28...SAFETY COMM	Internal Safety Communication	Communication with the safety hardware within the drive malfunctioned.		Cycle control power. Replace module.
FLT M64...SENSOR ASSIGNMENT	No Quick View message	<ul style="list-style-type: none"> The Home, Registration1, or Registration2 digital input function has been requested but is not assigned to an input. Multiple inputs have been assigned the same function. 		Assign proper function to the four available digital inputs.
FLT M68...IPIM	IPIM Module Fault	A fault has occurred in one or more IPIM modules on the power rail.		Refer to the troubleshooting chapter in the Kinetix 6000M Integrated Drive-Motor System User Manual, publication 2094-UM003 .

Table 91 - INIT FLT Fault Codes

Four-character Display Message	Logix Designer Fault Message	Problem or Symptom	Potential Cause	Possible Resolution
INIT FLT S03...NVMEM CHKSUM	User Non-volatile Memory Checksum	Data in the user nonvolatile memory has a checksum error.	Non-volatile memory is corrupt due to control board software error.	<ul style="list-style-type: none"> Cycle power or reset the drive. Contact your Rockwell Automation sales representative and return module for repair.
INIT FLT M01...ENCODER DATA	Smart Encoder Data Corruption Fault	The motor data stored in a smart encoder has a checksum error.	Faulty intelligent encoder.	<ul style="list-style-type: none"> Cycle power or reset the drive. Replace motor if faulting continues.
INIT FLT M02...MTR DATA RANGE nn	Motor Data Range Error	Data within a motor data blob is out of range. The nn sub-code is defined as follows: 01: Memory map revision of the blob is not supported by the firmware. 02: Rated current is out of range. 03: Peak current is out of range. 04: Rated power is out of range. 05: Overload limit is out of range. 06: Thermal capacitance is out of range. 07: Thermal resistance is out of range. 08: Motor resistance is out of range. 09: Motor inductance is out of range. 10: Inertia is out of range. 11: Rated speed is out of range. 12: Max speed is out of range. 13: Rated torque is out of range. 14: Torque constant is out of range. 15: Back EMF is out of range. 16: Pole pitch is out of range. If there is error in the blob that comes from the controller then 50 is added to the subcode.	Faulty intelligent encoder or incorrect motor file.	<ul style="list-style-type: none"> Cycle power or reset the drive. Check validity of the motion database. Replace motor if faulting continues.
INIT FLT M03...MTR ENC STARTUP	Motor Feedback Communication Startup	Communication with a smart encoder could not be established on the motor feedback port.	Incorrect motor selected or connected.	Check motor selection.
			Faulty wiring.	Check motor encoder wiring.
INIT FLT M03...AUX ENC STARTUP	Auxiliary Feedback Communication Startup	Communication with a smart encoder could not be established on the auxiliary feedback port.	Incorrect motor selected or connected.	Check motor selection.
			Faulty wiring.	Check motor encoder wiring.
INIT FLT M04...MTR ABS SPEED	Motor Absolute Encoder Overspeed Fault	Excessive speed was detected in the motor battery-backed encoder while power was off.	High motor speed while power was off.	Clear faults and re-home.
INIT FLT M05...MTR ABS TRAVEL	Motor Absolute Encoder Power-off Travel	The power-off travel range of the motor battery-backed encoder has been exceeded.	Large travel distance while power was off.	Clear faults and re-home.
INIT FLT M06...MTR ABS STARTUP	Motor Absolute Startup Speed	The motor absolute encoder was not able to accurately determine the position after powerup due to motor speed greater than 100 rpm.	Mechanical movement of machine causing excessive rotation of motor during powerup.	Allow machine motion to stop before powerup.
INIT FLT M07...COMMUTATION OFFSET (Kinetix 6500 drive only)	Uninitialized Commutation Offset	The commutation offset stored in a third-party motor has not been initialized.	Third party motors do not contain Rockwell Automation® motor data.	Run Commutation Test from the Logix Designer application.
INIT FLT M12...INVALID KCL REV	Invalid KCL revision	The FPGA image is incompatible with hardware operation.		<ul style="list-style-type: none"> Flash control module with correct firmware. Replace module.
INIT FLT M13...INVALID BSP REV	Invalid BSP revision	The board support package is incompatible with hardware operation.		<ul style="list-style-type: none"> Flash control module with correct firmware. Replace module.

Table 91 - INIT FLT Fault Codes (continued)

Four-character Display Message	Logix Designer Fault Message	Problem or Symptom	Potential Cause	Possible Resolution
INIT FLT M14...SAFETY FIRMWARE	Invalid Safety Firmware	The loaded Safety firmware is not a valid revision for the rev of drive firmware.		Flash control module with correct revision of safety firmware.
INIT FLT M19...VOLTAGE MISMATCH	Voltage Mismatch on Power Rail	The IAM detected that both 230V and 460V modules have been installed on the same power rail.		Replace the mismatched AM module with one that matches the IAM module.
INIT FLT M20...UNKNOWN MODULE	Unknown Axis on Backplane	Unknown module is detected on the modular backplane.	Faulty Module.	<ul style="list-style-type: none"> Recycle control power. Replace module.
INIT FLT M21...FACTORY CFG	Factory Configuration	Factory Configuration Data is missing or invalid.	Defective memory in module.	Replace defective module.
INIT FLT M22...ILLEGAL ADDRESS	Illegal Node Switch Setting	AM Node Address is out of range (>254).	IAM node switch set such that an AM node address is greater than 254.	Select IAM node address that permits all AM node addresses to be less than 254.
INIT FLT M23...SERIES MISMATCH	Series Mismatch on Power Rail	Sercos and EtherNet/IP control modules exist on the same power rail.		Replace the mismatched control module.
INIT FLT M24...OPEN SLOT	Open Power Rail Slot	IAM detects an open slot on the power rail.	Missing module or bent pins on module.	<ul style="list-style-type: none"> Check control pin on back of module. Install slot filler module in open slot.
INIT FLT M32...MTR KEYING nn (Kinetix 6200 drives only)	Motor Keying Fault	The attached motor model does not match the model in the axis configuration. The nn sub-code is defined as follows: 01: Encoder communication expected but not operational. 02: Feedback type does not match. 03: Motor ID does not match. 04: Single-turn resolution does not match.	Incorrect motor selected from motor database.	Verify motor selection in Axis Properties configuration.
INIT FLT M33...ENABLE UNASSIGNED (Kinetix 6200 drives only)	Enable Input Not Assigned	The enable function has been requested for use but has not been assigned to a digital input.		Assign an available digital input as Enable.
INIT FLT M34...OTRAVEL UNASSIGNED (Kinetix 6200 drives only)	Overtravel Input Not Assigned	The positive or negative overtravel function has been requested for use but has not been assigned to a digital input.		Assign an available digital input for the desired overtravel function.
INIT FLT M35... NAND FLASH nn	Storage failure	The nn sub-code is defined as follows: 01: Main application storage failed. 02: Log file storage failed. 03: Web file storage failed.	Faulty memory component.	<ul style="list-style-type: none"> Recycle control power or reset the drive. Replace control module if problem persists.

Table 92 - NODE FLT Fault Codes

Four-character Display Message	Logix Designer Fault Message	Problem or Symptom	Potential Cause	Possible Resolution
NODE FLT 01...LATE CTRL UPDATE (Kinetix 6500 drives only)	Control Update Fault	Several consecutive updates from the controller have been lost.	Excessive network traffic.	<ul style="list-style-type: none"> Remove unnecessary network devices from the motion network. Change the network topology so that fewer devices share common paths. Use faster/higher performance network equipment.
			Noisy environment.	<ul style="list-style-type: none"> Segregate signal wiring from power wiring. Use shielded cables. Add snubbers to power devices.
NODE FLT 02...PROC WATCHDOG	Processor Watchdog Fault	The watchdog circuit monitoring processor operation detected a problem.		<ul style="list-style-type: none"> Recycle control power or reset the drive. Replace control module if problem persists.
NODE FLT 03...HARDWARE nn	Hardware Fault	The drive has an internal hardware problem. The nn sub-code is defined as follows:		<ul style="list-style-type: none"> Recycle control power or reset the drive. Replace power module or power rail if problem persists
		01: Invalid slot ID.	Faulty power rail or power module.	
		02: Cannot read slot ID.		<ul style="list-style-type: none"> Recycle control power or reset the drive. Replace control module if problem persists.
		03: Nonvolatile write to memory failed.	Faulty memory component.	
		04: Nonvolatile memory read failed.		
NODE FLT 04...DATA FORMAT ERROR (Kinetix 6200 drives only)	Data Format Error	A data format error was discovered in the controller-to-drive message.	Faulty memory component.	<ul style="list-style-type: none"> Recycle control power or reset the drive. Replace control module if problem persists.
NODE FLT 06...LOST CTRL CONN (Kinetix 6500 drives only)	Lost Controller Connection	communication with the controller have been lost	<ul style="list-style-type: none"> Faulty Ethernet cable. Ethernet cable disconnected. 	Check Ethernet connection.
			Controller lost power.	Check controller operation.
NODE FLT 08...LOGIC WATCHDOG (Kinetix 6500 drives only)	Custom Logic Update Timeout	The watchdog circuit monitoring custom logic operation detected a problem.	Faulty control module.	<ul style="list-style-type: none"> Recycle control power or reset the drive. Replace control module if problem persists.

Table 92 - NODE FLT Fault Codes (continued)

Four-character Display Message	Logix Designer Fault Message	Problem or Symptom	Potential Cause	Possible Resolution
NODE FLT 09...IP ADDRESS (Kinetix 6500 drives only)	Duplicate IP Address	This drive and another EtherNet device on the same subnet have identical IP addresses.	Incorrect node switch setting.	Select a node address not already in use on the network.
NODE FLT 128...DRAM TEST	DRAM Test Fault	A power-up test of the DRAM indicated a memory problem.	Faulty memory component.	<ul style="list-style-type: none"> Recycle control power or reset the drive. Replace Control module if problem persists.
NODE FLT 129...FPGA CONFIG	FPGA Configuration Fault	The FPGA could not be configured properly.	Faulty component.	Replace module.
NODE FLT 133...SERCOS ADDRESS (Kinetix 6200 drives only)	Duplicate Sercos Node Address	This axis and one or more other axes have identical Sercos addresses.		Check Node Switch configuration of all axes on the Sercos ring and adjust for no overlap of addresses.
NODE FLT 139...SERCOS RING (Kinetix 6200 drives only)	Sercos Ring Fault	The Sercos ring is not active after being active and operational.	Loose or damaged Sercos cable.	Check that fiber-optic cable is present and connected properly.

Table 93 - NODE ALARM Fault Codes

Four-character Display Message	Logix Designer Fault Message	Problem or Symptom	Potential Cause	Possible Resolution
NODE ALARM 01...CTRL UPDATE	Control Connection Update Alarm	The Control Update Alarm bit is used to indicate that updates from the controller have been late	Excessive network traffic.	<ul style="list-style-type: none"> Remove unnecessary network devices from the motion network. Change the network topology so that fewer devices share common paths. Use faster/higher performance network equipment.
			Noisy environment.	<ul style="list-style-type: none"> Segregate signal wiring from power wiring. Use shielded cables. Add snubbers to power devices.
NODE ALARM 05...CLOCK SYNC	Clock Jitter Alarm	Sync Variance has exceeded the Sync Threshold while the device is running in Sync mode.	<ul style="list-style-type: none"> Switched to grandmaster clock of significantly different frequency. Lost connection to grandmaster clock. 	<ul style="list-style-type: none"> Drive auto-corrects upon time synchronization. Restore network connections.
NODE ALARM 128...NODE SWITCH	No Quick View message	The node address switches have been altered because they were first read after powerup.	Node Switches adjusted after powerup.	Return node switches to power-up setting.

Table 94 - INHIBIT Fault Codes

Four-character Display Message	Logix Designer Fault Message	Problem or Symptom	Potential Cause	Possible Resolution
INHIBIT S01...ENABLE INPUT	Axis Enable Input Fault - Start Inhibit	When Enable Input Checking is enabled, the drive displays Axis Enable Input start inhibit when it detects the enable input is inactive and while the axis is in Starting/Running/Testing/Hold sub-state of Stopped state.		<ul style="list-style-type: none"> Confirm that the digital input assigned to the Enable is active Check module enable input wiring Check digital input assignments
INHIBIT S02...MOTOR NOT CONFIGURED	Motor Not Configured	The motor has not been properly configured for use.		Verify motor configuration in the Logix Designer application.
INHIBIT S03...FEEDBACK NOT CONFIGURED	Feedback Not Configured	The feedback has not been properly configured for use.		Verify feedback configuration in the Logix Designer application.
INHIBIT S04...COMMUTATION NOT CONFIGURED	Commutation Not Configured - Standard Start Inhibit	<ul style="list-style-type: none"> Associated permanent magnet motor commutation has not been configured for use. After commutation test, the offset value stored on the motor encoder differs from value sent from the controller by 15° or more. 		<ol style="list-style-type: none"> Verify that the proper motor feedback commutation alignment has been selected. To run the commutation test and to measure the commutation offset it should be set as Controller Offset. Download project or power-cycle drive after accepting commutation test results.
INHIBIT M05...SAFE TORQUE OFF	Start Inhibit - Safe Torque Off	The safety function has disabled the power structure.		<ul style="list-style-type: none"> Check safety input wiring Check state of safety devices
INHIBIT M07...SAFETY NOT CONFIGURED	Start Inhibit - Safety Not Configured Inhibit	Drive firmware was uploaded.		Reapply safety configuration signature by using Apply File from the Safety Main web page.

Table 95 - ALARM Fault Codes

Four-character Display Message	Logix Designer Fault Message	Problem or Symptom	Potential Cause	Possible Resolution
ALARM S52...POS SW OTRAVEL (Kinetix 6200 drives only)	Software Overtravel - Positive	Axis position exceeded maximum software setting.		<ul style="list-style-type: none"> Verify motion profile. Verify overtravel settings are appropriate.
ALARM S53...NEG SW OTRAVEL (Kinetix 6200 drives only)	Software Overtravel - Negative			
ALARM M13...POWER CYCLE UL (Kinetix 6200 drives only)	Does not apply ⁽¹⁾	The converter estimates that the precharge circuit has exceeded its limit due to excessive power cycling.	The DC bus power has been cycled too frequently.	Limit power cycles to two per minute maximum.

(1) Use the Sercos Read IDN message instruction to check the status of this fault condition.

Control Module Status Indicators

Table 96 - Drive Status Indicator (Sercos control modules)

Condition	Drive Status	Possible Resolution
Off	No power	Apply power.
Alternating green/red	Self-test (power-up diagnostics)	Wait for steady green.
Flashing green ⁽¹⁾	Standby (device not configured)	Wait for steady green.
Steady green	Normal operation, no faults	–
Flashing red	Minor fault (recoverable)	Refer to four-character fault message.
Steady red	Major fault (non-recoverable)	Refer to four-character fault message.

(1) This condition is the same as Sercos ring phases 0, 1, 2, and 3.

Table 97 - Comm Status Indicator (Sercos control modules)

Condition	Drive Status	Potential Cause	Possible Resolution
Off	No communication ⁽¹⁾	Loose fiber-optic connection.	Verify proper fiber-optic cable connections.
		Broken fiber-optic cable.	Replace fiber-optic cable.
		Receive fiber-optic cable connected to Sercos transmit connector and vice versa.	Check proper Sercos fiber-optic cable connections.
Flashing green ⁽²⁾	Establish communication	System is still in the process of establishing Sercos communication.	Wait for steady green indicator.
		Node address setting on the drive module does not match Sercos controller configuration.	Verify proper node switch setting.
Steady green	Communication ready	No faults or failures.	–
Steady red	No communication	Duplicate node address	Verify proper node addressing. Refer to Configure the Drive Modules on page 161 .

(1) Refer to Fiber-optic Cable Installation and Handling Instructions, publication [2090-IN010](#), for more information.

(2) This condition is the same as Sercos ring phases 1, 2, and 3.

Table 98 - Bus Status Indicator

Condition	Bus Status	Condition
Off	No power or DC bus is not present.	<ul style="list-style-type: none"> Normal when bus power is not applied. Fault exists, refer to Fault Codes troubleshooting on page 189.
	Bus power is present in follower IAM.	<ul style="list-style-type: none"> Follower IAM power module is not configured as CommonBus Follow in Logix Designer application. After DC bus voltage is applied, a 2.5 second delay before the indicator begins flashing green is normal operation to provide the common-bus leader module time to complete precharge.
Flashing green	Bus power is present, axis disabled. No major faults.	Normal when: <ul style="list-style-type: none"> 24V is not applied to Hardware Enable Input. MSO instruction is not commanded in the Logix Designer application.
Steady green	Bus power is present, axis enabled. No major faults.	Normal when: <ul style="list-style-type: none"> 24V is applied to Hardware Enable Input. MSO instruction is commanded in the Logix Designer application.

Table 99 - Safety Lock Status Indicator

Condition ⁽¹⁾	Status
Off	No power or safety circuitry not configured.
Flashing amber	Safety circuitry configured, but not locked.
Steady amber	Safety circuitry locked.

(1) This status indicator applies to only 2094-xx02x-M0x-S1 control modules.

Table 100 - Port 1 and Port 2 Ethernet Communication Status Indicators

Condition	Status
Off	No link partner present.
Flashing green	Link partner present, communication occurring.
Steady green	Link partner present, no communication occurring.

Table 101 - Module and Network Status Indicators (EtherNet/IP control modules)

Condition	Status
Off	No power or no IP address defined.
Alternating green/red	Self-test mode (powerup diagnostics).
Flashing green	Standby (device not configured, or connection not established).
Steady green	Normal operation. Device has at least one established connection.
Flashing red	Recoverable minor fault or connection timeout.
Steady red	Non-recoverable major fault or duplicate IP address.

Shunt Module Status Indicators

Each of the shunt module status indicators provide specific troubleshooting information.

Table 102 - General Shunt Module Troubleshooting

Module	Status	Under These Conditions
Shunt	Fault is latched.	Until fault condition is corrected and cleared.
	Fault is cleared.	<ul style="list-style-type: none"> Using MASR, MAFR, MGSR instructions or the HIM (red stop button). Only after the DC bus is discharged (bus status indicator is flashing). Drive must be configured with 2094-BSP2 shunt module or Bulletin 1394 external shunt module.
IAM/AM	Disabled (for DC bus regulation).	<ul style="list-style-type: none"> When the 2094-BSP2 shunt module is used on a 230V system. When either 230V or 460V system is configured with a Bulletin 1394 external shunt module. When configured in Common-bus Follower mode.
	Enabled to discharge the DC bus.	Drive (IAM or leader IAM module) three-phase power is removed.
	Disabled from discharging the DC bus.	When configured in Common-bus Follower mode.

IMPORTANT Under some fault conditions, two reset commands can be required to clear drive and shunt module faults.

Table 103 - Bus Status Indicator

Bus Status Indicator	Status	Potential Cause	Possible Resolution
Flashing	Normal condition when control power is applied and bus voltage is less than 60V DC.		–
Steady Green	Normal condition when control power is applied and bus voltage is greater than 60V DC.		–
Off	Control power is not present.	Internal power supply failure.	Replace shunt module.

Table 104 - Temperature Fault Status Indicator

Over-Temp Fault Indicator	Status	Potential Cause	Possible Resolution
Off	Normal condition.		–
Steady Red	Shunt module internal temperature exceeds operating temperature specification.	Shunt module fan failed.	Replace shunt module.
		Shunt module temperature exceeds rating.	<ul style="list-style-type: none"> • Wait for shunt module to cool. • Reset faults. • Verify IAM module bus regulator configuration.
	External over temperature condition.	External temperature switch is open.	<ul style="list-style-type: none"> • Wait for shunt module to cool. • Reset faults. • Verify IAM module bus regulator configuration.
		TS jumper is not present.	Install jumper.

Table 105 - Shunt Fault Status Indicator

Shunt Fault Indicator	Status	Potential Cause	Possible Resolution
Off	Normal condition		–
Steady Red	Shorted internal or external shunt resistor.	Mis-wired shunt jumper or other short on RC connector.	<ul style="list-style-type: none"> • Correct mis-wire (shorted) condition. • If problem persists, replace shunt module.
		Mis-wired (shorted) external shunt wiring.	

Table 106 - All Shunt Module Status Indicators

Shunt Module Status Indicator	Status	Potential Cause	Possible Resolution
<ul style="list-style-type: none"> • Bus Status • Over-Temp Fault • Shunt Fault 	All three status indicators flash simultaneously.	Shunt module hardware failure.	<ul style="list-style-type: none"> • Cycle power. • If problem persists, replace shunt module.

General System Anomalies

These anomalies do not always result in a fault code, but may require troubleshooting to improve performance.

Table 107 - General System Anomalies

Condition	Potential Cause	Possible Resolution
Axis or system is unstable.	The position feedback device is incorrect or open.	Check wiring.
	Unintentionally in Torque mode.	Check to see what primary operation mode was programmed.
	Motor tuning limits are set too high.	Run Tune in the Logix Designer application.
	Position loop gain or position controller accel/decel rate is improperly set.	Run Tune in the Logix Designer application.
	Improper grounding or shielding techniques are causing noise to be transmitted into the position feedback or velocity command lines, causing erratic axis movement.	Check wiring and ground.
	Motor Select limit is incorrectly set (servo motor is not matched to axis module).	<ul style="list-style-type: none"> • Check setups. • Run Tune in the Logix Designer application.
	Mechanical resonance.	Notch filter or output filter may be required (refer to Axis Properties dialog box, Output tab in the Logix Designer application).

Table 107 - General System Anomalies (continued)

Condition	Potential Cause	Possible Resolution
You cannot obtain the motor acceleration/deceleration that you want.	Torque Limit limits are set too low.	Verify that current limits are set properly.
	Incorrect motor selected in configuration.	Select the correct motor and run Tune in the Logix Designer application again.
	The system inertia is excessive.	<ul style="list-style-type: none"> Check motor size versus application need. Review servo system sizing.
	The system friction torque is excessive.	Check motor size versus application need.
	Available current is insufficient to supply the correct accel/decel rate.	<ul style="list-style-type: none"> Check motor size versus application need. Review servo system sizing.
	Acceleration limit is incorrect.	Verify limit settings and correct them, as necessary.
	Velocity Limit limits are incorrect.	Verify limit settings and correct them, as necessary.
Motor does not respond to a velocity command.	The axis cannot be enabled for 1.5 seconds after disabling.	Disable the axis, wait for 1.5 seconds, and enable the axis.
	Enable signal has not been applied or the enable wiring is incorrect.	<ul style="list-style-type: none"> Check the controller. Check the wiring.
	The motor wiring is open.	Check the wiring.
	The motor thermal switch has tripped.	<ul style="list-style-type: none"> Check for a fault. Check the wiring.
	The motor has malfunctioned.	Repair or replace the motor.
	The coupling between motor and machine has broken (for example, the motor moves, but the load/machine does not).	Check and correct the mechanics.
	Primary operation mode is set incorrectly.	Check and properly set the limit.
	Velocity or current limits are set incorrectly.	Check and properly set the limits.
Presence of noise on command or motor feedback signal wires.	Recommended grounding per installation instructions have not been followed.	<ul style="list-style-type: none"> Verify grounding. Route wire away from noise sources. Refer to System Design for Control of Electrical Noise, publication GMC-RM001.
	Line frequency may be present.	<ul style="list-style-type: none"> Verify grounding. Route wire away from noise sources.
	Variable frequency may be velocity feedback ripple or a disturbance caused by gear teeth or ballscrew balls, and so forth. The frequency may be a multiple of the motor power transmission components or ballscrew speeds resulting in velocity disturbance.	<ul style="list-style-type: none"> Decouple the motor for verification. Check and improve mechanical performance, for example, the gearbox or ballscrew mechanism.
No rotation	The motor connections are loose or open.	Check motor wiring and connections.
	Foreign matter is lodged in the motor.	Remove foreign matter.
	The motor load is excessive.	Verify the servo system sizing.
	The bearings are worn.	Return the motor for repair.
	The motor brake is engaged (if supplied).	<ul style="list-style-type: none"> Check brake wiring and function. Return the motor for repair.
	The motor is not connect to the load.	Check coupling.
Motor overheating	The duty cycle is excessive.	Change the command profile to reduce accel/decel or increase time.
	The rotor is partially demagnetized causing excessive motor current.	Return the motor for repair.
Abnormal noise	Motor tuning limits are set too high.	Run Tune in the Logix Designer application.
	Loose parts are present in the motor.	<ul style="list-style-type: none"> Remove the loose parts. Return motor for repair. Replace motor.
	Through bolts or coupling is loose.	Tighten bolts.
	The bearings are worn.	Return motor for repair.
	Mechanical resonance.	Notch filter may be required (refer to Axis Properties dialog box, Output tab in Logix Designer application).
Erratic operation - Motor locks into position, runs without control or with reduced torque.	Motor power phases U and V, U and W, or V and W reversed.	Check and correct motor power wiring.
	Sine, Cosine or Rotor leads are reversed in the feedback cable connector.	Check and correct motor feedback wiring.