


**LabView™**  
**Virtual Instrument Libraries**  
**for**  
**E-710 Digital PZT Controller**



---

SID#	069
Name:	E710LV10.LLB
Release:	1.1
Release Date:	26.10.98

---

## Table of Contents :

<b>1.</b>	<b>Introduction.....</b>	<b>3</b>
<b>2.</b>	<b>E-710 Virtual Instruments .....</b>	<b>3</b>
<b>3.</b>	<b>Virtual Instruments Usage .....</b>	<b>4</b>
<b>4.</b>	<b>VI Reference.....</b>	<b>5</b>
4.1.	E710_init.vi.....	5
4.2.	E710_send.vi .....	5
4.3.	E710_Receive.vi .....	6
4.4.	E710_Query.vi .....	7
4.5.	E710_AZ.vi.....	8
4.6.	E710_GH.vi.....	8
4.7.	E710_MA.vi.....	9
4.8.	E710_MR.vi.....	9
4.9.	E710_SL.vi.....	10
4.10.	E710_SP.vi .....	10
4.11.	E710_SV.vi .....	11
4.12.	E710_TA.vi.....	11
4.13.	E710_TP.vi.....	12
4.14.	E710_TV.vi.....	12
4.15.	E710_VR.vi .....	13
4.16.	E710_VS.vi .....	13
4.17.	E710_VT.vi.....	14
4.18.	E710_ZM.vi .....	14

© 1998 by Physik Instrumente PI GmbH

Polytec Platz 1-7, D-76337 Waldbronn

Email : [info@physikinstrumente.com](mailto:info@physikinstrumente.com)

FAX: (+49) 7243-604-145

Document: SM069E11.doc

Version: 1.10

PDate: 25.06.01 15:12

## 1. Introduction

E-710 Digital Motor Controllers are intended to be used with P-500 series of modular PZT flexure stages and can also be used to control other PZT positioners equipped with capacitive sensors.

Details and format of commands are described in Operating Manuals PZ 80E operating manual.

The E-710 LabView drivers are provided to help the customer to generate his own LabView program. Both RS-232 and IEEE488 interfaces (manufacturer National Instruments) are supported. Prior to use the LabView Vis with the IEEE488 interface, the IEEE488 board and its software has to be installed.

Most commands can be accessed via VIs that can be implemented in your LV program. Connecting the icons with the desired parameter values and function attributes, LV applications using the E-710 are very easy to accomplish.



## 2. E-710 Virtual Instruments

List of Vis:

VI Name	Function
<i>System related Vis</i>	
E710_PortGlobe.vi	This Vi contains some global variables regarding the selected interface.
E710_init.vi	Performs initialization procedures
E710_Send.vi	Send a command string
E710_Receive.vi	Receives a report string
E710_query.vi	Requests a report
<i>Command related Vis</i>	
E710_AZ.vi	Auto Zero
E710_GH.vi	Go Home
E710_MA.vi	Move Absolute
E710_MR.vi	Move Relative
E710_SL.vi	Set Servo Loop
E710_SP.vi	Set p-Term
E710_SV.vi	Set Velocity
E710_TA.vi	Tell A/D value
E710_TP.vi	Tell Position
E710_TV.vi	Tell Velocity
E710_VR.vi	Voltage Relative
E710_VS	Voltage Set
E710_VT	Voltage Tell
E710_ZM	Zoom Mode

### 3. Virtual Instruments Usage

The first VI that has to be called in a working session is the E710\_init.vi.



This VI initializes the interface and reports the GI report of the E710 device.

#### Inputs:

Interface Select:      0=IEEE488  
                             1=RS232

IEEE488 Address:      Device Address (only if IEEE488 is selected)

RS232 Port Select:    0=COM1  
                             1=COM2  
                             2=COM3  
                             3=COM4

Error in:                Standard cluster

#### Output:

Error out:               Standard cluster



## 4. VI Reference

### 4.1. E710\_init.vi

see chapter 3

### 4.2. E710\_send.vi

VI Library : E710LV10.LLB



**E710\_send.vi**

sends a command to the device using IEEE488 or RS232 interface

#### Inputs:

Command: Command string  
example: "1MR50.234"

Error in: Standard cluster

#### Output:

Status: Status byte



byte count: number of bytes sent to the device

Error out: Standard cluster

**Function :** This VI sends a command string. It should not request an answer, so query commands should be send with the query vi for convenient report handling.

### 4.3. E710\_Receive.vi

VI Library : E710LV10.LLB



**E710\_Receive.vi**

- Receives data from Interface (GPIB or RS232)
- Selects interface and port via port\_GLOBE.VI

#### Inputs:

Error in: Standard cluster

#### Output:

bytes received: number of bytes received from the device

E-710 report: report string


Error out: Standard cluster

**Function :** This VI reads the report of a previously send query command. If none report is available, an error message occurs.

#### 4.4. E710\_Query.vi


VI Library : E710LV10.LLB

Purpose: Reads a report string



**E710\_query.vi**

This Vi requests a report from the E-710.  
Command example: "1TP", "1TA"



#### Inputs:

Command: Command string

Error in: Standard cluster

#### Output:

Response: Response string

Bytes received: number of bytes received from the device

Error out: Standard Error Cluster

**Note :** This VI can be used with commands creating a report string. If non report string is available after 50 ms, a timeout occurs.


---

**4.5. E710\_AZ.vi**

---

**VI Library :** E710LV10.LLB

**Purpose:** Starts a zero point calibration for the entire system.

**E710\_AZ.vi****Inputs:**

Error in: Standard cluster

**Output:**

Bytes send: number of bytes sent to the device

Error out: Standard Error Cluster


---

**4.6. E710\_GH.vi**

---

**VI Library :** E710LV10.LLB

**Purpose:** Starts a move to the home position.

**E710\_GH.vi****Inputs:**

Axis Select: Select active axis

Error in: Standard Error Cluster

**Output:**


Bytes send: number of bytes sent to the device

Error out: Standard Error Cluster



**4.7. E710\_MA.vi**

---

**VI Library :** E710LV10.LLB**Purpose:** Starts a move to the absolute Position.**E710\_MA.vi****Inputs:**

Axis Select: Select active axis

Position String:

Error in: Standard Error Cluster


**Output:**

Bytes send: number of bytes sent to the device

Error out: Standard Error Cluster

**4.8. E710\_MR.vi**

---

**VI Library :** E710LV10.LLB**Purpose:** Starts a move relative from the current position.**E710\_MR.vi****Inputs:**

Axis Select: Select active axis

Relative Move: Relative move in  $\mu\text{m}$  as string, e.g "5.8"

Error in: Standard Error Cluster

**Output:**


Bytes send: number of bytes sent to the device

Error out: Standard Error Cluster

**4.9. E710\_SL.vi**

**VI Library :** E710LV10.LLB

**Purpose:** Set servo loop on/off

**E710\_SL.vi****Inputs:**

Axis Select: Select active axis

Servo Loop: Boolean value: TRUE = servo on, FALSE = servo off

Error in: Standard Error Cluster

**Output:**


Bytes send: number of bytes sent to the device

Error out: Standard Error Cluster

**4.10. E710\_SP.vi**

**VI Library :** E710LV10.LLB

**Purpose:** Set the p-term (proportional filter term)

**E710\_SP.vi****Inputs:**

Axis Select: Select active axis

new p-term: p-term value as string

Error in: Standard Error Cluster


**Output:**

Bytes send: number of bytes sent to the device

Error out: Standard Error Cluster

**4.11. E710\_SV.vi**

---

**VI Library :** E710LV10.LLB**Purpose:** Set velocity**E710\_SV.vi****Inputs:**


Axis Select: Select active axis  
 Velocity String: new velocity as string format  
 Error in: Standard Error Cluster

**Output:**

Bytes send: number of bytes sent to the device  
 Error out: Standard Error Cluster

**4.12. E710\_TA.vi**

---

**VI Library :** E710LV10.LLB**Purpose:** Tell Analog, reads the last converted analog value of the A/D converter.**E710\_TA.vi****Inputs:**

Axis Select: Select active axis  
 Error in: Standard Error Cluster


**Output:**

Analog read: numeric value of the read value  
 Bytes received: number of bytes received from E-710  
 Error out: Standard Error Cluster

---

**4.13. E710\_TP.vi**

---

**VI Library :** E710LV10.LLB**Purpose:** Reads the sensor position of the indicated axis.**E710\_TP.vi****Inputs:**

Axis Select: Select active axis

Error in: Standard Error Cluster

**Output:**

Position: read position value


Bytes received: number of bytes received from E-710

Error out: Standard Error Cluster

---

**4.14. E710\_TV.vi**

---

**VI Library :** E710LV10.LLB**Purpose:** Reads the programmed velocity of the indicated axis.**E710\_TV.vi****Inputs:**

Axis Select: Select active axis


Error in: Standard Error Cluster

**Output:**

Velocity: Read velocity

Bytes received: number of bytes received from E-710


Error out: Standard Error Cluster

**4.15. E710\_VR.vi****VI Library :** E710LV10.LLB**Purpose:** Voltage Relative, sets the voltage of the indicated channel relative to the current voltage.**Inputs:**

Axis Select: Select active axis  
 Relative Voltage: Relative voltage value as string  
 Error in: Standard Error Cluster

**Output:**

Bytes send: number of bytes sent to the device  
 Error out: Standard Error Cluster

**4.16. E710\_VS.vi****VI Library :** E710LV10.LLB**Purpose:** Sets the output voltage in open loop for the indicated axis.**Inputs:**


Axis Select: Select active axis  
 Voltage(string): New output voltage as string  
 Error in: Standard Error Cluster

**Output:**


Bytes send: number of bytes sent to the device  
 Error out: Standard Error Cluster

**4.17. E710\_VT.vi**

---

**VI Library :** E710LV10.LLB**Purpose:** Reports the output voltages of all 4 channels.**E710\_VT.vi****Inputs:****Error in:** Standard Error Cluster**Output:****VT report:** voltages of all axes**Bytes received:** number of bytes received from E-710**Error out:** Standard Error Cluster**4.18. E710\_ZM.vi**

---

**VI Library :** E710LV10.LLB**Purpose:** Activates the entire device in zoom mode.**E710\_ZM.vi****Inputs:****ZOOM Mode:** TRUE = Zoom on, FALSE = Zoom off**Error in:** Standard Error Cluster**Output:****Bytes send:** number of bytes sent to the device**Error out:** Standard Error Cluster