

## TROUBLESHOOTING INDEX [BLIND SPOT MONITORING (BSM)]

id0903d9990200

No.	Troubleshooting item	Description
1	BSM OFF INDICATOR LIGHT DOES NOT ILLUMINATE WHEN THE IGNITION IS SWITCHED TO ON [BLIND SPOT MONITORING (BSM)]	<ul style="list-style-type: none"> <li>The BSM OFF indicator light does not illuminate when the ignition is switched to ON.</li> <li>The BSM control module does not communicate with the M-MDS.</li> </ul>
2	BSM OFF INDICATOR LIGHT DOES NOT ILLUMINATE WHILE BSM SYSTEM IS OFF [BLIND SPOT MONITORING (BSM)]	<ul style="list-style-type: none"> <li>The BSM indicator light does not illuminate after the BSM OFF switch turns off the system when the ignition is switched to ON.</li> </ul>
3	BSM OFF INDICATOR LIGHT ILLUMINATES CONTINUOUSLY [BLIND SPOT MONITORING (BSM)]	<ul style="list-style-type: none"> <li>The BSM OFF indicator light illuminates for 4 s or more without the BSM OFF switch turning off the system when the ignition is switched to ON.</li> </ul>
4	BSM INDICATOR LIGHT ILLUMINATES WHILE NOT UNDER LIGHT-ILLUMINATION CONDITIONS [BLIND SPOT MONITORING (BSM)]	<ul style="list-style-type: none"> <li>The BSM indicator light illuminates, but the conditions to illuminate the BSM indicator light are not satisfied (vehicle speed above 32 km/h {20 mph} or more, turn signals off, and vehicle in warning zone).</li> </ul>
5	BSM INDICATOR LIGHT DOES NOT ILLUMINATE WHILE UNDER BSM INDICATOR LIGHT-ILLUMINATION CONDITIONS [BLIND SPOT MONITORING (BSM)]	<ul style="list-style-type: none"> <li>The BSM indicator light does not illuminate despite satisfying the conditions to illuminate the BSM indicator light (vehicle speed above 32 km/h {20 mph} or more, turn signals off, and vehicle in warning zone).</li> </ul>
6	BSM INDICATOR LIGHT FLASHES WHILE NOT UNDER BSM INDICATOR LIGHT-FLASHING CONDITIONS (NO LIGHT SWITCH OPERATION (TURN SIGNAL SWITCH)) [BLIND SPOT MONITORING (BSM)]	<ul style="list-style-type: none"> <li>The BSM indicator light flashes despite not satisfying the BSM indicator light flashing conditions (vehicle speed above 32 km/h {20 mph} or more, turn signal on, and vehicle in warning zone).</li> <li>The BSM indicator light flashes, but the turn signals are off.</li> </ul>
7	BSM INDICATOR LIGHT DOES NOT FLASH WHILE UNDER BSM INDICATOR LIGHT-FLASHING CONDITIONS (WITH LIGHT SWITCH OPERATION (TURN SIGNAL SWITCH)) [BLIND SPOT MONITORING (BSM)]	<ul style="list-style-type: none"> <li>The BSM indicator light does not flash or illuminate continuously, but the conditions to flash the BSM indicator light are satisfied (vehicle speed above 32 km/h {20 mph} or more, turn signal on, and vehicle in warning zone).</li> </ul>
8	THE BSM INDICATOR LIGHT DOES NOT FLASH OR ILLUMINATE CONTINUOUSLY, BUT A TURN SIGNAL IS ON [BLIND SPOT MONITORING (BSM)]	<ul style="list-style-type: none"> <li>BSM warning alarm sounds but BSM indicator light does not flash.</li> <li>The BSM warning alarm is triggered on the side opposite to the direction in which the turn signal is operated.</li> <li>The M-MDS is communicating with only the left or right BSM control module.</li> </ul>
9	BSM WARNING ALARM DOES NOT SOUND WHILE BSM INDICATOR LIGHT FLASHES [BLIND SPOT MONITORING (BSM)]	<ul style="list-style-type: none"> <li>The BSM control module recognizes that a vehicle is in the warning zone on the side in which the turn signal is operated, but the BSM warning alarm does not sound despite the BSM indicator light flashing.</li> </ul>