

DTC U3000:01 [BLIND SPOT MONITORING (BSM)]

id0902i3393200

System malfunction location	Electrical malfunction inside BSM control module
Detection condition	• An electrical malfunction inside BSM control module is detected.
Fail-safe	• BSM is stopped.
Possible cause	• BSM control module malfunction
System wiring diagram	—

Diagnostic Procedure

Step	Inspection	Action
1	PERFORM DTC INSPECTION AND VERIFY IF MALFUNCTIONING PART IS BSM CONTROL MODULE <ul style="list-style-type: none">• Clear BSM control module DTCs using the M-MDS. (See CLEARING DTC [BLIND SPOT MONITORING (BSM)].)• Perform the DTC inspection for the BSM control module using the M-MDS. (See DTC INSPECTION [BLIND SPOT MONITORING (BSM)].)• Is DTC U3000:01 displayed?	Yes Replace the BSM control module, then go to the next step. (See BLIND SPOT MONITORING (BSM) CONTROL MODULE REMOVAL/INSTALLATION.)
		No Go to the next step.
2	VERIFY IF OTHER DTCs DISPLAYED <ul style="list-style-type: none">• Are any other DTCs displayed?	Yes Repair the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [BLIND SPOT MONITORING (BSM)].)
		No DTC troubleshooting completed.