
ACTIVE COMMAND MODES TABLE [BLIND SPOT MONITORING (BSM)]

id0902i3960900

BSM Control Module (LH)

Command name	Unit/Operation	Data contents	Output part name
VSPD	OFF/ON	<ul style="list-style-type: none">• OFF: Does not input vehicle speed.• ON: Inputs vehicle speed of 34 km/h {21 mph}.	BSM control module (LH)
WRN_IND_L	Off/On	<ul style="list-style-type: none">• Off: Turns off BSM indicator light (LH).• On: Illuminates BSM indicator light (LH).	BSM indicator light (LH)

BSM Control Module (RH)

Command name	Unit/Operation	Data contents	Output part name
BSM_OFF_IL	On/Off	<ul style="list-style-type: none">• On: Illuminates BSM OFF indicator light.• On: Turns off BSM OFF indicator light.	BSM OFF indicator light (Instrument cluster)
Buzzer	On/Off	<ul style="list-style-type: none">• On: Operates BSM warning alarm.• Off: Stops BSM warning alarm.	BSM warning alarm (Instrument cluster)
VSPD	OFF/ON	<ul style="list-style-type: none">• OFF: Does not input vehicle speed.• ON: Inputs vehicle speed of 34 km/h {21 mph}.	BSM control module (RH)
WRN_IND_R	Off/On	<ul style="list-style-type: none">• Off: Turns off BSM indicator light (RH).• On: Illuminates BSM indicator light (RH).	BSM indicator light (RH)