


DTC P0652:00 [SKYACTIV-D 2.2]

id0102s4065200

DTC P0652:00	Constant voltage power supply control circuit low input
DETECTION CONDITION	<ul style="list-style-type: none"> When the following condition is met, the output voltage of the 5 V power supply terminal is 3.9 V or less for a continuous 1 s: MONITORING CONDITIONS <ul style="list-style-type: none"> Battery voltage: 8—20 V Diagnostic support note This is a continuous monitor (CCM). The check engine light illuminates if the PCM detects the above malfunction condition during the first drive cycle. FREEZE FRAME DATA (Mode 2)/Snapshot data is available. DTC is stored in the PCM memory.
FAIL-SAFE FUNCTION	<ul style="list-style-type: none"> Inhibits the EGR control. Inhibits engine-stop by operating the i-stop function.
POSSIBLE CAUSE	<ul style="list-style-type: none"> APP sensor connector or terminals malfunction CMP sensor connector or terminals malfunction EGR cooler bypass valve/EGR cooler bypass valve position sensor connector or terminals malfunction EGR valve/EGR valve position sensor connector or terminals malfunction Intake shutter valve/intake shutter valve position sensor connector or terminals malfunction Exhaust gas pressure sensor No.1 connector or terminals malfunction Exhaust gas pressure sensor No.2 connector or terminals malfunction MAP sensor No.1 connector or terminals malfunction Fuel pressure sensor connector or terminals malfunction Short to ground in wiring harness between the following terminals: <ul style="list-style-type: none"> APP sensor terminal A—PCM terminal 2AM CMP sensor terminal C—PCM terminal 1K EGR cooler bypass valve/EGR cooler bypass valve position sensor terminal B—PCM terminal 1AU EGR valve/EGR valve position sensor terminal B—PCM terminal 1AP Intake shutter valve/intake shutter valve position sensor terminal E—PCM terminal 1AZ Exhaust gas pressure sensor No.1 terminal C—PCM terminal 1CJ Exhaust gas pressure sensor No.2 terminal A—PCM terminal 1AK MAP sensor No.1 terminal A—PCM terminal 1BJ Fuel pressure sensor terminal C—PCM terminal 1AR PCM connector or terminals malfunction PCM malfunction

**DTC
P0652:00**

Constant voltage power supply control circuit low input



Diagnostic Procedure

STEP	INSPECTION		ACTION
1	VERIFY FREEZE FRAME DATA (MODE 2)/ SNAPSHOT DATA HAS BEEN RECORDED <ul style="list-style-type: none"> Has the FREEZE FRAME DATA (Mode 2)/ snapshot data been recorded? 	Yes	Go to the next step.
		No	Record the FREEZE FRAME DATA (Mode 2)/snapshot data on the repair order, then go to the next step.
2	VERIFY RELATED SERVICE INFORMATION AVAILABILITY <ul style="list-style-type: none"> Verify related Service Information availability. Is any related Service Information available? 	Yes	Perform repair or diagnosis according to the available Service Information. • If the vehicle is not repaired, go to the next step.
		No	Go to the next step.
3	VERIFY RELATED PENDING CODE AND/OR DTC <ul style="list-style-type: none"> Switch the ignition off, then ON (engine off). Perform the Pending Trouble Code Access Procedure and DTC Reading Procedure. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-D 2.2].) Are any other PENDING CODEs and/or DTCs present? 	Yes	Go to the applicable PENDING CODE or DTC inspection. (See DTC TABLE [SKYACTIV-D 2.2].)
		No	Go to the next step.
4	INSPECT APP SENSOR CONNECTOR CONDITION <ul style="list-style-type: none"> Switch the ignition off. Disconnect the APP sensor connector. Inspect for poor connection (such as damaged/ pulled-out pins, corrosion). Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 15.
		No	Go to the next step.
5	INSPECT CMP SENSOR CONNECTOR CONDITION <ul style="list-style-type: none"> Disconnect the CMP sensor connector. Inspect for poor connection (such as damaged/ pulled-out pins, corrosion). Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 15.
		No	Go to the next step.
6	INSPECT EGR COOLER BYPASS VALVE/EGR COOLER BYPASS VALVE POSITION SENSOR CONNECTOR CONDITION <ul style="list-style-type: none"> Disconnect the EGR cooler bypass valve/EGR cooler bypass valve position sensor connector. Inspect for poor connection (such as damaged/ pulled-out pins, corrosion). Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 15.
		No	Go to the next step.
7	INSPECT EGR VALVE/EGR VALVE POSITION SENSOR CONNECTOR CONDITION <ul style="list-style-type: none"> Disconnect the EGR valve/EGR valve position sensor connector. Inspect for poor connection (such as damaged/ pulled-out pins, corrosion). Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 15.
		No	Go to the next step.
8	INSPECT INTAKE SHUTTER VALVE/INTAKE SHUTTER VALVE POSITION SENSOR CONNECTOR CONDITION <ul style="list-style-type: none"> Disconnect the intake shutter valve/intake shutter valve position sensor connector. Inspect for poor connection (such as damaged/ pulled-out pins, corrosion). Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 15.
		No	Go to the next step.
9	INSPECT EXHAUST GAS PRESSURE SENSOR NO.1 CONNECTOR CONDITION <ul style="list-style-type: none"> Disconnect the exhaust gas pressure sensor No. 1 connector. Inspect for poor connection (such as damaged/ pulled-out pins, corrosion). Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 15.
		No	Go to the next step.

STEP	INSPECTION	ACTION	
10	INSPECT EXHAUST GAS PRESSURE SENSOR NO.2 CONNECTOR CONDITION <ul style="list-style-type: none"> • Disconnect the exhaust gas pressure sensor No. 2 connector. • Inspect for poor connection (such as damaged/ pulled-out pins, corrosion). • Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 15.
		No	Go to the next step.
11	INSPECT MAP SENSOR NO.1 CONNECTOR CONDITION <ul style="list-style-type: none"> • Disconnect the MAP sensor No.1 connector. • Inspect for poor connection (such as damaged/ pulled-out pins, corrosion). • Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 15.
		No	Go to the next step.
12	INSPECT FUEL PRESSURE SENSOR CONNECTOR CONDITION <ul style="list-style-type: none"> • Disconnect the fuel pressure sensor connector. • Inspect for poor connection (such as damaged/ pulled-out pins, corrosion). • Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to Step 15.
		No	Go to the next step.
13	INSPECT EACH POWER CIRCUIT FOR SHORT TO GROUND <ul style="list-style-type: none"> • Verify that the APP sensor, CMP sensor, EGR cooler bypass valve/EGR cooler bypass valve position sensor, EGR valve/EGR valve position sensor, intake shutter valve/intake shutter valve position sensor, exhaust gas pressure sensor No. 1, exhaust gas pressure sensor No.2, MAP sensor No.1 and fuel pressure sensor connectors are disconnected. • Inspect for continuity between the following terminals (wiring harness-side) and body ground: <ul style="list-style-type: none"> — APP sensor terminal A — CMP sensor terminal C — EGR cooler bypass valve/EGR cooler bypass valve position sensor terminal B — EGR valve/EGR valve position sensor terminal B — Intake shutter valve/intake shutter valve position sensor terminal E — Exhaust gas pressure sensor No.1 terminal C — Exhaust gas pressure sensor No.2 terminal A — MAP sensor No.1 terminal A — Fuel pressure sensor terminal C • Is there continuity? 	Yes	If the short to ground circuit could be detected in the wiring harness: <ul style="list-style-type: none"> • Repair or replace the wiring harness for a possible short to ground. If the short to ground circuit could not be detected in the wiring harness: <ul style="list-style-type: none"> • Replace the PCM (short to ground in the PCM internal circuit). (See PCM REMOVAL/INSTALLATION [SKYACTIV-D 2.2].) Go to Step 15.
		No	Go to the next step.
14	INSPECT PCM CONNECTOR CONDITION <ul style="list-style-type: none"> • Disconnect the PCM connector. • Inspect for poor connection (such as damaged/ pulled-out pins, corrosion). • Is there any malfunction? 	Yes	Repair or replace the connector and/or terminals, then go to the next step.
		No	Go to the next step.
15	VERIFY DTC TROUBLESHOOTING COMPLETED <ul style="list-style-type: none"> • Always reconnect all disconnected connectors. • Clear the DTC from the PCM memory using the M-MDS. (See AFTER REPAIR PROCEDURE [SKYACTIV-D 2.2].) • Perform the DTC Reading Procedure. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-D 2.2].) • Is the same DTC present? 	Yes	Repeat the inspection from Step 1. <ul style="list-style-type: none"> • If the malfunction recurs, replace the PCM. (See PCM REMOVAL/INSTALLATION [SKYACTIV-D 2.2].) Go to the next step.
		No	Go to the next step.

STEP	INSPECTION		ACTION
16	VERIFY AFTER REPAIR PROCEDURE • Perform the “AFTER REPAIR PROCEDURE”. (See AFTER REPAIR PROCEDURE [SKYACTIV-D 2.2].) • Are any DTCs present?	Yes	Go to the applicable DTC inspection. (See DTC TABLE [SKYACTIV-D 2.2].)
		No	DTC troubleshooting completed.