

# DTC P0112:00 [SKYACTIV-D 2.2]

id0102s4701400

DTC P0112:00	IAT sensor No.1 circuit low input
<b>DETECTION CONDITION</b>	<ul style="list-style-type: none"> <li>The PCM monitors the IAT sensor No.1 signal. If the PCM detects that the IAT sensor No.1 voltage at the PCM terminal 2Y is <b>below 0.10 V</b> for <b>1 s</b>, the PCM determines that the IAT sensor No.1 circuit has a malfunction.</li> </ul> <p><b>MONITORING CONDITIONS</b></p> <ul style="list-style-type: none"> <li>Battery voltage: <b>8—20 V</b></li> </ul> <p><b>Diagnostic support note</b></p> <ul style="list-style-type: none"> <li>This is a continuous monitor (CCM).</li> <li>The check engine light illuminates if the PCM detects the above malfunction condition during the first drive cycle.</li> <li>FREEZE FRAME DATA (Mode 2)/Snapshot data is available.</li> <li>DTC is stored in the PCM memory.</li> </ul>
<b>FAIL-SAFE FUNCTION</b>	<ul style="list-style-type: none"> <li>PCM restricts engine torque.</li> <li>Inhibits the two-stage turbo control.</li> <li>Inhibits the EGR control.</li> <li>Inhibits the diesel particulate filter regeneration control.</li> <li>The fast idle up correction for the idle speed control is inhibited.</li> <li>Inhibits engine-stop by operating the i-stop function.</li> <li>PCM restricts engine-transaxle integration control.</li> </ul>
<b>POSSIBLE CAUSE</b>	<ul style="list-style-type: none"> <li>Intake air temperature is too high</li> <li>MAF sensor/IAT sensor No.1 connector or terminals malfunction</li> <li>IAT sensor No.1 malfunction</li> <li>Short to ground in wiring harness between MAF sensor/IAT sensor No.1 terminal A and PCM terminal 2Y</li> <li>PCM connector or terminals malfunction</li> <li>IAT sensor No.1 signal circuit and ground circuit are shorted to each other</li> <li>PCM malfunction</li> </ul>
<div> <div> <p>④</p> <p>IAT SENSOR NO.1 (MAF SENSOR/IAT SENSOR NO.1)</p> </div> <div> <p>PCM</p> </div> <div> <p>MAF SENSOR/IAT SENSOR NO.1 WIRING HARNESS-SIDE CONNECTOR</p> </div> <div> <p>PCM WIRING HARNESS-SIDE CONNECTOR</p> </div> </div>	

## Diagnostic Procedure

STEP	INSPECTION	ACTION
1	<b>VERIFY FREEZE FRAME DATA (MODE 2)/ SNAPSHOT DATA HAS BEEN RECORDED</b>	Yes
	• Has the FREEZE FRAME DATA (Mode 2)/ snapshot data been recorded?	No Record the FREEZE FRAME DATA (Mode 2)/snapshot data on the repair order, then go to the next step.
2	<b>VERIFY RELATED SERVICE INFORMATION AVAILABILITY</b>	Yes
	• Verify related Service Information availability. • Is any related Service Information available?	No Perform repair or diagnosis according to the available Service Information. • If the vehicle is not repaired, go to the next step. Go to the next step.

STEP	INSPECTION		ACTION
3	<b>INSPECT MAF SENSOR/IAT SENSOR NO.1 CONNECTOR CONDITION</b> <ul style="list-style-type: none"> <li>Switch the ignition off.</li> <li>Disconnect the MAF sensor/IAT sensor No.1 connector.</li> <li>Inspect for poor connection (such as damaged/pulled-out pins, corrosion).</li> <li>Is there any malfunction?</li> </ul>	Yes	Repair or replace the connector and/or terminals, then go to Step 8.
		No	Go to the next step.
4	<b>INSPECT IAT SENSOR NO.1</b> <ul style="list-style-type: none"> <li>Inspect the IAT sensor No.1. (See INTAKE AIR TEMPERATURE (IAT) SENSOR INSPECTION [SKYACTIV-D 2.2].)</li> <li>Is there any malfunction?</li> </ul>	Yes	Replace the MAF sensor/IAT sensor No.1, then go to Step 8. (See MASS AIR FLOW (MAF) SENSOR/INTAKE AIR TEMPERATURE (IAT) SENSOR NO.1 REMOVAL/INSTALLATION [SKYACTIV-D 2.2].)
		No	Go to the next step.
5	<b>INSPECT IAT SENSOR NO.1 SIGNAL CIRCUIT FOR SHORT TO GROUND</b> <ul style="list-style-type: none"> <li>Verify that the MAF sensor/IAT sensor No.1 connector is disconnected.</li> <li>Inspect for continuity between MAF sensor/IAT sensor No.1 terminal A (wiring harness-side) and body ground.</li> <li>Is there continuity?</li> </ul>	Yes	If the short to ground circuit could be detected in the wiring harness: <ul style="list-style-type: none"> <li>Repair or replace the wiring harness for a possible short to ground.</li> </ul> If the short to ground circuit could not be detected in the wiring harness: <ul style="list-style-type: none"> <li>Replace the PCM (short to ground in the PCM internal circuit). (See PCM REMOVAL/INSTALLATION [SKYACTIV-D 2.2].)</li> </ul> Go to Step 8.
		No	Go to the next step.
6	<b>INSPECT PCM CONNECTOR CONDITION</b> <ul style="list-style-type: none"> <li>Disconnect the PCM connector.</li> <li>Inspect for poor connection (such as damaged/pulled-out pins, corrosion).</li> <li>Is there any malfunction?</li> </ul>	Yes	Repair or replace the connector and/or terminals, then go to Step 8.
		No	Go to the next step.
7	<b>INSPECT IAT SENSOR NO.1 SIGNAL CIRCUIT AND GROUND CIRCUIT FOR SHORT TO EACH OTHER</b> <ul style="list-style-type: none"> <li>Verify that the MAF sensor/IAT sensor No.1 and PCM connectors are disconnected.</li> <li>Inspect for continuity between MAF sensor/IAT sensor No.1 terminals A and B (wiring harness-side).</li> <li>Is there continuity?</li> </ul>	Yes	Repair or replace the wiring harness for a possible short to each other, then go to the next step.
		No	Go to the next step.
8	<b>VERIFY DTC TROUBLESHOOTING COMPLETED</b> <ul style="list-style-type: none"> <li>Always reconnect all disconnected connectors.</li> <li>Clear the DTC from the PCM memory using the M-MDS. (See AFTER REPAIR PROCEDURE [SKYACTIV-D 2.2].)</li> <li>Perform the KOEO or KOER self test. (See KOEO/KOER SELF TEST [SKYACTIV-D 2.2].)</li> <li>Is the same DTC present?</li> </ul>	Yes	Repeat the inspection from Step 1. <ul style="list-style-type: none"> <li>If the malfunction recurs, replace the PCM. (See PCM REMOVAL/INSTALLATION [SKYACTIV-D 2.2].)</li> </ul> Go to the next step.
		No	Go to the next step.
9	<b>VERIFY AFTER REPAIR PROCEDURE</b> <ul style="list-style-type: none"> <li>Perform the "AFTER REPAIR PROCEDURE". (See AFTER REPAIR PROCEDURE [SKYACTIV-D 2.2].)</li> <li>Are any DTCs present?</li> </ul>	Yes	Go to the applicable DTC inspection. (See DTC TABLE [SKYACTIV-D 2.2].)
		No	DTC troubleshooting completed.