

**DTC P2110:00 [SKYACTIV-G 2.0, SKYACTIV-G 2.5]**

id0102h4303500

<b>DTC P2110:00</b>	<b>Throttle valve actuator control system-forced limited RPM</b>
<b>DETECTION CONDITION</b>	<ul style="list-style-type: none"> <li>• PCM internal malfunction.</li> </ul> <b>Diagnostic support note</b> <ul style="list-style-type: none"> <li>• This is a continuous monitor (CCM).</li> <li>• The check engine light illuminates if the PCM detects the above malfunction condition during the first drive cycle.</li> <li>• FREEZE FRAME DATA (Mode 2)/Snapshot data is available.</li> <li>• DTC is stored in the PCM memory.</li> </ul>
<b>FAIL-SAFE FUNCTION</b>	<ul style="list-style-type: none"> <li>• Restricts the upper limit of the engine speed.</li> <li>• Stops drive-by-wire control (throttle valve is open at <b>approx. 8 °</b> by return spring force)</li> </ul>
<b>POSSIBLE CAUSE</b>	<ul style="list-style-type: none"> <li>• Throttle body malfunction</li> <li>• PCM malfunction <ul style="list-style-type: none"> <li>— Throttle valve actuator control module internal processor error (built-into PCM)</li> <li>— Fuel injector control driver internal processor error (built-into PCM)</li> </ul> </li> </ul>
<b>SYSTEM WIRING DIAGRAM</b>	Not applicable

**Diagnostic Procedure**

STEP	INSPECTION		ACTION
1	<b>VERIFY FREEZE FRAME DATA (MODE 2)/ SNAPSHOT DATA HAS BEEN RECORDED</b> <ul style="list-style-type: none"> <li>• Has the FREEZE FRAME DATA (Mode 2)/snapshot data been recorded?</li> </ul>	Yes	Go to the next step.
		No	Record the FREEZE FRAME DATA (Mode 2)/snapshot data on the repair order, then go to the next step.
2	<b>VERIFY RELATED SERVICE INFORMATION AVAILABILITY</b> <ul style="list-style-type: none"> <li>• Verify related Service Information availability.</li> <li>• Is any related Service Information available?</li> </ul>	Yes	Perform repair or diagnosis according to the available Service Information. • If the vehicle is not repaired, go to the next step.
		No	Go to the next step.
3	<b>VERIFY RELATED PENDING CODE AND/OR DTC</b> <ul style="list-style-type: none"> <li>• Switch the ignition off, then ON (engine off).</li> <li>• Perform the Pending Trouble Code Access Procedure and DTC Reading Procedure. (See ON-BOARD DIAGNOSTIC TEST [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)</li> <li>• Are any other PENDING CODEs and/or DTCs present?</li> </ul>	Yes	Go to the applicable PENDING CODE or DTC inspection. (See DTC TABLE [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)
		No	Go to the next step.
4	<b>INSPECT THROTTLE BODY AND PCM</b> <ul style="list-style-type: none"> <li>• Switch the ignition off.</li> <li>• Visually inspect the following for obvious signs of damage: <ul style="list-style-type: none"> <li>— Throttle body</li> <li>— PCM</li> </ul> </li> <li>• Is a concern present?</li> </ul>	Yes	Isolate the concern and repair if necessary, then go to Step 6.
		No	Go to the next step.
5	<b>INSPECT THROTTLE BODY</b> <ul style="list-style-type: none"> <li>• Inspect the throttle body. (See THROTTLE BODY INSPECTION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)</li> <li>• Is there any malfunction?</li> </ul>	Yes	Replace the throttle body, then go to the next step. (See INTAKE-AIR SYSTEM REMOVAL/INSTALLATION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)
		No	Go to the next step.
6	<b>VERIFY DTC TROUBLESHOOTING COMPLETED</b> <ul style="list-style-type: none"> <li>• Always reconnect all disconnected connectors.</li> <li>• Clear the DTC from the PCM memory using the M-MDS. (See AFTER REPAIR PROCEDURE [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)</li> <li>• Perform the KOER self test. (See KOEO/KOER SELF TEST [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)</li> <li>• Is the same DTC present?</li> </ul>	Yes	Repeat the inspection from Step 1. • If the malfunction recurs, replace the PCM. (See PCM REMOVAL/INSTALLATION [SKYACTIV-G 2.0, SKYACTIV-G 2.5].) Go to the next step.
		No	Go to the next step.

STEP	INSPECTION	ACTION
7	<b>VERIFY AFTER REPAIR PROCEDURE</b> <ul style="list-style-type: none"> <li>Perform the "AFTER REPAIR PROCEDURE". (See AFTER REPAIR PROCEDURE [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)</li> <li>Are any DTCs present?</li> </ul>	Yes Go to the applicable DTC inspection. (See DTC TABLE [SKYACTIV-G 2.0, SKYACTIV-G 2.5].)
		No DTC troubleshooting completed.