
INTAKE SHUTTER VALVE POSITION SENSOR REMOVAL/INSTALLATION [SKYACTIV-D 2.2]

id0140z7960500

Note

- Because the intake shutter valve position sensor is integrated in the intake shutter valve, replacing the intake shutter valve position sensor includes replacement of the intake shutter valve.

1. Remove the intake shutter valve. (See INTAKE SHUTTER VALVE REMOVAL/INSTALLATION [SKYACTIV-D 2.2].)