

**SECURITY INDICATOR LIGHT: 09, DTC: U3000:96/P1260:00 [IMMOBILIZER SYSTEM]**

id0902e4028200

<b>System malfunction location</b>	Start stop unit malfunction
<b>Detection condition</b>	• Start stop unit malfunction detected.
<b>Fail-safe</b>	—
<b>Possible cause</b>	• Start stop unit malfunction
<b>System wiring diagram</b>	—

**Diagnostic Procedure**

Step	Inspection	Action
1	<b>PERFORM DTC INSPECTION AND VERIFY IF MALFUNCTIONING PART IS START STOP UNIT</b> <ul style="list-style-type: none"><li>• Clear DTC for the immobilizer system using the M-MDS. (See CLEARING DTC [IMMOBILIZER SYSTEM].)</li><li>• Perform the DTC inspection for the immobilizer system using the M-MDS. (See DTC INSPECTION [IMMOBILIZER SYSTEM].)</li><li>• Security indicator light: 09, DTC U3000:96/P1260:00 displayed?</li></ul>	Yes Replace the start stop unit, then go to the next step. (See START STOP UNIT REMOVAL/INSTALLATION.)
		No Go to the next step.
2	<b>VERIFY IF OTHER DTCs DISPLAYED</b> <ul style="list-style-type: none"><li>• Are any other DTCs displayed?</li></ul>	Yes Repair the malfunctioning part according to the applicable DTC troubleshooting. (See DTC TABLE [IMMOBILIZER SYSTEM].)
		No DTC troubleshooting completed.