

## ON/OFF SOLENOID [GW6A-EL, GW6AX-EL]


id0517i2361600

### Purpose/Function

- The on/off solenoid performs switching of the shift valve in the control valve body according to the vehicle conditions.

### Construction

- The on/off solenoid is installed to the solenoid control valve body.
- The on/off solenoid is a normal open-type on/off solenoid.



am3uun00002360

### Operation

#### Non-energization (OFF)

- When the on/off solenoid is off, the supply port in the solenoid opens. As a result, hydraulic pressure is supplied to operate the shift valve.

#### Energized (ON)

- When the on/off solenoid is on, the drain port in the solenoid opens. As a result, hydraulic pressure which operates the shift valve is drained.